

CIRCUIT OPERATION**Selector Interlock**

When the gear selector is in the park position, the Transmission Range Selector Switch (Z110) is de-energized and prevents the selector from being moved into another gear. To free the selector, the Ignition Switch (X134) must be in position II and the brake pedal must be depressed. When this occurs, voltage from Fuse F B1 is applied to the Transmission Range Selector Switch through the closed Stop Lamp Switch (X168). The Transmission Range Selector Switch is grounded at E200 through the selector switch, the KS wire and the B wire. The solenoid now energizes, freeing the selector.

Ignition Key Interlock

On vehicles equipped with the interlock safety feature the vehicle must be in park and the transfer case in high or low gear before the key can be removed from the ignition. If the gear selector or transfer were out of gear, the key must be cycled before removal.

If the vehicle is not in park, voltage from Fuse B2 is applied to the Ignition Key Switch and Solenoid (X177) through the closed contacts of the Transmission Range Selector Switch (Z110). When the ignition switch is placed in the 0 position, the switch in the Ignition Key Switch and Solenoid closes to energize the solenoid and prevent key removal.

If the transfer box is in the neutral position, Interlock Relay 1 (K153) is de-energized, since the relay coil is not grounded by the Transfer Box Position Switch. When the relay is de-energized, voltage is applied to the Ignition Key Switch and Solenoid (X177) through the relay's switch contacts causing the solenoid to energize and prevent key removal.

Transfer Box Interlock


The Transfer Box Interlock safety feature is designed to prevent the transfer case shifter from being shifted out of "H" or "L" unless the vehicle's gear selector is in the neutral position.

When the gear selector is placed in the neutral position, voltage is applied to the Interlock Relay 2's coil through the Transmission Range Selector Switch (Z110). The relay's coil is grounded through the Park/ Neutral Position Switch (X167).

Interlock Relay 2 now energizes and applies voltage from Fuse E1 to the Transfer Box Solenoid. When the Transfer Box Solenoid is energized the transfer box shifter can be operated.

Wire Colour Chart


B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow




C1 ETM

Wire Colour Chart

B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow





SYSTEM DIAGNOSIS

1. If the transmission range selector cannot be shifted out of park, do Test A.
2. If the ignition key cannot be removed with the transmission range selector in park and the transfer box is in "H" or "L", do test B.
3. If the transfer box can be shifted out of "H" or "L" while in any gear except neutral, do test C.
4. If the ignition key can be removed with the transmission range selector in any gear except park or with the transfer box in the neutral position, do test D.
5. If the transfer box cannot be shifted into "N", "H", or "L", with the ignition key inserted and gear selector in "N", do test F.

Test A


1A

CONDITIONS

- Ignition Switch
Position: II

RESULTS

- Brake Pedal - Depressed
BAT VOLT
- Brake Pedal - Released
0V



Z110
Transmission
Range Selector
Switch



PROBLEM CAUSE

- GP Wire
- WP Wire
- F B1 Fuse
- Stop Lamp Switch




2A

CONDITIONS

- Ignition Switch
Position: 0

RESULTS

Less than 1 ohm




Z110
Transmission
Range Selector
Switch




PROBLEM CAUSE

- B Wire
- E200





C1 ETM

1993 RANGE ROVER



~~OK~~ PROBLEM CAUSE
- KS Wire



~~OK~~ PROBLEM CAUSE
- Microswitch (Gear Selector)

OK PROBLEM CAUSE
- Interlock Solenoid


Test B

1B


CONDITIONS

- Ignition Switch
Position: II
- Gear Selector
P
- Transfer Box Position Switch
H or L

RESULTS
0V



X177
Ignition Key Switch
and Solenoid



PROBLEM CAUSE
- Ignition Key Switch
and Solenoid


2B

CONDITIONS

- Ignition Switch
Position: 0

RESULTS


- Gear Selector
P = more than 1 ohm



Z110
Transmission Range
Selector Switch




PROBLEM CAUSE
- Transmission Range
Selector Switch



C1 ETM

1993 RANGE ROVER



PROBLEM CAUSE


- BK Wire
- Transfer Box Position Switch



PROBLEM CAUSE

- Interlock Relay 1
- RB Wire
- BR Wire

Test C



PROBLEM CAUSE

- Interlock Relay 2



PROBLEM CAUSE

- SB Wire
- Transfer Box Solenoid

Test D

1D

CONDITIONS

- Ignition Switch
Position: II
- Gear Selector
P

RESULTS

- Transfer Box Position Switch
N = BAT VOLT

BR

X177
Ignition Key
Switch and Solenoid

~~OK~~ GO TO TEST E

OK



2D

CONDITIONS

- Ignition Switch
Position: II
- Transfer Box Position Switch
H or L

RESULTS

- Gear Selector
P = 0 VOLTS
R, N, D, 3, 2, 1 = BAT VOLTS

BR

X177
Ignition Key
Switch and Solenoid


~~OK~~ PROBLEM CAUSE

- BR Wire
- Transmission Range Selector Switch

OK PROBLEM CAUSE


- Ignition Key Switch and Solenoid

Test E



PROBLEM CAUSE

- WP Wire
- Ignition Key Switch and Solenoid



PROBLEM CAUSE

- BK Wire
- Transfer Box Position Switch




2E

3E

CONDITIONS

- Ignition Switch
Position: 0
- Gear Selector
P

RESULTS
Ignition key cannot be removed



**K153
Interlock
Relay 1**

OK PROBLEM CAUSE

- RB Wire
- Diode
- BR Wire

OK PROBLEM CAUSE

- Interlock Relay 1

Test F


1F

CONDITIONS

- Ignition Switch
Position: II

RESULTS

- Gear Selector
N = BAT VOLT



**K151
Interlock
Relay 2**

OK PROBLEM CAUSE

- BR Wire
- Transmission Range Selector Switch


OK

↓

2F

C1 ETM


1993 RANGE ROVER



~~OK~~ **PROBLEM CAUSE**

- E1 Fuse
- WY Wire

OK




~~OK~~ **PROBLEM CAUSE**

- YB Wire
- Diode
- BY Wire

OK





PROBLEM CAUSE

- SB Wire
- Transfer Box Solenoid
- B Wire



PROBLEM CAUSE

- Interlock Relay 2


1993 RANGE ROVER

KEY INFORMATION


CIRCUIT DIAGRAMS

- Circuit diagrams are arranged so that current flow is from the top of the diagram (current source) to the bottom of the diagram (ground).
- Only those components that work together in the circuit are shown. If only part of a component is used in the circuit, then only that part of the component is shown.

● Remember:



Entire component



Part of a component

TERMINAL NUMBER

DESIGNATION

50	Battery voltage: Ignition Switch in position III
30	Battery voltage: supplied constantly
15	Battery voltage: Ignition Switch in position II or III
R	Battery voltage: Ignition Switch in positions I, II
31	Ground

See Introduction (i) for additional circuit diagram symbols.

DIAGNOSIS


- If the diagram is accompanied by text:
 - Read the Circuit Operation before proceeding with the electrical diagnosis.
 - Read the Troubleshooting Hints before performing the System Diagnosis.
 - Tests follow the System Diagnosis.
 - When performing the System Diagnosis, be certain that all components disconnected in previous steps are reconnected unless otherwise directed.



Component is disconnected.
Backprobe harness connector



Component is connected.
Backprobe harness connector



Component is disconnected.
Probe component



Component is disconnected.
Probe harness connector



Probe in-line connector