




**CIRCUIT OPERATION****Driver Seat**

When the Ignition Switch (X134) is in position I or II, the Passenger Seat Relay (K131) applies ground to the Driver Seat Relay (K113). Ground is also applied to this relay when the driver's door is open. This allows the driver's seat to be adjusted with the door open. When the Driver Seat Relay (K113) is energized, battery voltage is applied to the Driver Seat Control Switch (X121). This switch is connected directly to ground. The Driver Seat Control Switch controls 4 seat control motors via 4 double-contact switches. When each switch is moved to operate its corresponding motor, 1 seat switch contact applies ground while the other applies battery voltage to the respective seat motor. The motor turns to adjust the seat in the requested direction.

**Passenger Seat**


Battery voltage is applied to the Passenger Seat Control Switch (X152) at all times. When the Ignition Switch (X134) is in position I or II, the Passenger Seat Relay (K131) is energized, applying ground to the Passenger Seat Control Switch. The Passenger Seat Control Switch operates like the Driver Seat Control Switch (X121).






**M1 ETM**

1993 RANGE ROVER



Wire Colour Chart

B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow




**TROUBLESHOOTING HINTS**

1. If the driver's seat does not operate only when the driver door is open, check the PU wire, PO wire, driver power seat diode and Driver Door Switch (X118).
2. If the passenger's seat is OK but the driver's seat operates only when the driver's door is open, check the PU wire, B wire and driver power seat diode.



**SYSTEM DIAGNOSIS**

1. If the driver's power seat does not move in any direction, do Test A.
2. If the passenger's power seat does not move in any direction but the driver's seat is OK, do Test C (left side) or Test E (right side).
3. If some, but not all, of the driver's power seat functions operate, do Test G.
4. If some, but not all, of the passenger's power seat functions operate, do Test H.
5. If neither power seat operates when the driver's door is closed, do Test F.

Test A



**PROBLEM CAUSE**  
 - OY Wire  
 - Fusible Link



**PROBLEM CAUSE**  
 - PW Wire  
 - F B2 Fuse



**PROBLEM CAUSE**  
 - LHD  
 Go to Test B  
 - RHD  
 Go to Test D

**Test B**

1B

**CONDITIONS**


- Ignition Switch  
*Position: 0*
- Driver's door  
*Open*

**RESULTS**  
BAT VOLT

**X121  
Driver Seat  
Control Switch**

**OK** PROBLEM CAUSE

- F E5 Fuse
- WR Wire
- WN Wire



2B

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver's door  
*Open*

**RESULTS**  
BAT VOLT

**X121  
Driver Seat  
Control Switch**


**OK** PROBLEM CAUSE

- F E6 Fuse
- WY Wire
- WN Wire



**OK** PROBLEM CAUSE

- B Wire
- Seat motors connector
- Driver Seat Control Switch

Test C



**PROBLEM CAUSE**  
 - F D1 Fuse  
 - WO Wire



**PROBLEM CAUSE**  
 - F D2 Fuse  
 - WU Wire



**PROBLEM CAUSE**  
 - B Wire  
 - Seat motors connector  
 - Passenger Seat Control  
 Switch



**Test D**

1D

**CONDITIONS**


- Ignition Switch  
*Position: 0*
- Driver's door  
*Open*

**RESULTS**  
BAT VOLT

**X121**  
Driver Seat  
Control Switch



- PROBLEM CAUSE**
- F E5 Fuse
  - WO Wire
  - WR Wire
  - WN Wire



2D

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver's door  
*Open*

**RESULTS**  
BAT VOLT

**X121**  
Driver Seat  
Control Switch



- PROBLEM CAUSE**
- F E6 Fuse
  - WU Wire
  - WY Wire
  - WN Wire



- PROBLEM CAUSE**
- B Wire
  - Seat motors connector
  - Driver Seat Control Switch

Test E

**1E**

**CONDITIONS**  
 • Ignition Switch  
 Position: 0

**RESULTS**  
 BAT VOLT

**X152 Passenger Seat Control Switch**



**PROBLEM CAUSE**

- F D1 Fuse
- WR Wire
- WO Wire



**2E**

**CONDITIONS**  
 • Ignition Switch  
 Position: 0

**RESULTS**  
 BAT VOLT

**X152 Passenger Seat Control Switch**



**PROBLEM CAUSE**


- F D2 Fuse
- WY Wire
- WU Wire



**PROBLEM CAUSE**



- B Wire
- BP Wire
- Seat motors connector
- Passenger Seat Control Switch

Test F



~~OK~~ PROBLEM CAUSE  
- F E6 Fuse  
- LGK Wire

OK




~~OK~~ PROBLEM CAUSE  
- B Wire

OK



**M1 ETM**

1993 RANGE ROVER




**PROBLEM CAUSE**  
- BP Wire



**PROBLEM CAUSE**  
- Passenger Seat Relay

**Test G**



**PROBLEM CAUSE**  
- WLG Wire  
- WS Wire  
- X121, X152 Seat Switches



1G

2G

**CONDITIONS**

- Ignition Switch  
*Position: I*

**RESULTS**

- X121, X152 Seat Switches  
*Rear up -BAT VOLT*  
*Rear down +BAT VOLT*

Seat motors connector

~~OK~~ PROBLEM CAUSE

- WP Wire
- WO Wire
- X121, X152 Seat Switches

OK

↓ 3G

3G

**CONDITIONS**

- Ignition Switch  
*Position: I*

**RESULTS**

- X121, X152 Seat Switches  
*Recline +BAT VOLT*  
*Raise -BAT VOLT*

Seat motors connector

~~OK~~ PROBLEM CAUSE

- WU Wire
- WN Wire
- X121, X152 Seat Switches

OK

↓ 4G

3G

4G

**CONDITIONS**

- Ignition Switch  
*Position: I*

**RESULTS**

- X121, X152 Seat Switches  
*Front down*  
+BAT VOLT  
*Front up*  
-BAT VOLT

Seat motors connector

- OK** PROBLEM CAUSE
- WB Wire
  - WK Wire
  - X121, X152 Seat Switches

- OK** PROBLEM CAUSE
- Seat motors

**Test H**

1H

**CONDITIONS**


- Ignition Switch  
*Position: I*

**RESULTS**

- X121, X152 Seat Switches  
*Forward*  
+BAT VOLT  
*Backward*  
-BAT VOLT

Seat motors connector

- OK** PROBLEM CAUSE
- SG Wire LHD
  - SB Wire LHD
  - WL Wire RHD
  - WS Wire RHD
  - X121, X152 Seat Switches



1H

**2H**

**CONDITIONS**

- Ignition Switch  
*Position: I*

**RESULTS**

- X121, X152 Seat Switches
- Rear up*  
-BAT VOLT
- Rear down*  
+BAT VOLT

WP RHD  
SR LHD

SP LHD  
WO RHD

Seat motors connector

**OK**

**PROBLEM CAUSE**

- SR Wire LHD
- SP Wire LHD
- WP Wire RHD
- WO Wire RHD
- X121, X152 Seat Switches

**OK**

↓

3H

3H

**CONDITIONS**

- Ignition Switch  
*Position: I*

**RESULTS**

- X121, X152 Seat Switches
- Recline*  
+BAT VOLT
- Raise*  
-BAT VOLT

WU RHD  
SU LHD

WNRHD  
SN LHD

Seat motors connector

**OK**


**PROBLEM CAUSE**

- SU Wire LHD
- SN Wire LHD
- WU Wire RHD
- WN Wire RHD
- X121, X152 Seat Switches

**OK**

↓

4H



## PROBLEM CAUSE

- WB Wire LHD
- WK Wire LHD
- WB Wire RHD
- WK Wire RHD
- X121, X152 Seat Switches




## PROBLEM CAUSE

- Seat motors




Wire Colour Chart

B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow




M2-2




**M2 ETM**

1993 RANGE ROVER



Wire Colour Chart

B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow



**CIRCUIT OPERATION**

When the Ignition Switch (X134) is in position II, voltage is supplied to the power mirrors circuit by fuse F E2.

**Right/Down Movement**

When the Mirror Adjustment Switch (X146) is in the RIGHT or DOWN position, voltage is applied to the selected Mirror Actuator (M115, M123) at terminal 4 through the Mirror Adjustment Switch, the SW wire, and the Mirror Changeover Switch (X192). The selected Mirror Actuator is grounded at E200 through the PR wire, the SLG wire, the 'Left/Up' contacts of the Mirror Adjustment Switch and the B wire. The mirrors now move.

If the DOWN position is selected, the 'Up/Down' contacts in the Mirror Adjustment Switch close to apply voltage to a solenoid in the Mirror Actuator through the WP wire. The solenoid energizes because it is grounded at E200 or E201 through the B wire. The energized solenoid engages the motor in the actuator with the up/down gearbox.


**Left/Up Movement**

When the Mirror Adjustment Switch (X146) is in the LEFT/UP position, voltage is applied to the selected mirror through the Mirror Adjustment Switch and the SLG wire. The selected Mirror Actuator (M115, M123) is grounded at E200 through the PW wire, the Mirror Changeover Switch (X192), the 'Right/Down' contacts of the Mirror Adjustment Switch and the B wire. The Mirror Actuator now runs.

When the UP position is selected, the 'up/down' contacts of the Mirror Adjustment Switch close to energize the Mirror Actuator solenoid. When the solenoid is energized, it engages the up/down gearbox.

Wire Colour Chart

B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow




**TROUBLESHOOTING HINTS**

If both mirrors will not move left or right but the mirror operates up and down, replace the Mirror Adjustment Switch (X146).

**SYMPTOM DIAGNOSIS**



1. If the mirrors do not operate at all, do Test A.
2. If one or both mirrors will not move up or down but the mirror does move left and right, do Test B.
3. If only one mirror does not operate, do Test C, the Mirror Actuator (M115, M123) Test.

Test A



PROBLEM CAUSE

- F 2 Fuse
- GLG Wire
- SN Wire



PROBLEM CAUSE

- B Wire



2A


3A

**CONDITIONS**

- Ignition Switch  
*Position: II*

**RESULTS**


- Mirror Adjustment Switch  
*Right/Down*  
BAT VOLT  
*Neutral*  
0V



X192  
Mirror Change-over Switch

**OK** PROBLEM CAUSE

- SW Wire
- Mirror Adjustment Switch




4A

**CONDITIONS**

- Ignition Switch  
*Position: II*

**RESULTS**


- Mirror Adjustment Switch  
*Left/Up*  
Less than 1 ohm  
*Neutral*  
More than 10K ohms



X192  
Mirror Change-over Switch

**OK** PROBLEM CAUSE

- Mirror Adjustment Switch



**M3 ETM**

1993 RANGE ROVER

4A


5A

**CONDITIONS**

- Ignition Switch  
*Position: 0*

**RESULTS**

- Mirror Adjustment Switch  
*Right/Down*  
*Less than 1 ohm*
- Neutral*  
*More than 10K ohms*



**OK** PROBLEM CAUSE

- SLG Wire
- Mirror Adjustment Switch



6A


6A

**CONDITIONS**

- Ignition Switch  
*Position: 0*


**RESULTS**

- Mirror Adjustment Switch  
*Left/Up*  
*Less than 1 ohm*
- Neutral*  
*More than 10K ohms*



**OK** PROBLEM CAUSE

- Mirror Adjustment Switch





6A


7A

**CONDITIONS**

- Ignition Switch  
*Position: II*
- Mirror Adjustment Switch  
*Right/Down*

**RESULTS**

- Mirror  
*Moves*



X192  
Mirror Change-over Switch



**PROBLEM CAUSE**

- SLG Wire
- SG Wire
- WP Wire
- Mirror Adjustment Switch
- M115, M123 Mirror Actuator



**PROBLEM CAUSE**

- Mirror Changeover Switch

**Test B**


1B

**CONDITIONS**

- Ignition Switch  
*Position: II*

**RESULTS**

- Mirror Adjustment Switch  
*Up/Down*  
*BAT VOLT*  
*Left/Right*  
*0V*




M115, M123  
Mirror Actuator




**PROBLEM CAUSE**

- WP Wire
- Mirror Adjustment Switch



**M3 ETM**

1993 RANGE ROVER



**PROBLEM CAUSE**


- B Wire
- E200



**PROBLEM CAUSE**


- M115, M123  
Mirror Actuator


**Test C**



**PROBLEM CAUSE**

- PU/PK Wire
- Mirror Changeover Switch





**PROBLEM CAUSE**

- PR Wire
- Mirror Changeover Switch



**PROBLEM CAUSE**

- M115, M123 Mirror Actuator


# 1993 RANGE ROVER

## KEY INFORMATION


### CIRCUIT DIAGRAMS

- Circuit diagrams are arranged so that current flow is from the top of the diagram (current source) to the bottom of the diagram (ground).
- Only those components that work together in the circuit are shown. If only part of a component is used in the circuit, then only that part of the component is shown.

#### ● Remember:



Entire component



Part of a component

TERMINAL NUMBER	DESIGNATION
50	Battery voltage: Ignition Switch in position III
30	Battery voltage: supplied constantly
15	Battery voltage: Ignition Switch in position II or III
R	Battery voltage: Ignition Switch in positions I, II
31	Ground

See Introduction (i) for additional circuit diagram symbols.

### DIAGNOSIS

- If the diagram is accompanied by text:
  - Read the Circuit Operation before proceeding with the electrical diagnosis.
  - Read the Troubleshooting Hints before performing the System Diagnosis.
  - Tests follow the System Diagnosis.
  - When performing the System Diagnosis, be certain that all components disconnected in previous steps are reconnected unless otherwise directed.



Component is disconnected.  
Backprobe harness connector



Component is connected.  
Backprobe harness connector



Component is disconnected.  
Probe component



Component is disconnected.  
Probe harness connector



Probe in-line connector

## CIRCUIT OPERATION

### Power and Ground

The Memory Seat Fuse (P115) applies battery voltage to retain the memory circuit of the Memory Seat ECU (Z146) at all times. Voltage to operate the seat motors (M126, M127, M128, M129) and the mirror actuators (M115, M123) is supplied to the Memory Seat ECU from fuses F D5 and F D6. The Fusible Link (P119) supplies voltage to fuses F D5 and F D6 whenever the Driver Seat Relay (K113) is energized. The relay is energized when the driver's door is open, causing the Driver Door Switch (X118) to ground the relay's coil, or when the ignition is in position 2, causing the Passenger Seat Relay (K131) to ground the Driver Seat Relay. The Memory Seat ECU is grounded at ground E301 through the B wires.

### Inhibit Inputs

The Memory Seat ECU (Z146) will not permit movement to the memorized position when the ignition is position 2 unless the handbrake is applied and vehicle speed is below 6 kmh. Vehicles equipped with an automatic transmission must also be in PARK or NEUTRAL for operation to occur.

The ECU monitors the Handbrake Switch (X191) position at terminal C1/13. When the handbrake is in position 1, the brake is applied and ground is applied to the ECU terminal.

Vehicle speed is monitored by the ECU at terminal C1/20 through the speed output signal supplied by the Vehicle Speed Sensor Buffer (Z160).

The ECU monitors gear position through the Starter Inhibit/Reverse Switch (X167). The switch grounds the ECU at terminal C1/24 when the transmission is in PARK or NEUTRAL.

### Seat Motors

4 reversible motors control seat position, with each motor controlling 1 plane of movement. The Memory Seat ECU (Z146) applies both voltage and ground to the motors based on the position of the Driver Seat Control Switch (X121) or the execution of a memory position.

### Memory Mirror Actuators (M115, M123)

Each Memory Mirror Actuator contains 2 motors which controls 1 plain of movement. The Memory Seat ECU (Z146) applies both voltage and ground to the motors based on the position of the Mirror Adjustment Switch (X146) or the execution of a memory position.

### Setting Memory

When the round, green memory set button is depressed, terminal C3/10 of the Memory Seat ECU (Z146) is grounded through the switch contacts. This signals the ECU to record the seat position as reported through the seat position sensors (X194, X195, X196, X197) and the mirror positions through the potentiometers of the Memory Mirror Actuators (M115, M123).

When memory seat position switch 1 or 2 is depressed, ECU terminals C3/8 or C3/9 are grounded through the switch. This signals ECU to record the current position as position '1' or '2'. Subsequent depressions of memory seat position switch 1 or 2 will cause the ECU to move the seat and mirrors to the position retained in memory. The memory can be cleared by setting a new position or by removing the Memory Seat Fuse (P115).

## SELF TEST MODE



The Self Test Mode is a test routine the Memory Seat ECU (Z146) performs when initialized. When the ECU is commanded into the Self Test Mode, it operates the seats and the mirrors in all planes of travel. Perform the self test before attempting any diagnosis of the memory seat and mirror system. The cause of a system fault can be narrowed down through observation of the seats and mirrors during the Self Test Mode. Before starting the Self Test Mode, be sure to clear away everything from the pathway of the seats.

To initialize the Self Test Mode, do the following:

1. Park vehicle and open driver's door.
2. Press round, green memory button 5 times.
3. Press seat position buttons 1 and 2 in the following sequence:  
2-1-1-2

Seat and mirrors will now move. The test is completed when the seat and mirrors stop in the mid-travel position.

If a motor did not operate at all during the test sequence, that motor or its wiring is faulty. If a motor moves in a plane and then suddenly stops, a loss of the feedback position is indicated. Proceed to the System Diagnosis for further testing.




# M5 ETM




## 1993 RANGE ROVER

### Wire Colour Chart

B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow








# M5 ETM



## 1993 RANGE ROVER



\* LHD  
\*\* RHD

### Wire Colour Chart

B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow









# M5 ETM

## 1993 RANGE ROVER

### Wire Colour Chart


B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow






**M5 ETM**

1993 RANGE ROVER



Wire Colour Chart

B- Black	P- Purple
G- Green	R- Red
K- Pink	S- Grey
L- Light	U- Blue
N- Brown	W- White
O- Orange	Y- Yellow



**SYSTEM DIAGNOSIS**

NOTE: Perform the Self Test before performing any diagnosis on the memory seats and mirrors.


1. If the system will not perform the Self Test, do Test E, Driver Seat Control Switch (X121) test.
2. If manual and memory seat functions are totally inoperative, check the Memory Seat Fuse (P115) and fuses F D5 and F D6. Do Test A if the fuses are OK.
3. If the system does not retain memory seat or mirror positions, do Test A, Memory Seat ECU (Z146) power test.
4. If the memory seat system does not operate when the ignition is in position II and the handbrake is applied, do Test B (manual transmission) or Test C (automatic transmission).
5. If memory seat and mirror functions do not operate but the seat does operate in some modes manually, do Test E, Driver Seat Control Switch (X121) test.
6. If all seat motors operate during the Self Test but do not operate when the Driver Seat Control Switch (X121) is used, do Test F.
7. If all mirror motors operate during the Self Test but do not operate when the Mirror Adjustment Switch (X146) is used, do Test G.
8. If a seat motor moves during the Self Test and then stops, replace the defective seat sensor (X194, X195, X196, X197).
9. If a seat motor (M126, M127, M128, M129) does not move at all during the Self Test, do Test J.
10. If a mirror motor does not move at all during the Self Test, do Test K (Left Memory Mirror Actuator, M115) or Test L (Right Memory Mirror Actuator, M123).
11. If a mirror motor moves during the Self Test and then stops, do Test H [Left Memory Mirror Actuator, M115 (LHD), Right Memory Mirror Actuator, M123 (RHD)] or Test I [Right Memory Mirror Actuator, M123 (LHD), Left Memory Mirror Actuator, M115 (RHD)].

**M5 ETM**

1993 RANGE ROVER





**Test A**



~~OK~~ **PROBLEM CAUSE**


- WR Wire
- Memory Seat Fuse


**OK**



~~OK~~ **GO TO TEST D**

**OK**






**PROBLEM CAUSE**  
- B Wire



**PROBLEM CAUSE**  
- Memory Seat ECU

**Test B**



**PROBLEM CAUSE**  
- BW Wire  
- Handbrake Switch



**PROBLEM CAUSE**  
- Memory Seat ECU

**Test C**

**1C**

**CONDITIONS**

- Ignition Switch  
*Position: II*

**RESULTS**


- Handbrake  
*Applied*  
0 VOLT  
*Released*  
BAT VOLT

Z146  
Memory Seat  
ECU

~~OK~~ **PROBLEM CAUSE**

- BW Wire
- Handbrake Switch

OK



**2C**

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Gear Selector  
*Park*

**RESULTS**

*Less than 1 ohm*

Z146  
Memory Seat  
ECU


~~OK~~ **PROBLEM CAUSE**

- RY Wire



OK **PROBLEM CAUSE**

- Memory Seat ECU

**Test D**



**PROBLEM CAUSE**  
 - OY Wire  
 - Fusible Link



**PROBLEM CAUSE**  
 - F B2 Fuse  
 - PW Wire



2D


3D

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver's door  
*Open*


**RESULTS**

*Test lamp  
illuminates*



**PROBLEM CAUSE**

- PU Wire
- Driver Door Switch




4D

**CONDITIONS**

- Ignition Switch  
*Position: II*
- Driver's door  
*Closed*


**RESULTS**


*Test lamp  
illuminates*



**PROBLEM CAUSE**

- PU Wire
- BP Wire





**PROBLEM CAUSE**


- F D5 Fuse
- F D6 Fuse
- WN Wire



**PROBLEM CAUSE**


- Driver Seat Relay

**Test E**



**PROBLEM CAUSE**

- SG Wire
- B Wire
- Driver Seat Control Switch



1E


2E

**CONDITIONS**

- Ignition Switch  
*Position: II*

**RESULTS**

- Position 1 button  
*Depressed*  
*Less than 1 ohm*  
*Released*  
*More than 10K ohms*




Z146  
Memory Seat  
ECU



**PROBLEM CAUSE**

- SP Wire
- Driver Seat Control Switch



3E


3E

**CONDITIONS**

- Ignition Switch  
*Position: 0*

**RESULTS**

- Position 2 button  
*Depressed*  
*Less than 1 ohm*  
*Released*  
*More than 10K ohms*



Z146  
Memory Seat  
ECU




**PROBLEM CAUSE**

- SG Wire
- Driver Seat Control Switch




**PROBLEM CAUSE**

- Memory Seat ECU



**PROBLEM CAUSE**

- G Wire
- Y Wire
- Driver Seat Control Switch



**PROBLEM CAUSE**


- B Wire
- R Wire
- Driver Seat Control Switch







**M5 ETM**


1993 RANGE ROVER



**PROBLEM CAUSE**  
- Driver Seat Control Switch



**PROBLEM CAUSE**  
- Driver Seat Control Switch




6F

7F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Front down*

**RESULTS**  
*Less than 1 ohm*



Z146  
Memory Seat  
ECU

**OK** PROBLEM CAUSE

- O Wire
- Driver Seat Control Switch

**OK**




8F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Front down*

**RESULTS**  
*Less than 1 ohm*



Z146  
Memory Seat  
ECU

**OK** PROBLEM CAUSE

- P Wire
- Driver Seat Control Switch

**OK**



8F

9F

**CONDITIONS**


- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Front up*

**RESULTS**  
*Less than 1 ohm*

Z146  
Memory Seat  
ECU



**PROBLEM CAUSE**  
- Driver Seat Control Switch



10F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Front up*





**RESULTS**  
*Less than 1 ohm*

Z146  
Memory Seat  
ECU



**PROBLEM CAUSE**  
- Driver Seat Control Switch






12F

13F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Raise*


**RESULTS**  
*Less than 1 ohm*



**Z146  
Memory Seat  
ECU**

**OK** PROBLEM CAUSE  
- Driver Seat Control Switch

**OK**




14F

14F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Raise*

**RESULTS**  
*Less than 1 ohm*



**Z146  
Memory Seat  
ECU**

**OK** PROBLEM CAUSE  
- Driver Seat Control Switch

**OK**



14F

15F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Rear down*


**RESULTS**  
*Less than 1 ohm*

Z146  
Memory Seat  
ECU



**PROBLEM CAUSE**

- R Wire
- Driver Seat Control Switch



16F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Rear down*


**RESULTS**  
*Less than 1 ohm*

Z146  
Memory Seat  
ECU



**PROBLEM CAUSE**

- Driver Seat Control Switch




16F

17F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Rear up*


**RESULTS**  
*Less than 1 ohm*



**Z146  
Memory Seat  
ECU**

~~OK~~ **PROBLEM CAUSE**  
- Driver Seat Control Switch

OK




18F

18F

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Driver Seat Control Switch  
*Rear up*

**RESULTS**  
*Less than 1 ohm*



**Z146  
Memory Seat  
ECU**

~~OK~~ **PROBLEM CAUSE**  
- Driver Seat Control Switch

OK

**Test G**

**1G**

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Mirror Adjustment Switch  
*Up*

**RESULTS**  
*Less than 1 ohm*

**Z146  
Memory Seat  
ECU**



**PROBLEM CAUSE**

- SN Wire
- SG Wire
- Mirror Adjustment Switch



**2G**

**CONDITIONS**

- Ignition Switch  
*Position: 0*
- Mirror Adjustment Switch  
*Down*
- Mirror Changeover Switch  
*Left*


**RESULTS**  
*Less than 1 ohm*

**Z146  
Memory Seat  
ECU**




**PROBLEM CAUSE**

- SR Wire
- SW Wire
- Mirror Changeover Switch
- Mirror Adjustment Switch










**PROBLEM CAUSE**


- SLG Wire
- Mirror Adjustment Switch



**PROBLEM CAUSE**



- SP Wire
- SU Wire
- Mirror Changeover Switch





**PROBLEM CAUSE**

- SLG Wire
- Mirror Adjustment Switch



**PROBLEM CAUSE**


- B Wire
- Mirror Adjustment Switch



**PROBLEM CAUSE**



- Memory Seat ECU

Test H




**PROBLEM CAUSE**


- YG Wire
- PN Wire
- OU Wire
- OW Wire
- Left Mirror Actuator
- Right Mirror Actuator



**PROBLEM CAUSE**

- PN Wire
- YG Wire
- Left Mirror Actuator
- Right Mirror Actuator







- ~~OK~~ **PROBLEM CAUSE**
- ON Wire
  - OW Wire
  - Left Mirror Actuator
  - Right Mirror Actuator


- OK** **PROBLEM CAUSE**
- Memory Seat ECU

**Test 1**





- ~~OK~~ **PROBLEM CAUSE**
- OU Wire
  - ON Wire
  - YG Wire
  - PB Wire
  - Right Mirror Actuator
  - Left Mirror Actuator





**PROBLEM CAUSE**

- ON Wire
- PB Wire
- Right Mirror Actuator
- Left Mirror Actuator



**PROBLEM CAUSE**

- OU Wire
- ON Wire
- Right Mirror Actuator
- Left Mirror Actuator



**PROBLEM CAUSE**

- Memory Seat ECU

**Test J**

1J

**CONDITIONS**

- Ignition Switch  
*Position: I*
- Driver's door  
*Open*

**RESULTS**

- Driver Seat Control Switch  
*Forward*  
+BAT VOLT  
*Backward*  
-BAT VOLT

**Z146  
Memory Seat  
ECU**

**PROBLEM CAUSE**  
- Memory Seat ECU

**OK**



2J

**CONDITIONS**

- Ignition Switch  
*Position: I*
- Driver's door  
*Open*

**RESULTS**

- Driver Seat Control Switch  
*Rear up*  
-BAT VOLT  
*Rear down*  
+BAT VOLT

**Z146  
Memory Seat  
ECU**

**PROBLEM CAUSE**  
- Memory Seat ECU

**OK**



**M5 ETM**

1993 RANGE ROVER

2J


3J

**CONDITIONS**

- Ignition Switch  
*Position: I*
- Driver's door  
*Open*


**RESULTS**

- Driver Seat Control Switch  
*Recline*  
+BAT VOLT  
*Raise*  
-BAT VOLT



**Z146  
Memory Seat  
ECU**

~~OK~~ PROBLEM CAUSE  
- Memory Seat ECU




4J

**CONDITIONS**

- Ignition Switch  
*Position: I*
- Driver's door  
*Open*

**RESULTS**

- Driver Seat Control Switch  
*Front up*  
+BAT VOLT  
*Front down*  
-BAT VOLT




**Z146  
Memory Seat  
ECU**

~~OK~~ PROBLEM CAUSE  
- Memory Seat ECU



OK PROBLEM CAUSE  
- Seat motors

Test K



**PROBLEM CAUSE**

- WG Wire
- PR Wire
- PK Wire
- Left Mirror Actuator
- Right Mirror Actuator



**PROBLEM CAUSE**

- WK Wire
- WP Wire
- OK Wire
- Left Mirror Actuator
- Right Mirror Actuator




**PROBLEM CAUSE**

- Memory Seat ECU





Test L



PROBLEM CAUSE

- WG Wire
- PU Wire
- PR Wire
- Right Mirror Actuator
- Left Mirror Actuator



PROBLEM CAUSE

- OP Wire
- WK Wire
- WP Wire
- Right Mirror Actuator
- Left Mirror Actuator



PROBLEM CAUSE

- Memory Seat ECU