

64 - REAR SUSPENSION

CONTENTS

Page

DESCRIPTION AND OPERATION

AXLE LOCATION	1
SELF LEVELLING UNIT	2

FAULT DIAGNOSIS

SELF LEVELLING UNIT	1
---------------------------	---

REPAIR

REAR ROAD SPRING	1
REAR SHOCK ABSORBER	1
LEVELLING UNIT	2
LEVELLING UNIT BALL JOINTS	3
BUMP STOP	4
SUSPENSION LINK UPPER	4
SUSPENSION LINK LOWER	5
ANTI-ROLL BAR REAR	7
ANTI-ROLL BAR BALL JOINT LINKS	8

SPECIFICATIONS, TORQUE


TORQUE VALUES	1
---------------------	---





AXLE LOCATION

Longitudinal location of the rear axle is by 2 long, rubber trailing links which allow maximum vertical movement of the wheels. Lateral movement of the axle is prevented by a centrally mounted 'A' frame. This frame assembly consists of 'I' section steel secured at the apex by a ball joint which is mounted on top of the axle to the left of the differential housing. The open end of the 'A' frame is bolted to the underside of the chassis cross-member. This permits vertical movement of the axle while articulation takes place around the ball joint, with the resultant controlled ride over rough terrain.



RR4245

Rear axle suspension


1. "A" frame upper link assembly - transverse location
2. Trailing links - longitudinal location
3. Coil springs
4. Shock absorbers
5. Self levelling unit

Long travel coil springs and hydraulic shock absorbers, provide the springing for each wheel. On the rear only, a self levelling unit is mounted in conjunction with the "A" frame to provide automatic self levelling of the vehicle, when heavily loaded or towing a trailer.

SELF LEVELLING UNIT

DESCRIPTION

The levelling unit fitted to the rear axle is a self contained and sealed for life hydropneumatic device, which resembles a large telescopic damper. The unit utilizes the energy produced by the relative movement of the axle to the vehicle, when the vehicle is in motion, to maintain the vehicle at nominally level height. The unit will compensate for additional loads placed on the vehicle up to the recommended maximum. Excess load beyond the design limits of the unit will prevent it levelling the vehicle but, will not impede its capabilities as a damper.



RR3812M

OPERATION

Levelling the suspension (Pumping up)

The unit, contains hydraulic fluid and an inert gas, pressurised to approximately 65 bar during manufacture. The gas which provides the springing medium, is contained in two chambers **A** and **B** and is separated from the fluid by rubber sleeves. The movement of the axle and pumping action of the piston shaft when the vehicle is in motion, causes fluid to be transferred from the lower chamber to the upper chamber via internal valves **1** and **2** and high pressure chamber **C**. As the fluid is transferred to the upper section of the unit, pressure is applied to the gas in chamber **A** which provides the springing. At the same time the piston shaft is forced outwards increasing the operating length of the levelling unit.

Level position (Fluid circulates)

When the optimum level position is reached, as illustrated in RR3812M, fluid pumped from the lower section to the upper section as previously explained, circulates via valve **3** and port **4** back to the lower section.

Full bump/over load

If the vehicle suspension encounters a large 'bump' in the road or is over loaded the unit provides a damping effect only, as valves **5** and **1** are forced open allowing the pressure to escape from the upper to the lower chamber.

Full rebound

If the vehicle suspension encounters a large 'hole' in the road, the unit extends causing port **4** to allow free flow of fluid between the upper and lower chambers and the pressures to equalise.




REAR ROAD SPRING

Service repair no - 64.20.01

Remove

1. Loosen rear road wheel retaining nuts.
2. Support chassis on stands and remove wheels.



RR3882A

3. Support rear axle weight with jack.
4. Disconnect shock absorbers at one end.
5. Position coil spring compressor correctly on road spring.
6. Compress spring evenly to facilitate removal.
7. Lower axle to free road spring from upper seat.



CAUTION: Avoid lowering axle further than rear brake flexible hose will allow.

8. Remove spring retainer plate.
9. Withdraw road spring and spring isolator.
10. Lift off spring.

Refit

11. Reverse removal procedure.

REAR SHOCK ABSORBER


Service repair no - 64.30.02

Remove



NOTE: Air suspension vehicles: See AIR SUSPENSION, Repair, Rear Damper

1. Loosen road wheel retaining nuts.
2. Support chassis on stands. Remove road wheel and support rear axle weight with jack.



RR3881M

3. Remove fixings and withdraw shock absorber from axle bracket.
4. Remove upper fixings.
5. Withdraw shock absorber.
6. If required remove mounting bracket.
7. If required remove mounting rubbers.

Refit

8. Reverse removal procedure.

LEVELLING UNIT

Service repair no - 64.30.09


Remove



WARNING: The levelling unit contains pressurised gas and must not be dismantled or casing screws removed.


Repair is by replacement of complete unit only.

1. Support chassis rear on stands.
2. Support axle weight with jack.
3. Disconnect suspension upper links at pivot bracket.



RR 1602

4. Lift up lower boot.
5. Unscrew lower ball joint at levelling unit push rod.
6. Remove top bracket fixings at cross member.
7. Withdraw levelling unit and top bracket complete.
8. Lift up upper boot.
9. Unscrew upper ball joint at levelling unit.
10. Withdraw upper and lower boots and retaining spring.



RR 1603

Refit

11. Coat ball pin threads with 'Loctite' grade CVX or equivalent sealant.
12. Reverse removal procedure. 1 to 10. Fit all items in position, then tighten to correct torque. **See Specifications, torque, Torque Values**




LEVELLING UNIT BALL JOINTS

Service repair no - 64.30.10


Remove

1. Remove levelling unit. *See Levelling Unit*



RR 1604


2. Remove cotter pin and nut at rear axle bracket.
3. Extract ball pin from axle bracket using extractor RO1006.
4. Withdraw pivot bracket with ball joints.
5. Unscrew ball joint assembly.
6. Remove ball joint assembly from axle bracket.



RR 1605

7. Replacement ball joints are supplied complete, less fixings, and greased.
8. Axle bracket ball joint must not be dismantled.
9. Levelling unit ball joint may be dismantled and cleaned.
10. Pack ball joint with Dextagrease GP or equivalent grease.
11. Ensure that ball is square in housing before refitting.

Refit



RR1606M


12. Press knurled ball joint into pivot bracket.
13. Screw levelling unit ball joints into mounting brackets. Ball joints should screw in easily and fully. Tighten to correct torque. *See Specifications, torque, Torque Values*
14. Fit pivot bracket complete with ball joints to rear axle. Tighten to **175Nm**.
15. Fit levelling unit.

BUMP STOP

Service repair no - 64.30.15

Remove

1. Remove fixings.
2. Remove bump stop.



RR 1607

Refit


3. Position bolts in slots in bracket.
4. Fit bump stop secure with washer and nuts.

SUSPENSION LINK UPPER

Service repair no - 64.35.44


Remove

1. Support rear of chassis on stands, allow axle to hang freely.



RR 1608

2. Remove fixings, upper link bracket to frame.
3. Remove fixings, upper links to pivot bracket.
4. Remove upper link complete with frame bracket.
5. Remove bolt.
6. Separate link from bracket.



RR 1609



Renew bush

7. Press out rubber bushes.
8. Fit bush centrally in housing.



CAUTION: Apply pressure to outer edge of bush, and not rubber inner.

Refit

9. Reverse removal procedure. 1 to 6. Do not fully tighten fixings until all components are in position.
10. Tighten fixings to correct torque. *See Specifications, torque, Torque Values*

SUSPENSION LINK LOWER


Service repair no - 64.35.02




WARNING: Air suspension vehicles: Depressurise system before commencing work. *See AIR SUSPENSION, Adjustment, Depressurise System*

Remove

1. Site vehicle on a ramp [hoist].
2. Alternatively, support vehicle on stands under rear axle.



3. Remove rear fixings.



4. Remove mounting bracket fixings at side member bracket.
5. Remove lower link complete.
6. Remove locknut.
7. Remove mounting bracket from lower link.

Renew bush

8. Press out rubber bushes.
9. Fit bush centrally in housing.



CAUTION: Apply pressure to outer edge of bush, and not rubber inner.

Refit

10. Reverse removal procedure. 6 and 7. Do not tighten locknut.
11. Reverse removal procedure. 3 to 5.
12. Lower vehicle, allow axle to take up static laden position. Tighten to **175Nm**




**NOTE: Air suspension vehicles:
Repressurise system**



ANTI-ROLL BAR REAR

Service repair no - 64.35.08



KEY

- | | |
|------------------------|-----------------------------------|
| 1. Anti-roll[sway] bar | 5. Nut and washer |
| 2. Rubber bush | 6. Ball joint link arm |
| 3. Strap | 7. Bolt and washer |
| 4. Nut, bolt, washer | 8. Castellated nut and cotter pin |

Remove

1. Note for reassembly, position of rubber bushes on anti-roll[sway] bar.
2. Remove four nuts, bolts and washers securing two bush straps.
3. Remove nuts, bolts, washers and rubber bushes from the ball joint links and remove anti-roll[sway] bar.


Refit

4. Position rubber bushes on anti-roll[sway] bar. Fit joint in bush towards axle.
5. Fit anti-roll[sway] bar with two straps. Ensure ball joint link arms point down as shown. Loosely fit, washers and new Nyloc nuts.
6. Fit bolt, washers and rubber bushes. Fit anti-roll[sway] bar to ball joint links. Tighten to **68Nm**
7. Tighten nuts securing straps to **30Nm**.

ANTI-ROLL BAR BALL JOINT LINKS

Service repair no - 64.35.24

Remove



1. Remove two nuts, bolts, washers and rubber bushes from ball joint links and lower anti-roll[sway] bar to clear links.
2. Remove cotter pin and loosen castellated nut a few turns.
3. Release ball joint using special tool 18G 1063A as shown.
4. Remove castellated nut and ball joint link.

Refit

5. Fit ball joint link arm and castellated nut. Point ball joint link arm down as shown. Tighten to **40Nm** and fit new cotter pin.
6. Align anti-roll[sway] bar to ball joint links.
7. Fit bolts, washers and rubber bushes using new self locking nuts secure anti-roll[sway] bar to ball joint links. Tighten to **68Nm**.



TORQUE VALUES



NOTE: Torque wrenches should be regularly checked for accuracy to ensure that all fixings are tightened to the correct torque.

	Nm
Anti-roll bar rear	
- Strap nyloc nuts	30
- Ball link self lock nut	68
- Castellated nut	40
Ball joint - levelling unit to rear axle	176
Top link to levelling unit	115
Top link to mounting bracket	176
Upper joint to levelling unit	34
Lower joint to levelling unit	34
Bottom link to axle	176
Bottom link to chassis	176
Top link bracket to rear cross member	47
Levelling unit to cross member	47
Shock absorber to axle	37

Torque values below are for all screws and bolts used except for those that are specified otherwise.

METRIC	Nm
M5	6
M6	9
M8	25
M10	45
M12	90
M14	105
M16	180

UNC / UNF	
1/4	9
5/16	24
3/8	39
7/16	78
1/2	90
5/8	136