

Freelander – Owner's Handbook





FREELANDER

Owner's Handbook Supplement

This supplement should be used in conjunction with your Owner's Handbook (Part No. LRL0442NAS-2nd edition) and provides additional and replacement information relevant to your vehicle.

Publication Part No. LRL 0442/1NAS-2nd edition

© Land Rover 2002

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, recording or other means without prior written permission from Land Rover.



As part of Land Rover environmental policy, this publication is printed on paper made from chlorine free pulp.

IMPORTANT

The specification of each vehicle will vary according to territorial requirements and also from model to model within the vehicle range. Some of the information published in this handbook, therefore, may not apply to your particular vehicle.

Land Rover operates a policy of constant product improvement and therefore reserves the right to change specifications without notice at any time. Whilst every effort is made to ensure complete accuracy of the information in this handbook, no liabilities for inaccuracies or the consequences thereof can be accepted by the manufacturer or the retailer, except in respect of personal injury caused by the negligence of the manufacturer or the retailer.

Quick Guide

GENERAL DATA

Recommended fuel

Unleaded gasoline with a CLC or AKI octane rating of 87 minimum.

Fuel tank capacity

16.9 US gallons (64 litres)

Tyre pressures - all conditions

Front: 30 psi (2.1 bar)

Rear: 30 psi (2.1 bar)

Recommended engine oil

Use **ONLY** an approved full synthetic engine oil. For approved brands see 'Engine oil' in the 'Technical Data' section of this handbook.

NOTE: *One quart is required to raise the level on the dipstick from 'min' to 'max'.*

For full technical data listings, please refer to the 'Technical Data' section of this handbook.


*An asterisk appearing within the text, identifies features or items of equipment that are either optional, or are only fitted to some vehicles in the model range.

Technical Data

CAPACITIES

Fuel tank (usable)	16.9 US gallons (64 litres)
Engine oil (and filter) refill:	5.5 US quarts (5.2 litres)
Automatic gearbox refill:	4.23 US quarts (4.0 litres)
Cooling system fill from dry:	8.25 US quarts (7.8 litres)
Washer reservoir	4.23 US quarts (4.0 litres)

DIMENSIONS



H3485

F	Overall length (inc. 195/80 spare wheel/tyre):	14 ft 6.5 in (4433 mm)
F	Overall length (inc. 215/65 spare wheel/tyre):	14 ft 7.5 in (4459 mm)
A	Overall width (inc. mirrors)	6 ft 9.4 in (2068 mm)
B	Overall height†(excl. roof bars and cross rails)	5 ft 7.2 in (1708 mm)
B	Overall height† (inc. roof bars and cross rails):	5 ft 11.9 in (1828 mm)
E	Wheelbase	8 ft 4.7 in (2557 mm)
	Ground clearance (minimum)†	7.3 in (186 mm)
	Wading depth (maximum)	15.7 in (400 mm)
C	Max. approach angle†	30.5°
G	Max. departure angle (with towbar)†	23.6°
G	Max. departure angle (without towbar)†	33.9°
D	Max. breakover angle	24°
† With 215/65 tyres at curb weight plus a 165 lb (75 kg) driver		



FREELANDER

Owner's Handbook

Publication Part No. LRL 0442NAS-2nd edition

© Land Rover 2002

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, recording or other means without prior written permission from Land Rover.



As part of Land Rover environmental policy, this publication is printed on paper made from chlorine free pulp.

Owner's Handbook

This handbook covers all derivatives in the Freelander range available at the date of publication and, together with the other publications in the literature pack, provides information you will need to derive maximum pleasure from owning and driving your new vehicle.

For your convenience, the handbook is divided into sections, each dealing with a different aspect of the vehicle. These are listed on the following page and you will find it worthwhile to take a little time to read each one, and get to know your Freelander as soon as you possibly can. The more you understand before you drive, the greater the satisfaction once you are seated behind the steering wheel.

IMPORTANT

The specification of each vehicle will vary according to territorial requirements and also from model to model within the vehicle range. Some of the information published in this handbook, therefore, may not apply to your particular vehicle.

Land Rover operates a policy of constant product improvement and therefore reserves the right to change specifications without notice at any time. Whilst every effort is made to ensure complete accuracy of the information in this handbook, no liabilities for inaccuracies or the consequences thereof can be accepted by the manufacturer or the retailer, except in respect of personal injury caused by the negligence of the manufacturer or the retailer.

Contents

Quick Guide

Quick Guide	5
-------------------	---

Introduction

Reporting Safety Defects	15
Auto Safety Hotline	15
California Proposition 65	16

Controls & Instruments

Locks & Alarm	21
Taildoor	28
Seats	29
Seat Belts	31
Child Restraints	35
Airbag SRS	39
Steering Column	44
Instruments	45
Warning Lights	47
Audible Warnings	50
Lights & Indicators	51
Wipers & Washers	53
Horn	56
Mirrors	57
Windows	59
Sunroof	61
Heating & Ventilation	62
Interior Equipment	68
Loadspace Cover	74
In-Car Telephones	75
In-Car Entertainment	76

Driving & Operating

Starting & Driving	79
Fuel System	84
Catalytic Converter	87
Automatic Gearbox	89
Hill Descent Control	94
Cruise Control	96
Brakes	98
Traction Control	101
Load Carrying	102
Towing	106

Off-Road Driving

Off-Road Driving	111
Driving Techniques	114

On-Road Driving

On-Road Driving	121
-----------------------	-----

Owner Maintenance

Maintenance	127
Hood Opening	131
Engine Compartment	132
Engine	133
Air Cleaner	136
Spark Plugs	137
Cooling System	138
Brakes	140
Power Steering	141
Washers	142
Wiper Blades	143
Battery	144
Tyres	148
Cleaning & Vehicle Care	152
Identification Numbers	155
Parts & Accessories	156

Emergency Information

Wheel Changing	161
Emergency Starting	165
Towing The Vehicle	167
Fuses	169
Bulb Replacement	173

Technical Data

Technical Data	185
----------------------	-----

Quick Guide

GENERAL DATA

Recommended fuel

Unleaded gasoline with a CLC or AKI rating of 87 minimum.

Fuel tank capacity

15.6 US gallons (59 litres)

Tyre pressures - all conditions

Front: 30 psi (2.1 bar)

Rear: 30 psi (2.1 bar)

Recommended engine oil

Use ONLY an approved full synthetic engine oil. For approved brands see 'Engine oil' in the 'Technical Data' section of this handbook.


NOTE: *One quart is required to raise the level on the dipstick from 'min' to 'max'.*

For full technical data listings, please refer to the 'Technical Data' section of this handbook.

*An asterisk appearing within the text, identifies features or items of equipment that are either optional, or are only fitted to some vehicles in the model range.

Quick Guide

FASCIA CONTROLS




H4069

- | | |
|--|--|
| 1. Clock display | 8. Bonnet release |
| 2. Audio system | 9. Starter switch |
| 3. Lighting and direction indicator controls | 10. Cruise control set and remote switches |
| 4. Instrument panel | 11. Steering column adjustment lever |
| 5. Horn switches | 12. Remote audio controls* |
| 6. Windscreen wiper/washer controls | 13. Instrument illumination control |
| 7. Exterior mirror control | |

NOTE: The precise specification and location of the controls may vary according to territorial requirements and from model to model within the vehicle range.

Quick Guide

INSTRUMENT PANEL AND BINNACLE SWITCHES



H4238

1. Cruise control master switch

Press to operate and switch off. Use in conjunction with the switches mounted on the steering wheel (see '*CRUISE CONTROL*', page 96).

2. Fuel gauge

The pointer indicates the fuel level when the starter switch is turned to position 'II'.

3. Tachometer

Indicates engine speed in revolutions per minute (x 1000).

4. Speedometer

Indicates road speed in miles per hour and/or kilometres per hour.

5. Digital display

Displays total distance travelled (odometer), individual trip distance and gear selector position.

6. Trip recorder reset/mode button

Press to alternate between total distance and trip recorders. Press and hold when in trip recorder mode to reset the display to zero.

7. Coolant temperature gauge

Under normal operating conditions the pointer will rise to the mid-point of the gauge.


8. Rear screen wash/wipe switch

9. Rear screen wiper switch

NOTE: This is a brief overview of the instrument panel and binnacle switches. For a more detailed description of each instrument, please refer to '*INSTRUMENT PANEL*', page 47, and to find out more about the rear screen wiper and washer, refer to '*REAR SCREEN WIPER AND WASHER*', page 55.

Quick Guide

WARNING LIGHTS




H4235A

1. Cruise control (AMBER)
2. Service engine soon (AMBER).
3. Parking brake & brake system (RED)).
4. Direction indicators (GREEN).
5. Headlight high beam (BLUE).
6. Battery charging (RED).
7. Service engine
8. Supplemental restraint system - airbags (RED).
9. Seat belt reminder (RED).
10. Low oil pressure (RED).
11. Hill descent control (GREEN).
12. Hill descent control 'failure' (AMBER).
13. Anti-lock braking system (AMBER).
14. Traction control (AMBER).
15. Hazard warning lights (RED)
16. Door open (RED)

NOTE: This is a brief overview of the warning lights, for more information concerning warning light functionality, please refer to 'INSTRUMENT PANEL', page 47.

Quick Guide

LIGHTS & INDICATORS



H3341

Side, tail and instrument panel lights

Turn lighting switch to position 1.


Headlights

Turn lighting switch to position 2.

Daytime running lights*

The headlights illuminate automatically, when the starter switch is turned to position 'II'.


Headlight high and dipped beams



H3342

Pull the lever fully towards the steering wheel to change headlight beams.

Direction indicators



H3340


Move the lever DOWN to indicate a LEFT turn, and UP to indicate a RIGHT turn.

NOTE: For further information concerning operation of the lights, please refer to 'DIRECTION INDICATORS', page 51.

Quick Guide

WIPERS & WASHERS

The wipers and washers will only operate when the starter switch is turned to position 'I' or 'II'.



H3345

Intermittent wipe

Turn switch to position 1.

Normal speed wipe

Turn switch to position 2.

Fast speed wipe


Turn switch to position 3.

Single wipe

Pull the lever down and release immediately.

NOTE: With the lever held down, the wipers will operate at fast speed until the lever is released.


Variable delay (intermittent wipe)



H3346

Rotate the inner switch to vary the delay between wiper cycles.

Windscreen washers




H3347


Pull the lever towards the steering wheel. The windscreen wipers will operate in conjunction with the washers.

Quick Guide

CENTRE CONSOLE SWITCHES



H4356



1. Heated front screen*

With the engine running, press to operate. Press again to switch off (see '1. Heated front screen*', page 63).

2. Rear screen demister

With the engine running, press to operate. Press again to switch off (see '2. Rear screen demister', page 63).

3. Hazard warning lights

Press to operate, press again to switch off (see 'HAZARD WARNING LIGHTS', page 52).

4. Recirculated air supply*

Press to recirculate air inside the vehicle (see '3. Air recirculation button*', page 12).

5. Air conditioning

Press to operate, press again to switch off (see 'AIR CONDITIONING', page 66).

6. Electric taildoor glass

With starter switch at position 'II', press and hold the lower part of the switch to open the taildoor glass. Press the upper part to close (see 'ELECTRIC TAILDOOR GLASS', page 60).

7. Central door locking

Press the lower part of the switch to lock and upper part of the switch to unlock (see 'DOOR LOCKING CUT-OFF SWITCH', page 26).

8. Sunroof*

Press lower part of switch to tilt the roof. With roof tilted, press again to open fully. Press upper part of switch to close roof (see 'ELECTRIC SUNROOF*', page 61).

9. Heated seats (2)*

With the engine running, press to operate. Press again to switch off (see 'HEATED FRONT SEATS*', page 67).

Quick Guide

10. Hill Descent Control

With the engine running, press to select or deselect (see 'HILL DESCENT CONTROL', page 94).


11. Electric windows (4)

With the starter switch at position 'II', press and hold the lower part of a switch to open a window; press the upper part of a switch to close (see 'ELECTRIC WINDOW CONTROLS', page 59).

12. Rear window isolation switch

Press to inhibit operation of rear window switches (see 'Rear window isolation switch', page 59).

HEATER CONTROLS



H3317A

1. Heated front screen*

With the engine running, press to operate (the screen heater will switch off automatically after approximately 10 minutes).

2. Rear screen demister

With the engine running, press to operate (the demister will switch off automatically after approximately 15 minutes).

3. Air recirculation button*

Press to recirculate air inside the vehicle.

4. Air conditioning

With the engine running, press to operate.

5. Air temperature control






Rotate the control clockwise (towards the RED segments) to increase the air temperature, or anti-clockwise (towards the BLUE) to reduce the temperature.

6. Air blower control

Turn the control clockwise to progressively increase the blower speed.

7. Air distribution control

Rotate to select air distribution:

-  Air to face vents.
-  Air to face vents and foot outlets.
-  Air to foot outlets.
-  Air to foot outlets and windscreen.
-  All air to windscreen.

Introduction

Introduction

REPORTING SAFETY DEFECTS	15
BEFORE YOU DRIVE	15
CALIFORNIA PROPOSITION 65 WARNING	16
WARNINGS IN THIS HANDBOOK	16
SYMBOLS USED	16
PASSPORT TO SERVICE	16
SUN VISOR LABELS	16
INFORMATION LABELS IN THE ENGINE COMPARTMENT	17
WARNING LABELS ATTACHED TO THE VEHICLE	17
ANTI-THEFT PRECAUTIONS	18
IN AN EMERGENCY	18

Introduction

REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect which could cause a crash, or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Land Rover North America Inc.

If NHTSA receives similar complaints, it may open an investigation and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign.

However, NHTSA cannot become involved in individual problems between you, your retailer or Land Rover North America.

AUTO SAFETY HOTLINE

To contact NHTSA, you may either call the Auto Safety HOTLINE toll free at 1-800-424-9393 (or 202-366-0123 in the Washington, D.C. area) or write to: NHTSA, U.S. Department of Transportation, Washington, DC 20590. You can also obtain other information about motor vehicle safety from the HOTLINE.

BEFORE YOU DRIVE

Your Freelander has a higher ground clearance and hence, a higher centre of gravity than ordinary passenger cars, to enable the vehicle to perform in a wide variety of off-road applications. An advantage of the higher ground clearance is a better view of the road allowing you to anticipate problems.

The vehicle is not designed for cornering at the same speed as conventional passenger cars any more than a low slung sports car is designed to perform satisfactorily under off-road conditions. If at all possible, avoid sharp turns or abrupt manoeuvres. As with other vehicles of this type, failure to operate the Freelander correctly may result in loss of control or vehicle rollover. For important safety information, be sure to read the 'On-Road' and 'Off-Road' driving guidelines given later in this handbook.

Introduction

CALIFORNIA PROPOSITION 65 WARNING

WARNING

Engine exhaust, some of its constituents and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm.

WARNING

Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.

WARNINGS IN THIS HANDBOOK

WARNING

Safety warnings are included in this handbook. These indicate a procedure which must be followed precisely in order to avoid the possibility of personal injury.

SYMBOLS USED

The following symbols used within the handbook call your attention to specific types of information.



This recycling symbol identifies items that must be disposed of safely in order to prevent unnecessary damage to the environment.





This symbol identifies features that can be adjusted or disabled/enabled by a Land Rover retailer

*An asterisk appearing within the text, identifies features or items of equipment that are either optional, or are only fitted to some vehicles in the model range.

PASSPORT TO SERVICE

The Passport to Service book included in your literature pack contains important vehicle identification information, details of your entitlement under the terms of the Land Rover warranty, as well as useful consumer advice. Also included is a section on maintenance, which outlines the servicing requirements for your vehicle, the First Service Voucher, and the service record slips, which the retailer will sign and stamp to certify the routine services have been carried out at the recommended intervals.

SUN VISOR LABELS



H4032

Take note of the warnings concerning the airbag SRS and risk of vehicle rollover.

Introduction

INFORMATION LABELS IN THE ENGINE COMPARTMENT

A/C **LAND-ROVER** SAE J 639

R134a CF3 CH2F PAG OIL ND 8

430 g ± 25 g (15 oz ± 1oz) **120ml (4.1 fl oz)**

CAUTION
SYSTEM TO BE SERVICED BY QUALIFIED PERSONNEL.

CAUTION / ATTENTION


USE ONLY APPROVED 5W-40 OR 5W-50 FULL SYNTHETIC ENGINE OIL

UTILISER UNIQUEMENT DE L'HUILE MOTOR SYNTHEIQUE APPROUVEE 5W-4- OU 5W-50

SEE HANDBOOK FOR SPECIFICATIONS

CONSULTEZ LE MANUEL DU CONDUCTEUR POUR LES SPECIFICATIONS

Three warning symbols: a hand near a hot engine, a hand near a fan, and a hand near a crossed-out oil can.



LAND ROVER VEHICLE EMISSION CONTROL INFORMATION		EPA APPROVED I/M TESTING EXEMPTION	VACUUM ROUTING DIAGRAM
	LOADED I/M TESTING OF PERMANENT FOUR WHEEL DRIVE OR TRACTION CONTROL EQUIPPED VEHICLES MUST BE CONDUCTED ON A FOUR WHEEL DRIVE SPEED SYNCHRONISED DYNAMOMETER OTHERWISE NONLOADED TEST PROCEDURE MUST BE PERFORMED		FUEL TANK CHARCOAL CANISTER PURGE VALVE
NO ENGINE ADJUSTMENT REQUIRED CATALYST THIS VEHICLE CONFORMS TO U.S. EPA NLEV REGULATIONS APPLICABLE TO 2002 MODEL YEAR NEW LEV LIGHT-DUTY TRUCKS AND CALIFORNIA REGULATIONS APPLICABLE TO 2002 MODEL YEAR NEW LEV LIGHT-DUTY TRUCKS	OBD II CERTIFIED 252EGFFE	BAC000800	

H4560

Various labels are attached to the hood locking platform, the number, position and content of which may vary from model to model. The following list is provided as a guide:

- Keep clear of rotating engine parts
- Air conditioning label
- Emission control label
- Engine oil label

WARNING LABELS ATTACHED TO THE VEHICLE



Warning labels attached to your vehicle bearing this symbol mean: **DO NOT touch or adjust components until you have read the relevant instructions in the handbook.**

Warning labels showing this symbol indicate that the ignition system utilizes very high voltages. **DO NOT touch any ignition components while the starter switch is turned on!**

Introduction

ANTI-THEFT PRECAUTIONS

While it may be difficult to deter the 'professional' car thief, the majority of thefts are carried out by unskilled opportunists.

Therefore, take vehicle security very seriously and ALWAYS adopt this simple 'four point' drill whenever you leave your vehicle - even for just a few minutes:

1. Fully close all the windows (and the sunroof).
2. Remove your valuable belongings (or hide them out of sight).
3. Remove the starter key.
4. Superlock the vehicle using the remote handset.

Thieves are attracted by 'vulnerable' vehicles. Even if you have followed the 'four point' drill, there is still much you can do to make your vehicle a less inviting target.

BE SAFE - NOT SORRY!

- Park where your vehicle can be easily seen by householders and passers-by.
- At night, park in well lit areas and avoid deserted or dimly-lit side streets.
- NEVER leave the keys in the vehicle.
- Do not keep important documents (or spare keys) in the vehicle - these are a real bonus for the thief.

IN AN EMERGENCY

IMPORTANT INFORMATION

Remember the breakdown safety code

If a breakdown occurs while travelling:

- Wherever possible, consistent with road safety and traffic conditions, the vehicle should be moved off the main thoroughfare, preferably onto the shoulder. If a breakdown occurs on a freeway, pull well over to the inside of the shoulder.
- Switch on hazard lights.
- If possible, position a warning triangle or a flashing amber light at an appropriate distance from the vehicle to warn other traffic of the breakdown, (note the legal requirements of some areas).
- Consider evacuating passengers through the doors facing away from the traffic, to a safe area away from the vehicle as a precaution in case your Freelander is accidentally struck by another vehicle.

Controls & Instruments

Locks & Alarm

KEYS AND HANDSETS	21
ALARM SYSTEM	21
LOCKING THE VEHICLE AND ARMING THE ALARM 22	
CHILD-PROOF LOCKS	25
ENGINE IMMOBILISATION	26
DOOR LOCKING CUT-OFF SWITCH	26
REMOTE HANDSET	27

Taildoor

OPENING AND CLOSING	28
-------------------------------	----

Seats

SEATING	29
-------------------	----

Seat Belts

SEAT BELT SAFETY	31
WEARING SEAT BELTS CORRECTLY	32
SEAT BELT PRE-TENSIONERS	34
CARE & MAINTENANCE OF SEAT BELTS	34

Child Restraints

CHILD RESTRAINTS FOR SMALL CHILDREN AND BABIES	35
'LATCH' TYPE CHILD RESTRAINTS	37
TETHER STRAP ANCHORAGES	38

Airbag SRS


AIRBAG SUPPLEMENTAL RESTRAINT SYSTEM (SRS)	39
HOW THE AIRBAG SRS WORKS	41
SERVICE INFORMATION	43



Steering Column		GLOVEBOX	69
STEERING COLUMN ADJUSTMENT	44	DRIVER'S STORAGE AREA	69
Instruments		DRINKS STOWAGE	70
INSTRUMENT PANEL	45	CUP HOLDERS	70
Warning Lights		SUN VISOR	71
INSTRUMENT PANEL	47	ASHTRAY	72
Audible Warnings		CIGAR LIGHTER	73
AUDIBLE WARNINGS	50	AUXILIARY POWER SOCKET	73
Lights & Indicators		Loadspace Cover	
DIRECTION INDICATORS	51	LOADSPACE COVER	74
LIGHTS	51	In-Car Telephones	
HAZARD WARNING LIGHTS	52	IN-CAR TELEPHONES	75
Wipers & Washers		In-Car Entertainment	
OPERATING	53	RADIO/CASSETTE PLAYER	76
WINDSCREEN WIPERS	53	RADIO AERIAL	76
WINDSCREEN WASHERS	54	REMOTE AUDIO CONTROLS	76
REAR SCREEN WIPER AND WASHER	55	NAVIGATION SYSTEM	76
Horn			
HORN	56		
Mirrors			
EXTERIOR MIRRORS	57		
INTERIOR MIRROR	58		
VANITY MIRROR	58		
Windows			
ELECTRIC WINDOW CONTROLS	59		
ELECTRIC TAILDOOR GLASS	60		
Sunroof			
ELECTRIC SUNROOF	61		
Heating & Ventilation			
VENTILATION	62		
HEATER CONTROLS	63		
USING YOUR HEATER	64		
FACE LEVEL VENTS	65		
AIR CONDITIONING	66		
HEATED FRONT SEATS	67		
Interior Equipment			
COURTESY & MAP READING LIGHTS	68		
LUGGAGE COMPARTMENT LIGHT	68		
CLOCK	68		

Locks & Alarm

KEYS AND HANDSETS



H3519A

You have been supplied with a pair of identical keys and two remote control handsets.

Keep the spare key in a safe place - **NOT IN THE VEHICLE!**

The keys supplied with your vehicle are programmed to the vehicle's security system - they **CANNOT** be reprogrammed and the engine cannot be started without a valid programmed key. If a key is lost or broken, a replacement can be ordered only from a Land Rover retailer.

NOTE: *Land Rover retailers do not stock spare keys, time has to be allowed for replacements to be programmed to your security system and then delivered to the retailer.*

If you lose a key, contact your Land Rover retailer; a key reported lost will be deactivated. If the key is later recovered, your Land Rover retailer can have it reactivated.

IMPORTANT INFORMATION

The handset complies with part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation. This applies to both alarm receivers and transmitters.

Any changes or modifications to the handset not expressly approved by the manufacturer or Land Rover North America, could void the user's authority to operate the equipment.

ALARM SYSTEM

Your vehicle is fitted with a sophisticated electronic anti-theft alarm and engine immobilisation system. In order to ensure maximum security and minimum inconvenience, you are strongly advised to gain a full understanding of the alarm system, by thoroughly reading this section of the handbook.

Locks & Alarm

LOCKING THE VEHICLE AND ARMING THE ALARM

Before locking the vehicle and arming the alarm, ensure that all doors (including taildoor), windows, sunroof and bonnet apertures are securely closed.


There are three methods for securing your vehicle:

- 'Superlocking' using the handset - (recommended high security method).
- 'Superlocking' using the key.
- Locking using the key.

IMPORTANT INFORMATION

- FOR MAXIMUM SECURITY ALWAYS SUPERLOCK THE VEHICLE USING THE REMOTE HANDSET

Using the remote handset



H3297

While it is not necessary to point the handset at the vehicle, the handset must be within range of the vehicle when a button is pressed. Note that the operating range may vary depending upon handset battery condition and may sometimes be limited by physical and geographical factors beyond your control. From a security point of view, it may not be wise to unlock unless you are within a few feet of the vehicle.

Locking

With the remote handset:

Press the lock (padlock symbol) button once. Each time the vehicle is locked using the handset, a coded signal is transmitted to a receiver inside the vehicle, which activates the following security features:

- the central door locking system (all the door locks are activated).
- the perimetric alarm (protects the door, taildoor, and bonnet apertures).

Pressing the lock (padlock symbol) a second time within one second of the first action activates:

- 'Superlocking' - the door locks cannot be operated from inside the vehicle.

With both levels of locking, if the doors lock correctly, the direction indicator lights flash three times to confirm that the vehicle is secure and the anti-theft alarm indicator light (in the instrument panel) will start to flash rapidly.

Once armed, the alarm will sound if any door is opened.

With the key:

Insert the key and turn the door lock clockwise. Turning the key ONCE activates the following:

- all doors locked (not superlocked)
- perimetric alarm activated (protects the doors, bonnet and taildoor)

Turning the key TWICE within 1 second activates, in addition to the above:

- Superlocking

If the doors lock correctly, the direction indicators flash three times to confirm that the vehicle is secure and the anti-theft alarm indicator light (in the instrument panel) will start to flash rapidly.

Locks & Alarm

NOTE: *The engine will automatically be immobilised 3 seconds after the starter switch is turned off, and immediately when the starter key is removed from the switch.*

Superlocking

Provided all the doors are fully closed, the Superlocking feature is activated automatically whenever the vehicle is locked by pressing the padlock symbol on the remote handset twice within one second. Superlocking immobilises the interior door handles, thereby preventing an intruder from gaining entry by smashing a window and reaching inside the vehicle to operate the door handles.

WARNING

For safety, NEVER use Superlocking if passengers are to remain inside the vehicle - in an emergency they would not be able to escape.


Mislock

If one of the doors, taildoor or bonnet is not properly closed when the alarm is armed, a mislock occurs (the horn will sound a warning). The alarm will still be armed and the engine immobilised, but the open aperture will not be protected. If the appropriate aperture is then closed, the alarm will fully arm without the need to press the lock button again unless the driver's door is open, in which case the alarm will be fully armed by pressing the lock button again.

If the taildoor glass is left open when the alarm is armed, the horn will sound as a reminder, but the vehicle will be locked and alarmed as normal. The taildoor glass can be closed from outside the vehicle using the starter key in the taildoor (see '*Raising and lowering*', page 60).

Locks & Alarm

Anti-theft alarm indicator light



H3298

After locking, the RED indicator light on the instrument panel flashes rapidly while the alarm is arming itself.

After approximately 10 seconds, the indicator light adjusts to a slower frequency, and continues to flash as an anti-theft deterrent until the alarm is disarmed.

Unlocking

With the remote handset:

If your vehicle is configured with the Single Point Entry security feature, and was locked with the handset, the handset unlocks the vehicle in two stages:

- Press the unlock (Land Rover) button once to disarm the alarm and unlock the driver's door only (see '*Single point entry*', page 24).
- Press the unlock button twice to disarm the alarm and unlock ALL the doors.

If your vehicle is not configured with Single Point Entry, all the doors will unlock at the first press.

In either case, the direction indicators flash once and the interior lights illuminate.

With the key:

Turn the key towards the front of the vehicle. The alarm will be fully disarmed. To remobilise the engine, the key must be inserted into the starter switch.

If the alarm sounds

If the alarm is triggered, it will sound for approximately 30 seconds before switching itself off and can be triggered up to ten times in total before needing to be reset.

To silence the alarm, press either handset button, or operate the door locks using the key in the driver's door.

Single point entry

This is a personal security feature, which enables the driver's door only to be unlocked, leaving the other doors in a locked state. It can be operated by the remote handset as follows:


Press the unlock button once to unlock the driver's door, press a second time to unlock the remaining doors and taildoor.



Single point entry can be configured by a Land Rover retailer.

Locks & Alarm

Interior locking switch



H3334

This is a personal security feature which allows the driver to lock (or unlock) all the doors from inside the vehicle (while driving or with the vehicle stationary). Press the lower part of the switch to lock (the alarm will not be armed), and the upper part to unlock.

NOTE: *If interior locking has been activated, pull the interior door handle once to unlock, and twice to open the door.*

Door handles and door sill locking buttons


From inside the vehicle, each door can be individually locked by depressing the appropriate door sill button. However, doors cannot be unlocked by raising the sill button.

Use the door handles to unlock, as follows:

- First operation of the door handle unlocks the door.
- Second operation of the door handle opens the door.

NOTE: *The door handles will not open the doors if the vehicle has been superlocked (see 'Superlocking', page 23)*

CHILD-PROOF LOCKS



H4034

Move the lever on the rear doors down (see inset) to engage.

With the child-proof locks engaged, the rear doors cannot be opened from inside the vehicle, thereby avoiding the risk of a door being opened accidentally while the vehicle is moving.

WARNING

To avoid injury or even death, NEVER leave children unsupervised in the vehicle.

Locks & Alarm

ENGINE IMMOBILISATION


Engine immobilisation is an important aspect of the security system and is designed to safeguard the vehicle from theft, should the driver forget to lock the doors. Engine immobilisation prevents the engine from being started unless a valid key is inserted into the starter switch, and occurs automatically whenever any of the following conditions occur:

- Three seconds after the starter switch has been turned off.
- As soon as the key is removed from the starter switch.

The engine is re-mobilised by a signal transmitted from a transponder contained within the key head, to the starter switch. This occurs automatically whenever a valid key is inserted into the starter switch and turned to position 'I'.

CAUTION: DO NOT keep more than one starter key, or keys from other vehicles, or gas station speed payment devices on the same key ring: the engine will not re-mobilise automatically.

DOOR LOCKING CUT-OFF SWITCH



An inertia switch, which operates when the starter switch is in position 'II', prevents the doors from centrally locking (or, if the doors are already locked, unlocks them) in the event of an accident or sudden impact. If this occurs, central locking will be inhibited until either:

- the starter switch is turned off and the driver's door has been opened and closed, or:
- the driver's door has been opened and closed, and the inertia switch is reset.

The inertia switch is located inside the engine compartment on the left hand side, beneath, and to the rear of, the engine compartment fuse box (a label attached to the bulkhead will assist in locating the switch). The switch must be reset before the engine can be restarted. Reset the switch by pressing the rubber top (arrowed in illustration).

This will also reset the fuel system, see 'FUEL CUT-OFF SWITCH', page 86).

WARNING

ALWAYS check for fuel leaks before resetting the switch! Activating the switch when the fuel system has been damaged (evidenced by fuel leakage or odor) will cause additional fuel leakage increasing the risk of fire.

Locks & Alarm

REMOTE HANDSET


CAUTION: The handset contains delicate electronic circuits and must be protected from impact and water damage, high temperatures and humidity, direct sunlight and the effects of solvents, waxes and abrasive cleaners.

The battery should last for approximately three years dependent upon use. When the battery needs replacing it will be apparent from the following symptoms:

- A gradual deterioration in range and performance.
- The alarm buzzer and the anti-theft alarm indicator light will double bleep/flash every second, for ten seconds, after the alarm is disarmed and driver's door opened.

It is recommended that you fit a Land Rover STC 4080 or a Panasonic CR2032 replacement battery (available from a Land Rover retailer).

Battery replacement



H3518

1. Carefully prise the handset apart, start from the keyring end using a small coin or screwdriver. Avoid damaging the seal between the two halves of the case and DO NOT allow dirt or moisture to get inside the handset.
2. Slide the battery out of its clip, taking care to avoid touching the circuit board or the contact surfaces of the clip.

3. Press and hold each button in turn for at least five seconds (this will drain any residual power from the handset).
4. Fit the new battery, ensuring that correct polarity is maintained ('+' side facing up). Finger marks will adversely affect battery life; if possible, avoid touching the flat surfaces of the battery and wipe them clean before fitting.
5. Press the two halves of the handset firmly together and ensure that both halves are fully joined to prevent dirt or moisture from entering the handset.
6. Resynchronise the handset.

The handset is now ready for use.


Handset resynchronisation

If the handset fails to lock or unlock the car, this may be because the coded signal transmitted by the handset, and the signal expected by the alarm control unit are no longer synchronised.

To resynchronise the handset, operate either button of the handset at least five times in quick succession (in close proximity to the vehicle).

Taildoor

OPENING AND CLOSING



H2317

Opening the taildoor

When the release catch is pulled (as shown in illustration), the taildoor lock is released in two phases:

1. the taildoor glass drops clear of its retaining channel.
2. the electronic door latch is released and the door can be opened.

Initially, the door opens approximately half way until resistance is felt; this prevents the door swinging fully open and possibly hitting an obstruction, yet still enables access in a situation where there is not enough room to open the door fully. Push, against resistance, to open the door fully.

NOTE: The taildoor latch will not operate if the glass is frozen to the door seals, as the glass needs to drop slightly before the door can be opened. Defrost the glass first.

WARNING

You are advised NOT to carry loads which require driving with the taildoor or taildoor window open - poisonous fumes will be drawn into the vehicle! If driving the vehicle in this condition is unavoidable, switch the heater to face level vents with all vents open, close the sunroof and windows and turn the air blower to position 4.

Closing

CAUTION: When closing the taildoor, push on the handle - NOT on the taildoor glass.

Load carrying

Long loads should be carried on the roof rack. If it is necessary to carry a load that protrudes through the taildoor window aperture, the weight of the load must NOT rest on the glass. Damage to the glass or window mechanism may occur (see also 'Accommodating long loads', page 103).

Seats

SEATING

WARNING

It is extremely dangerous to ride in the cargo area, inside or outside the vehicle. In a collision, people riding in these areas are more likely to be seriously injured or killed. Do not allow people to ride in any area of your vehicle that is not equipped with seats and safety belts. Be sure everyone in your vehicle is in a seat and using a safety belt properly.

FRONT SEAT ADJUSTMENT

WARNING

To avoid the risk of loss of control and personal injury, DO NOT adjust the driver's seat or head restraint while the vehicle is in motion.

DO NOT travel with the seat backs reclined steeply rearwards. Optimum benefit is obtained from the seat belt, with the backrest angle set to 25 degrees from the upright (vertical).

An inflating airbag can cause facial abrasions and other injuries. The injurious effects of airbag inflation can be minimised by ensuring that driver and passenger are seated correctly, with the seat moved back as far as is practical, and the seat belts worn correctly.

Forward/backward adjustment


Lift the lever (1) and slide the seat into position. Make sure the seat is locked in position before driving.

Backrest adjustment

Rotate the handwheel (2) to adjust.

Lumbar support adjustment (Driver's seat only)

Rotate the handwheel (3) to increase or decrease support to the lumbar region of the back.



H4033

Head restraint adjustment

WARNING

Head restraints are designed to support the back of the head (NOT THE NECK), and to restrain rearward movement of the head in the event of a collision. The restraint must be positioned level with the head to be effective.

DO NOT drive or carry passengers with the head restraints removed from occupied seats, or adjust the head restraints while the vehicle is in motion.

Failure to have the head restraint installed and properly positioned will increase the potential for serious injuries.

Raise or lower the restraint (4), until the cushion is level with the back of the head.

Seats

Head restraint removal

Turn the right-hand mounting (5) a quarter turn anti-clockwise and pull the restraint upwards.

After replacing a head restraint, turn the right-hand mounting clockwise.

Rear seats

For information on folding the rear seats, refer to '*FOLDING THE REAR SEATS*', page 103.

Heated front seats*

For information on the operation of the front seat heaters, refer to '*HEATED FRONT SEATS**', page 67.

Seat Belts

SEAT BELT SAFETY

WARNING

Seat belts are life-saving equipment. In a collision, occupants not wearing a seat belt will be thrown around inside, or possibly thrown out of, the vehicle. This is likely to result in more serious injuries than would have been the case had a seat belt been worn. It may even result in loss of life!

Don't take chances with safety!

- *DO make sure that ALL occupants are securely strapped in at all times - even for the shortest journeys.*
 - *The airbag supplemental restraint system (SRS) is designed to add to the overall effectiveness of the seat belts. It does not replace them. SEAT BELTS MUST ALWAYS BE WORN!*
 - *Ensure that all seat belts are worn correctly - an improperly worn seat belt increases the risk of death or serious injury in the event of a collision.*
 - *DO use the seat belts to secure items of luggage that are to be carried on the seats - in the event of an accident, loose items become flying missiles capable of causing serious injury, or even death.*
-

WARNING

- *DO NOT fit more than one person into a belt; this could result in the occupants striking each other and causing injury in the event of a crash.*
 - *DO NOT use, or attempt to fit, a seat belt that is twisted or obstructed in any way that could impede its smooth operation. If a belt is twisted, it must be straightened before use. Using a twisted or obstructed seat belt could increase the risk of injury in a crash.*
 - *ALWAYS use the seat belt lock (buckle) nearest the wearer. If the belt is locked in the wrong place, the seat belt will not fit correctly and may ride up over the abdomen, causing serious internal injury in a crash.*
 - *ALWAYS transport children 12 years old and under in the back seat and always properly use appropriate child restraints.*
-


Seat Belts

WEARING SEAT BELTS CORRECTLY

Fastening the seat belts

WARNING

Maladjustment of a seat belt could reduce its effectiveness in a crash, thereby increasing the risk of serious injury or death.



H3303

Inertia reel belts are fitted to all front and rear seating positions.

Draw the belt over the shoulder and across the chest and, ensuring that the webbing is not twisted, insert the metal tongue plate into the buckle nearest the wearer - a 'CLICK' indicates that the belt is securely locked.

In some circumstances, perhaps due to the vehicle being parked on a slope, the inertia mechanism may engage, preventing the initial extension of a belt. This is not a fault - ease the belt free and use it.

NOTE: *The centre rear seat belt tongue plate will not latch into either of the outer seating position buckles.*

NOTE: *Where possible, rear seat passengers should adjust their position on the seat to enable the seat belt webbing to cross the shoulder without pressing on the neck.*

Adjust the seat belt to eliminate any slack in the webbing. DO NOT slacken the webbing by holding the belt away from the body - to be fully effective, the seat belt must remain in full contact with the body at all times. Also, ensure that the lap belt fits as low on the hips as possible and that the shoulder belt passes across the shoulder without slipping off or pressing on the neck.

Positioning the belt

WARNING

Seat belts are designed to bear upon the bony structure of the body (pelvis, chest and shoulders), and can only be worn safely with the seats in a normal, upright, position.

- ***ALWAYS fit the lap strap as low on the hips as possible (never across the abdomen) and ensure that the diagonal belt passes across the shoulder without slipping off or pressing on the neck.***
- ***DO NOT travel with the seat backs reclined steeply rearwards. Optimum benefit from the seat belt is obtained with the seat back set to an angle of 25 degrees from the upright (vertical). Seat belts are only effective when they are properly positioned on the body - a steeply reclined seat could allow a passenger to slip under either the shoulder or the lap belt.***
- ***DO NOT wear the shoulder belt under your arm. In an accident this could increase your chances of being injured.***


Seat Belts

Wearing seat belts during pregnancy

The seat belts have been designed for all adults, including pregnant women. In a crash situation any occupant is less likely to be injured while correctly restrained by a seat belt. However, pregnant women should wear the lap belt as low on the hips as possible to avoid pressure on the abdomen.

Women should consult their doctor to establish the best use of seat belts during pregnancy.

Upper anchorage adjustment (front seats only)



H2344A

The height of the seat belt upper anchorage can be adjusted for comfort AND safety. Adjust the height of the anchorage point by pressing the button (arrowed in illustration). For safety, the seat belt should always be worn with the webbing crossing the shoulder **MIDWAY BETWEEN THE NECK AND THE EDGE OF THE SHOULDER.**

Misadjustment of the seat belt could reduce its effectiveness in a crash. Always ensure that the anchorage is correctly located in one of the height positions before driving and **DO NOT** adjust the height once the vehicle is in motion.

For children where the seat belt cannot be properly positioned, the use of a booster seat appropriate to the age and size of the occupant is recommended.

Releasing the belt

Press the **RED** button on the seat belt buckle.

Seat Belts

SEAT BELT PRE-TENSIONERS

The seat belt pre-tensioners activate in conjunction with the airbag SRS and provide additional protection in the event of a severe frontal impact on the vehicle (see 'HOW THE AIRBAG SRS WORKS', page 41). The pre-tensioners automatically retract the seat belts fitted to the front seats. This reduces any slack in both the lap and diagonal portions of the belts, thereby reducing forward movement of the belt wearer in the event of a severe frontal collision.

The airbag SRS warning light on the instrument panel will alert you to any malfunction of the seat belt pre-tensioners.

If the pre-tensioners have been activated, the seat belts will still function as restraints, and must be worn in the event that the vehicle remains in a driveable condition.

NOTE: *The seat belt pre-tensioners will NOT be activated by rear, side or minor frontal impacts.*

WARNING

After the seat belt pre-tensioners have been activated once, they MUST BE REPLACED by a Land Rover retailer. Failure to replace the pre-tensioners will reduce the efficiency of the vehicle's front restraint systems.

After any frontal impact, always have the seat belts and pre-tensioners checked and, if necessary, replaced by a Land Rover retailer.

In the interests of safety, it is recommended that removal or replacement of the front seats and seat belts, with the use of factory-specified parts, should ONLY be carried out by a Land Rover retailer.

CARE & MAINTENANCE OF SEAT BELTS

WARNING

- ***DO NOT allow foreign matter (particularly sugary food and drink particles) to enter the seat belt locks - such substances can render the locks inoperative.***
 - ***Regularly inspect the belt webbing for signs of fraying, cuts and wear, and also pay particular attention to the condition of the fixing points and adjusters.***
 - ***DO NOT bleach or dye the webbing. Clean the webbing using warm water and non-detergent soap only - allow to dry naturally and DO NOT retract or use the belts until they are completely dry.***
 - ***Always replace a seat belt that shows signs of webbing wear or has withstood the strain of a severe vehicle impact.***
-

Testing inertia reel belts

- With the seat belt fastened, give the webbing near the buckle a quick upward pull. The buckle must remain securely locked.
- With the seat belt unfastened, unreel the webbing to the limit of its travel. Check that unreeling is free from snatches and snags and then allow the belt to FULLY retract.
- Partially unreel the webbing, then hold the tongue plate and give it a quick forward pull. The mechanism must lock automatically and prevent any further unreeling.

If a seat belt should fail any of these tests, contact your retailer immediately.

Child Restraints

CHILD RESTRAINTS FOR SMALL CHILDREN AND BABIES

Infants and children too small for adult seat belts should be restrained in a child safety seat or restraint system appropriate to their age and/or size.

Child seats and restraint systems are designed to be secured in vehicle seats by lap belts (or the lap belt portion of a lap/shoulder belt). Some child restraint systems also incorporate a tether strap which can be attached to an anchorage point on the vehicle. Information about tether strap attachment points and the seat belt locking mechanism, which is used to restrain child seats and restraints is shown later in this section.

CAUTION: When fitting child seats and restraint systems, always ensure that the manufacturer's fitting instructions are followed exactly. Note that crash statistics show that children are safer when properly restrained in the rear seating positions than in the front.

WARNING

- ***DO NOT allow a baby or infant to be carried on the lap. The force of a crash can increase effective body weight by as much as 30 times, making it impossible to hold on to the child.***
 - ***Children typically require the use of a booster seat appropriate to their age and size, thereby enabling the seat belts to be properly fitted, reducing the risk of injury in a crash.***
 - ***Children could be endangered in a crash if their child restraints are not properly secured in the vehicle.***
 - ***DO NOT use a child seat that hooks over the seat back. This type of seat cannot be satisfactorily secured, and is unlikely to be safe for your child.***
 - ***Never leave a child unattended in your vehicle.***
-

Child Restraints

Vehicles fitted with a passenger airbag

For optimum safety, children should travel in the rear of the vehicle at all times; front passenger seat travel is NOT recommended. However, if it is essential that a child travel in the front, set the seat fully rearward and seat the child in a FORWARD FACING child seat.



The above symbol affixed to the passenger side fascia panel of your vehicle, warns against the use of a REAR FACING child seat in the front passenger seat, when a passenger airbag is fitted. This type of child seat could cause serious injury to a child in the event of an airbag deployment.

WARNING

UNDER NO CIRCUMSTANCES SHOULD A REARWARD FACING CHILD SEAT BE INSTALLED IN ANY FRONT PASSENGER SEAT POSITION. INFLATION OF THE AIRBAG COULD RESULT IN SERIOUS INJURY OR DEATH TO THE CHILD.

Seat belt locking mechanism


All front passenger and rear seat belts have a special locking mechanism which aids the securing of child restraints. The mechanism is used to secure a child restraint as follows:

1. Attach the seat belt to the child restraint in accordance with the manufacturer's instructions.
2. Insert the metal tongue of the seat belt into the lock ensuring that it engages with a 'click'.
3. Pull on the shoulder section of the belt until it is fully extended.
4. Allow the belt to retract. A 'clicking' sound will confirm that the mechanism has engaged.
5. Remove all slack from the mechanism, by pulling upwards on the shoulder belt, immediately above the child restraint.
6. Evaluate the tightness of the installation by rocking the child seat back and forth to ensure it is tight and stable.
7. If the child seat needs to be tightened further, remove the metal tongue of the seat belt from the buckle and feed some of the shoulder belt webbing back into the reel (thereby shortening the belt). Then re-attach the metal tongue into the buckle (if the belt has been tightened correctly, this will take some effort).
8. Re-evaluate the tightness of the installation. If the child seat is still too loose, repeat the above procedure, making the belt incrementally shorter (and therefore tighter). It may be necessary to put your weight onto the seat (to compress the seat cushion) in order to fasten the belt.

To deactivate the locking mechanism, unlatch the seat belt and allow it to fully retract.

Child Restraints

'LATCH' TYPE CHILD RESTRAINTS



H4322

'LATCH' (Lower Anchors and Tether for Children)

The 'LATCH' three-point type child restraint system complies with Federal Motor Vehicle Safety Standards guidelines and is approved for fitting in your vehicle.

Fitting the restraints

This type of child restraint system should only be fitted in the two outer seating positions of the rear seats. Anchor bars built into the rear seat frame enable 'LATCH' type restraints to be securely attached to the vehicle seat in these positions only. The anchor bar locations are shown in the illustration above.

WARNING

If the restraint is not correctly anchored, there is a significant risk of injury to the child, in the event of a collision or emergency braking.

WARNING


DO NOT attempt to fit 'LATCH' type restraints to the centre seating position - the anchor bars are designed to hold restraints in the outer seating positions only.

When fitting this type of child restraint, always follow the instructions supplied by the manufacturer of the restraint.

Once the restraint is installed, you are recommended to test the security of the installation before seating the child. Attempt to twist the restraint from side to side and to pull the restraint away from the vehicle seat; then check that the anchors are still securely in place.

Child Restraints

TETHER STRAP ANCHORAGES



H4240

Provision is made for the fitting of up to three child seats or restraint systems in the rear seats, of the type that require tether strap anchorage points.

There are three tether strap anchorage points. These should be used to attach tether straps from child seats or restraint systems. All three anchorage points are fitted to the back of the rear seat (shown in the accompanying illustration).

Attaching tether straps


1. Install the child restraint securely in one of the rear seating positions.
2. Pass the tether strap over the back of the vehicle seat and beneath the underside of the head restraint.
3. Attach the clip on the head of the tether strap to the tether anchor on the back of the vehicle seat.
4. Tighten the tether strap according to the manufacturer's instructions to remove any slack in the webbing.

WARNING

- ***Always follow the child seat or restraint system manufacturer's instructions when fitting tether straps.***
- ***When fitting a child seat or restraint system, always pass the tether strap over the top of the seat back and beneath the underside of the head restraint.***
- ***If a child seat or restraint system is to be fitted to the centre seating position, the centre armrest must be in the stowed position (folded into the seat).***

Airbag SRS

AIRBAG SUPPLEMENTAL RESTRAINT SYSTEM (SRS)



H3362

The airbag supplemental restraint system (SRS) provides additional protection for the driver and front seat passenger, in the event of a severe frontal impact on the vehicle.

Provided the front seat occupants are correctly seated, with seat belts properly worn, the airbags will provide additional protection to the chest and facial areas in the event of the vehicle receiving a severe frontal impact.

NOTE: *Inflation and deflation of the airbags takes place very quickly and will not protect against the effects of secondary impacts that can occur during multiple vehicle collisions.*

The airbags are located in the centre pad of the steering wheel and the fascia panel above the glovebox.

WARNING

Always remember; the SRS/airbags are a supplemental restraint system providing ADDITIONAL protection in certain types of frontal impact collisions only - they DO NOT replace the need to wear a seat belt. To

To ensure correct deployment of the airbags, it is essential that obstructions are not allowed to intervene between an airbag and the occupant. The following are examples of the type of obstructions that could either, impede correct operation of the airbags, or jeopardise personal safety in the event of an airbag deployment:

- Accessories attached to or obscuring an airbag cover.
- Items of hand luggage, or other objects placed on an airbag cover.
- Feet, knees or any other part of the anatomy in contact with, or in close proximity to, an airbag cover.

minimize the risk of severe injury or death in the event of a crash, all occupants in all seating positions including the driver, should always wear their seat belt whether or not an airbag is present in that seating position!

Airbag SRS

WARNING

Following inflation, some SRS/airbag components are hot - DO NOT touch until they have cooled.

Even with SRS/airbag equipment fitted, seat belts must ALWAYS be worn because:

- An airbag will only provide additional protection in certain types of frontal collisions. NO protection is afforded against the effects of side or rear impacts, rollover accidents, or minor frontal impacts.*
 - Inflation and deflation take place instantaneously and will not provide protection against the effects of secondary impacts that can occur during multiple vehicle collisions.*
-

WARNING

The airbag module inflates with considerable speed and force. For your safety:

An inflating airbag can cause facial abrasions and other injuries. The injurious effects of airbag inflation can be minimized, by ensuring driver and passenger are seated correctly, with the seat moved back as far as is practical, and the seat belts worn correctly.

NEVER attach accessory items to an airbag module cover, or place items of hand luggage or any objects on the top of a module cover. These could interfere with the inflation of the airbag, or if the airbag inflates, be propelled inside the vehicle causing injury or death to the occupants.

DO NOT allow occupants to obstruct the operation of the airbag modules by placing their feet, knees or any part of their person in contact with, or close to, an airbag module whilst the vehicle is moving.

Activation of an airbag creates dust, causing possible breathing difficulties for asthma sufferers or other people with respiratory problems. If an airbag is activated, any occupant who suffers from breathing difficulties should; either leave the vehicle as quickly as possible, or obtain fresh air by fully opening the windows or doors.

When an airbag inflates, a fine powder is released. This is not an indication of a malfunction. However, the powder may cause irritation to the skin and should be thoroughly flushed from the eyes and any cuts or abrasions of the skin.

Airbag SRS

Seating positions

In order to provide optimum protection in the event of a severe frontal impact, it is necessary for the airbags to deploy with considerable speed.

An inflating airbag can cause facial abrasions and other injuries if the occupant is too close to the airbag at the time of its deployment.

WARNING

- ***To reduce the risk of accidental injury from inflating airbags, seat belts should be correctly worn at all times. The National Highway Traffic Safety Administration (NHTSA) recommends a minimum distance of 10 inches (25 cm) between an occupant's chest and the steering wheel.***
 - ***Occupants not seated correctly in allocated seats may be subject to serious injury or death upon airbag deployment.***
-

HOW THE AIRBAG SRS WORKS

In the event of a severe frontal impact, the airbag control unit monitors the rate of deceleration induced by the collision, to determine whether the airbags should be deployed.

Operation of the airbag SRS is dependent entirely on the rate at which the vehicle's passenger compartment changes speed as a result of a collision. The circumstances affecting different collisions (vehicle speed, angle of impact, type and size of object hit, for example), vary considerably and will affect the rate of deceleration accordingly.


NOTE: *The SRS/airbag is not designed to activate in all frontal impacts; most minor frontal impacts, heavy braking and driving over pot holes will not result in sufficient deceleration to cause the airbags to inflate. This does not indicate that there is a fault with the system. However, if as a result of an impact, you believe the airbags should have deployed and they failed to do so, please call 1(800)637-6837 for advice, or to arrange for a Land Rover representative to inspect the vehicle to determine whether the system operated correctly.*

It follows, therefore, that significant superficial damage can occur without the airbags deploying or, conversely, that a relatively small amount of structural damage may cause the airbags to be deployed.

Airbags will only deploy when they are required to supplement the restraining force of the seat belts.

In the case of a severe frontal collision, both front airbags and seat belt pre-tensioners will be deployed.

Airbag SRS



H3307

Airbag inflation is virtually instantaneous and occurs with considerable force, accompanied by a loud noise. The inflated bag, together with the seat belt restraint system, limit the movement of a front seat occupant, thereby reducing the risk of injury to the head and upper torso.

After inflation the airbags deflate immediately. This provides a gradual cushioning effect for the occupant and also ensures that the driver's forward vision is not impaired.

NOTE: After inflation, some airbag components are hot - DO NOT touch until they have cooled.

Airbag SRS warning light

Whenever the starter switch is turned to position 'II', the diagnostic control unit monitors the readiness of the system's electrical circuits. The elements of the system being monitored include:

- SRS warning light
- Rotary coupler
- Airbag modules
- Airbag diagnostic control unit
- Airbag wiring harness

A warning light mounted on the instrument panel will alert you to any malfunction of the SRS/airbag. The system should always be checked by a retailer if any of the following symptoms occurs. These indicate a fault, which may result in the SRS/airbag not operating as required in the event of a frontal impact.

- The warning light fails to illuminate when the starter switch is turned to position 'II'.
- The warning light fails to extinguish within approximately five seconds after the starter switch is turned to position 'II'.
- The warning light illuminates after the engine is started, or while the vehicle is being driven.

Airbag SRS

SERVICE INFORMATION

WARNING

DO NOT attempt to service, repair, replace, modify or tamper with any part of the airbag SRS, or wiring in the vicinity of an airbag SRS component; this could cause the system to activate, resulting in personal injury.

After ten years from the date of manufacture (this is shown on the certification plate attached to the lock face of the front left hand door), some components will need to be replaced by a Land Rover retailer.

In addition, ALWAYS contact your retailer if:

- an airbag inflates.
- the front of the vehicle is damaged, even if an airbag has not inflated.
- any part of an airbag module cover shows signs of cracking or damage.

WARNING

The components that make up the airbag SRS are sensitive to electrical or physical interference, either of which could easily damage the system and cause inadvertent operation or a malfunction of the airbag.

For your safety it is recommended that you seek the assistance of a Land Rover retailer to carry out any of the following:

- ***Removal or repair of any wiring or component in the vicinity of any of the SRS components, including the steering wheel, steering column, instrument and fascia panels.***
 - ***Installation of electronic equipment such as a mobile phone, two-way radio or in-car entertainment system.***
 - ***Attachment of accessories to the front of the vehicle.***
-

WARNING

Modification of the front of the vehicle could adversely affect airbag performance and should NOT be undertaken.


Disposing of vehicles

If you sell your vehicle, be sure to inform the new owner that the vehicle has an airbag SRS and make the new owner aware that certain components of the system will need replacing after 10 years.

If your vehicle is to be scrapped; uninflated airbags are potentially very dangerous and must be safely deployed in a controlled environment by qualified personnel, before a vehicle is scrapped.

Steering Column

STEERING COLUMN ADJUSTMENT



H2300

The angle of the steering column can be adjusted to suit your driving position:

1. With the vehicle stationary, push the locking lever fully down to free the steering column.
2. Move the steering wheel (up or down) into the desired position, making sure the instrument panel is clearly visible.
3. When adjustment is complete, pull the locking lever fully up to lock the steering column in position.


WARNING

DO NOT adjust the steering column while the vehicle is in motion. This is extremely dangerous and may result in loss of control of the vehicle!

DO NOT drive the vehicle unless the locking lever is in the locked position (fully up).

Instruments

INSTRUMENT PANEL



H4236

1. Fuel gauge

The pointer indicates the fuel level when the starter switch is turned to position 'II'. After refuelling, the pointer slowly rises to the new level after the starter switch is turned on. When the starter switch is turned off, the pointer quickly lowers to the 'empty' position.

An indicator light in the fuel gauge illuminates when the fuel level is low (approximately 2.4 US gallons (9 litres) fuel remaining). If the light illuminates, refuel at the earliest opportunity.

An arrow on the face of the gauge indicates on which side of the vehicle the filler is located.

CAUTION: Never allow the vehicle to run out of fuel - the resultant misfire could damage the catalytic converter.

NOTE: *Driving on twisting or hilly roads may disturb the accuracy of the fuel gauge. It is advisable to check the fuel level when the vehicle is travelling on a straight, level road.*

2. Tachometer

Indicates engine speed in revolutions per minute (x 1000). To protect the engine from damage, NEVER allow the tachometer pointer to enter the RED sector.

3. Speedometer

Indicates road speed in miles per hour and kilometres per hour.

4. Trip recorder reset button

When the starter switch is turned on, the display shows either the odometer reading, or the trip recorder reading. By pressing the trip recorder reset button briefly, the display will change between trip recorder and odometer modes.

With the trip recorder mode displayed, press and hold the reset button for 2 seconds to reset the trip recorder display to zero.

5. Temperature gauge

This gauge indicates the temperature of the engine coolant. As the engine warms up, the pointer will rise to the mid-point of the gauge, where it should remain while the engine is operating at its normal temperature.

If the pointer reaches the RED mark, the coolant is too hot and severe engine damage could result; in which case you should stop the vehicle as soon as safety permits and seek qualified assistance.

Instruments

6. Digital display





H3370

The panel displays the following:

- Odometer reading (shows the total distance travelled by the vehicle). The word 'ODO' is displayed.
- Trip recorder (for recording individual journey distances). The word 'TRIP' is displayed instead of 'ODO'.
- Gear selector position ('1', '2', '4', 'P', 'R', 'N', 'D').
- The word 'SPORT' confirms the selection of Sport mode.
- Manual mode gear selection information ('1', '2', '3', '4' or '5').

For further information concerning the automatic transmission, (see "*CommandShift™ TRANSMISSION*", page 89').

Instrument illumination control




H4019

Rotate the control up to increase, or down to reduce, the intensity of instrument panel illumination.

The instrument illumination control also adjusts illumination of all switch lighting sources forward of the driver.

Warning Lights

INSTRUMENT PANEL



H4237A

IMPORTANT INFORMATION

RED warning lights are of particular importance, their illumination indicates that a fault exists. If a RED warning light illuminates, stop the vehicle and review the specific instructions given in this section.

Direction indicators - GREEN



The left or right warning light flashes in time with the relevant direction indicator when they are operated. If either warning light fails to flash or flashes rapidly, the selected direction indicator light is not operating.

NOTE: If the hazard warning lights are operated, both direction indicator warning lights will flash together.

Headlight high beam - BLUE



Illuminates when the headlights are switched to high beam.

Cruise control - AMBER*



Illuminates when the cruise control master switch is turned on and cruise control is active, and extinguishes when the switch is turned off or if cruise control is deactivated.

Service engine soon- AMBER



Illuminates as a bulb check when the starter switch is turned to position 'I' and extinguishes when the engine is started. If the light illuminates while the engine is running, this indicates the detection of an emissions fault by the engine management system.

If the light illuminates and the vehicle drives normally:

- Contact a retailer to arrange a service appointment at your earliest convenience - you may still drive the vehicle.

If the light flashes and/or the vehicle does not drive normally:

- Avoid high speeds and seek immediate assistance from your retailer.

Warning Lights

Parking brake & brake system - RED

BRAKE

The light illuminates when the parking brake is applied and extinguishes when it is fully released. If the light continues to illuminate after the handbrake is released, a fault with the braking system is indicated; check the brake fluid level (see '*BRAKE FLUID*', page 140). If the light continues to illuminate after this, seek qualified assistance urgently.

Door open - RED



Illuminates when any of the doors (including the taildoor and bonnet) are not fully closed. DO NOT drive the vehicle with the light illuminated.

Hazard warning lights - RED



Illuminates in conjunction with the direction indicator warning lights, when the hazard warning lights are operating.

Traction control - AMBER



Illuminates as a bulb and system check when the starter switch is turned to position 'II' and extinguishes after 4 seconds approx. The light illuminates for a minimum of 2 seconds, when traction control is operating.

If the light illuminates continuously while traction control is NOT operating, a fault with the system is indicated; seek qualified assistance.

The light also has an overheat function: if traction control is required, but the brakes are too hot, the light will flash for the period when traction control is required and traction has been lost.

ABS - AMBER



Illuminates for approximately 1 second as a bulb and system check when the starter switch is turned to position 'II', and then extinguishes. If the light does not extinguish, a fault has occurred with the ABS system and you should consult your Land Rover retailer at the earliest opportunity.

If the light remains on or subsequently illuminates while driving, a fault has been detected by the self-monitoring system. This means that full ABS control may not be available and you should consult your retailer at the earliest opportunity.

Hill descent control (HDC) 'failure' - AMBER



The light illuminates briefly as a bulb check when the starter switch is turned to position 'II'. The light will flash if the brakes become in danger of overheating and continue flashing until the brakes have cooled sufficiently to enable HDC to operate again (see also '*HDC fade-out*', page 95).

If the light illuminates at any other time, a fault in the system is indicated. If this occurs, deselect HDC and consult your Land Rover retailer.

Warning Lights

Hill descent control (HDC) 'information' - GREEN



Illuminates briefly as a bulb check when the starter switch is turned to position 'II' and will illuminate when HDC is selected.

If HDC is selected when either of the operating gears is engaged (1st or reverse), the light will illuminate continuously.

When HDC is selected and a non-operating gear position is engaged, the light will flash to inform the driver that HDC is selected, but not operating (see also '*HDC fade-out*', page 95).

Low oil pressure - RED



Illuminates as a bulb check when the starter switch is turned to position 'II' and extinguishes when the engine is started. If the light remains on, flashes on and off or illuminates continuously when driving, serious engine damage could occur; stop the vehicle as soon as safety permits and SWITCH OFF THE ENGINE IMMEDIATELY. Seek qualified assistance before driving.

Seat belt - RED*



The light illuminates when the starter switch is turned to position 'II' as a reminder to the driver to ensure that all occupied seat belts are securely fastened. The light extinguishes after approximately five seconds, or when the driver's seat belt is fastened.

Airbag SRS - RED



The light illuminates when the starter switch is turned to position 'II' and extinguishes after about five seconds. If the light illuminates at any other time, seek qualified assistance urgently.

Service engine - AMBER



Illuminates briefly when the starter switch is turned to position 'II'. If it remains on, or illuminates at any other time, the engine management system requires attention. Stop the vehicle as soon as safety permits and switch off the engine for at least 30 seconds; if the light illuminates again after the engine is restarted, it is permissible to continue driving (with reduced engine power), but qualified assistance must be sought as soon as possible, to prevent potential engine damage.

Battery charging - RED



The light illuminates as a bulb check when the starter switch is turned to position 'II' and extinguishes as soon as the engine is running. If it remains on, or illuminates when driving, a fault with the battery charging system is indicated. Seek qualified assistance urgently.

Audible Warnings

AUDIBLE WARNINGS

Lights on reminder


If the lights are left on after the starter switch is turned off, a warning chime will sound when the driver's door is opened. The chime will cease as soon as the lights are switched off or when the driver's door is closed.

Starter key reminder

If the key is left in the starter switch while the driver's door is open, a warning will chime continuously. The chime stops as soon as the door is closed, or the key is removed from the starter switch.

Lights & Indicators

DIRECTION INDICATORS




H3340

Move the lever **DOWN** to indicate a **LEFT** turn, and **UP** to indicate a **RIGHT** turn (the appropriate **GREEN** warning light on the instrument panel will flash in time with the direction indicators).

Hold the lever part-way up or down against spring pressure to indicate a lane change.

LIGHTS



H3341

The side, tail and headlights operate with the starter switch in any position.

If the exterior lights are left on after the starter switch is turned off, a warning chime will sound as soon as the driver's door is opened. The chime will cease as soon as the lights are switched off, or the door is closed.

Side, tail and instrument panel lights


Turn lighting switch to position 1.

Headlights

Turn lighting switch to position 2.

Lights & Indicators

Headlight high and dipped beams




H3342

Pull the lever fully towards the steering wheel to change headlight beams (BLUE warning light glows when the headlights are on high beam).

To flash the headlights, pull the lever part way towards the steering wheel and release.

HAZARD WARNING LIGHTS



H3344



Press to operate; all the direction indicator lights (including those fitted to a trailer) will flash together. Use **ONLY** in an emergency to warn other road users when your stationary vehicle is causing an obstruction, or is in a hazardous situation. Remember to switch off before moving away.

Wipers & Washers

OPERATING


The wipers and washers will only operate when the starter switch is turned to position 'I' or 'II'.

IMPORTANT

- DO NOT operate the wipers on a dry screen.
- To prevent possible overload damage to the wiper motor, in freezing or very hot conditions ensure that the blades are not frozen or stuck to the glass before operating the wipers.
- In winter, remove any snow or ice from around the arms and blades, including the wiped area of the windscreen and the heater air intakes.

NOTE: If the wiper blades have stuck to the glass, a thermal cut-out may temporarily prevent the wiper motor from operating. If this is the case, switch the wipers off, free the blades from the obstruction and then switch on again.

WINDSCREEN WIPERS



H3345

Intermittent wipe

Turn switch to position 1.

Normal speed wipe

Turn switch to position 2.


Fast speed wipe

Turn switch to position 3.

NOTE: If the front screen wipers are operating (in either intermittent or continuous mode), the rear wiper operates automatically whenever reverse gear is selected.

Wipers & Washers

Single wipe




H3520

Pull the lever down and release immediately.

NOTE: With the lever held down, the wipers will operate at high speed until the lever is released.


Variable delay (intermittent wipe)



H3346

Rotate the inner switch to vary the delay between wipes.

WINDSCREEN WASHERS




H3347

Pull the lever toward the steering wheel. The windscreen wipers will operate in conjunction with the washers for as long as the lever is held in this position, the wipers continuing for a further 3 to 4 wipes after the lever is released.

Wipers & Washers

REAR SCREEN WIPER AND WASHER

Rear window wash/wipe




H3510



Press and hold the switch for the required duration of screen washing. The wiper operates automatically during washing and continues for a further 4 wipes (approx.) after the switch is released.

Rear screen wiper



H3508




Press to operate: after continuously wiping 3 or 4 times, the wiper operates intermittently (approx. once every 6 seconds) until switched off.

NOTE: When reverse gear is selected, the rear wiper will operate continuously in tandem with the front wipers.

NOTE: Opening the taildoor, or lowering the rear screen, will switch the rear wiper off.

Horn

HORN



H3349


To operate, press either of the horn switches set into the steering wheel pad.

Mirrors

EXTERIOR MIRRORS

NOTE: The right hand mirror glass is convex, providing a wider field of vision. As a result, objects reflected in this mirror are closer than they appear.

Adjustment



H3363

- Turn the control to the 'L' or 'R' position to select either the left or right hand mirror.
- With the starter switch turned to position 'II', push the control in the appropriate direction to tilt the mirror glass up/down/left or right.
- When adjustment is complete, return the control to the OFF position (midway between 'L' and 'R').

Heating elements


The exterior mirrors have integral heating elements for dispersing ice and mist, which operate automatically whenever the starter switch is in position 'II'.

Folding the mirror body

The body of each door mirror is designed to fold forwards or rearwards on impact. They can also be folded back manually towards the side windows into a 'park' position, to enable the vehicle to negotiate narrow openings.

Mirrors

INTERIOR MIRROR




H2319

The interior mirror can be dipped to reduce glare from following vehicles. In the event of excessive glare, move the lever at the base of the mirror forward to 'dip' the mirror. Normal visibility is restored by pulling the lever back to its original position.

NOTE: In some circumstances, the view reflected in a 'dipped' mirror can confuse the driver as to the precise position of following vehicles. Remember to take additional care!

VANITY MIRROR*



H3335

To use the vanity mirror, pull down the passenger's sun visor. On some models, the vanity mirror is illuminated; lift the cover to illuminate the mirror.

NOTE: Always close the cover, or on vanity mirrors not fitted with a cover, always return the visor to its stowed position when not in use, to avoid possible scorching of the seats by the sun reflected in the mirror.


Windows

ELECTRIC WINDOW CONTROLS

WARNING

Accidental closure of an electrically operated window on fingers, hands or any vulnerable part of the body, can result in serious personal injury. Always observe the following precautions:

- **ENSURE that passengers are kept clear while the windows are being operated and that the windows are not obstructed when opening or closing.**
- **ENSURE that all adult passengers are familiar with the controls and the potential dangers of operating electric windows.**
- **DO NOT allow passengers to extend any part of their bodies through the windows while the vehicle is moving.**
- **NEVER leave children alone in the vehicle as this could result in injury or even death.**



H4331

The switches on the centre console operate the windows as follows:

1. Right-hand rear window.
2. Left-hand rear window.
3. Left-hand front window.
4. Right-hand front window.
5. Isolation switch for rear door windows.

NOTE: Electric rear windows can also be operated by the individual switches mounted on each rear door, provided that the isolation switch has not been activated.

Window operation

The electric windows can be operated when the starter switch is at position 'II' and for up to 45 seconds after the starter switch is turned off (provided neither front door is opened in the meantime).

Press and hold the bottom half of a switch to lower and the upper half to raise. The window will stop moving when the switch is released.

ALWAYS close the windows when the vehicle is unattended.

Rear window isolation switch

Press once to isolate the rear window switches (indicator light in the switch illuminates); press a second time to restore independent control.

WARNING

ALWAYS isolate the rear window switches when carrying children.

'One touch' down (Driver's door only)

By briefly pressing (and then releasing) the bottom half of the switch, the window will open fully at a single touch. Window movement can be stopped at any time by briefly pressing the upper half of the switch.


Windows

ELECTRIC TAILDOOR GLASS

NOTE: Long loads should be carried on the roof rack. If it is necessary to carry a load that protrudes through the taildoor window, the weight of the load must NOT rest on the glass of a partially open window. Damage to the glass or window mechanism may occur (see also 'Accommodating long loads', page 103).

The taildoor glass can be lowered from outside the vehicle, to enable easy access to the loadspace area when it is impossible or inconvenient to open the taildoor.

Raising and lowering




From inside the vehicle:

With the starter switch in position 'II', press and hold the bottom half of the switch to lower the glass. Movement will stop when the switch is released.

Press the upper half of the switch to raise the glass. If the switch is released before the glass is fully raised it will automatically lower again.

One touch down:

By briefly pressing (and then releasing) the bottom half of the switch, the taildoor glass will open fully at a single touch.



From outside the vehicle:

Press and hold the UNLOCK button on the remote handset (hold for 2 seconds) - the taildoor glass will fully lower.

To raise the glass, insert the key into the switch mounted in the taildoor and turn clockwise. If the switch is released before the glass is fully raised it will automatically lower again.

NOTE: If the vehicle is locked when the glass is lowered using the handset, the driver's door will unlock and vehicle security will be disabled. In this case, remember to relock the vehicle.


Battery disconnection

If the battery has been disconnected, the taildoor glass will need to be recalibrated. If the alarm was armed when the battery was disconnected (or discharged), disarm the alarm after reconnection - the glass will fully lower (this will happen automatically if the alarm was in a disarmed state when the battery was disconnected).

After battery reconnection, fully raise the glass - the taildoor glass is now recalibrated (if the glass is not fully raised, an error 'beep' will sound).

Sunroof

ELECTRIC SUNROOF*



H3312

The sunroof can be operated when the starter switch is turned to position 'II' and for up to 45 seconds after the starter switch is turned off (provided neither front door is opened in the meantime).

The roof opens in two separate phases as follows:

- **To tilt the roof:** Press the bottom half of the switch - the rear edge of the roof rises to the tilted position.
- **To open the roof:** With the sunroof fully tilted, press the bottom half of the switch - the roof remains tilted and slides towards the rear until fully open or the switch is released.

To close the roof: press the upper half of the switch - the sunroof will first close to the tilted position, then it will return the tilted roof to the fully closed position. The sunroof can be stopped (at any position) by releasing the switch.

WARNING

Accidental closure of a sunroof on fingers, hands or any vulnerable part of the body, can result in serious personal injury. Always observe the following precautions:

- **ENSURE** that passengers are kept clear when operating the sunroof and that the sunroof is not obstructed when opening or closing.
- **ENSURE** that all adult passengers are familiar with the controls and the potential dangers of operating an electrically operated sunroof.
- **DO NOT** allow passengers to extend any part of their bodies through the sunroof aperture while the vehicle is moving.
- **NEVER** leave children alone in the vehicle as this could result in injury or even death.
- **Do not** open the sunroof if the load on the roof rack will impede its operation.


CAUTION: Do not operate the sunroof in freezing conditions, or when the roof panel is covered in ice or snow.

Sunroof visor

The sunroof visor must be opened and closed manually.

Heating & Ventilation

VENTILATION



H2422

The ventilation system provides fresh or heated air to the interior of the vehicle from the air intake grille in front of the windscreen.


NOTE: Always keep the air intake grille clear of obstructions such as leaves, snow or ice.

Air outlets are provided to the windscreen, face and feet - the location of the vents is shown in the illustration above. The temperature of the air is controlled by the heater.

Information concerning the operation of the heating and ventilation system, as well as the air conditioning, appears on the pages that follow.

Heating & Ventilation

HEATER CONTROLS



H3317A

1. Heated front screen *

Press to operate; the indicator light in the switch illuminates whenever the heater is on and extinguishes when the heater is turned off.

NOTE: The front screen heater will operate only when the engine is running and will switch off automatically after approximately 10 minutes.

2. Rear screen demister

Press to operate; the indicator light in the switch illuminates whenever the demister is on and extinguishes when the demister is turned off.

NOTE: The rear screen demister will operate only with the taildoor fully closed and when the engine is running and will switch off automatically after approximately 15 minutes.

NOTE: DO NOT stick labels over the heating elements, and DO NOT scrape or use abrasive materials to clean the inside of the window.

3. Air recirculation button *

Press to recirculate air inside the vehicle (indicator light illuminates).

The air recirculation mode prevents the heating system from taking in fresh air from outside the vehicle. Instead, the air already inside the vehicle is recirculated, thus preventing the entry of traffic fumes. In cold weather air recirculation also enables warmer air to be used to defrost the windscreen when the engine is still cold.

WARNING

The air recirculation mode can cause the windscreen to mist. If this happens, switch off air recirculation immediately.

4. Air conditioning

With the engine running, press to operate. The indicator light in the switch illuminates when the air conditioning is switched on.

5. Air temperature control

Rotate the control clockwise (towards the RED segments) to increase the air temperature, or anti-clockwise (towards the BLUE) to reduce the temperature.

6. Air blower control






Turn the control clockwise to progressively increase the blower speed.

NOTE: With the control in position '0', the volume of air entering the vehicle is dependent on driving speed alone.

Heating & Ventilation

7. Air distribution control

Rotate to select air distribution:

-  Air to face vents
(to ensure best performance, the face level vents must be fully open)
-  Air to face vents and foot outlets
(to ensure best performance, the face level vents must be fully open)
-  Air to foot outlets
-  Air to foot outlets and windscreen
(if the ambient temperature is approximately 41° F (5° C) or higher, the air conditioning will automatically dehumidify the air to reduce misting).
-  All air to windscreen
(if the ambient temperature is approximately 41° F (5° C) or higher, the air conditioning will automatically dehumidify the air to reduce misting).


USING YOUR HEATER

Fresh air enters the heater unit through the grille in front of the windscreen and stale air is drawn out through vents in the rear of the vehicle. Ducts beneath the front seats provide heating for rear seat passengers - these must not be obstructed.

The following examples of basic heater settings are intended as a general guide; the air distribution, temperature and blower controls can then be further adjusted to suit your comfort requirements.

Always remember that full heating is not available until the engine has reached its normal operating temperature.


Maximum heating



H3318A

Set the controls as shown, with the blower at the slowest speed (position 1) until the temperature gauge indicates that the engine is warming up - the blower speed can then be increased.

Demisting




H3319A

Set the controls as shown, to obtain the maximum flow of heated air from the windscreen and side window vents.

Opening a window may improve ventilation.

Heating & Ventilation


Defrosting



H3320A

Set the controls as shown and switch on air recirculation to prevent cold air from being drawn into the vehicle. Turn air recirculation off as soon as the windscreen is clear, to prevent any possibility of the windscreen misting.

Maximum ventilation




H3321A

Set the controls as shown, with the face level vents open.

Adjust the blower speed as required.

FACE LEVEL VENTS



H2329A

Rotate the thumbwheel down to open or up to close the vents. Direct the air flow by moving the control in the centre of the louvres up or down, or from side to side.

To increase output from the centre face vents, shut the outer vents.

When carrying rear seat passengers, use the outer vents for the front seat occupants and use the more powerful centre vents for the rear seat passengers.

WARNING

Driving with the taildoor or taildoor window open is not recommended because poisonous exhaust fumes will be drawn into the vehicle (see 'Accommodating long loads', page 103 for advice).

Heating & Ventilation

AIR CONDITIONING

The air conditioner provides additional cooling and also reduces humidity. This can be used to demist windows quickly in damp weather and, when used in conjunction with the heater, makes the interior of the vehicle warm and dry.

NOTE: *In high humidity conditions, slight screen misting may be experienced when the air conditioning is turned on. This is a natural occurrence for most automotive air conditioning systems; it is not a fault with the system and will clear after a few seconds, once the air conditioning is operating.*

Using the air conditioning

The air conditioning can only be used when the engine is running. For the air conditioning system to operate efficiently, all windows (and the sunroof) should be closed, and the air intake vents free from ice, snow, leaves and other debris.

With the engine running, press the 'A/C' button, and adjust the air distribution, air temperature and blower controls as required.

NOTE: *The air conditioner will only operate when the blower is switched on.*

Operation of the air conditioning system places an extra load on the engine. In very hot conditions or when the engine is required to work unusually hard (climbing long hills or driving in congested traffic, for example), this could result in high engine temperatures. If the pointer nears the RED zone of the temperature gauge, temporarily turn the air conditioning off until engine temperatures return to normal.

NOTE: *Under extreme conditions, the air conditioning may automatically switch off, to prevent damage to the engine.*

Rapid cooling:

With the engine running press the 'A/C' button, turn the air temperature control to the BLUE segment, select air recirculation and turn the blower switch to 4. Turn off air recirculation and adjust the blower when the vehicle interior is cool.

NOTE: *In very hot conditions, it may be advisable to fully ventilate the vehicle by opening the windows and sunroof for a while before closing them again and operating the air conditioning.*


Maintaining the air conditioning

The air conditioning system is sealed and major maintenance should only be carried out by a qualified technician. To maintain the system in peak condition, owners should ensure that the system is operated for a short period every week (even during the cold winter months); with the engine at its normal operating temperature, run the air conditioning for at least ten minutes whilst driving at a steady speed.

Surplus water produced by the dehumidifying process is expelled from the system via drain tubes beneath the vehicle. This may result in a small pool of water forming on the road when the vehicle is stationary and is not a cause for concern.

Heating & Ventilation

HEATED FRONT SEATS*



H3494

With the starter switch turned on and the engine running, press the switches to operate the heating elements in either the driver's or front passenger seat (the indicator light in the switch illuminates). Press a second time to switch off.


NOTE: *The seat heaters will switch off automatically 15 seconds after the starter switch is turned off.*

The seat heaters are thermostatically controlled and operate intermittently to achieve and then maintain a predetermined temperature between 79° F and 97° F (26° C and 36° C).

NOTE: *Owners should be aware that the seat heaters consume considerable power from the battery and for this reason, it is recommended that they are operated only with the engine running.*


Interior Equipment

COURTESY & MAP READING LIGHTS



H2352A

Front courtesy and map reading lights



H2593

Rear courtesy light

Press the appropriate switch to illuminate (or extinguish) the lights manually.

The front and rear lights illuminate automatically when the vehicle is unlocked or whenever a door or taildoor is opened, and extinguish approximately 15 seconds after ALL the doors are closed, or as soon as the starter switch is turned on.

If a door or the taildoor remains open for ten minutes or more, a 'time out' function will extinguish the courtesy lights in order to prevent the battery from discharging.


NOTE: If the map reading lights or rear courtesy light are left on after being manually selected, they will NOT extinguish automatically.

The courtesy lights will extinguish when the vehicle is locked.

LUGGAGE COMPARTMENT LIGHT

Illuminates automatically when the taildoor is opened.

CLOCK



H4326

The digital clock display illuminates when the starter switch is turned on and dims for night viewing when the sidelights are switched on.

With the starter switch turned to position 'I', depress the hour ('H') and minute ('M') buttons to set the time. If both buttons are pressed together, the display will change between 24 hour and 12 hour displays.


NOTE: If the battery is disconnected, the clock will need to be reset.

Interior Equipment

GLOVEBOX

WARNING

DO NOT drive with the glovebox open. An open glovebox could cause injury to the front seat passenger in the event of a collision.



H3534

Lift the handle to open the glovebox.

The left hand compartment in the glovebox can be used to store CD cases.


Glovebox light

Operates automatically when the exterior lights are switched on and the passenger glovebox is opened.

DRIVER'S STORAGE AREA

WARNING

DO NOT drive with the storage area open. The storage area lid could cause serious injury in the event of a collision.




H3365

Lift the handle to open the driver's storage area - only when the vehicle is stationary.

The left hand compartment in the storage area can be used to store tape and CD cases.

Interior Equipment

DRINKS STOWAGE



H3325A

The expanding strap fitted to the front door stowage compartments can be used to store drink containers securely when driving.

NOTE: Drink containers over 0.5 litre capacity will not be properly secured by the strap.

WARNING

Do not use the strap to store hot drinks.

CUP HOLDERS

WARNING


The driver should not drink while driving.

DO NOT carry open-top drink containers in the cup holders while the vehicle is in motion; a spilled hot drink could cause personal injury. Spilled drinks can also damage upholstery, carpeting and electrical components.

DO NOT place anything other than soft containers in the cup holders. **DO NOT** use to hold cups made of glass, china or hard plastic, as these items may be thrown about in the passenger compartment and possibly injure occupants in the event of an accident or emergency manoeuvre. Unopened sealed containers (drinks cans, for example) are hard objects and may also cause injury.

If the cup holder is retractable, it should be kept closed when not in use.

Front cup holders*




H3774

Interior Equipment

Press the button (arrowed) to open the cup holder. Push the flap centrally to close. The rubber mats inside the holder can be removed for cleaning.


Rear cup holders



H2550

With the centre armrest lowered, press the front of the cup holder to open. The retaining arms can be adjusted to suit a range of container sizes. Press the front of the cup holder again to close.

SUN VISOR



H2424

To shield your eyes from the sun, pull the visor down from the roof; the visor can be used to shield the upper part of the windscreen or the side window as required.


NOTE: On some models, the sun visors are fitted with a vanity mirror on the underside.

Interior Equipment

ASHTRAY

WARNING

DO NOT use the ashtray for disposing of waste paper or other combustible items.




H3336

Front ashtray illustrated

Push to access the front or rear ashtray. To remove for emptying; with the ashtray open, carefully pivot the ashtray upwards and withdraw it from the aperture.

To refit the ashtray, partially insert the tray into the aperture, then pivot downwards before pushing the ashtray closed.

CIGAR LIGHTER*




H3337

With the starter switch turned on, press the lighter in to heat up. When it has reached the correct temperature it will partially eject and can then be withdrawn for use.

- ONLY hold the cigar lighter by the handle.
- DO NOT plug accessories into the cigar lighter socket unless they are approved for that purpose by Land Rover.

Interior Equipment

AUXILIARY POWER SOCKET



H3327


An auxiliary power socket is mounted in the centre console, above the rear ashtray. This can be used to power Land Rover approved accessories that use a maximum of 180 watts.

Always run the engine during prolonged use of electrical accessories, otherwise the battery may become discharged.

CAUTION: NEVER plug non-approved accessories into the power socket - damage to the vehicle's electrical systems could occur.

Loadspace Cover

LOADSPACE COVER*



H3328

The rear loadspace can be covered by a spring loaded roller blind, which can be retracted when not in use by detaching the cover from the hooks at the rear of the vehicle (see lower inset).

To remove the loadspace cover:

1. Slide the retracted cover firmly to the right.
2. Lift the left hand end of the cover from its location.
3. Carefully manoeuvre the cover from the rear of the vehicle.

Refitting the loadspace cover is the reverse of the removal procedure.

NOTE: Removal of the loadspace cover may be eased by folding the rear seat backrest forward.

WARNING

DO NOT carry loose items of luggage on top of the loadspace cover - these may obscure vision and could become dangerous projectiles in the event of a sudden stop or collision.

All equipment, luggage or tools carried in the loadspace should be secured to reduce the risk of injury to the driver and passengers in the event of an accident or emergency manoeuvre.

DO NOT store the loadspace cover loose in the vehicle.

In-Car Telephones

IN-CAR TELEPHONES

For your safety, always note the following precautions before fitting or using an in-car telephone, or any mobile communication equipment.

- Only use an installation kit incorporating an aerial external to the vehicle.
- Ensure that the installation is carried out by a competent installer.

WARNING

Using any hand-held appliance while driving can be dangerous. Always stop the vehicle before making a call and ensure the telephone is switched off while you are driving.

In-Car Entertainment


RADIO/CASSETTE PLAYER

NOTE: Full operating instructions for any audio equipment fitted as standard to your vehicle, are contained in the 'In-car Entertainment' book in the literature pack.

CD autochanger*

The CD autochanger is located under the front right hand seat. Full operating instructions are contained in the 'In-car Entertainment' book in the car literature pack.

RADIO AERIAL



Your vehicle is equipped with a detachable mast aerial, mounted on the roof.


NOTE: ALWAYS unscrew and remove the aerial before entering an automatic car wash.

Aerial height

Always check the available headroom and, if necessary, adjust the angle of the aerial (see illustration) before entering or leaving a garage or car park with insufficient headroom.

NOTE: The aerial of the navigation system* (if fitted) cannot be adjusted for height.

REMOTE AUDIO CONTROLS*



Volume control

Lift or press down to increase or decrease volume.

Search control

Lift or press down to search for the next or previous radio station on the selected waveband.

During CD play, lift the control to move forward to the next track, or press down to return to the start of the current track. Operate the control repeatedly to move forward or back through several tracks at a time.

NAVIGATION SYSTEM*

NOTE: Full operating instructions for the navigation system, if fitted to your vehicle, are contained in the 'Audio and Navigation System' book in the literature pack.

Driving & Operating

Starting & Driving

STEERING COLUMN LOCK	79
STARTER SWITCH.....	79
STARTING	80
DRIVING	81
FUEL ECONOMY	82
EMISSION CONTROL SYSTEM	83

Fuel System

TYPE OF FUEL	84
GAS STATION SAFETY.....	85
FUEL FILLER	85
FUEL FILLING	86
EMPTY FUEL TANK	86
FUEL CUT-OFF SWITCH.....	86

Catalytic Converter

CATALYTIC CONVERTER	87
---------------------------	----

Automatic Gearbox

CommandShift™ TRANSMISSION	89
GEAR SELECTOR LEVER	89
USING AN AUTOMATIC GEARBOX	91
AUTOMATICALLY SELECTED MODES.....	93

Hill Descent Control

HILL DESCENT CONTROL	94
----------------------------	----

Cruise Control

CRUISE CONTROL.....	96
---------------------	----



Brakes

FOOT BRAKE	98
PARKING BRAKE	99
ANTI-LOCK BRAKES	99

Traction Control

ELECTRONIC TRACTION CONTROL	101
---------------------------------------	-----

Load Carrying


LUGGAGE ANCHOR POINTS	102
STOWAGE BOX	102
FOLDING THE REAR SEATS	103
VEHICLE LOADING	105
ROOF RACK	105

Towing

TOW BARS	106
TOWING A TRAILER	106

Starting & Driving

STEERING COLUMN LOCK



To unlock the steering column

Insert the key FULLY and turn the starter switch to position 'I'. A small movement of the steering wheel may be necessary to disengage the steering lock while turning the switch.

To lock the steering column

With the gear selector in 'P' (Park), turn the key to position '0' and withdraw the key from the starter switch. Turn the steering wheel slightly until the lock engages.

WARNING

Once the steering lock has engaged, it is impossible to steer the vehicle. DO NOT remove the key or turn the starter switch to position '0' while the vehicle is in motion.

STARTER SWITCH

The starter switch is located to the right of the steering column, and uses the following sequence of key positions to operate the steering lock, electrical circuits and starter motor:

Position '0'

- Steering locked (if key is removed).
- Most lighting circuits are operational, including: sidelights, headlights and hazard warning lights.
- Gear selector lever locked in 'P'.

Position 'I'

- Steering unlocked.
- Clock, radio/cassette player and cigar lighter can now be operated.

Position 'II'

- All instruments, warning lights and electrical circuits are operational.

Position 'III'

- Starter motor operates.

Release the key immediately the engine starts (the key will automatically return to position 'I'). Note that operation of position 'I' electrical functions will be interrupted during engine cranking.

NOTE: Gear selector position 'P' or 'N' must be selected before the engine will start.

NOTE: Gear selector position 'P' must be selected before the key can be removed from the starter switch.

NOTE: Immediately after the engine is started, a short, low pitched 'buzz' may be heard; this is the ABS system priming and is no cause for concern.

Starting & Driving

STARTING

WARNING

Exhaust fumes contain poisonous substances which can cause unconsciousness and may even be fatal.

- ***DO NOT inhale exhaust gases.***
- ***DO NOT start or leave the engine running in an enclosed unventilated area, or drive with the taildoor open.***
- ***DO NOT modify the exhaust system from the original design.***
- ***ALWAYS repair exhaust system leaks immediately.***
- ***If you think exhaust fumes are entering the vehicle have the cause determined and corrected immediately.***

Before starting the engine and driving, ENSURE you are familiar with the precautions shown under 'CATALYTIC CONVERTER', page 87.

In particular, you should be aware that if the engine fails to start, continued use of the starter may result in unburnt fuel damaging the catalytic converter.

1. Check that the parking brake is applied and that the gear selector is 'P' (Park) or 'N' (Neutral).
2. Switch off all unnecessary electrical equipment (including the air conditioning).
3. Turn the starter switch to position 'III' to operate the starter motor. DO NOT press the accelerator pedal while starting, and RELEASE THE KEY as soon as the engine is running.

DO NOT pump the accelerator pedal during starting.

In temperate climates, DO NOT operate the starter for longer than 15 seconds. If the engine fails to start, switch off and wait for at least 10 seconds before trying again.

NOTE: *Continued use of the starter will not only discharge the battery, but may cause damage to the starter motor and the catalytic converter.*

NOTE: *The battery charging, oil pressure and engine malfunction indicator warning lights should extinguish as soon as the engine is running.*

After starting, ensure that the parking brake and foot brake are firmly applied and the accelerator pedal is not depressed while moving the gear selector lever from 'N' or 'P', otherwise, the vehicle may move immediately the selector lever is moved to one of the drive positions (1, 2, 4, D or R). This is particularly important when the engine is cold, because the engine will be idling at a faster speed than normal.

NOTE: *The selector lever cannot be moved from 'P' into a drive position while the engine is running, unless the brake pedal is applied.*

Cold climates

The engine of your Freelander is fitted with an advanced 'drive by wire' engine management system. This is designed to optimise the vehicle's cold start behaviour - pressing the accelerator pedal has no effect on starting performance.

At temperatures down to -15°F (-26°C), the engine should start within 5 to 8 seconds. Below this temperature, engine cranking times will increase significantly and the starter motor may need to be operated continuously for as long as 30 seconds before the engine will start. For this reason, ensure that all non-essential electrical equipment is switched off.

In very cold climates the oil pressure warning light may take several seconds to extinguish.

Starting & Driving

Sump Heater (Canadian specification only)*

If the vehicle is left in temperatures of -15°F (-25°C) or lower, the sump oil heater should be used to improve the engine's starting characteristics.

The heater plug is clipped behind the lower radiator grille. Unclip the cable adjacent to the plug and pull the plug through the grille. Remove the protective cover from the plug then connect it to an appropriate mains supply cable socket.

The cover should always be refitted when the the heater is unplugged from the mains socket to prevent ingress of dirt, snow or other contaminants. It is also recommended that the cable and plug is wire tied to one of the upright grille supports for easy use if the heater is to be used regularly.

DRIVING

WARNING

Your vehicle has a higher ground clearance and, therefore, a higher centre of gravity than ordinary passenger cars, to enable the vehicle to perform in a variety of off-road applications. An advantage of the higher ground clearance, is a better view of the road allowing you to anticipate problems. The Freelander is not designed for cornering at the same speed as conventional passenger cars, any more than a low slung sports car is designed to perform satisfactorily under off-road conditions. If at all possible, avoid sharp turns or abrupt manoeuvres. As with other vehicles of this type, failure to operate the Freelander correctly may result in loss of control or vehicle rollover.

Before driving

Learn the layout and function of all the warning lights and controls, and adjust the seat to a comfortable driving position, from which you can ensure full control of the vehicle.

Always start the engine and operate the controls from the driving position.

Instruments and warning lights

Before driving it is important to fully understand the function of the instruments and warning lights.

NOTE: *Red warning lights are of particular importance; illumination indicates that a safety-related problem or potentially serious mechanical fault exists. If a red light illuminates, always stop the vehicle and seek qualified assistance before continuing.*

Warming-up

DO NOT warm-up the engine by allowing it to idle at a slow speed.

In the interests of fuel economy, it is advisable to drive the vehicle straight away, remembering that harsh acceleration and labouring the engine before the normal operating temperature has been reached can damage the engine.

Parking

WARNING

After bringing the vehicle to a stop, ALWAYS apply the parking brake and select 'P' (Park) before releasing the foot brake and switching off the engine.

Switching off

With 'P' (Park) selected, return the starter switch to position '1' and then to position '0' to remove the key.

Starting & Driving

NOTE: *The key cannot be removed from the starter switch unless the gear selector is in the 'P' (Park) position.*

Breaking-in

Proper breaking-in will have a direct bearing on the reliability and smooth running of your vehicle throughout its life.

In particular, the engine, gearbox, brakes and tyres need time to 'bed-in' and adjust to the demands of everyday motoring. During the first 600 miles (1000 km), it is essential to drive with consideration for the breaking-in process and heed the following advice:

- LIMIT maximum road speed to 70 mph (110 km/h) or 3,000 rev/min. Initially, drive the vehicle on a light throttle and only increase engine speeds gradually once the breaking-in distance has been completed.
- DO NOT operate at full throttle or allow the engine to labour in any gear.
- AVOID fast acceleration and heavy braking except in emergencies.

After the breaking-in distance has been completed, engine speeds may be gradually increased.

FUEL ECONOMY

Fuel consumption is influenced by two major factors:

- How your vehicle is maintained.
- How you drive your vehicle.

To obtain optimum fuel economy, it is essential that your vehicle is maintained in accordance with the manufacturer's service schedule.

Items such as the condition of the air cleaner element, tyre pressures and wheel alignment will have a significant effect on fuel consumption. But, above all, the way in which you drive is most important. The following hints may help you to obtain better value from your motoring:

- Avoid unnecessary, short, start-stop journeys.
- Avoid fast starts by accelerating gently and smoothly from rest.
- Do not drive in the lower gears for longer than necessary.
- Decelerate gently and avoid sudden and heavy braking.
- Anticipate obstructions and adjust your speed accordingly well in advance.
- When stationary in traffic, select neutral to improve fuel economy and air conditioning performance.

EMISSION CONTROL SYSTEM

Land Rover vehicles are fitted with emission and evaporative control equipment necessary to meet a number of territorial requirements.

In many countries it is against the law for vehicle owners to modify or tamper with emission control equipment, or to sanction the unauthorised replacement or modification of this equipment. In such cases the vehicle owner and the repairer may both be liable for legal penalties.

It is important to remember that all Land Rover retailers are properly equipped to perform repairs and to maintain the emission control system on your vehicle.

Fuel System

TYPE OF FUEL

IMPORTANT INFORMATION

ONLY USE UNLEADED FUEL

- Unleaded fuel is essential for proper operation of the emission control system.

DO NOT use leaded fuel! Your engine is designed to use unleaded fuel ONLY.

- Even a very small quantity of leaded fuel will damage your vehicle's emission control system and could invalidate the emissions warranty. In addition, leaded fuel will damage the oxygen sensors in the fuel injection system and also seriously damage the catalyst in the catalytic converter.

Fuel system cleaning agents should be avoided, as many of these products can be harmful to gaskets and other materials used in fuel system components.

Octane requirements

Unleaded gasoline with a CLC or AKI minimum octane rating of 87 is recommended.

NOTE: Federal law requires that gasoline octane ratings be posted on the pumps. The Cost of Living Council (CLC) octane rating or Anti Knock Index (AKI) octane rating shown is an average of Research Octane Number (RON) and Motor Octane Number (MON).

NOTE: Engine performance and fuel economy may improve if higher octane fuel is used.

Using unleaded fuel with an octane rating lower than that recommended above may reduce performance and economy and can also cause persistent, heavy 'engine knock' (a metallic rapping noise). If severe, this can lead to engine damage.

If heavy engine knock is detected when using the recommended octane rated fuel, or if steady engine knocking is present while maintaining a steady speed on level roads, contact your retailer for advice.

NOTE: An occasional, light, engine knock while accelerating or climbing hills is acceptable.

Octane enhancers

The use of octane enhancers is not recommended, and may invalidate the vehicle warranty.

NOTE: Reformulated gasolines and gasolines that contain detergents, anti-corrosion and stability additives are recommended - they will help your vehicle maintain the correct level of emissions and engine performance.

Driveability

If you encounter driveability, starting and stalling problems, especially in high ambient temperatures or at high altitude when the engine is cold, it may be caused by poor quality fuel. Try an alternative brand, and if the problem persists, seek advice from your retailer.

Gasoline/oxygenated fuel blends

To avoid invalidating the vehicle warranty, use ONLY fuels blended within the following limits:

- Up to 15% of Methyl Tertiary Butyl Ether (MTBE) and unleaded fuel mix.
- Up to 15% of Ethyl Tertiary Butyl Ether (ETBE) and unleaded fuel mix.
- Up to 10% of Ethanol (Ethyl or grain alcohol) and unleaded fuel mix.

Fuel System

Methanol/unleaded fuel blends

In some areas, it is possible to buy unleaded fuel that is blended with up to 5% Methanol (Methyl or wood alcohol) and cosolvents and corrosion preventatives. Using these blends can cause driveability problems and damage to the fuel system components. Their use may also invalidate the vehicle warranty.

WHEREVER POSSIBLE, AVOID USING FUEL CONTAINING METHANOL!

WARNING

Automotive fuels can cause serious injury, and even death if misused.

Methanol/unleaded fuel blends, even in small amounts, can cause blindness and possible death if swallowed. Additionally, take precautions to prevent methanol from coming into contact with the skin.

GAS STATION SAFETY

Always take sensible precautions when refuelling:


- Switch off the engine.
- DO NOT smoke or introduce other ignition sources.
- Do not operate a mobile phone.
- Take care not to spill fuel.
- DO NOT overfill the tank.
- DO NOT fill gas cans in the vehicle.

WARNING

Petroleum gases are highly inflammable and, in confined spaces, are also extremely explosive.

Always place portable gasoline containers on the ground while filling. A fire may result if gasoline is pumped into a container that is inside a vehicle or on a truck bed. You could be burned!

FUEL FILLER



H3376

The fuel filler is located in the rear right-hand fender. Insert the key in the lock, turn it anti-clockwise and allow any pressure inside the tank to escape, before removing the cap.

NOTE: The key cannot be removed from the filler cap unless the cap is correctly positioned in the filler neck.

Fuel System

FUEL FILLING

Gas station pumps are equipped with automatic cut-off sensing to avoid fuel spillage. Fill the tank **SLOWLY** until the filler nozzle automatically cuts-off the supply. **DO NOT** attempt to fill the tank beyond this point or spillage could result due to expansion of the fuel.

The fuel filler neck will accept **ONLY** a narrow filler nozzle of the type found on pumps that deliver **UNLEADED** fuel. A flap lies across the filler neck; insert the nozzle sufficiently to fully open the flap before filling.

Filling difficulties


The fuel delivery rate of gas station pumps can vary significantly. This, coupled with the fact that modern pumps are equipped with a sensor which automatically cuts off the supply as soon as turbulence is detected in the upper part of the vehicle's filler neck, could result in isolated fuel filling problems.

EMPTY FUEL TANK

NEVER allow the vehicle to run out of fuel - the resultant misfire may destroy the catalytic converter.

In the event of a fuel tank running dry, contact your Land Rover retailer before attempting to start the engine.

FUEL CUT-OFF SWITCH



The fuel cut-off switch is a safety device which, in the event of a collision or sudden impact, automatically cuts off the fuel supply to the engine.

The switch is located inside the engine compartment on the left hand side, beneath, and to the rear of, the engine compartment fuse box (a label attached to the bulkhead will assist location of the switch). If the switch has been activated, it must be reset by pressing the rubber top (arrowed in illustration) before the engine can be restarted.

See also '*DOOR LOCKING CUT-OFF SWITCH*', page 26.

WARNING

Always check for fuel leaks before resetting the switch! Activating the switch when the fuel system has been damaged (evidenced by fuel leakage and odour) will cause additional fuel leakage, increasing the risk of fire and personal injury.

Catalytic Converter

CATALYTIC CONVERTER

The exhaust system on your vehicle incorporates a catalytic converter, which converts poisonous exhaust emissions from the engine into environmentally less harmful gases.

CAUTION: Catalytic converters can be easily damaged through improper use, particularly if the wrong fuel is used, or if an engine misfire occurs. For this reason it is VERY IMPORTANT that you heed the precautions which follow.

Fuel

ONLY use fuel recommended for your vehicle, see 'TYPE OF FUEL', page 84.

Starting the engine

- DO NOT continue to operate the starter after a few failed attempts (unburnt fuel may be drawn into the exhaust system, thereby poisoning the catalyst), and do not attempt to clear a misfire by pressing the accelerator pedal - seek qualified assistance.
- When starting a COLD engine, DO NOT drive if a misfire is suspected and do not attempt to clear a misfire by pressing the accelerator - seek qualified assistance.
- Do not attempt to push or tow-start the vehicle.

Catalytic Converter

Driving

- If a misfire is suspected, or the 'Service engine soon' warning light is flashing, avoid high speeds and seek immediate assistance from your Land Rover retailer.
- NEVER allow the vehicle to run out of fuel (the resultant misfire could damage the catalyst).
- Consult your retailer if your vehicle is burning excessive oil (blue smoke from the exhaust), as this will progressively reduce catalyst efficiency.
- On rough terrain do not allow the underside of the vehicle to be subjected to heavy impacts which could damage the catalytic converter.
- DO NOT overload or excessively 'rev' the engine.
- DO NOT switch off the engine when the vehicle is in motion with a drive gear selected.

WARNING


Exhaust system temperatures can be extremely high - DO NOT park on ground where combustible materials such as dry grass or leaves could come into contact with the exhaust system - in dry weather a fire could result.

Vehicle maintenance

- Any engine misfire, loss of engine performance or engine run-on, could seriously damage the catalytic converter. For this reason, it is vital that unqualified persons do not tamper with the engine, and that regular systematic maintenance is carried out by a Land Rover retailer.
- DO NOT run the engine with a spark plug or HT lead removed, or use any device that requires an insert into a spark plug.

Automatic Gearbox

CommandShift™ TRANSMISSION



CommandShift™ provides both automatic and manual operation of the gears.

Automatic operation

The transmission is naturally in automatic mode. With the engine started, gear selection can be made by moving the selector backward or forward to the appropriate position in a similar manner to other automatic gearboxes.

GEAR SELECTOR LEVER

Selector release button

The gearbox is fitted with a locking mechanism, designed to minimise the risk of accidental selection of the 'P' (Park) and 'R' (Reverse) positions.

The selector release button (arrowed in illustration) must be pressed while selecting 'R' from 'P', and also to enable the lever to be moved between the 'N' and 'R' positions.

The selector release button must also be pressed when selecting '2', and when selecting 'N' from 'D' and when selecting '2' from '1'.

NOTE: With the engine running, or the starter switch in position 'II', the selector lever cannot be moved from 'P' (Park) into a drive position unless the foot brake is applied.

NOTE: In key position 1, the selector lever can be moved from 'P' to select a gear.

CAUTION: DO NOT select 'P' or 'R' if the vehicle is moving.

CAUTION: DO NOT select a forward drive gear when the vehicle is moving backwards.

CAUTION: To prevent transmission wear, keep engine speed as low as possible when moving the selector between 'R' and a forward gear.

Automatic Gearbox

Selector lever positions

An indicator light on the selector panel and a number or letter on the digital display in the instrument panel, identify the selected gear position.

'P' - Park:

This position mechanically locks the transmission and should be selected before switching the engine off. To avoid transmission damage, ensure the vehicle is completely stationary, with the handbrake applied, before selecting 'P'.

The selector release button **MUST** be pressed, in order to move the selector lever out of the Park position.

'R' - Reverse:

Before selecting reverse, ensure the vehicle is stationary, with the brakes applied. Press the selector release button in order to move the selector lever into Reverse.

With the selector lever in the 'R' position, Hill Descent Control can be selected (see '*HILL DESCENT CONTROL*', page 94).

'N' - Neutral:

Select neutral when the vehicle is stationary and the engine is required to idle for a brief period (at traffic lights, for example). In neutral, the transmission is not locked, so the parking brake must be applied whenever 'N' is selected.

Press the selector release button to move from 'D' (Drive) to neutral and from neutral to reverse.

'D' - Drive:

Select for all normal driving; full automatic gear changing occurs on all five forward gears, according to road speed and accelerator position.

'4' (1st, 2nd, 3rd and 4th gears):

Automatic gear changing is limited to the lower four gears only; use this position for town driving and in congested traffic conditions.

'2' (1st and 2nd gears):

Automatic gear changing is limited to the first and second gears only; use when driving up steep gradients, for negotiating very narrow twisting roads and for most 'Off-road' driving. This position also provides moderate engine braking when descending slopes.

The selector release button **MUST** be pressed, in order to move the selector lever into, or out of, the '2' position.

'1' (1st gear only):

Use on very severe gradients. With the selector in this position, Hill Descent Control can be selected (see '*HILL DESCENT CONTROL*', page 94).

Sport mode


In Sport mode, full automatic progression through the gear ratios is retained. By selecting Sport mode however, the power transmitted to the road wheels is increased, resulting in improved acceleration. Engine revs are higher in all driving conditions, making the vehicle more responsive to driver commands.

To select Sport mode, move the gear lever sideways across the gate (from the Drive position towards the right hand side of the vehicle) - the word SPORT will appear in the digital display.

Sport mode can be deselected at any time, by returning the lever to the 'D' position.

Automatic Gearbox

CommandShift™ manual gear selection



H3530

There are five predetermined gear ratios, all of which can be selected sequentially by a single forward or rearward movement of the gear selector lever, as follows:

1. With 'D' (Drive) selected, move the gear selector lever sideways from the 'D' position towards the right hand side of the vehicle. This is exactly the same as selecting Sport mode; the gearbox will then remain in 'Sport' until the gear selector is moved forward or back (see '3', below).
2. The transmission then automatically selects the ratio most appropriate to the vehicle's road speed and accelerator depression.
3. A single forward movement of the selector lever will change the transmission to a higher gear, while rearward movement of the lever will change down to a lower gear. Repeated forward or rearward movements of the lever can be made until the desired gear ratio has been selected (the selected gear will be indicated in the digital display in the instrument panel).

4. To deselect manual mode, simply move the selector lever sideways, back to the 'D' position. Automatic gear changing will then resume.

NOTE: When coming to a halt with manual mode selected, the vehicle will remain in 2nd gear. When starting again, 'kick down' can be used to select 1st gear if necessary (see following page).

USING AN AUTOMATIC GEARBOX

The following information is particularly important for drivers who are unfamiliar with the techniques required to drive vehicles with automatic transmission.

Starting

The engine can only be started with the selector lever in the 'P' (Park) or 'N' (Neutral) positions.

- ALWAYS apply the parking brake and foot brake before starting the engine.
- KEEP THE BRAKES APPLIED while moving the selector lever into a drive position (the selector lever cannot be moved from the 'P' position unless the foot brake is applied).
- DO NOT 'rev' the engine or allow it to run above normal idle speed while selecting 'D' or 'R', or while the vehicle is stationary with any gear selected.
- ALWAYS keep the brakes applied until you are ready to move off - remember, once a drive gear has been selected, an 'automatic' will tend to creep forward (or backward if reverse is selected).
- DO NOT allow the vehicle to remain stationary for any length of time with a drive gear selected and the engine running (always select 'N' if the engine is to idle for a prolonged period).

CAUTION: Vehicles fitted with automatic transmission CANNOT be 'push' or 'tow' started.

Automatic Gearbox

Driving

When driving, the transmission will automatically adjust to the most appropriate ratio, according to accelerator position, vehicle speed and terrain (whether the vehicle is driving uphill, downhill or on the flat).

Gear change speeds

With 'D' selected, the road speeds at which gear changes take place will vary according to the position of the accelerator pedal: minimum acceleration will result in gear changes at low road speeds, while larger throttle openings will cause the gearbox to delay gear changes until faster road speeds have been reached (thereby increasing the rate of acceleration).

With practice, gear changes can be made to occur at a wide range of road speeds depending on the accelerator position.

'Kick-down'

To provide rapid acceleration for overtaking, push the accelerator pedal to the full extent of its travel in a single, quick movement (this is known as 'kick-down'). Up to a certain speed, this will cause an immediate downshift to the lowest appropriate gear, followed by rapid acceleration. Once the pedal is relaxed, normal gear change speeds will resume (dependent upon road speed and accelerator pedal position).

If the accelerator pedal is pushed down to its full extent and then immediately released, unlike most 'automatic' vehicles, the transmission will not automatically select the highest suitable gear ratio. Instead, the transmission will maintain the current gear ratio, to enable engine braking. This function is especially useful when an overtaking manoeuvre is aborted, enabling the driver to retake the vehicle's previous road position.

Parking

After bringing the vehicle to a stop, ALWAYS apply the parking brake and select 'P', before releasing the foot brake and switching off the engine.

Automatic Gearbox

AUTOMATICALLY SELECTED MODES

The transmission control system automatically selects different gear change modes, listed below, designed to suit a variety of driving conditions.

***NOTE:** Automatically selected modes cannot be manually selected by the driver and will not operate if 'Sport' mode is selected.*

Hill ascent, trailer and high altitude mode

A suitable gear change pattern is selected to counter momentum loss, caused by the more frequent gear changing which can occur when climbing hills, or when towing a trailer. This gear change pattern is also selected at high altitudes to combat low engine torque.

Cruise control mode

When cruise control is activated, a suitable gear change pattern is selected which is less sensitive to throttle changes. This reduces the amount and frequency of gear changes, providing a smoother ride.

High coolant temperature mode

In high ambient temperatures during extreme load conditions, it is possible for the engine and the gearbox to overheat. At a certain temperature the transmission will select a gear change pattern designed to aid the cooling process, whilst enabling the gearbox to continue performing normally in high temperatures.

Smooth change mode

Engine torque is reduced during gear changes, creating a much smoother ride.

Hill Descent Control

HILL DESCENT CONTROL


Hill Descent Control (HDC) is of particular value when driving off road, and operates in conjunction with the anti-lock braking system to provide greater control in off-road situations, when descending severe gradients.

Selecting HDC

HDC cannot be selected when in CommandShift™ mode, Sport mode, Drive or positions '2' and '4'. HDC is only available when gear selector positions '1' or 'R' are engaged.

NOTE: Reverse gear should only be selected when the vehicle is stationary.

With HDC selected, if '1' or 'R' have been engaged, the HDC information light (GREEN) in the instrument panel will illuminate continuously (if '1' or 'R' have not been selected, the information light will flash).



To select, press the HDC button, situated to the rear of the gear selector lever.

To deselect, press the HDC button again.

Hill descent control in action

During a descent, if engine braking is insufficient to control the vehicle speed, HDC (if selected) automatically operates the brakes to slow the vehicle and maintain a speed relative to the accelerator pedal position.

When driving off-road, HDC can be permanently selected, to ensure that control is maintained whenever '1' or 'R' are engaged. ABS and traction control are still fully operational and will assist if the need arises.

NOTE: HDC can be left selected while off-road driving, the system will only operate when needed and gear changes can be carried out in the normal way.

If the brake pedal is depressed when HDC is active, HDC is overridden and the brakes will perform as normal (a pulsation might be felt through the brake pedal). If the brake pedal is then released, HDC will recommence operating if necessary.

In extreme circumstances, the HDC system may cause brake temperatures to exceed their pre-set limits. If this occurs, the information warning light will extinguish and the HDC 'failure' warning light (AMBER) will start to flash. You should stop the vehicle and disengage HDC. If HDC remains operating and the brake temperature continues to rise the HDC system will gradually fade out and the 'failure' warning light will continue to flash until the brakes have cooled.

Hill Descent Control

HDC fade-out

HDC fade-out gradually decreases the HDC brake intervention with the effect that the rate of hill descent will increase. If this occurs either one of the two HDC warning lights will flash for the period that HDC takes to fade. HDC will be disabled completely once the descent is complete.

If required (e.g. the angle of the descent levels out significantly), fade-out may be achieved deliberately by deselecting HDC while the system is operating or by changing out of the appropriate operating gear, in which case the green information light will flash.

If a fault with the HDC system is detected, or if the braking system reaches a pre-set temperature due to extreme conditions, HDC will automatically fade out (amber failure light flashes).

HDC warning lights



HDC information light - GREEN:

The light illuminates briefly as a bulb check when the starter switch is turned to position 'II'. If HDC is selected when either of the operating gears are engaged ('1' or 'R'), the light will illuminate continuously. When HDC is selected and a non-operating gear is engaged, the light will flash to inform the driver that HDC is selected, but not operating. The light will also flash to indicate that HDC is fading out.




HDC 'failure' light - AMBER:

The light illuminates briefly as a bulb check when the starter switch is turned to position 'II'. The light will start flashing if the brakes become in danger of overheating and continue flashing until the brakes have cooled sufficiently for HDC to operate again.

If the light illuminates at any other time, a fault in the system is indicated. If this occurs, deselect HDC and consult your Land Rover retailer.


Cruise Control

CRUISE CONTROL



Cruise control enables the driver to maintain a constant road speed without using the accelerator pedal. This is particularly useful for freeway cruising or for any journey where a constant speed can be maintained for a lengthy period.

The cruise control system has three switches; a master switch on the left side of the instrument binnacle (illustrated above) and two control switches marked 'SET +' and 'RES' mounted on the steering wheel.



WARNING

DO NOT use cruise control on winding or slippery road surfaces, or in traffic conditions where a constant speed cannot easily be maintained.

IMPORTANT

Always observe the following precautions:

- DO NOT use cruise control when 'R' (Reverse) has been selected.
- Use of 'sport' mode is not recommended when cruise control is selected.
- DO NOT rest your foot under the accelerator pedal while cruise control is engaged - your foot could be trapped.
- ALWAYS switch off the master switch when you no longer intend to use cruise control.

To operate:

1. Press the master switch (the switch indicator light and the warning light in the instrument panel illuminate whenever the switch is pressed to the 'on' position).
2. Accelerate until the desired cruising speed is reached. This must be above the system's operational minimum speed of 28 mph (45 km/h).
3. Press the 'SET +' switch to set the vehicle speed in the system's memory. Cruise control will now maintain that road speed without the need for operation of the accelerator pedal.

With cruise control operating, speed can be increased, by normal use of the accelerator, when overtaking for example. When the accelerator is released, road speed will return to the selected cruising speed.

Cruise Control

To reduce the cruising speed:

Press the 'RES' switch to slow the vehicle, until the required speed has been reached. Then press the 'SET +' switch to establish the new cruising speed (remember that cruise control will not operate at speeds below 28 mph (45 km/h)).

To increase the set cruising speed:

Press and hold the 'SET +' switch: the vehicle will accelerate automatically. Release the switch as soon as the desired speed has been reached.

Alternatively, the set speed can be increased incrementally by 'tapping' the 'SET +' switch. Each press of the switch will increase the speed by approximately 1 mph (1.5 km/h).

Disengaging cruise control

The cruise control will automatically disengage when the gear selector is moved into 'N' (Neutral), or when the brake pedal is pressed. Cruise control can also be disengaged by pressing the 'RES' switch.

To re-engage cruise control at the previously set speed, press the 'RES' switch.

NOTE: *The speed held in the cruise control memory will be cancelled when either the cruise control master switch or the starter switch is turned off.*

Brakes

FOOT BRAKE

For your safety, the hydraulic braking system operates through dual circuits. However, in the event of a brake failure where only one circuit is operational, the vehicle should only be driven at slow speed to the nearest Land Rover retailer. In these circumstances, exercise EXTREME CAUTION and be aware that much greater pedal effort and longer stopping distances will be required.

Servo assistance

The braking system is servo assisted, but ONLY when the engine is running. Without this assistance greater braking effort is necessary to safely control the vehicle, resulting in longer stopping distances. Always observe the following precautions:

- NEVER allow the vehicle to coast with the engine turned off.
- ALWAYS take particular care when being towed with the engine turned off.
- If the engine should stop for any reason while the vehicle is in motion, bring the vehicle to a halt as quickly as traffic conditions safely allow, and DO NOT pump the brake pedal as the braking system may lose any remaining assistance available.

WARNING

NEVER move a vehicle without the engine running because braking assistance will not be available. The brake pedal will still function, but more pressure will be required.

CAUTION: Never place additional floor matting or any other obstructions under the brake pedal. This restricts pedal travel and braking efficiency.

Brake pads

Brake pads and linings require a period of bedding in. For the first 200 miles (300 km), you should avoid situations where heavy braking is required.

Remember that regular servicing is vital to ensure that the brake components are examined for wear at the correct intervals and changed whenever necessary to ensure long term safety and optimum performance.

CAUTION: DO NOT rest your foot on the brake pedal while driving as this may overheat the brakes, reduce their efficiency and cause excessive wear.

Brake warning light



If the warning light on the instrument panel illuminates while driving, and the handbrake is fully released, a fault with the braking system is indicated. Check the brake fluid level; if the light continues to illuminate, seek qualified assistance before continuing.

WARNING


If the brake warning light should illuminate while the vehicle is in motion, be prepared for increased brake pedal travel, and then stop the vehicle as quickly as traffic conditions and safety permit and seek qualified assistance before continuing.

Wet conditions

CAUTION: Driving through water or even very heavy rain may adversely affect braking efficiency. Always dry the braking surfaces by intermittent light application of the brakes, first ensuring that you are at a safe distance from other road users.

Brakes

PARKING BRAKE



The parking brake operates on the rear wheels only and should not require adjustment.

To engage the parking brake, pull the lever up fully.

To release, pull the lever up slightly, depress the button (arrowed in illustration) and lower the lever.

When parking on a slope, do not rely on the parking brake alone to hold the vehicle. Always ensure the parking pawl of the gearbox has fully engaged by carefully releasing the foot brake and allowing the vehicle to 'rock' into 'P' (park).

CAUTION: Always apply the parking brake fully whenever the vehicle is parked.

CAUTION: DO NOT apply the parking brake while the vehicle is in motion (except in an emergency), as this could damage the rear brakes and will also prevent the anti-lock braking system from functioning correctly.

CAUTION: Do not rely on the parking brake to operate effectively if the vehicle has been subjected to immersion in mud and water (see the 'Off-road driving' section).

ANTI-LOCK BRAKES

CAUTION: ABS cannot overcome the physical limitations of stopping the vehicle in too short a distance, cornering at too high a speed, or the danger of aquaplaning, i.e. where a layer of water prevents adequate contact between the tyres and the road surface.

CAUTION: The fact that a vehicle is fitted with ABS must never tempt the driver into taking risks that could affect his/her safety or that of other road users. In all cases, it remains the driver's responsibility to drive within normal safety margins, having due consideration for prevailing weather and traffic conditions.

CAUTION: The ABS is designed to operate only with the tyres specified in 'Technical Data' (see 'WHEELS & TYRES', page 186) and genuine Land Rover parts. The manufacturers cannot accept any responsibility for inefficient operation of the system caused by modifications to the vehicle, or the fitting of non-approved components. Always consult your Land Rover retailer for advice.

CAUTION: The driver should always take account of the surface to be travelled over and the fact that brake pedal reactions will be different to those experienced on a non-ABS vehicle.

The purpose of the anti-lock braking system (ABS) is to allow efficient braking without wheel locking - thereby allowing the driver to retain steering control of the vehicle.

Under normal braking conditions, (where sufficient road surface friction exists to reliably bring the vehicle to a halt without the wheels locking), ABS will not be activated. However, should the braking force exceed the available adhesion between the tyres and the road surface causing one or more wheels to lock, then ABS will come into operation.

Brakes

This will be recognisable by a rapid pulsation felt through the brake pedal.

NOTE: *Immediately after the engine is started, a short, low pitched 'buzz' may be heard; this is the ABS system priming and is no cause for concern.*

Anti-lock braking in action

In normal road use, during an emergency situation full braking effort should always be applied even when the road surface is slippery. The anti-lock braking system constantly monitors the speed of each wheel and varies braking pressure to each, according to the amount of traction available, thereby ensuring that the wheels do not lock.

No matter how hard you brake, you should be able to continue steering the vehicle as normal.

WARNING

DO NOT pump the brake pedal at any time; this will interrupt operation of the system and may increase braking distance.

DO NOT place non-approved floor mats, or any other obstruction under the brake pedal. This restricts pedal travel and, therefore, impairs braking efficiency.

NOTE: *On soft surfaces such as powdery snow, sand or gravel, braking distances may be greater than those achievable on a vehicle without anti-lock braking. This is because the action of locked wheels on loose surfaces, is to build up a wedge of material in front of the wheels, which assists in bringing the vehicle to a halt. However, even in these circumstances, the anti-lock braking system will provide better stability and steering control.*

Warning light



The anti-lock braking system incorporates a monitoring system, which checks that all the electrical components are in working order, as soon as the starter switch is turned to position 'II' and also at frequent intervals during your journey.

The warning light on the instrument panel is an important part of this system. The warning light should illuminate for a short period as a bulb and system check when the starter switch is turned to position 'II' and then extinguish (the light may flash during this period).

If the light remains on or subsequently illuminates while driving, a fault has been detected by the self monitoring system and full ABS control may not be available - consult your retailer at the earliest opportunity. The normal braking system remains fully operational and is not affected by partial or full loss of the ABS. However, braking distances may increase.

Off-road driving

While anti-lock braking is designed to operate equally effectively in 'off-road' driving conditions, on certain surfaces total reliance on the system may be unwise - remember, in normal circumstances, anti-lock braking operates only AFTER the driver has already lost control. It cannot reliably compensate for driver error or inexperience on difficult off-road surfaces. Also, note the following:

- If the vehicle is stopped on a very steep slope where little traction is available, it may slide with the wheels locked because there is no wheel rotation to signal movement to the ABS. To counteract this, briefly release the brakes to permit some wheel movement, then re-apply the brakes to allow ABS to gain control.
- Before driving off-road, read and thoroughly understand the 'Off-road driving' section of this handbook.

Traction Control

ELECTRONIC TRACTION CONTROL

The purpose of electronic traction control is to aid traction when one wheel spins while the other still has good grip (if one side of the vehicle is on ice and the other is on tarmac, for example). The system works by applying the brake to a spinning wheel in order to transfer torque to the other side of the axle.

NOTE: *Traction control only operates below approximately 30 mph (50 km/h).*

Warning light



The instrument panel warning light will illuminate whenever the system is active (for a minimum of 2 seconds) and also illuminates as a bulb check (for approximately 4 seconds) when the starter switch is turned to position 'II'.

If the warning light illuminates continuously while traction control is NOT operating, a fault with the system is indicated; seek qualified assistance.

The light also has an overheat function: if traction control is required, but the brakes are too hot, the light will flash for the period when traction control is required and traction has been lost

Load Carrying


LUGGAGE ANCHOR POINTS

Four fixing points are provided in the rear loadspace floor, to assist in safely securing large items of luggage. Land Rover provide a range of approved luggage retention accessories.

WARNING

DO NOT carry unsecured equipment, tools or luggage, which could move and cause personal injury in the event of an accident or emergency manoeuvre either on or off-road.

STORAGE BOX



The storage box, set into the loadspace floor, can be used to secure small or valuable items.

On some models, the box has a lockable lid.

To unlock: Press the flap (see inset) to access the lock. Insert the starter key and turn 90° clockwise. Lift the lid to open.

To lock: Turn the key anti-clockwise and remove the key.

On models without a lock, the stowage box lid is secured by turnbuckle fixings.

On some models, the stowage box houses the audio system subwoofer, in which case the stowage box should not be used to store other items.

CAUTION: If a subwoofer is fitted, take care to avoid knocking the underside of the subwoofer and disturbing the speaker harness and connection.

NOTE: The stowage box may become hot when driving - do not store items in the stowage box, that could be damaged by heat.

NOTE: Do not store damp items in the stowage box for prolonged periods - condensation may cause mould to form.

Load Carrying

FOLDING THE REAR SEATS

Either or both parts of the 60/40 split rear seat can be folded forward to increase the luggage space.



WARNING

DO NOT adjust any part of a seat whilst the vehicle is in motion. Vehicle movement may cause the unlatched seat to suddenly shift, potentially causing injury.

To avoid injury, ensure your fingers are clear of the seat latches when folding the rear seats.

Ensure that the rear seat backrests are securely latched in the upright position when the seat is in use and when loads are carried in the luggage area.

DO NOT carry unsecured equipment, tools or luggage that could move, causing personal injury in the event of an accident, or emergency manoeuvre - where possible, use the seat belts to secure luggage carried on the seats.



H3331

Lift one or both of the levers (see inset) to release part or the whole of the backrest, and then fold the backrest forwards.

Accommodating long loads

Remove the head restraints from the front passenger and rear seats (see 'Head restraint removal', page 30), move the front passenger seat forwards as far as possible and fully recline the seat backrest. Finally, fold the appropriate part of the backrest fully forward as shown.

Loads that are too long to be carried inside the vehicle should be carried on the roof (see 'ROOF RACK', page 105).


If it is necessary to carry a load that protrudes through the taildoor, or taildoor window, be aware of any territorial restriction restricting the length of any such load. In addition, ensure that loads DO NOT rest on the glass of a partially open window. Damage to the glass or window mechanism may occur.

Load Carrying

WARNING

You are advised NOT to carry loads which require driving with the taildoor or taildoor window open - poisonous fumes will be drawn into the vehicle! If driving the vehicle in this condition is unavoidable, switch the heater to face level vents with all vents open, close the sunroof and windows and turn the air blower to position 4.

Maximum luggage space



H3332

To create an extra large luggage area:


1. Lift the seat release levers to release the backrest and fold the seat backrest forward.
2. Tip the whole seat assembly forward as shown in illustration and re-adjust the front seats as required.

To return the seats to their normal position; push the seat base release levers (shown in lower inset) rearwards to unlock the seat base and unfold the seats.

WARNING

Ensure the seat backrests are properly secured by attempting to push them forwards -there should be no movement.

'Latch secure' indicator



H3333

'Latch secure' indicators, mounted on the top of both ends of the rear seat backrest, will pop up showing a red band, when each catch is released.

When returning either, or both, parts of the seat to the upright position, ensure that the indicators have dropped back into the backrest and that the red bands are no longer visible - this confirms that the backrest is secure.

NOTE: When returning the seats to the upright position, ensure that the seat belts are not trapped!

Load Carrying

VEHICLE LOADING



H4011

When loading a vehicle to its maximum (gross vehicle weight), consideration must be given to the unladen vehicle weight and the distribution of the load, to ensure that axle loadings do not exceed the permitted maximum values.

It is your responsibility to limit the vehicle load in such a way that neither the maximum axle loads nor the gross vehicle weight are exceeded (see 'VEHICLE WEIGHTS', page 188).

ROOF RACK

Roof bars are available as an option.

The total roof rack load must NEVER exceed that given in 'TOWING WEIGHTS', page 188.

WARNING

To avoid the risk of personal injury or even death, DO NOT permit children or any other person to travel on the roof rack while the vehicle is in motion.

A loaded roof rack can reduce the stability of the vehicle, particularly when cornering and encountering crosswinds.

IMPORTANT

- Only carry loads on the accessory cross-rails - do not attach loads directly onto the roof bars.
- It is recommended that Land Rover approved load carrying accessories are used, however, if it is necessary to attach a load directly to the accessory cross-rails, use webbing straps (preferably with a ratchet clamp) - do not use elastic or 'bungee' straps.
- All loads should be evenly distributed and secured within the periphery of a rack.
- Position the roof rack and load so that it does not impede the opening of the sunroof.
- If it is necessary to stow luggage on a roof rack while driving off-road, all loads MUST be removed before traversing side slopes.
- Check to ensure that roof rack and load are secure after 30 miles (50 km) of any journey.

Towing

TOW BARS

NOTE: Only fit towing accessories that have been approved by Land Rover.

TOWING A TRAILER

WARNING

In the interest of safety, the maximum permissible trailer weight, the maximum rear axle load, gross train and tongue weights must not be exceeded (see 'TOWING WEIGHTS', page 188).

The tongue weight plus the combined weight of the vehicle's load carrying area and rear seat passengers must never exceed the specified maximum rear axle load (see 'TOWING WEIGHTS', page 188).

DO NOT exceed the gross weight or axle loads stated on the certification label attached to the vehicle. Exceeding allowable vehicle and axle loads will increase the risk of tyre or suspension failure, increase vehicle brake stopping distance, and adversely affect vehicle handling and stability which may result in a crash or rollover.

CAUTION: DO NOT use the rear lashing eyes or vehicle recovery towing eyes to tow a trailer - serious damage to the vehicle may result.

CAUTION: DO NOT carry unsecured equipment, tools or luggage, which could move and cause personal injury in the event of an accident or emergency manoeuvre, either on or off road.

It is the driver's responsibility to ensure that vehicle and trailer are loaded and balanced so that the combination is stable when in motion.

When preparing the vehicle for towing, pay careful attention to the trailer manufacturer's recommendations and also follow the guidelines below:

- Ensure that the vehicle's tyre pressures are correct for towing and that the trailer tyre pressures are as recommended by the trailer manufacturer.
- Check the operation of the trailer brakes and lights.
- For maximum stability, ensure that loads are properly secured and unable to shift position during transit. Also, position loads so that most of the weight is placed close to the floor and, where possible, immediately above or close to the trailer axle(s).
- After loading the trailer, check that the weight on the tow hitch point (this is also called the tongue weight), does not exceed 250 lb (113 kg).
- With the towing vehicle and trailer laden, it is essential that the trailer adopts a level aspect. In other words, the trailer must be level with the ground, with the towing hitch and trailer drawbar at the same height.
- Where the load can be divided between trailer and tow vehicle, loading more weight into the vehicle will generally improve the stability of the combination. However, you must ensure that the gross vehicle and maximum rear axle weights are not exceeded and that the trailer remains level.
- The vehicle's maximum rear axle and gross train weights must not be exceeded when the trailer is attached and both towing vehicle and trailer have been loaded.

NOTE: *It is the driver's responsibility to ensure that all regulations with regard to towing, are complied with according to the state in which the vehicle is being operated. All relevant information should be obtained from an appropriate motoring organisation.*

Towing

NOTE: The maximum permissible towed weights quoted in 'TOWING WEIGHTS', page 188, refer to the vehicles's design limitations and NOT to any specific territorial restriction.

Trailer hitch

Maximum recommended drawbar length (A)


Maximum recommended drawbar rise (B)

Maximum recommended drawbar drop (C)

WARNING

If the maximum recommended drawbar length is exceeded, it may have an adverse effect on the vehicle handling whilst towing.

NOTE: A drawbar of length 7.75 inches (197 mm) with a 0.625 inch (16 mm) rise is recommended for use with the Land Rover approved Class II towing hitch. (Please consult your local dealership for the latest information).



H4561

Towing on severe inclines at full capacity

The maximum permissible Gross Train Weight (GTW) is the maximum weight of vehicle, plus trailer (see 'TOWING WEIGHTS', page 188). If a journey includes severe inclines, ensure that the grille and radiator are free from obstruction and that only high quality fuel is used. This enables the engine and the cooling system to operate more efficiently.

Towing

Correct gear selection will improve vehicle performance: select 'D' (Drive) and, where possible, maintain a speed that minimises automatic gear changes.

IMPORTANT

For all the towing conditions described, it is important that the following points are observed:

- All loads in the vehicle should be distributed as far forward as possible.
- The maximum Gross Vehicle Weight must not be exceeded, (see '*TOWING WEIGHTS*', page 188).
- The maximum individual axle weights must not be exceeded (see '*TOWING WEIGHTS*', page 188).
- Total trailer weight and tongue load can be measured with platform scales found at highway weighing stations, building companies, etc...

Off-Road Driving

Off-Road Driving

BEFORE YOU DRIVE	111
BASIC OFF-ROAD TECHNIQUES	111
AFTER DRIVING OFF-ROAD	113
SERVICING REQUIREMENTS	113

Driving Techniques

DRIVING ON SOFT SURFACES & DRY SAND ..	114
DRIVING ON SLIPPERY SURFACES (ice, snow, mud, wet grass)	114
CLIMBING STEEP SLOPES	115
DESCENDING STEEP SLOPES	116
TRAVERSING A SLOPE	116
NEGOTIATING A 'V' SHAPED GULLY	117
DRIVING IN EXISTING WHEEL TRACKS	117
CROSSING A RIDGE	117
CROSSING A DITCH	117
WADING	118

Off-Road Driving

BEFORE YOU DRIVE

Before venturing off-road, it is **absolutely essential** that inexperienced drivers become fully familiar with the vehicle's controls and also study the off-road driving techniques described on the following pages.

WARNING

- ***Off-road driving can be hazardous! DO NOT take unnecessary risks.***
 - ***Be prepared for emergencies at all times.***
 - ***Your vehicle has higher ground clearance and hence a higher centre of gravity than an ordinary passenger car. An abrupt manoeuvre at an inappropriate speed or on an unstable surface could cause the vehicle to go out of control or rollover.***
 - ***Familiarise yourself with the recommended driving techniques in order to minimise risks to yourself, your vehicle AND your passengers.***
 - ***Always ensure that seat belts are worn for personal protection in all off-road driving conditions.***
 - ***DO NOT drive if the fuel level is low - undulating ground and steep inclines could cause fuel starvation to the engine and consequent damage to the catalytic converter.***
 - ***DO NOT drive off-road alone or without letting someone know where you are going and when you plan to return.***
-

BASIC OFF-ROAD TECHNIQUES

These basic driving techniques are an introduction to the art of off-road driving and do not necessarily provide the information needed to successfully cope with every single off-road situation.

We strongly recommend that owners who intend to drive off-road frequently, should seek as much additional information and practical experience as possible.

Before driving off-road it is important that you check the condition of the wheels and tyres and that the tyre pressures are correct. Worn or incorrectly inflated tyres will adversely affect the performance, stability and safety of the vehicle.

Gear selection

With the main selector lever set at 'D', the gearbox automatically provides the correct gear for the majority of off-road conditions. Remember that position '1' will hold the gearbox in first gear to give maximum engine braking when required.

When descending very steep slopes, always select position '1' and Hill Descent Control (HDC).

Braking

As far as possible, vehicle speed should be controlled through correct gear selection and the use of Hill Descent Control (HDC). Application of the brake pedal should be kept to a minimum. In fact, if the correct gear and HDC have been selected, braking will be largely unnecessary.

If the brake pedal is depressed when HDC is active, HDC is overridden and the brakes will perform as normal. If the brake pedal is then released, HDC will recommence operating, if necessary.

Off-Road Driving

Hill descent control (HDC)


During a descent, if engine braking is insufficient to control the vehicle speed, HDC (if selected) automatically operates the brakes to slow the vehicle and maintain a speed relative to the accelerator pedal position

When driving off-road, HDC can be permanently engaged, to ensure that control is maintained whenever gear selector positions '1' or 'R' are selected. ABS and Traction control are still fully operational and will assist if the need arises.

Accelerating

Use the accelerator with care - any sudden surge of power may induce wheel spin and, therefore, invoke unnecessary operation of traction control, or in extreme conditions could lead to loss of control of the vehicle.

Steering



H2410A

WARNING

DO NOT hold the steering wheel with your thumbs inside the rim - a sudden 'Kick' of the wheel as the vehicle negotiates a rut or boulder could seriously injure them. ALWAYS grip the wheel on the outside of the rim (as shown) when traversing uneven ground.

Survey the ground before driving

Before negotiating difficult terrain, it is wise to carry out a preliminary survey on foot. This will minimise the risk of your vehicle getting into difficulty through a previously unnoticed hazard.

Off-Road Driving

Ground clearance

Don't forget to allow for ground clearance beneath the body and under the front and rear bumpers. Note that the suspension arms are situated below the body. Note also that there are other parts of the vehicle which may come into contact with the ground - take care not to ground the vehicle.

Ground clearance is particularly important at the bottom of steep slopes, or where wheel ruts are unusually deep and where sudden changes in the slope of the ground are experienced.

ALWAYS attempt to avoid obstacles that may foul the underside of the vehicle.

Loss of traction

If the vehicle is immobilised due to loss of tyre grip, the following hints could be of value:

- Remove obstacles rather than forcing the vehicle to cross them.
- Clear clogged tyre treads.
- Reverse as far as possible, then attempt an increased speed approach - additional momentum may overcome the obstacle.
- Brushwood, sacking or any similar material placed in front of the tyres may improve tyre grip.

CD Autochanger

Playing CDs while negotiating arduous off-road terrain is not recommended. Severe jolting of the vehicle may disturb the operation of the autochanger, causing the disc to 'jump or skip'.

AFTER DRIVING OFF-ROAD

IMPORTANT

Before rejoining the public highway, or driving at speeds above 25 mph (40 km/h), consideration should be given to the following:

- Wheels and tyres must be cleaned of mud and inspected for damage - ensure there are no lumps or bulges in the tyres, or exposure of the ply or cord structure.
- If wheels and tyres are not cleaned properly, damage to the wheels, tyres, braking system and suspension components could occur.
- Brake discs and callipers should be examined and any stones or grit that may affect braking efficiency removed.

SERVICING REQUIREMENTS

Vehicles operated in arduous conditions, particularly on dusty, muddy or wet terrain, and vehicles undergoing frequent or deep wading conditions will require more frequent servicing. Contact a Land Rover retailer for advice.

After wading in salt water or driving on sandy beaches, use a hose to wash the underbody components and any exposed body panels with fresh water. This will help to protect the vehicle's cosmetic appearance, and also help to prevent corrosion.

Driving Techniques

DRIVING ON SOFT SURFACES & DRY SAND

The ideal technique for driving on soft sand requires the vehicle to be kept moving at all times - soft sand causes excessive drag on the wheels, resulting in a rapid loss of motion once driving momentum is lost. For this reason, gear changing should be avoided.

Select the highest suitable gear and REMAIN in that gear until a firm surface is reached.

Stopping the vehicle on soft ground, in sand or on an incline

If you do stop the vehicle, remember:

Starting on an incline or in soft ground or sand may be difficult. Always park on a firm level area, or with the vehicle facing downhill.

To avoid wheel spin, select 'D' (Drive) and use the MINIMUM throttle necessary to get the vehicle moving.

If forward motion is lost, avoid excessive use of the throttle - this will cause wheel spin and tend to dig the vehicle into the sand. Clear sand from around the tyres and ensure that the body is not bearing on the sand before again attempting to move.

If the wheels have sunk, use an air bag lifting device or high lift jack to raise the vehicle, and then build up sand under the wheels so that the vehicle is again on level ground. If a restart is still not possible, place sand mats or ladders beneath the wheels.

DRIVING ON SLIPPERY SURFACES (ice, snow, mud, wet grass)

- Select 'D' (Drive) and drive away using the MINIMUM throttle possible.
- Drive slowly at all times, keeping braking to a minimum and avoiding violent movements of the steering wheel.

Driving Techniques

CLIMBING STEEP SLOPES

ALWAYS follow the fall line of the slope - travelling diagonally could encourage the vehicle to slide broadside down the slope.

Select gear selector position '1' and engage hill descent control (HDC). If the surface is loose or slippery, use sufficient speed in the highest practical gear to take advantage of your vehicle's momentum. However, too high a speed over a bumpy surface may result in a wheel lifting, causing the vehicle to lose traction. In this case try a slower approach. Traction can also be improved by easing off the accelerator just before loss of forward motion.

If the vehicle is unable to complete a climb, do not attempt to turn it around while on the slope. Instead, adopt the following procedure to reverse downhill to the foot of the slope.

1. Hold the vehicle stationary using both foot and parking brakes.
2. Restart the engine if necessary.
3. Engage 'R' (Reverse).
4. Select hill descent control (HDC), if not already selected.
5. Release the parking brake. Then release the foot brake and allow the vehicle to reverse down the slope using engine braking and HDC to control the rate of descent.
6. Unless it is necessary to stop the vehicle to negotiate obstructions, DO NOT apply the brake pedal during the descent.
7. If the vehicle begins to slide, accelerate slightly to allow the tyres to regain grip.

When the vehicle is back on level ground or where traction can be regained, a faster approach will probably enable the hill to be climbed. However, DO NOT take unnecessary risks, if the hill is too difficult to climb, find an alternative route.

WARNING


DO NOT attempt to reverse down a slope without the engine running, or HDC and the braking effect of the gearbox will be lost.

Driving Techniques

DESCENDING STEEP SLOPES


WARNING

Failure to follow these instructions may cause the vehicle to roll over.



H3446


- Stop the vehicle at least a vehicle length before the start of the slope and engage gear selector position '1' and hill descent control (HDC).
- Unless it is necessary to stop the vehicle in order to negotiate obstructions, DO NOT touch the brake pedal during the descent - the engine and HDC will limit the speed, keeping the vehicle under perfect control provided the front wheels are rotating. If the vehicle begins to slide, the limits of adhesion have been reached, and it may be impossible to maintain the minimum speed relative to the gear selected. In this case, HDC may automatically accelerate the vehicle sufficient to maintain directional stability. DO NOT use the accelerator or the brakes or attempt to change gear. HDC will automatically slow the vehicle down again as soon as possible.
- Once level ground is reached, select a suitable gear range for the next stage of your journey.



TRAVERSING A SLOPE

WARNING

Failure to follow these instructions may cause the vehicle to roll over.



H3447

Before crossing a slope ALWAYS observe the following precautions:

- Check that the ground is firm and not slippery.
- Check that the wheels on the downhill side of the vehicle are not likely to drop into depressions in the ground and that the 'uphill' wheels will not run over rocks, tree roots, or similar obstacles that could suddenly increase the angle of tilt.
- Ensure that passenger weight is evenly distributed, that all roof rack luggage is removed and that all other luggage is properly secured and stowed as low as possible. Always remember; any sudden movement of the load could cause the vehicle to overturn.
- Rear seat passengers should sit on the uphill side of the vehicle or, in extreme conditions, should vacate the vehicle until the sloping ground has been safely negotiated.

Driving Techniques

NEGOTIATING A 'V' SHAPED GULLY

Observe extreme caution! Steering up either of the gully walls could cause the side of the vehicle to be trapped against the opposite gully wall.

DRIVING IN EXISTING WHEEL TRACKS

As far as possible allow the vehicle to steer itself along the bottom of the ruts. However, always keep a light hold of the steering wheel to prevent it from spinning free.

Particularly in wet conditions, if the steering wheel is allowed to spin free, the vehicle may appear to be driving straight ahead in the ruts, but in actual fact (due to the lack of traction caused by the wet ground) is unknowingly on full right or left lock. Then, when level ground is reached, or if a dry patch of ground is encountered, the wheels will find traction and cause the vehicle to suddenly veer to left or right.

CROSSING A RIDGE



H3448

Approach at right angles so that both front wheels cross the ridge together - an angled approach could cause diagonally opposite wheels lifting from the ground at the same time.

CROSSING A DITCH



H3449

Cross ditches at an angle so that three wheels always maintain contact with the ground. If a ditch is approached head on, both front wheels will drop into the ditch together, possibly resulting in the body and front bumper being trapped on opposite sides of the ditch.

Driving Techniques

WADING

CAUTION: The maximum advisable wading depth is 16 inches (0,4 m).

CAUTION: Severe electrical damage may occur if the vehicle remains stationary for any length of time when the water level is above the door sills.

If the depth of water is likely to exceed 16 inches (0,4 m), the following precautions should be observed:

- Fix a plastic sheet in front of the radiator grille to prevent water from soaking the engine and mud from blocking the radiator.
- Ensure that the silt bed beneath the water is free of obstacles and firm enough to support the vehicle's weight and provide sufficient traction.
- Ensure that the engine air intake is clear of the water level.
- Select a low gear and maintain sufficient throttle to prevent the engine from stalling. This is particularly important if the exhaust pipe is under water.
- Drive slowly into the water and accelerate to a speed which causes a bow wave to form; then maintain that speed.

At all times, keep all the doors fully closed.

After wading

- Immediately after wading, remove any protective covering from in front of the radiator grille.
- DO NOT rely on the parking brake to hold the vehicle stationary until the brakes are thoroughly dried out; in the meantime, leave the vehicle parked with the gear selector in 'P' (Park).
- Drive the vehicle a short distance and apply the foot brake to check that the brakes are fully effective.
- If the water was particularly muddy, remove any blockages (mud and leaves) from the radiator to reduce the risk of overheating.
- If deep water is regularly negotiated, check all oils for signs of water contamination - contaminated oil can be identified through its 'milky' appearance. In addition, check the air filter element for water ingress and replace if wet - consult a Land Rover retailer if necessary.
- If salt water is frequently negotiated, thoroughly wash the underbody components and exposed body panels with fresh water.

NOTE: *Vehicles required to undergo frequent or deep wading conditions will require more frequent servicing. Contact a Land Rover retailer for advice.*

On-Road Driving

On-Road Driving

INSTRUMENTS AND WARNING LIGHTS	121
POWER ASSISTED STEERING	121
WARMING UP	121
VEHICLE HEIGHT	121
DRIVING PRECAUTIONS	122
FUEL ECONOMY	123
BREAKDOWN SAFETY	123

On-Road Driving

INSTRUMENTS AND WARNING LIGHTS

Before driving it is important to fully understand the function of the instruments and warning lights.

NOTE: *Red warning lights are of particular importance, illumination indicating that a fault exists. If a red light illuminates, always stop the vehicle and seek qualified assistance before continuing.*

POWER ASSISTED STEERING

The hydraulic power-assisted steering is progressively geared; when steering straight ahead gearing is relatively low, but becomes progressively higher as the steering wheel is turned.

NOTE: *Power assistance is dependent on the engine running. If the engine is not running, a much greater effort will be required to steer the vehicle.*

WARMING UP

In the interests of fuel economy, it is advisable to drive the vehicle straight away, remembering that harsh acceleration or labouring the engine before the normal operating temperature has been reached can damage the engine.

When the engine is cold, engine idle speeds will be faster than normal. Under these circumstances, use the foot brake to control the vehicle until the engine is warm and running at normal speed, and be aware of the need to take additional care when manoeuvring the vehicle.

VEHICLE HEIGHT

CAUTION: The overall height of your vehicle exceeds that of ordinary passenger cars. Always be aware of the height of your vehicle and check the available headroom before driving through low entrances. This is particularly important if the vehicle is fitted with a roof rack or if a sunroof is open.

On-Road Driving

DRIVING PRECAUTIONS

WARNING

Utility vehicles have a significantly higher roll-over rate than other types of vehicles. Since these vehicles are designed to be operated off-road, these vehicles have a higher ground clearance and hence a higher centre of gravity. Such a feature has been associated with an increased risk of vehicle roll-over. An advantage associated with higher ground clearance vehicles is a better view of the road, allowing the driver to anticipate problems. Another factor shown to significantly increase roll-over risk is unauthorized vehicle modifications such as fitting incorrect specification tyres (see 'WHEELS & TYRES', page 186), oversize tyres, body lifting, incorrect springs/dampers, incorrect vehicle loading/trailer towing.

However, on-road crash data also indicates that driver behaviour is a greater factor than a high centre of gravity in determining a vehicle's overall roll-over rate. The single most effective driver behaviour that can reduce the risk of injury or death in all crashes including roll-over, is to ALWAYS WEAR YOUR SEAT BELT and to properly restrain all child passengers in an appropriate child safety seat. In a roll-over crash, an unbelted person is significantly more likely to die than a person wearing a seat belt.

Other measures that can reduce the risk of injury and death from vehicle crashes and roll-over are:

- Limit speed. Posted speed limits should never be exceeded, and you should always drive below these limits whenever traffic, weather, road or other conditions dictate. Always use your common sense and good judgement.
- Take curves at reasonable speeds avoiding unnecessary braking.
- Drive defensively. Be aware of traffic, road and weather conditions. Avoid risk taking behaviour such as following too close, rapid lane changing or abrupt manoeuvres.
- Assume that pedestrians or other drivers are going to make mistakes. Anticipate what they might do. Be ready for their mistakes.
- Avoid distractions such as cellular phone calling, reading, eating, drinking or reaching for items on the floor.
- Before changing lanes, check your mirrors and flash your turn signal lights.
- Always leave room for unexpected events such as sudden braking.
- Never operate your vehicle when you have consumed alcohol, are sleepy or fatigued or have taken any medications that affect judgement, reflexes or alertness.
- Many vehicle rollovers occur when a driver attempts to bring a vehicle back onto the road after some or all of the wheels drift onto the shoulder of the road, especially when the shoulder is unpaved. If you find yourself in such a situation, do not initiate any sharp or abrupt steering and/or braking manoeuvres to re-enter the roadway. Instead, let the vehicle slow down as much as safely possible before attempting to re-enter the roadway and keep your wheels as straight as possible while re-entering the roadway.

On-Road Driving

FUEL ECONOMY

Fuel consumption is influenced by two major factors:

- How your vehicle is maintained.
- How you drive your vehicle.

To obtain optimum fuel economy, it is essential that your vehicle is maintained in accordance with the manufacturer's service schedule.

Items such as the condition of the air cleaner element, tyre pressures and wheel alignment will have a significant effect on fuel consumption. But, above all, the way in which you drive is most important. The following hints may help you to obtain better value from your motoring:

- Avoid unnecessary, short, start-stop journeys.
- Avoid fast starts by accelerating gently and smoothly from rest.
- Do not drive in the lower gears for longer than necessary.
- Decelerate gently and avoid sudden and heavy braking.
- Anticipate obstructions and adjust your speed accordingly well in advance.
- When stationary in traffic, select neutral to improve fuel economy and air conditioning performance.

BREAKDOWN SAFETY

IMPORTANT INFORMATION

Remember the breakdown safety code

If a breakdown occurs while travelling:

- Wherever possible, consistent with road safety and traffic conditions, the vehicle should be moved off the main thoroughfare, preferably onto the shoulder as far as possible. If a breakdown occurs on a freeway, pull well over to the inside of the hard shoulder.
- Switch on hazard lights.
- If possible, position a warning triangle or a flashing amber light at an appropriate distance from the vehicle to warn other traffic of the breakdown, (note the legal requirements of some countries).
- Consider evacuating passengers through the doors facing away from traffic, to a safe area away from the vehicle, as a precaution in case your Discovery is accidentally struck by another vehicle.

Owner Maintenance

Maintenance

ROUTINE MAINTENANCE	127
OWNER MAINTENANCE	128
SAFETY IN THE GARAGE	129
EMISSION CONTROL	130
ROAD TESTING DYNAMOMETERS (‘rolling roads’)	130

Hood Opening

OPENING THE HOOD	131
------------------------	-----

Engine Compartment

2.5 PETROL ENGINE	132
-------------------------	-----

Engine

ENGINE OIL	133
DRAIN & REFILL	134

Air Cleaner

AIR CLEANER ELEMENT RENEWAL	136
-----------------------------------	-----

Spark Plugs

SPARK PLUG REMOVE & REFIT	137
---------------------------------	-----

Cooling System

COOLANT CHECK & TOP-UP	138
ANTI-FREEZE	139

Brakes

BRAKE FLUID	140
-------------------	-----

Power Steering

POWER STEERING FLUID	141
----------------------------	-----



Washers

WINDSCREEN WASHERS 142

Wiper Blades

WIPER BLADE REPLACEMENT 143

Battery

BATTERY SAFETY 144

BATTERY MAINTENANCE 144

THE EFFECTS OF BATTERY DISCONNECTION 147

Tyres

CARING FOR YOUR TYRES 148

UNIFORM TYRE QUALITY GRADING 150

SNOW CHAINS 151

Cleaning & Vehicle Care

WASHING YOUR VEHICLE 152

CLEANING THE INTERIOR 154

Identification Numbers

CONTACTING YOUR retailer 155

IDENTIFICATION NUMBER LOCATIONS 155

VEHICLE IDENTIFICATION NUMBER 155

Parts & Accessories

PARTS AND ACCESSORIES 156

Maintenance

ROUTINE MAINTENANCE

Regular systematic maintenance is the key to ensuring the continued reliability and efficiency of your vehicle.

Maintenance is the owner's responsibility and it is essential that all routine services, as well as the owner maintenance operations, brake fluid and coolant changes, are carried out when required and according to the manufacturer's recommendations.

The routine maintenance requirements for your vehicle are shown in the separate Passport to Service book. Most of the necessary workshop maintenance requires specialised knowledge and equipment, and should preferably be entrusted to a Land Rover retailer.

Passport to Service

The Passport to Service book includes a Service Record section, which enables a record to be kept of all services that are carried out on the vehicle. This section of the book also provides a facility for the retailer to record brake fluid and camshaft drive belt changes, as well as the fitting of replacement airbag modules.

Ensure your retailer signs and stamps the book after each service.

Brake fluid and coolant replacement

The brake fluid and engine coolant (anti-freeze and water solution) needs to be replaced every 36,000 miles (60,000 km) or 36 months, whichever is the sooner. Your retailer will replace the brake fluid and coolant at the scheduled services.

Maintenance

OWNER MAINTENANCE

In addition to the routine services which should be carried out by your Land Rover retailer at the intervals shown in the Passport to Service, a number of simple checks (listed below) must be carried out by the owner or driver on a regular basis. These are fully described on the pages that follow.

WARNING

If brake travel is unusually long or there is any evident loss of brake fluid, contact your retailer immediately.

CAUTION: Any significant or sudden drop in fluid levels, or uneven tyre wear, should be reported to a retailer without delay; driving under such conditions could result in extended stopping distances, or complete brake failure.

Daily checks

- Operation of inertia reel seat belts.
- Operation of parking brake and foot brake.
- Operation of lights, horn, direction indicators, wipers, washers and warning lights.
- Look for fluid deposits underneath the vehicle that might indicate a leak.

Weekly checks (or at least every 250 miles/400 km)

- Engine oil level.
NOTE: *The engine oil level should be checked more frequently if the vehicle is driven for prolonged periods at high speeds.*
- Coolant level.
- Screen washer fluid level.
- Brake fluid level.
- Power steering fluid level.
- Tyre pressures and condition.
- Operate the air conditioning.

IMPORTANT

Special operation conditions

When a vehicle is operated in extremely arduous conditions or a dusty, wet or muddy terrain, more frequent attention must be paid to servicing requirements. For example: if your vehicle experiences deep wading conditions, even DAILY servicing could be necessary to ensure the continued safe and reliable operation of the vehicle.
Contact a Land Rover retailer for advice.

Maintenance

SAFETY IN THE GARAGE

WARNING

Cooling fans may continue to operate after the engine is switched off. When the engine is hot, the cooling fans may also COMMENCE operating after the engine is switched off and continue operating for up to 8 minutes. To avoid injury, keep clear of all fans while working in the engine compartment.

If you need to carry out maintenance, observe the following safety precautions at all times:

- Keep your hands and clothing away from drive belts and pulleys.
- If the vehicle has been driven recently, DO NOT TOUCH exhaust and cooling system components until the engine, exhaust and radiator have cooled.
- DO NOT TOUCH electrical leads or components while the engine is running, or with the starter switch turned on.
- NEVER leave the engine running in an unventilated area - exhaust gases are poisonous and extremely dangerous.
- DO NOT work beneath the vehicle with the wheel changing jack as the only means of support.
- Ensure sparks and naked lights are kept away from the engine compartment.
- Wear protective clothing, including, where practicable, gloves made from an impervious material.
- Remove metal wrist bands and jewellery before working in the engine compartment.
- DO NOT allow tools or metal parts of the car to make contact with the battery leads or terminals.

Poisonous fluids

Fluids used in motor vehicles are poisonous and should not be consumed or brought into contact with open wounds. These include: battery acid, anti-freeze, brake and power steering fluid, as well as gasoline, engine oil and windscreen washer additives.

For your own safety, ALWAYS read and obey all instructions printed on labels and containers.

Used engine oil

Prolonged contact with engine oil may cause serious skin disorders, including dermatitis and cancer of the skin. ALWAYS wash thoroughly after contact.



It is illegal to pollute drains, water courses or soil with toxic chemicals such as used engine oil. Use authorised waste disposal sites to dispose of used oil and toxic chemicals.

Maintenance

EMISSION CONTROL

Your vehicle is fitted with various items of emission and evaporative control equipment designed to meet specific territorial requirements. You should be aware that unauthorised replacement, modification or tampering with this equipment by an owner or repair shop may be unlawful and subject to legal penalties.

In addition, engine settings must not be tampered with. These have been established to ensure that your vehicle complies with stringent exhaust emission regulations. Incorrect engine settings may adversely affect exhaust emissions, engine performance and fuel consumption, as well as causing high temperatures, which will result in damage to the catalytic converter and the vehicle.

Whilst Land Rover North America Inc. maintains that an authorised Land Rover retailer is best equipped to carry out repairs and maintenance on the emission control system, such work may be carried out by any competent automotive repair shop, or individual, using certified parts.

WARNING


Under no circumstances should any part of the fuel system be dismantled or replaced by anyone other than a suitably qualified motor vehicle technician. Failure to comply with this instruction may result in fuel spillage with a consequent serious risk of fire.

ROAD TESTING DYNAMOMETERS (‘rolling roads’)

Because your vehicle is equipped with anti-lock brakes and permanent four-wheel drive, it is essential that any dynamometer testing is carried out ONLY by a qualified person familiar with the dynamometer testing and safety procedures practiced by Land Rover retailers. Contact your Land Rover retailer for further information.

Hood Opening

OPENING THE HOOD



H3450

1. From inside the vehicle on the right hand side, pull the hood release handle (see illustration).
2. Lift the safety catch lever and raise the hood.
3. Unclip the hood support stay.
4. Fit the support stay into the cut-out in the underside of the hood.

Closing the hood

WARNING


DO NOT drive with the hood retained by the safety catch alone.

Replace the support stay in its retaining clip, then lower the hood, allowing it to drop for the last 12 inches (30 cm) approx.

After closing, check that the lock is fully engaged by attempting to lift the front edge of the hood. This should be free from all movement.

Engine Compartment

2.5 PETROL ENGINE



H3515A

1. Power steering reservoir.
2. Cooling system reservoir.
3. Brake fluid reservoir.
4. Engine oil filler cap.
5. Engine oil dipstick.
6. Washer reservoir.

WARNING

While working in the engine compartment, ALWAYS observe the safety precautions listed under 'SAFETY IN THE GARAGE', page 129.

Engine

ENGINE OIL

Check the oil level weekly, or every 250 miles (400 km). Ideally the oil level should be checked with the engine cold and the vehicle resting on level ground. If the engine is already warm, then wait for at least two minutes after switching off before checking the level.


NOTE: Check the engine oil more frequently if the vehicle is driven at high speeds for prolonged periods.

Oil specification

Use only an approved full synthetic engine oil. For approved brands, see 'Engine oil' in the 'Technical Data' section.

NOTE: Mixing additives with the engine oil is not recommended and could damage the engine.

It is essential to use an oil suitable for the climatic conditions in which the vehicle is to be operated. Oils manufactured to the above specification are suitable for use in temperatures between -4°F to 86°F (-20°C to +30°C). If the ambient temperature falls outside these limits, seek advice from your retailer.



H4022

Oil level check & top-up

WARNING

Take care to avoid spilling engine oil onto a hot engine - a fire may result! Wipe up any spillage immediately.

1. Withdraw the dipstick and wipe the blade clean.
2. Slowly insert the dipstick and withdraw again to check the level, which should NEVER be allowed to fall below the lower mark on the dipstick.
3. To top-up, remove the oil filler cap and add oil to maintain a level between the upper and lower marks on the dipstick. As a general guide, if the level on the dipstick is:
 - nearer to the upper mark than the lower, add no oil.
 - nearer to the lower mark than the upper, add 0.5 US quart (0.5 litre) of oil.
 - at or below the lower mark, add 1 US quart (1 litre) of oil.
4. Wait for five minutes and then recheck the level, adding more oil if necessary - DO NOT OVERFILL!
5. Finally, ensure the dipstick and filler cap are replaced.

CAUTION: Driving the vehicle with the engine oil level ABOVE the upper mark, or BELOW the lower mark on the dipstick, can damage the engine.

NOTE: If oil consumption seems excessive, check the system for leaks and contact your retailer.

Engine

DRAIN & REFILL


Ensure the engine oil is changed at the recommended service intervals as specified in the Passport to Service book.

NOTE: Under severe operating conditions (i.e. regular use in muddy terrain or dusty conditions), the engine oil must be changed more frequently, even to the extent of a daily change. Consult your Land Rover retailer for guidance.

Used engine oil


WARNING

Prolonged contact with used engine oil can cause serious skin disorders, including dermatitis and cancer of the skin. Wear protective clothing if possible and ALWAYS wash thoroughly after contact.

 It is illegal to pollute drains, water courses or soil with toxic chemicals such as used engine oil. Use authorised waste disposal sites to dispose of used oil and toxic chemicals.

Removing the underbelly panel

Before it is possible to drain the engine oil and/or replace the oil filter, the underbelly panel beneath the engine must be removed.




H4323

The underbelly panel is held in position by 14 screws and bolts. These are best removed in the following order:

1. Remove the 2 screws securing bumper valance to underbelly panel brackets.
2. Remove the 4 screws securing wheel arch liners to bumper valance.
3. Remove the 2 bolts securing the rear of the underbelly panel.
4. Remove the 6 bolts securing the underbelly panel frame.

Drain

With the engine warm (to assist oil drainage) and the vehicle parked on firm, level ground, remove the filler cap and position a container of suitable size (at least 5.5 US quarts or 5.2 litres) under the drain plug, in the bottom of the sump.



H4242

Remove the drain plug and sealing washer and allow the engine oil to drain into the container.

WARNING

Oil from the engine can be very hot, to avoid harmful burns, take care when removing the drain plug.

Engine

Refill

Clean the oil drain plug and its mating surface on the engine sump. Fit the drain plug, complete with a new sealing washer and tighten to 18 lbf.ft (25 Nm).

Refill the engine with fresh oil, suitable for the climatic conditions in which the vehicle is to be operated and confirming strictly to the specification shown under 'Engine oil' in the 'Technical Data' section.

DO NOT overfill the engine! Remember that a little oil will always remain in the engine after draining and that, therefore, the quantity of oil required to refill the engine will be slightly less than the full capacity quoted in the Technical Data section of this handbook.

After filling, allow a few minutes to elapse before checking the level on the dipstick (this will allow all the oil to drain into the sump and enable a true reading to be obtained). Once the correct level of oil is shown on the dipstick, replace the filler cap.


Start and run the engine. Do not rev the engine until the oil pressure warning light extinguishes. Check for oil leaks around the drain plug.

Stop the engine, wait a few minutes, then check the oil level and top up if necessary.

Finally, replace the underbelly panel.

OIL FILTER RENEWAL

It is assumed that oil filter renewal will take place at the same time as oil drain and refill and that the underbelly panel will, therefore, already have been removed.




1. Clean the area around the filter head and place a suitable container beneath the engine.
2. Using a strap wrench, or similar tool, unscrew the filter anti-clockwise and discard it.
3. Smear the seal of the new filter with clean engine oil.
4. Fit the new filter and tighten clockwise until the bowl seats, then tighten a further half turn. Use hand force only, DO NOT overtighten.
5. Start and run the engine. Do not rev the engine until the oil pressure warning light extinguishes. Check for oil leaks around the filter and drain plug.
6. Stop the engine, wait a few minutes, then check the oil level and top up if necessary.

Air Cleaner

AIR CLEANER ELEMENT RENEWAL

Renewing the air cleaner element at the recommended service intervals (see your 'Passport to Service book'), is extremely important. However, to maintain optimum engine performance under dusty operating conditions, more frequent renewal will be necessary. Consult your Land Rover retailer for guidance.


Removing the engine cover



H4243

1. Loosen the clip and disconnect the fresh air intake hose from the side of the engine cover (see left inset to illustration).
2. Loosen the clip and disconnect the air intake and bypass hose from the throttle body (see right inset to illustration).
3. Release the two turnbuckle fastenings that secure the front of the engine cover (arrowed in main illustration).
4. Release the retaining strap at the rear of the engine cover and remove the cover.

Renewing the air cleaner element



H4246

With the engine cover turned upside down, remove the screws securing the heat shield to the underside of the engine cover. This will provide access to the air cleaner cartridge.

Remove the two screws securing the air cleaner cartridge to the engine cover, then release the cartridge and remove the air cleaner element.

Before fitting a new element, clean the inside of the air cleaner cartridge.


IMPORTANT INFORMATION

Always fit a NEW element; under no circumstances should a contaminated element be cleaned and used again.

Spark Plugs

SPARK PLUG REMOVE & REFIT

Spark plug removal




H4254

1. Disconnect the battery earth cable.
2. Remove the engine acoustic cover (see 'Removing the engine cover', page 136).
3. **Right hand bank only:** Release the locking clips and disconnect the multiplugs from the plug top coils.
4. **Right hand bank only:** Remove the six bolts securing the plug top coils to the right hand camshaft cover and remove the coils.
5. **Left hand bank only:** Carefully noting the relative fitting positions, disconnect the plug leads.
6. Use a suitable spark plug wrench to remove the plugs from both cylinder heads.

Refitting the plugs

When refitting, take care not to cross-thread the spark plugs, otherwise costly damage to the cylinder head will result.



H4253

Only fit plugs of a type recommended by the vehicle manufacturer (see 'ENGINES', page 185) and tighten to a torque of 18 lbf.ft (25 Nm). Please note that incorrect grades of plug may lead to engine failure and serious damage.

Refitting the high tension (H.T.) leads

1. **Left hand bank only:** Connect the plug leads, ensuring they are replaced in the correct relationship to each other. Failure to maintain the correct plug lead connections, will result in a misfire and possible damage to the catalytic converter.
2. **Right hand bank only:** Refit the plug top coils to the spark plugs.
3. **Right hand bank only:** Refit the bolts securing the plug top coils to the right hand camshaft cover and tighten to 6.5 lbf.ft (9 Nm).
4. **Right hand bank only:** Reconnect the multiplugs to the plug top coils and secure with the locking clips.
5. Refit the engine cover and then the battery earth cable.

CAUTION: To ensure the correct firing order (1, 6, 5, 4, 3, 2), the high tension leads must be replaced in the correct relationship to each other.

Cooling System

COOLANT CHECK & TOP-UP

WARNING

NEVER remove the filler cap when the engine is hot - escaping steam or scalding water could cause serious personal injury.

Take care not to spill anti-freeze onto a hot engine - a fire may result. Wipe up any spillage immediately.

CAUTION: DO NOT overfill the reservoir and NEVER run the engine without coolant.

The coolant level in the expansion tank should be checked at least weekly (more frequently in high mileage or arduous operating conditions). Always check the level WHEN THE SYSTEM IS COLD and with the vehicle resting on level ground.

If it is necessary to remove the filler cap before the system has fully cooled, loosen the cap slowly, allowing the air pressure to escape gradually.

CAUTION: DO NOT add rust inhibitors or other additives to the coolant - these may not be compatible with the coolant or engine components.


CAUTION: Anti-freeze will damage painted surfaces: Soak up any spillage with an absorbent cloth immediately and wash the area with a mixture of car shampoo and water.

CAUTION: Never top up with salt water. Even when travelling in territories where the water supply contains salt, always carry a supply of fresh (rain or distilled) water.

If the coolant level has fallen appreciably, suspect leakage or overheating and arrange for your retailer to examine the vehicle.

If the cooling system is to be topped-up before the vehicle is to be left undriven over the winter, mix the anti-freeze and water together thoroughly BEFORE adding it to the cooling system.

Ensure the cap is tightened fully after top-up is completed.



H2347A

Top-up with a 50% mixture of anti-freeze and water (see 'Coolant specification', page 139) so that the surface of the coolant is level with the 'MAX' indicator on the side of the tank.

Cooling System

ANTI-FREEZE

WARNING

Anti-freeze is poisonous and can be fatal if swallowed - keep containers sealed and out of the reach of children. If accidental consumption is suspected, seek medical attention immediately.

Prevent anti-freeze coming in contact with the skin or eyes. If this occurs, rinse immediately with plenty of water.

Anti-freeze contains important corrosion inhibitors. The anti-freeze content of the coolant must be maintained at 50% \pm 5% all year round (not just in cold conditions). To ensure that the anti-corrosion properties of the coolant are retained, the anti-freeze content should be checked once a year (regardless of mileage) and completely renewed every 3 years or 36,000 miles (60,000 km), whichever is the sooner. Failure to do so may cause corrosion of the radiator and engine components.

The specific gravity of a 50% anti-freeze solution at 68°F (20°C) is 1.075 and protects against frost down to -33°F (-36°C).

Coolant specification

Use ONLY Havolene Extended Life Coolant (XLC) or any ethylene glycol based anti-freeze (containing no methanol) with only Organic Acid Technology (OAT) corrosion inhibitors.

In an emergency - and only if this type of anti-freeze is unavailable - top-up the cooling system with clean water, but be aware of the resultant reduction in frost protection. DO NOT top-up or refill with conventional anti-freeze formulations. If in doubt consult a Land Rover retailer.

Brakes

BRAKE FLUID

WARNING

DO NOT drive if the reservoir fluid level is below the minimum mark.

Contact your retailer immediately if brake pedal travel is unusually long or if there is any appreciable drop in brake fluid level.

Brake fluid is highly toxic and could be fatal if swallowed - keep containers sealed and out of the reach of children. If accidental consumption of fluid is suspected, seek medical attention immediately.

If brake fluid should come into contact with the skin or eyes, rinse immediately with plenty of water.

Take care not to spill fluid onto a hot engine - a fire may result. Wipe up any spillage immediately.

CAUTION: Brake fluid will damage painted surfaces: Soak up any spillage with an absorbent cloth immediately and wash the area with a mixture of car shampoo and water.

IMPORTANT


Brake fluid must be completely renewed every 36,000 miles (60,000 km) or 36 months, whichever is the sooner.

Check

The fluid level may fall slightly during normal use as a result of brake pad wear but should not be allowed to fall below the 'MIN' mark. If there is any appreciable drop in level over a short period, consult your retailer. **DO NOT drive if the fluid level is below the minimum mark on the reservoir.**

With the vehicle on level ground, check the fluid level at least every week (more frequently in high mileage or arduous operating conditions). Check the level visually through the side of the transparent reservoir without removing the cap.

Top-up



Wipe the filler cap clean before removing, to prevent dirt from entering the reservoir. Unscrew the cap and top-up the reservoir to the 'MAX' mark using a recommended fluid.

Use only new fluid from an airtight container (old fluid from opened containers or fluid previously bled from the system will have absorbed moisture, which will adversely affect performance, and must NOT be used). **DO NOT OVERFILL!**

Brake fluid specification

Only use Shell Donax YB DOT 4 brake fluid or, if this is unavailable, use a brake fluid of the same specification.

Power Steering

POWER STEERING FLUID

WARNING


Power steering fluid is highly toxic and could be fatal if swallowed - keep containers sealed and out of reach of children. If consumption of fluid is suspected, seek medical attention immediately.

If power steering fluid should come into contact with the skin or eyes, rinse immediately with plenty of water.

Take care not to spill power steering fluid onto a hot engine - a fire may result. Wipe up any spillage immediately.

Check and Top-up

Check and top-up the fluid level **ONLY** when the engine is cold. You should also ensure that the front wheels are in the straight ahead position before stopping the engine and checking the fluid level.



H2346

Check the fluid level against the marks on the side of the reservoir.

If more fluid is needed, first wipe the filler cap clean to prevent dirt from entering the reservoir, then twist the cap a quarter turn anti-clockwise and pull to remove.

Top up the reservoir to the upper level mark using a recommended fluid. **DO NOT OVERFILL!**

CAUTION: Power steering fluid will damage painted surfaces: Soak up any spillage with an absorbent cloth immediately and wash the area with a mixture of car shampoo and water.

Emergency operation

Any large or sudden drop in the fluid level must be investigated by a qualified retailer.

If it can be established that fluid loss is slow, then the reservoir may be topped-up to the upper level mark to enable the vehicle to be driven to the nearest qualified retailer for examination.

If the fluid level has dropped below the lower level mark, top-up the reservoir before starting the engine, or damage to the steering pump could result.

Fluid specification

Only use fluids to Dexron IID or III specification.


Oils manufactured to the above specifications are suitable for use in temperatures between -4°F to $+86^{\circ}\text{F}$ (-20°C to $+30^{\circ}\text{C}$). If climatic temperature falls outside these limits, seek advice from your retailer.

NOTE: The colour of commercially available fluids may differ from that of the power steering fluid used to fill the system during manufacture. This is not cause for concern.

Washers

WINDSCREEN WASHERS

Fluid top-up



The windscreen washer reservoir supplies both front and rear screen washer jets.

Check the reservoir level at least every week and to prevent freezing in cold weather, top-up with a mixture of water and a recommended screenwash.

Preferably mix the recommended quantities of water and screenwash in a separate container before topping-up the system, and always follow the instructions on the screenwash container.

CAUTION: DO NOT use an anti-freeze or vinegar/water solution in the washer reservoir - anti-freeze will damage painted surfaces, while vinegar can damage the windscreen washer pump.

Screenwash

Use Land Rover Parts STC8249 screenwash, or any good quality proprietary screenwash.

WARNING

Some screenwash products are inflammable, particularly if high or undiluted concentrations are exposed to sparking. Do not allow screenwash to come into contact with naked flames or sources of ignition.

NOTE: Body panels may suffer discoloration as a result of screenwash spillage. Take care to avoid spillage, particularly if an undiluted or high concentration of screenwash is being used. If spillage occurs, wash the affected area immediately with water.

Washer jets

Operate the washer switches periodically to check that the nozzles are clear and properly directed.

The windscreen washer jets are set during manufacture and should not need adjusting. However, if adjustment is ever necessary, insert a needle into the jet orifice and lever gently to position each jet so that the spray is directed towards the centre of the windscreen.

Should a windscreen washer jet become obstructed, insert a needle or thin strand of wire into the orifice to clear the blockage.

NOTE: The rear screen washer jet is integral with the wiper arm and requires no adjustment.


Wiper Blades

WIPER BLADE REPLACEMENT

IMPORTANT

- Grease, silicone and gasoline based products impair the blade's wiping capability. Wash the wiper blades in warm soapy water and periodically check their condition.
- If signs of hardness or cracking in the rubber are found, or if the wipers leave streaks or unwiped areas on the windscreen during use, then the wiper blades should be replaced.
- Clean the windscreen regularly with an approved glass cleaner and ensure the screen is thoroughly cleaned before fitting replacement wiper blades.

Front wiper blades




H3457

Lift the wiper arm away from the windscreen. With the blade at 90° to the arm as shown, disconnect the blade by pushing in the locking tab (1) and sliding the blade (2) down the arm (3).

Fitting a replacement blade is a reversal of this process; position the new blade assembly on the wiper arm and slide the blade fully towards the hooked end of the arm until it locks in place. Check that the blade is securely locked before returning the wiper assembly to the windscreen.

Only fit replacement wiper blades that are identical to the original specification.

Rear wiper blades



H3458

Lift the wiper arm away from the rear screen, as far as the spare wheel carrier will allow. Pivot the blade assembly away from the arm (as arrowed), levering against resistance, until the two retaining lugs detach from their slots at the end of the arm. Carefully replace the arm to its stowed position.

To replace, position the wiper arm into the aperture in the middle of the blade assembly, line up the retaining lugs with the corresponding slots in the wiper arm and push firmly into position until the blade clips into place.

Battery

BATTERY SAFETY

WARNING

Always wear eye protection when working around batteries.

Batteries contain sulphuric acid, which is both corrosive and poisonous. If spillage occurs:

- *On clothing or the skin - remove any contaminated clothing immediately, flush the skin with large amounts of water, and seek medical attention urgently.*
- *In the eyes - flush with clean water immediately for at least 15 minutes. Seek medical attention urgently.*
- *Swallowing battery acid can be fatal unless IMMEDIATE action is taken - seek medical attention urgently.*


During normal operation batteries emit explosive hydrogen gas - to avoid fire, ensure sparks and naked lights are kept away from the engine compartment.

For your safety, remove all metal wrist bands and jewellery before working in the engine compartment and NEVER allow the battery terminals or vehicle leads to make contact with tools or metal parts of the vehicle.

WARNING

Battery posts, terminals, and related accessories contain lead and lead compounds. Wash hands after handling.

BATTERY MAINTENANCE



The battery is designed to be maintenance free, so topping-up is unnecessary. On the top of the battery there is a battery condition indicator (arrowed in illustration). Examine the indicator periodically to check the battery's condition. When the indicator shows:

- GREEN - the battery is in a good state of charge.
- DARK (turning to black) - the battery needs charging.
- CLEAR (or light yellow) - the battery must be replaced. Do not charge the battery or push start the vehicle in this condition.

NOTE: *If necessary, clean the battery top to ensure a clear view. Use a flashlight if natural light is poor.*

If the indicator shows clear or yellow, tap the indicator with the handle of a screwdriver to disperse any air bubbles. If the colour is unchanged, the battery must be replaced.

Battery

Battery removal and replacement

IMPORTANT

- Do not reverse the polarity of the battery - the electrical system may be damaged if the battery leads are connected to the wrong terminals.
- DO NOT run the engine with the battery disconnected, or disconnect the battery while the engine is running.
- Keep the battery upright at all times - damage will be caused if the battery is tilted more than 45 degrees.
- DO NOT disconnect the battery when the security system is armed.

Before disconnecting the battery, disarm the alarm, and ensure that the starter switch and all electrical equipment is turned off.

To remove: disconnect the negative ('-') cable first and then the positive ('+') cable. When reconnecting, connect the positive cable first and then the negative cable. Do not allow the battery terminals to make contact with metal parts of the vehicle.

To release the battery from the vehicle, undo the bolt and remove the battery clamping plate (see illustration).

When replacing, ensure the battery is fitted the right way round (terminal posts towards the rear of the vehicle) and that the clamping plate is secure. Tighten the clamping plate bolt until the clamping plate is free from movement (maximum torque 12 Nm (9 lbf.ft). Do not overtighten.

Battery disposal



Used batteries should be recycled.

However, batteries are hazardous - you should seek advice about disposal from a Land Rover retailer or your local authority.

Replacement batteries

Only fit a replacement battery of the same type and specification as the original - other batteries may vary in size or have different terminal positions which could cause a fire hazard when connected to the vehicle's electrical system. Contact a Land Rover retailer for suitable replacements.

Battery

Battery charging

WARNING

Batteries generate explosive gases, contain corrosive acid and produce levels of electric current sufficient to cause serious injury.

While charging always heed the following precautions:

- **Before charging, disconnect and remove the battery from the vehicle - charging the battery with the cables connected may damage the vehicle's electrical system.**
- **Make sure the battery charger leads are securely clamped to the battery terminals BEFORE switching on the battery charger. Do not move the leads once the charger is switched on.**
- **While charging, shield your eyes or avoid leaning over the battery and keep the area around the top of the battery well ventilated.**
- **Do not allow open flame and/or incandescent lamps near the battery (batteries generate inflammable hydrogen during and after charging).**
- **If the battery is fitted with a condition indicator, the indicator shows GREEN when the battery is charged sufficiently. When charging is finished, switch off the battery charger BEFORE disconnecting the leads from the battery terminals.**

After charging, leave the battery for an hour BEFORE reconnection to the vehicle - this will allow time for explosive gases to disperse, thereby minimising the risk of fire or explosion.

As the battery ages, it may not retain its charge as effectively as when it was new. Vehicles that are used infrequently, or are used excessively for short journey motoring, or operation in cold climates, may need the battery to be charged regularly.

Always check the battery condition indicator before charging.

NOTE: Be aware that a battery will take longer to charge in a cold environment.

IMPORTANT INFORMATION

DO NOT attempt to charge the battery if the battery condition indicator is clear or light yellow.

DO NOT charge the battery if it is suspected of being frozen.

CAUTION: DO NOT charge the battery if it is connected to the vehicle - this may seriously damage the vehicle's electrical system.

THE EFFECTS OF BATTERY DISCONNECTION

Some of the vehicle's electrical systems will be affected if the battery is disconnected. These are listed below, together with the symptoms you might experience once the battery is reconnected and the actions required to restore operation.

Radio/cassette player

After battery disconnection, the radio code may be lost and the set fail to operate; this will be apparent from the message appearing in the display. To restore operation, enter the security code using the procedure described in the *'In-car Entertainment' book*.

Taildoor glass

If the battery has been disconnected, the taildoor glass will need to be recalibrated. If the alarm was armed when the battery was disconnected (or discharged), disarm the alarm after battery reconnection - the taildoor glass will fully lower. This will happen automatically if the alarm was in a disarmed state when the battery was disconnected.

After battery reconnection, fully raise the taildoor glass (if the glass is not fully raised, an error 'beep' will sound) - the taildoor glass is now recalibrated.

Alarm system

The alarm system will automatically reset to the status in operation prior to battery disconnection, but the handset will need to be resynchronised (see *'Handset resynchronisation'*, page 27).

Clock

The clock will need to be reset to the correct time, see *'CLOCK'*, page 68.

CARING FOR YOUR TYRES

WARNING

Do not drive if any tyre is damaged, is excessively worn, or is inflated to an incorrect pressure.

ALWAYS replace worn or defective tyres with the factory recommended specification (see 'WHEELS & TYRES', page 186). Failure to do so may affect the safe handling of the vehicle.

Always drive with consideration for the condition of the tyres, and regularly inspect the tread and side walls for any sign of distortion (bulges), cuts or wear.

The most common causes of tyre failure are:

- Bumping against kerbs
- Driving over deep potholes in the road
- Driving with under or over-inflated tyres

NOTE: *If possible, protect tyres from contamination by oil, grease, gasoline and other automotive fluids.*

Tyre pressures

Correctly inflated tyres will ensure that you enjoy the best combination of tyre life, ride comfort, fuel economy and road handling.

Under-inflated tyres wear more rapidly, can seriously affect the vehicle's road handling characteristics and fuel consumption, as well as increasing the risk of tyre failure.

Over-inflated tyres give a harsher ride, wear unevenly and are more prone to damage.

Tyre pressures should be checked at least once a week with normal road use, but should be checked DAILY if the vehicle is used off-road.

Check the pressures (including the spare wheel) when the tyres are cold - be aware that air pressure naturally increases in warm tyres and it only takes a mile (1.6 km) of driving to warm up the tyres sufficiently to affect the tyre pressures.



If it is necessary to check the tyres when they are warm (after the vehicle has been driven for a while), you should expect the pressures to have increased between 4 and 6 lbf/in² (0.3 and 0.4 kgf/cm²). In this circumstance, DO NOT let air out of the tyres in order to match the recommended pressures.

CAUTION: If the vehicle has been parked in strong sunlight or used in high ambient temperatures, DO NOT reduce tyre pressures; instead, move the vehicle into the shade and allow the tyres to cool before checking.

The recommended pressures for cold tyres are shown in the Technical Data section.

Tyres

Tyre wear



H3460

The tyres fitted as original equipment to your vehicle have wear indicators moulded into the tread pattern. When the tread has worn down to 1/16 inch (1.6 mm) the indicators start appearing at the surface of the tread pattern, producing the effect of a continuous band of rubber across the width of the tyre.

A tyre **MUST** be replaced as soon as an indicator band becomes visible or the tread depth reaches the minimum permitted by legislation.

NOTE: If tyre wear is uneven (on one side of the tyre only) or becomes abnormally excessive, the wheel alignment should be checked by your retailer.

Tread depth must be checked regularly (at every maintenance service, or more frequently). Always replace a tyre before the tread reaches a remaining depth of 1/16 inch (1.6 mm). **DO NOT** drive with tyres worn to this limit because the safety of the vehicle and occupants will be adversely affected.

NOTE: After off-road use, check to make sure there are no lumps or bulges in the tyres or exposure of the ply or cord structure.

Valves

Keep the valve caps screwed down firmly - they prevent dirt from entering the valve. Check the valve for leaks (listen for a tell-tale hissing) when you check the tyre pressure.

Punctured tyres

Your vehicle is fitted with tubeless tyres, which may not leak if penetrated by a sharp object, provided the object remains in the tyre. If you are aware of this occurring, reduce speed immediately and drive with caution until the spare wheel can be fitted.

A puncture of this kind will eventually cause the tyre to lose pressure, which is why regular (and frequent) checking of tyre pressures is important. Punctured or damaged tyres must be permanently repaired or replaced as soon as possible - if in doubt, seek expert advice.

DO NOT DRIVE WITH A PUNCTURED TYRE!

Tyres

Replacement tyres

Wheel rims and tyres are matched to suit the handling characteristics of the vehicle. For safety, ALWAYS check that replacement tyres comply with the original specification shown in 'WHEELS & TYRES', page 186, later in this handbook and that the load and speed ratings shown on the side wall are the same as that of the original equipment. Contact your Land Rover retailer for further information or assistance.

Ideally, tyres should be replaced as sets of four, but if this is not possible, replace the tyres as axle sets. When replacing tyres in axle sets, always fit the new tyres to the rear axle.

WARNING

ALWAYS use the same type of radial-ply tyres front and rear. DO NOT use cross-ply tyres, or interchange tyres from front to rear. Make sure that all replacement tyres are of the same size, type, load carrying capacity and tread design as original equipment tyres.

Your vehicle is fitted with road wheels that will NOT accept inner tubes. DO NOT fit a tubed tyre.

DO NOT replace wheels with any type other than genuine Land Rover parts. Wheels and tyres are designed for both off-road and on-road use and have a very important influence on vehicle handling. Alternative wheels which do not meet original equipment specifications should not be fitted.

Always have the wheels and tyres re-balanced after replacing.

UNIFORM TYRE QUALITY GRADING

Quality Grades can be found where applicable on the tyre sidewall between tread shoulder and maximum section width. For example:

Treadwear 200	Traction AA	Temperature A
---------------	-------------	---------------

Tyres that are deep tread, winter-type snow tyres are exempt from the marking requirements as described above.

Consequently, the tyres fitted to your vehicle may not carry these markings.

All passenger car tyres must conform to Federal Safety Requirements in addition to these grades.

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tyre when tested under controlled conditions on a specified government test course. For example; a tyre graded 150 would wear one and one-half (1½) times as well on the government course as a tyre graded 100. However, the relative performance of tyres depends upon the actual conditions of their use, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction

The traction grades, from highest to lowest, are AA, A, B and C. The grades represent a tyre's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tyre marked 'C' may have poor traction performance.

WARNING

The traction grade assigned to this tyre is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Temperature

The temperature grades A (the highest), B, and C, represent a tyre's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperatures can cause the material of a tyre to degenerate and reduce tyre life, and excessive temperature can lead to sudden tyre failure.

The grade 'C' corresponds to a level of performance which all passenger car tyres must meet under the Federal Motor Safety Standard No 109.

Grades 'B' and 'A' represent higher levels of performance on the laboratory test wheel than the minimum required by law.

WARNING

The temperature grade for this tyre is established for a tyre that is properly inflated and not overloaded. Excessive speed, under inflation, or excessive loading, either separately or in combination can cause heat buildup and possible tyre failure.

SNOW CHAINS

Snow chains are designed for use on roads in extreme conditions only, and are not recommended for off-road use. If it is necessary to fit snow chains to your vehicle, ALWAYS observe the following:


- ONLY Land Rover approved chains should be used - these are designed for your vehicle and will eliminate any risk of damage to other components.
- Always adhere to the snow chain fitting and retensioning instructions, and the speed limitations recommended for varying road conditions. NEVER exceed 30 mph (50 km/h).
- Avoid tyre damage by removing the chains as soon as the road is free from snow.

For further information about approved snow chains, consult your Land Rover retailer.

CAUTION: DO NOT fit unapproved snow chains - this could damage brake components, and seriously affect the vehicle's ability to stop, potentially resulting in occupant or third party injury.

Cleaning & Vehicle Care

WASHING YOUR VEHICLE



H3461

WARNING

Read individual product warnings before using any cleaning or washing products.

CAUTION: Some high pressure cleaning systems are sufficiently powerful to penetrate door and window seals and damage rubbing strips and locking mechanisms. Never aim the water jet directly at heater air intakes, body and sunroof seals, or at any components that might easily be damaged.

If the vehicle is particularly dirty, use a hose to flush grime and grit from the painted surfaces, prior to washing. Then, wash the vehicle using cold or lukewarm water containing a good quality wash and wax shampoo. Always use plenty of water to ensure that grit is flushed from the surface and not ground into the paintwork. After washing, rinse the vehicle with clean water and dry off with a chamois leather.

- Do not use hot water!
- Do not use detergent soap products or washing-up liquid!
- In hot weather, do not wash the vehicle in direct sunlight.

When using a hose, do not direct the jet into the heater air intake ducts, or through the wheel trim apertures onto the brake components, or at the door, window or sunroof seals.

Automatic car wash

If using an automatic car wash remove the radio aerial before entering the car wash.

Removing tar spots

Use mineral spirit or turpentine to remove tar spots and stubborn grease stains from paintwork. Then wash immediately with soapy water to remove all traces of spirit.

Underbody maintenance

Corrosive materials used for snow and ice removal and dust control can collect on underbody parts. If these materials are not removed, accelerated rusting can occur. Use a hose to regularly flush the underbody with plain water, taking particular care to thoroughly clean those areas where mud and other debris can easily collect.

Similarly, after off-road driving or wading in muddy or salt water conditions, use a hose to wash underbody components and other exposed parts of the vehicle.

Cleaning & Vehicle Care

Engine compartment

The engine compartment must only be cleaned by steam cleaning.

CAUTION: DO NOT use a high pressure hose to clean the engine compartment - damage to the vehicle's electronic systems may occur.

Steam cleaning

Before steam cleaning the engine compartment, cover the power steering reservoir to prevent contamination of fluid, and ensure the covers/seals protecting all the electrical components are in place. After steam cleaning carefully re-wax the metallic components, especially the steering column, engine coolant pipes, hose clips and the ignition coil clamp, to prevent corrosion.

CAUTION: DO NOT direct high temperature, or high pressure, steam or water onto electrical wiring and components.

Body protection

After washing, inspect the paintwork for damage. Any stone chips, fractures or deep scratches in the bodywork should be repaired promptly. Bare metal will corrode quickly and can develop into major repair expense.

Minor chips and scratches can be repaired with touch-up materials available from your retailer. Larger areas of damage need to be corrected to professional standards immediately.

Polishing

Occasionally treat the paint surface with an approved polish containing the following properties:

- Very mild abrasives to remove surface contamination without removing or damaging the paint.
- Filling compounds that will fill scratches and reduce their visibility.

- Wax to provide a protective coating between the paint and the elements.

NOTE: DO NOT apply wax polish to the bumper mouldings - polish will become ingrained in the textured finished.

Windows and mirrors

Regularly clean all windows and mirrors, inside and out, using an approved glass cleaner.

Windscreen: In particular, clean the outside of the screen with glass cleaner after washing the vehicle with wash and wax products, and before fitting new wiper blades.

Rear screen: Clean the inside with a soft cloth, using a side to side motion to avoid damaging the heating elements. DO NOT scrape the glass or use abrasive cleaners - this will damage the heating elements.

Mirrors: Wash with soapy water. Use a plastic scraper to remove ice. DO NOT use abrasive cleaners or metal scrapers.

Wiper blades

Wash in warm soapy water. DO NOT use spirit or gasoline-based cleaners.

Cleaning & Vehicle Care

CLEANING THE INTERIOR

WARNING

Read individual product warnings before using any cleaning or washing products.

Plastic materials

Clean plastic-faced or cloth covered surfaces with diluted upholstery cleaner and wipe with a clean cloth.

NOTE: *DO NOT polish fascia components - for safety, these should remain non-reflective.*

Leather

Leather seats, steering wheel and trim features should be cleaned with warm water and a non-detergent soap. Dry and polish the leather with a dry, lint-free cloth.

NOTE: *DO NOT use gasoline, detergents, furniture creams or polishes!*

Carpet and fabrics

Clean with diluted nylon upholstery cleaner - test a concealed area first.

Instrument pack, clock and radio

Use a clean cloth which has been moistened slightly with water.

CAUTION: Do not use chemicals or household cleaners. Keep fluids and liquids of all kinds away from the radio.

Fascia mounted rubber mats

The mats are removable for cleaning - replace with care.

Seat belts

Extend the belts, then use warm water and a non-detergent soap to clean. Allow the belts to dry naturally, and do not retract them or use the vehicle until they are completely dry.

CAUTION: DO NOT use bleaches, dyes or cleaning solvents on seat belts.

Airbag module covers

To prevent airbag SRS damage, the steering wheel centre pad and area of the fascia panel containing the passenger airbag should **ONLY** be cleaned sparingly with a damp cloth and upholstery cleaner.

DO NOT allow these areas to be flooded with liquid, and DO NOT use petrol, detergent, furniture cream or polishes.

Identification Numbers

CONTACTING YOUR retailer

When communicating with your retailer, always quote the Vehicle Identification Number (VIN). If your communication concerns the engine or gearbox, it may be necessary to quote these numbers as well.


IDENTIFICATION NUMBER LOCATIONS

1. Vehicle identification number (VIN)
2. Engine Number

Stamped vertically into the right side of the cylinder block (when viewed from the front).

3. Gearbox number

On a label attached to the upper face of the gearbox housing.




H3527

VEHICLE IDENTIFICATION NUMBER

The VIN (and recommended maximum vehicle weights) is stamped on a label at the foot of the driver's door pillar and also stamped into the bulkhead, at the top, inside the engine compartment. In addition, as a deterrent to car thieves and to help the police, the VIN is stamped into a plate, visible at the bottom left hand corner of the windscreen.

GVWR - 2060 KG (4544 LB) GAWR FRONT - 1080 KG (2382 LB) WITH 195/80R15 TIRES. 5.5JX15 RIMS AT 207 KPA (30 PSI) COLD OR WITH 215/65R16 TIRES. 6.0JX16 RIMS AT 207 KPA (30 PSI) COLD OR WITH 225/55R17 TIRES. 7.0JX17 RIMS AT 207 KPA (30 PSI) COLD	GAWR REAR - 1120 KG (2470 LB) WITH 195/80R15 TIRES. 5.5JX15 RIMS AT 207 KPA (30 PSI) COLD OR WITH 215/65R16 TIRES. 6.0JX16 RIMS AT 207 KPA (30 PSI) COLD OR WITH 225/55R17 TIRES. 7.0JX17 RIMS AT 207 KPA (30 PSI) COLD
--	---



MFD IN THE UK BY LAND ROVER GVWR - 2060 KG (4544 LB) GVWR-FRONT-1080 KG (2382 LB). REAR-1120 KG (2470 LB) THIS VEHICLE CONFORMS TO ALL APPLICABLE U.S.A. FEDERAL MOTOR VEHICLE SAFETY AND THEFT PREVENTION STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE.	DATE 10:10:01
VIN SALNY22242A333056	TYPE MPV
	PAINT 644 TRIM Q

H4252

Parts & Accessories

PARTS AND ACCESSORIES

Your vehicle has been designed, built and tested to cope with a variety of off-road driving conditions, some of which can place the severest possible demands on control systems and components. As such, fitting replacement parts and accessories that have been developed and tested to the same stringent standards as the original components will safeguard the continued reliability, safety and performance of your vehicle.

To augment the vehicle's already impressive performance, a comprehensive range of Land Rover-approved spare parts and accessories is available, enabling the vehicle to fulfil a wide variety of roles, and enhancing and protecting the vehicle in the many tasks to which it can be applied.

Land Rover parts are the only parts built to original equipment specifications AND approved by Land Rover designers; this means that every single part and accessory has been rigorously tested by the same engineering team that designed and built the vehicle and, with the exception of maintenance items that are designed to be replaced sooner, is warranted as provided in the Passport to Service.

A full list and description of all accessories is available from your Land Rover retailer.

WARNING

DO NOT fit unapproved accessories or conversions, as they could affect the safety of the vehicle.

Land Rover will not accept any liability for death, personal injury or damage to property which may occur as a direct result of fitment of non-approved accessories or the carrying out of non-approved conversions to Land Rover vehicles.

Land Rover North America Inc. strongly advises against making any modifications to the suspension or steering system. This could seriously affect the handling and stability of the vehicle leading to loss of control or rollover.

Parts & Accessories

Electrical equipment

WARNING

The proper operation of the electrical, fuel and SRS airbag systems on your vehicle is very important. Do not fit or replace parts or accessories, the installation of which requires the dismantling of or addition to any of these systems

ALWAYS consult a Land Rover retailer before fitting any electrical accessory.

Fitting inferior quality parts or accessories may be dangerous and could invalidate the vehicle warranty.

It is recommended that you always consult a Land Rover retailer for advice regarding the approval, suitability, installation and use of any parts or accessories before fitting.

Travelling abroad

In certain countries, it is illegal to fit parts which have not been made to the vehicle manufacturer's specification.

Owners should ensure that any parts or accessories fitted to the vehicle while travelling abroad will also conform to the legal requirements of their own country when they return home.

SRS/Airbag

WARNING

The components that make up the SRS/airbag are sensitive to electrical or physical interference, either of which could easily damage the system and cause inadvertent operation or a malfunction of the airbag module.

To prevent any SRS/airbag malfunction, ALWAYS consult a Land Rover retailer before fitting any of the following:

- *Electronic equipment such as a mobile phone, two-way radio or in-car entertainment system.*
 - *Accessories attached to the front of the vehicle.*
 - *Any modification to the front of the vehicle.*
 - *Any modification involving the removal or repair of any wiring or component in the vicinity of any of the SRS components (yellow wiring harness), including: the steering wheel, steering column, instrument and fascia panels.*
 - *Any modification to the fascia panels or steering wheel.*
-

Emergency Information

Wheel Changing

TOOL KIT	161
SPARE WHEEL.....	162
JACKING	163
CHANGING A WHEEL.....	164

Emergency Starting

STARTING WITH A DISCHARGED BATTERY ...	165
BATTERY SAFETY	166

Towing The Vehicle

TOWING EYES	167
TOWING FOR RECOVERY	167
LONG DISTANCE/MOTORHOME TOWING.....	168
TRANSPORTER OR TRAILER LASHING.....	168

Fuses

FUSES	169
MAIN FUSE BOX	169
ENGINE COMPARTMENT FUSE BOX	171
SUPPLEMENTARY FUSE BOX	172





Bulb Replacement

REPLACING BULBS	173
HEADLIGHT AND SIDELIGHT	174
FRONT DIRECTION INDICATOR	175
SIDE REPEATER LIGHT	175
SIDE MARKER LIGHTS (front and rear)	176
REAR LIGHT CLUSTER (Reverse & fog/tail lights)	176
REAR BUMPER MOUNTED LIGHTS (Rear direction indicator & tail/stop lights)	177
HIGH MOUNTED STOP LIGHT	177
NUMBER PLATE LIGHTS	178
FRONT COURTESY & MAP READING LIGHTS	178
REAR COURTESY LIGHT	179
GLOVEBOX LIGHT	180
LOADSPACE LIGHT	180
VANITY MIRROR LIGHT	181

Wheel Changing

TOOL KIT



H3492

The tool kit is contained in a toolbox located in the rear loadspace storage box. To remove the toolbox from the storage box, unscrew the restraining clamp.

To open the toolbox, lift the two catches.


NOTE: When not in use, the tools should always be returned to the toolbox, and the toolbox should be securely clamped in the storage box.

Only tighten the restraining clamp to ‘finger’ tightness, when making the toolbox secure.

WARNING

DO NOT drive with the tools or toolbox loose in the vehicle. In the event of a collision they could become dangerous projectiles and cause serious personal injury.

Tools



H3497

The tool kit contains the jack, wheel chock, and wheel wrench.

The wheel chock is designed to fold flat and must be assembled, as shown in the illustration, before use.

Care of the jack


Examine the jack occasionally and clean and grease the moving parts.

Always close the jack and return the jack to the toolbox when not in use.

Wheel Changing

SPARE WHEEL

Removing the spare wheel



Use the wheel nut wrench supplied in the tool kit to remove the nuts securing the spare wheel to the carrier and then lift off the wheel.

WARNING

DO NOT use the spare wheel securing nuts in place of the road wheel nuts, or use the road wheel nuts to secure the spare wheel - the nuts are not inter-changeable.

The wheels are extremely heavy. Take care when lifting and particularly when removing the spare wheel from its mounting position on the tail door.

Refitting the spare wheel

Position the spare wheel on the carrier, then fit and tighten the nuts securing the spare wheel to the carrier.

Wheel Changing

JACKING

If possible, choose a safe place to stop away from the main thoroughfare. Always ask your passengers to get out of the vehicle and wait in a safe area away from other traffic.

NOTE: Switch on the hazard warning lights to alert other road users.

Before changing a wheel, ensure the front wheels are in the straight ahead position, apply the handbrake and select 'P' (Park).


Turn off the starter switch and remove the key. Observe the following precautions:

- Ensure the jack is positioned on firm, level ground; NEVER on soft ground, or over metal gratings or manhole covers. DO NOT place additional material between the jack and the ground, this may jeopardise the safety of the jacking operation.
- Jacking on a slope is NOT recommended, but if it is unavoidable, chock the wheel diagonally opposite the one to be removed on the downhill side, using the chock provided in the tool kit.
- NEVER jack the vehicle with passengers inside or with a caravan or trailer connected!

WARNING

NEVER work beneath the vehicle with the jack as the only means of support. The jack is designed for wheel changing only!

Positioning the jack



Use the flat, wedge-shaped end of the wheel nut wrench to lever off the appropriate jacking point cover (1).

Position the jack with the base directly under the jacking point (2) nearest the wheel to be removed and with the handle dropping vertically towards the ground (3). Ensure the jack is positioned on firm, level ground.

Turn the jack screw clockwise to raise the jack until the jack head fits snugly around the centre of the jacking point.

NOTE: ONLY jack the vehicle using the jack location points described, or damage to the vehicle could occur. Under no circumstances should any part of the undertray assembly be used as a jacking point.

Wheel Changing

CHANGING A WHEEL

WARNING

Avoid accidental contact with any underbody parts, especially hot exhaust components.

Removing

1. Use the wheel nut wrench to slacken the wheel nuts half a turn anti-clockwise.
2. Turn the jack handle clockwise to raise the vehicle until the tyre is clear of the ground.
3. Remove the wheel nuts and place to one side to prevent them from being lost.
4. Remove the road wheel.

NOTE: Avoid placing wheels face down on the ground. This may scratch the alloy surface.

Refitting

1. Before fitting a wheel, ensure that the mating faces of the hub and wheel are clean and free from rust or anti-seize compound - any accumulation of dirt or rust could cause the wheel nuts to become loose and result in an accident. Use an approved anti-seize compound to treat the wheel mounting spigot. This will minimise the tendency for adhesion between wheel and spigot. If this is not practicable at the time of the wheel change, refit the spare wheel for the time being, but remove and treat the wheel at the earliest opportunity. Ensure that no compound comes into contact with brake components or the flat mounting surfaces of the wheel.
2. Fit the spare wheel and lightly tighten the wheel nuts (domed side towards the wheel) until the wheel is firmly seated against the hub.
3. Ensure that the space under and around the vehicle is free from obstructions, then lower the vehicle and remove the jack.


4. Fully tighten the wheel nuts in an alternating pattern until all are tightened. **DO NOT OVERTIGHTEN** by using foot pressure or extension bars on the wheel nut wrench, as this could overstress the wheel studs.
5. Refit the jacking point cover.
6. Fit the replaced wheel to the spare wheel carrier (see '*Refitting the spare wheel*', page 162).
7. Return the tools to the toolbox and secure the toolbox to its bracket in the lockable stowage box in the rear loadspace.

WARNING

Always check the tyre pressure after changing a wheel, and have the tightness of the wheel nuts checked by a retailer as soon as possible!

Emergency Starting

STARTING WITH A DISCHARGED BATTERY



H4008

- A. Disabled vehicle
- B. Donor vehicle
- C. Engine earth point

Using booster cables (jump leads) from a donor battery, or a battery fitted to a donor vehicle, is the only approved method of starting a vehicle with a discharged battery. Push or tow starting is NOT possible!

If the battery is completely discharged (battery condition indicator shows CLEAR), it may not be possible to start the engine using booster cables. In this case, a replacement battery must be fitted.

WARNING

Before using booster cables, ensure that you are familiar with the information shown under 'BATTERY SAFETY', page 166.

Emergency Starting

Always adopt the following procedure:

If a donor vehicle is to be used, both vehicles should be parked with their battery locations adjacent to each other. Ensure that the two vehicles do not touch.

Apply the parking brakes and ensure that the transmission of both vehicles is set in neutral ('P' or Park for vehicles with automatic transmission).

Turn off the starter switch and ALL electrical equipment of BOTH vehicles.

Connect the RED booster cable between the positive (+) terminal of the donor battery and the positive (+) terminal of the discharged battery.

Connect the BLACK booster cable from the negative (-) terminal of the donor battery to a good earth point (eg. an engine mounting or other unpainted surface) at least 0.5m from the battery and well away from fuel and brake lines on the disabled vehicle (refer to inset 'C' on the previous page).

WARNING

For safety reasons:

- **DO NOT connect a booster cable to the negative (-) terminal of the discharged battery! If in doubt, seek qualified assistance.**
- **ENSURE that each connection is securely made and that there is no risk of the clips accidentally slipping or being pulled from the battery terminals - this could cause sparking, which could lead to fire or explosion.**

Check that the cables are clear of any moving parts of both engines, then start the engine of the donor vehicle and allow it to idle for a few minutes. Now start the vehicle with the discharged battery (DO NOT crank the engine for more than 15 seconds).

Once both engines are running normally, allow them to idle for two minutes before switching off the engine of the donor vehicle. DO NOT switch on any electrical circuits on the previously disabled vehicle until AFTER the booster cables have been removed.

Disconnect the booster cables in an EXACT reversal of the procedure used to connect them, ie: disconnect the BLACK cable from the earth point on the disabled vehicle FIRST.

BATTERY SAFETY

WARNING

- **Always wear appropriate eye protection when working with batteries.**
 - **During normal use, batteries emit explosive hydrogen gas sufficient to cause severe explosions capable of causing serious injury - keep sparks and naked lights away from the engine compartment.**
 - **DO NOT attempt to start the vehicle if the battery is suspected of being frozen.**
 - **Make sure BOTH batteries are of the same voltage (12 volts), and that the booster cables have insulated clamps and are approved for use with 12 volt batteries.**
 - **DO NOT disconnect the discharged battery.**
 - **DO NOT connect positive (+) terminals to negative (-) terminals, and ensure booster cables are kept away from any moving parts in the engine compartment.**
 - **Take care when working near rotating parts of the engine.**
 - **ENSURE that each connection is securely made and that there is no risk of the clips accidentally slipping or being pulled from the battery terminals - this could cause sparking, which could lead to fire or explosion.**
-


Towing The Vehicle

TOWING EYES

WARNING

The towing eyes at the front and rear of the vehicle are designed for vehicle recovery purposes only and must NOT be used to tow a trailer or caravan. Excessive force should not be used when being recovered, or when recovering other vehicles using the towing eyes.

Front




H3470A

A single towing eye, set in the front spoiler is provided for use **ONLY** when the vehicle is to be towed with all four wheels on the ground.

DO NOT use the front lashing ring for towing purposes.

Rear



H3471

A single towing eye is provided at the rear of the vehicle for use **ONLY** when towing another vehicle.

TOWING FOR RECOVERY

Most vehicle recovery specialists will load your vehicle onto a trailer. However, if it is necessary to recover the vehicle by towing with all four wheels on the ground, observe the following procedure:

CAUTION: To avoid serious damage to the transmission, towing distance must be limited to a maximum of 50 miles.

1. Secure the towing attachment from the recovery vehicle to the front towing eye of the vehicle to be recovered.
2. With the parking brake applied and gear selector position 'P' (Park) selected, insert the key and turn the starter switch to position 'I' to unlock the steering.
3. Place the gear selector lever in 'N' (Neutral).
4. If it is necessary for the brake lights, wipers and direction indicators to be operated, turn the starter switch to position 'II'.
5. Release the parking brake.

NOTE: If, due to an accident or electrical fault, it is not considered safe to turn the starter switch, the battery should first be disconnected.

Towing The Vehicle

WARNING

DO NOT allow the vehicle to be towed further than 50 miles (80 km) and restrict towing speed to 30 mph (50 km/h).

CAUTION: DO NOT tow the vehicle unless the starter switch is turned to position 'I' or 'II' (to unlock the steering).

CAUTION: DO NOT turn the starter switch to position 'O', or attempt to remove the key, while the vehicle is in motion.

Suspended tow


If it is necessary to tow your vehicle on two wheels (ie: suspended from a recovery vehicle), it is essential that the propeller shaft connected to the axle that is to remain on the ground is disconnected by qualified personnel, prior to being towed.

CAUTION: If the rear axle is to be raised, the steering wheel and/or linkage **MUST** be secured in a straight ahead position, but the steering lock **MUST NOT** be used for this purpose. The vehicle can then be attached to the towing truck.

LONG DISTANCE/MOTORHOME TOWING

CAUTION: Your Feelanders is not suitable for being towed on four wheels for distances exceeding 50 miles, as this will seriously damage the transmission of the vehicle.

TRANSPORTER OR TRAILER LASHING



H3472

Lashing rings are fixed to the underside of the vehicle, where shown in the illustration.

Under no circumstances should the vehicle be towed or recovered by lashing to the rear subframes. Serious damage to the subframe and body may occur.

WARNING

The lashing rings are for lashing only and must NOT be used for towing.

Fuses

Fuse specifications

Fuse number	Rating (amps)	Circuits protected
1	15	Rear screen washers, heated mirrors
2	15	Stop lights, reversing lights
3	20	Windscreen wash/wipe
4	25	Heater blower
5	10	Starter motor
6	10	Engine management
7	5	Anti-lock brakes
8	15	Direction indicators
9	15	Audio system
10	15	Cigar lighter*
11	10	Audio system
12	15	Sunroof*
13	20	Electric accessories socket
14	10	Interior lights, clock, electric mirrors, diagnostic socket
15	20	Central door locking
16	10	Sidelights - RH
17	10	Electric mirrors
18	15	Headlight main beam - RH
19	10	Alternator
20	15	Headlight main beam - LH
21	15	Front fog lights*
22	10	Rear fog guard lights
23	20	Rear screen demister
24	10	Headlight dipped beam - LH
25	10	Headlight dipped beam - RH
26	20	Window - rear LH
27	20	Window - rear RH
28	10	Sidelights - LH
29	20	Heated seats*
30	10	Rear screen wiper
31	20	Taildoor glass lift/drop
32	5	Engine immobilisation
33	25	Window - front LH
34	25	Window - front RH
35	10	Cruise control*, engine immobilisation
36	10	Airbag SRS - DO NOT REMOVE

Fuses

ENGINE COMPARTMENT FUSE BOX


WARNING

Batteries emit explosive hydrogen gas; ensure that sparks, flames and other ignition sources are kept away from the engine compartment.

Press the catch (arrowed in illustration) to release the cover.

Information on the underside of the cover identifies the fuses and their ratings. This information is also listed in the table below.

NOTE: Owners are advised against removing or replacing the fusible links and relays, identified on the underside of the fuse box lid as: FL (numbers 1 - 12) and R (numbers 1 - 7). Failure of any of these items should be investigated by a qualified technician.



The engine compartment fuse box is located on the left side of the engine compartment.

Fuse specification

Fuse number	Rating (amps)	Circuit protected
1	15	Engine management
2	20	Engine management
3	15	Engine management
4	15	Air conditioning, cooling fan, automatic transmission
5	20	Engine management
6	15	Horn
7	15	Hazard warning lights
8	30	Heater blower speed 4
9	10	Air conditioning
10	20	Fuel system

Fuses



SUPPLEMENTARY FUSE BOX*

WARNING

Batteries emit explosive hydrogen gas; ensure that sparks, flames and other ignition sources are kept away from the engine compartment.

An additional, supplementary fuse box is fitted to some vehicles, containing fuses for the heated front screen.

The fuse values are shown below.



H3959

Fuse specification for vehicles with a heated front screen

Fuse number	Rating (amps)	Circuit protected
1	30	LH heated front screen
2	30	RH heated front screen
3	7.5	Switch illumination
4	-	-

Bulb Replacement

REPLACING BULBS

Check the operation of all exterior lights before you use the vehicle.

IMPORTANT

Before replacing a bulb, always switch off the starter switch and appropriate lighting switch to prevent any possibility of a short circuit. Only replace bulbs with the same type and specification.

Halogen bulbs

Halogen bulbs are used for headlight dipped and main beams. This type of bulb may shatter in use if the glass has been scratched, or contaminated with oil or perspiration. Take care NOT to touch the glass with your fingers; always use a cloth to handle the bulb. If necessary, clean the glass with methylated spirits to remove fingerprints.


Replacement bulbs

Bulb	Watts
Headlights dipped/main beam	60/55
Side lights	5
Direction indicators	21
Side repeater lights	5
Side marker lights	3
Reverse & fog/tail lights	5/21
Tail/stop lights	5/21
High mounted stop light	21
Number plate light	5
Interior courtesy lights	10
Map reading lights	5
Glovebox light	5
Loadspace light	10
Vanity mirror light	3

NOTE: All bulbs must be rated at 12 volts

Bulb Replacement

HEADLIGHT AND SIDELIGHT



H2371A

The headlight and sidelight bulbs can be accessed from within the engine compartment.

1. Turn the circular plastic cover a quarter turn anti-clockwise and pull rearwards to remove.
2. Detach the electrical connector from the rear of the bulb.
3. Unhook the wire securing clip (arrowed in small inset) and pivot it away from the rear of the bulb.
4. Remove the bulb.

NOTE: When fitting the new bulb, ensure that the larger of the rectangular metal tabs is located in the upper recess.


CAUTION: During use, headlight bulbs may shatter if the glass has been scratched, or contaminated with oil or perspiration. DO NOT touch the glass. If handled, clean with methylated spirits and a clean cloth.

Sidelight bulb replacement

The sidelight holder is immediately adjacent to the headlight bulb. With the circular plastic cover removed, pull the bulb holder from the light unit and pull the bulb to remove.

Bulb Replacement

FRONT DIRECTION INDICATOR




The front direction indicator lights are reached through an access panel in the wheel arch liner. To release the panel:

1. Push the centre pin of the fixing into the fixing (as condition 'B' in upper inset).
2. Prise the fixing from the access panel.
3. Push the tab at the top of the access panel upwards (as arrowed in main illustration). This will enable the panel to be removed.
4. Reach into the recess and turn the bulb holder anti-clockwise to remove.
5. Twist the bulb anti-clockwise to release it from the bulb holder.

When replacing the access panel, insert the top first, then lower the panel so that the bottom edge slots onto the wheel arch liner.

To replace the fixing, push the centre pin out of the fixing (as condition 'C'), then locate the fixing through the access panel and into the wheel arch liner. Finally, push the centre pin into the fixing until it lies flush with the body of the fixing.

SIDE REPEATER LIGHT




Push the lens firmly towards the rear of the vehicle and withdraw the light unit from the wing.

Twist to release the bulb holder from the light unit, then pull the bulb from its socket.

When refitting the light unit, ensure that the little tabs (arrowed in illustration) are pointing towards the front of the vehicle.

Bulb Replacement

SIDE MARKER LIGHTS (front and rear)




H4249

Push the lens firmly towards the front of the vehicle to release the light unit from the bumper. Withdraw the light unit and twist the bulb holder anti-clockwise to release it from the lens. Pull the bulb from its socket.

When replacing, locate the metal spring (arrowed in illustration) end of the light unit into the aperture in the bumper, and push against spring pressure to enable the light unit to be refitted.

REAR LIGHT CLUSTER (Reverse & fog/tail lights)



H2323A

Remove the three Torx (size 20) screws securing the light unit to the body and withdraw the light unit.

Disconnect the electrical connectors from the light unit if necessary.


NOTE: Make sure that the twin filament bulb and bulb holder is fitted to the lower (red lens) section of the light unit. The single filament bulb and holder should be fitted to the upper reversing light section of the light unit.

Twist the bulb holder anti-clockwise to release from the light unit, then twist the bulb to remove from the holder.

NOTE: When refitting the light unit, ensure that the foam seal is correctly positioned between the light unit and body.

Bulb Replacement

REAR BUMPER MOUNTED LIGHTS (Rear direction indicator & tail/stop lights)




H3478

Remove the two Torx (size 20) screws securing the light unit to the rear bumper. Withdraw the unit from the bumper.

Twist the appropriate bulb holder anti-clockwise to release from the light unit, then twist the bulb to remove from the holder.

HIGH MOUNTED STOP LIGHT



H2358A


To gain access to the light unit, the taildoor glass needs to be lowered (see '*ELECTRIC TAILDOOR GLASS*', page 60).

Remove the 3 screws securing the front of the light unit to the surround and withdraw the light unit.

Twist the bulb holder anti-clockwise, then pull the bulb to remove.

Bulb Replacement

NUMBER PLATE LIGHTS




Remove both screws to release the light unit. Withdraw the light unit from its surround.

Twist the appropriate bulb holder anti-clockwise to release, then pull the bulb from the holder to remove.

FRONT COURTESY & MAP READING LIGHTS


Front courtesy light



Insert a small, flat-bladed screwdriver into the indent on one side of the centre lens (arrowed in illustration). Pry the centre lens from the light unit, then pull the bulb from the clips.

Bulb Replacement

Map reading lights




H4255

Remove the centre lens (as described on previous page) to reveal two Torx screws.

Remove both screws.

Use a larger flat-bladed screwdriver to prise the courtesy light unit from the headlining, then pull the bulbs to remove.

REAR COURTESY LIGHT




H3480

Insert a small flat-bladed screwdriver into the indent on the side of the lens and prise the lens from the light unit, then pull the bulb from the clips.

Bulb Replacement


GLOVEBOX LIGHT



H3482

Insert a small flat-bladed screwdriver (preferably with a short handle, due to limited access) into the indent (arrowed in illustration) on the narrow side of the light unit, and carefully prise the unit from the glovebox panel. Remove the bulb from the clips.

LOADSPACE LIGHT




H2305A

Insert a small flat-bladed screwdriver into the indent on one of the narrow sides of the lens (see arrow on illustration) and carefully prise the unit from the loadspace trim panel. Push and twist the bulb to remove.

Bulb Replacement

VANITY MIRROR LIGHT*



H3483

Using a small, flat-bladed screwdriver as a lever (see inset), prise the lens and mirror from the light unit. 'Spring' the bulbs free from the connectors to remove.

Bulb Replacement

Technical Data

Technical Data

ENGINES	185
ELECTRICAL	185
WHEELS & TYRES.....	186
TYRE PRESSURES.....	186
CAPACITIES.....	187
DIMENSIONS.....	187
STEERING GEOMETRY	188
VEHICLE WEIGHTS	188
TOWING WEIGHTS	188

Technical Data

ENGINES

2.5 litre petrol

Fuel	Unleaded gasoline with a CLC or AKI octane rating of 87 minimum (see 'TYPE OF FUEL', page 84).
Capacity	2497 cm ³
Firing order	1-6-5-4-3-2
Idle speed	750 ± 50 rev/min
Bore	80 mm (3.15 in)
Stroke	82.8 mm (3.26 in)
Number of cylinders	6 V-arrangement
Compression ratio	10.5:1
Ignition system	Siemens engine management system
Spark plugs	GSP 66527
Spark plug gap	1.0 mm ± 0.05

ENGINE OIL

Brand	Grade
Castrol Syntec full synthetic	5w/50
Mobil 1	0w/40
Phillips 66 TropArtic 100% Synthetic	5w/50
Quaker State Ultra Premium full synthetic	5w/50
Texaco Havoline Formula 3 Synthetic Motor Oil	5w/40
Valvoline SynPower Full Synthetic Motor Oil	5w/40
<i>Only these engine oils of the grades shown above are approved for use in Freelander engines. Similarly named oils of a different grade to that shown must NOT be used...</i>	

ELECTRICAL

Battery type:	H6 sealed for life
Battery rating:	75 amp/hr
Voltage and polarity	12 V, negative (-) earth

Technical Data

WHEELS & TYRES

CAUTION:

- ALWAYS use the same make and type of radial-ply tyres front and back. DO NOT use cross-ply tyres, or interchange tyres from front to back. For optimum performance and handling ALWAYS replace tyres with those recommended below. Failure to do so may adversely affect vehicle handling.
- NEVER drive your vehicle if the tyres are badly worn, cut or damaged, or if the pressures are incorrect.
- Incorrectly inflated tyres wear rapidly and seriously affect the vehicle's safety and road handling characteristics.
- Your vehicle is fitted with tubeless road wheels that will NOT accept inner tubes. DO NOT fit a tube tyre.

Wheel size and type

Type	Size
Alloy wheels: 16" wheels 17" wheels	6.0J x 16 7.0J x 17
Road wheel nut torque	84 lbf/ft (115 Nm)
Spare wheel nut torque	33 lbf/ft (45 Nm)

Tyre specification

Wheel size	Tyre
6.0J x 16 (alloy)	215/65 R16 'Multi terrain' tyre
7.0J x 17 (alloy)	225/55 R17 'Multi terrain' tyre

TYRE PRESSURES



	Tyre pressures - lbf/in ² (kPa)	
All driving conditions (all tyre sizes)	Front & Rear	30 (206)

Technical Data

CAPACITIES

Fuel tank (usable)	15.6 US gallons (59 litres)
Engine oil (and filter) refill:	5.5 US quarts (5.2 litres)
Automatic gearbox refill:	4.23 US quarts (4.0 litres)
Cooling system fill from dry:	8.25 US quarts (7.8 litres)
Washer reservoir	4.23 US quarts (4.0 litres)

DIMENSIONS



H3485

F	Overall length (inc. 195/80 spare wheel/tyre):	14 ft 6.5 in (4433 mm)
F	Overall length (inc. 215/65 spare wheel/tyre):	14 ft 7.5 in (4459 mm)
A	Overall width (inc. mirrors)	6 ft 9.4 in (2068 mm)
B	Overall height†(excl. roof bars and cross rails)	5 ft 7.2 in (1708 mm)
B	Overall height† (inc. roof bars and cross rails):	5 ft 11.9 in (1828 mm)
E	Wheelbase	8 ft 4.7 in (2557 mm)
	Ground clearance (minimum)†	7.3 in (186 mm)
	Wading depth (maximum)	15.7 in (400 mm)
C	Max. approach angle†	30.5°
G	Max. departure angle (with towbar)†	23.6°
G	Max. departure angle (without towbar)†	33.9°
D	Max. breakover angle	24°
	† With 215/65 tyres at curb weight plus a 165 lb (75 kg) driver	

Technical Data

STEERING GEOMETRY

Track:	
- Front	60.4 in (1534 mm)
- Rear	60.8 in (1545 mm)
Turning circle	38 ft 1.2 in (11.6 m)
Steering wheel turns lock to lock	3.16
Wheel alignment:	
- Front (toe out)	20' ± 15"
- Rear (toe in)	20' ± 15"

VEHICLE WEIGHTS

DEFINITIONS:

- **Curb Weight:** minimum unladen vehicle weight plus a full fuel tank.
- **Gross Vehicle Weight:** maximum permissible weight of vehicle with driver, passengers, payload equipment and towing attachment load (where applicable)

Curb weight	3109 - 3572 lb (1694 - 1717 kg)
Max gross vehicle weight	4560 lb (2060 kg)
Max rear axle load	2480 lb (1120 kg)
Max. front axle load	2391 lb (1080 kg)

NOTE: The maximum axle weights are individual axle loadings. Loading both axles to their respective maximums **MUST BE AVOIDED**, as the overall maximum vehicle weight would then be exceeded. The individual maximum axle weights and gross vehicle weight must not be exceeded.

TOWING WEIGHTS

Max. trailer weight	2500 lb (1134 kg)
Max tongue weight	250 lb (113 kg)
Gross train weight	7023 lb (3190 kg)
Max roof rack load	165 lb (75 kg)
† To increase stability, it is recommended that you adjust the tongue weight to the maximum limit, when loading to the maximum trailer weight.	

Index

A

Accessories	156
Aerial	76
Air blower control	12, 63
Air cleaner element renewal	136
Air conditioning	12, 63
maintenance	66
operation	66
Air distribution control	12, 64
Air recirculation control	12, 63
Air temperature control	12, 63
Air vents	65
Airbag SRS	
disposal	43
location	39
operation	41
precautions	39
servicing	43
warning light	42
Alarm	21
Alarm indicator light	24
Anti-freeze	139
Anti-lock braking (ABS)	99
Ashtray	72
Audible warnings	50
Audio equipment	76
Automatic transmission	89
Auxiliary power socket	73

B

Battery	
charging	146
disposal	145
maintenance	144
remove & replace	145
specification	185
Bonnet	131
Booster cables	165
Brake fluid	
check & top-up	140
Brakes	
anti-lock brakes (ABS)	99
brake pads	98
foot brake	98
handbrake	99
servo assistance	98
warning light	98, 100
Breakdown recovery	167

Bulb replacement	173
------------------	-----

C

Capacities	187
Catalytic converter	87
CD autochanger	76
Child restraints	
LATCH anchorages	37
tether straps	38
Child seats	35
Child-proof door locks	25
Cigar lighter	72
Cleaning (exterior)	152
Cleaning (interior)	154
Clock	68
Cold climates	80
Controls	
fascia	6
fascia switches	11
instrument panel	7
Coolant	
check & top-up	138
replacement	127
specification	139
Cooling system	138
Courtesy lights	
bulb replacement	178, 179
operation	68
Cruise control	96
Cup holders	70

D

Data	185
Daylight running lights	
operation	9
Defrosting	65
Demisting	64
Digital display	46
Dimensions	187
Dipstick	133
Direction indicators	
bulb replacement (front)	175
bulb replacement (rear)	177
operation	51
Distance recorder	46
Door handles (interior)	25
Door locking cut-off switch	26
Door mirrors	57
Door sill locking buttons	25

Index

Drinks stowage	70
Driver's storage	69
Driving	81, 88, 92
E	
Electronic traction control	101
Emergency starting	165
Emergency towing	167
Emission control system	83, 130
Engine	
compartment (petrol)	132
fuse box	171
oil check & top-up	133
specifications	185
starting (petrol)	80
warming-up	81, 121
Engine immobilisation	26
Engine oil	
disposal (used oil)	134
drain & refill	134
filter renewal	135
specification	5
Exterior mirrors	57
F	
Face level vents	65
Fascia switches	11
Fog lights (rear)	
bulb replacement	176
Foot brake	98
Fresh air vents	65
Fuel	
cut-off switch (petrol)	86
economy	82, 123
empty tank	86
filling	85
filling difficulties	86
gauge	45
safety	85
specification	5, 84
tank capacity	5, 187
Fuel gauge	7
Fuse box (supplementary)	172
Fuses	169

G

Gauges	
fuel	45
speedometer	45
tachometer	45
temperature	45
Gearbox (automatic)	89
automatically selected modes	93
display	46
'kick-down'	92
lever positions	90
selector release button	89
sport mode	90
starting	91
'steptronic' selection	91
Glovebox	69
Glovebox light	
bulb replacement	180
operation	69
Ground clearance	113, 187

H

Handbrake	99
Handset	
battery replacement	27
operation	22
replacement	21
resynchronise	27
Hazard warning lights	52
Head restraints	29
Headlights	51
bulb replacement	174
main beam	52
operation	9, 51
Heated rear screen	12, 63
Heated seats	67
Heater controls	12, 63
Heating	64
High mounted stop light	
bulb replacement	177
Hill descent control (HDC)	94
Horn	56

I

Ignition switch	79
Immobilisation	26
In-car entertainment	76

Index

Indicators		Luggage anchor points	102
bulb replacement	175	Luggage area	102
operation	51	M	
Inertia switch	26, 86	Maintenance	16, 127, 128
Information labels	17	Map reading lights	
Instrument illumination control	46	bulb replacement	178
Instrument panel	7	operation	68
digital display	46	Mileometer	46
instruments	45	Mirrors (exterior)	
warning lights	47	adjustment	57
Interior (cleaning)	154	folding	57
Interior lights		Mirrors (interior)	58
bulb replacement	178, 179	Mislock	23
operation	68	Mobile phones	75
Interior mirror	58	N	
J		Navigation system	76
Jacking the vehicle	163	Number plate lights (bulb replacement)	178
Jump leads	165	O	
K		Odometer	7, 46
Key replacement	21	Off-road driving	100, 111
Kick-down	92	Oil (engine)	
L		check & top-up	133
Labels	17	disposal	129, 134
Lashing rings	168	drain & refill	134
LATCH child restraint anchorages	37	filter renewal	135
Lights (exterior)		specification	5, 133
direction indicators	51	Owner maintenance	128
side, tail, headlights	9, 51	P	
Lights (interior)		Parking	81
courtesy	68	Parts & accessories	156
map-reading	68	Poisonous fluids	129
Load carrying		Polishing (bodywork)	153
loading weights	105	Power socket	73
lockable stowage box	102	Power steering top-up	141
long loads	103	Pre-tensioners	34
luggage anchor points	102	Punctured tyres	149
luggage space (maximum)	104	R	
rear seat folding	103	Radio/cassette player	76
roof rack	105	aerial	76
Loadspace cover	74	display	68
Loadspace light		remote controls	76
bulb replacement	180	Reading lights	68
operation	68		
Locking	22		
Locking switch (interior)	25		

Index

Rear fog guard lights		Sport mode	90
bulb replacement	176	Starter switch	79
Rear lights (bulb replacement)	176	Starting	
Rear screen - operation	60	automatic models	91
Rear screen demister	12, 63	diesel models	87
Rear seats	103	emergency	165
Rearscreen washers	55	petrol models	80, 87
Rearscreen wipers	55	warming-up the engine	121
Rear-view mirror	58	Steering column	
Recovery (of vehicle)	167	adjustment	44
Remote audio controls	76	lock	79
Remote handset battery	27	Steering data	188
Reverse lights (bulb replacement)	176	Steptronic transmission	89
Road testing on dynamometers	130	Stop lights (bulb replacement)	177
Roof rack	105	Stowage box	102
Running-in	82	Sun visor	71
S		Sunroof	61
Safety in the garage	129	Superlocking	23
Safety on the forecourt	85	T	
Screen wash	142	Tachometer	7, 45
Seat belt		Tail lights	
adjustment	33	bulb replacement	177
care	34	operation	9, 51
child seat locking mechanism	36	Taildoor	
operation	32	operation	28
pre-tensioners	34	Taildoor glass	
safety	31	operation	60
testing	34	recalibration	60
Seat heaters	67	Technical data	185
Seats		Telephones	75
child seats	35	Temperature gauge	7, 45
front	29	Tether straps	38
heated	67	Tool kit	161
rear - folding	103	Tow bars	106
Security box	102	Towing eyes	167
Selector lever	89	Towing for recovery	167
Service portfolio book	16, 127	Towing on severe inclines	107
Servicing	127, 128	Towing precautions	106
Servo assistance	98	Towing weights	188
Sidelights		Traction control	101
bulb replacement	174	Trailer hitch	107
operation	9, 51	Transporter or trailer lashing	168
Side-repeater light (bulb replacement)	175	Trip recorder	7
Single point entry	24	display	46
Snow chains	151	reset button	45
Spare wheel (removing)	162		
Spark plugs	137		
Speedometer	7, 45		

Index

Tyre		Washing (the bodywork)	152
pressures	148, 186	Weights	188
punctures	149	Wheel changing	
replacement	150	jacking	163
specifications	186	spare wheel	162
wear indicators	149	tools	161
Tyre pressures	5	wheel removal	164
Tyres		Wheel sizes	186
pressures	5	Windows	
U		inhibit switch (rear)	59
Unlocking	24	'one touch' down (driver's)	59
V		operation	59
Vanity mirror	58	taildoor	60
Vanity mirror (bulb replacement)	181	Windscreen washers	
Vehicle identification number	155	fluid top-up	142
Ventilation	62, 65	operation	10, 54
W		Windscreen wipers	
Wading	118	operation	10, 53
Warming-up (the engine)	121	variable delay	10, 54
Warning labels	17	wiper blade replacement	143
Warning lights	47		
ABS	48		
Airbag SRS	49		
Battery charging	49		
Cruise control	47		
Direction indicators	47		
Door open	48		
Engine malfunction (diesel)	49		
Engine malfunction (petrol)	47		
Handbrake & brake system	48		
Hazard warning	48		
HDC 'failure'	48		
HDC 'information'	49		
Headlight main beam	47		
Low oil pressure	49		
overview	8		
Seat belt	49		
Traction control	48		
Warnings (in handbook)	16		
Warranty information	16		
Washer fluid	142		
Washer jets	142		
Washers (windscreen)			
operation	10		