


# EATON 2075 NOISE-GAIN ANALYZER



REVISED DECEMBER 1985

# EATON

Eaton Corporation  
Electronic Instrumentation Division  
Los Angeles, California 90066

## WARRANTY

Eaton Corporation, Electronic Instrumentation Division, (SELLER) warrants each new instrument to be free from defects in material and workmanship, effective after delivery to the original purchaser as follows:

Electrical and Electronic Measuring Instruments . . . . . 1 Year

Repair or replacement (at our option) without charge (F.O.B. factory) will be effected when our examination satisfactorily indicates that defects are due to workmanship or materials. Electron tubes, semiconductors, batteries, fuses, lamps, thermoelements, and Ratio Tran potentiometers are excluded from warranty coverage. Warranty returns must first be authorized by the factory.

If the instrument or any portion thereof, has been abused, misused, damaged by accident or negligence, or if any serial number or seal has been removed or altered, the warranty is void.

This warranty is in lieu of all other warranties, express or implied INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, or fitness for a particular purpose. In no event shall the SELLER be liable for INCIDENTAL OR CONSEQUENTIAL damages. The SELLER neither assumes, nor authorizes any person to assume for it, any other liability in connection with sales of instruments manufactured by SELLER.

With respect to repairs, the foregoing warranty shall apply for a period of ninety days to the repaired portion.

## REPAIR AND MAINTENANCE

Instruments should be returned only on prior authorization from the Representative or the factory. You will be advised of detailed shipping instructions at that time. Return the instrument to the factory prepaid. Validity of warranty will be determined by the factory.

Chargeable repairs: If requested, an estimate of charges will be made prior to repairs. Please provide us with the following information in order to expedite the processing of your instrument:

- |   |   |
|---|---|
| 1. Model or Type  | 5. Approximate number of hours in use.                  |
| 2. Serial Number  | 6. Maintenance action previously requested or performed |
| 3. Description of trouble <sup>(1)</sup>                | 7. Other comments.                                      |
| 4. Approximate date instrument was placed in operation. |   |

<sup>(1)</sup> Include data on symptoms, measurements taken, suspected location of trouble, maintenance action taken and any other relevant data.

## SERVICE

Additional service information can be made available by calling any of these Eaton Sales and Service Centers:

Elmhurst, IL — (312) 279-8220  
Fairfield, NJ — (201) 227-8990  
Los Angeles, CA — (213) 822-3061  
Oakton, VA — (703) 620-5820  
Sunnyvale, CA — (408) 733-6574

FRANCE • Argenteuil • Telephone: (03) 99817446 • Telex: 609036  
UNITED KINGDOM • Wokingham • Telephone: (0734) 794717 • Telex: 847238  
GERMANY • Munich • Telephone: (089) 5233023-24 • Telex: 529420

## TABLE OF CONTENTS

<u>Paragraph</u>	<u>Title</u>	<u>Page</u>
SECTION 1—GENERAL INFORMATION		
1-1	Scope and Organization of the Manual.....	1-1
1-2	Introduction.....	1-2
1-3	Purpose and Use of Equipment.....	1-2
1-4	Calibration Cycle.....	1-2
1-5	Equipment Supplied.....	1-3
1-6	Equipment Required But Not Supplied.....	1-3
1-7	Optional Accessories.....	1-3
1-8	Specifications.....	1-4
1-9	Safety Precautions.....	1-7
SECTION 2—INSTALLATION		
2-1	Introduction.....	2-1
2-2	Unpacking and Physical Inspection.....	2-1
2-3	AC Power Requirements.....	2-1
2-4	Operational Inspection.....	2-3
2-5	Operating Temperature.....	2-5
2-6	Selection of Relay DC Voltage.....	2-3
2-7	Equipment Mounting.....	2-5
2-8	Rack Mounting the Eaton 2075.....	2-5
2-9	Equipment Interconnections.....	2-7
2-10	Reference Card.....	2-8
2-11	Pre-Operational Adjustments.....	2-8
SECTION 3—OPERATION		
3-1	Introduction.....	3-1
3-2	Capabilities of the Eaton 2075.....	3-1
3-3	Controls and Indicators.....	3-3
3-4	Power-On Conditions, Preset, and Total System Reset.....	3-16
3-5	Continuous Measurement Mode and the Hold Function.....	3-20
3-6	Fixed Frequency Operation.....	3-21
3-7	Swept Frequency Operation.....	3-22
3-8	Uncorrected and Corrected Measurements.....	3-24
3-9	Entry of Frequency and ENR Values.....	3-26
3-10	Selecting the Correct Test Configuration.....	3-27
3-11	Procedure for Test Configuration 1.....	3-31
3-12	Procedure for Test Configuration 2—Double Sideband.....	3-33
3-13	Procedure for Test Configuration 2—Single Sideband.....	3-37
3-14	Procedure for Test Configuration 3—Single Sideband.....	3-41
3-15	Procedure for Test Configuration 4—Double Sideband.....	3-45
3-16	Procedure for Test Configuration 4—Single Sideband.....	3-49
3-17	Procedure for Test Configuration 5—Single Sideband.....	3-53

Thanks to Geotek Design Services for scanning this document to PDF so that users of the Eaton 2075, 2075-2, and 2075-2A can continue to use this fine instrument.

## TABLE OF CONTENTS (Continued)

<u>Paragraph</u>	<u>Title</u>	<u>Page</u>
3-18	Procedure for Test Configuration 6—Single Sideband .....	3-57
3-19	Additional Types of Measurements .....	3-62
3-20	Effective Input Noise Temperature ( $T_e$ ) Measurement .....	3-63
3-21	Y-Factor (Y) Measurement .....	3-63
3-22	Operating Noise Temperature ( $T_{op}$ ) Measurement .....	3-64
3-23	Power (dB) Measurements .....	3-65
3-24	ENR Measurement .....	3-66
3-25	Noise Measure (M) Measurement .....	3-67
3-26	Manual Measurements .....	3-67
3-27	Manual Measurement of Noise Figure and Gain .....	3-67
3-28	Manual Measurement of Y-Factor .....	3-69
3-29	Calibrated Noise Source .....	3-70
3-30	Noise Drive Voltage and Indicator .....	3-71
3-31	ENR Tables .....	3-72
3-32	Calibration .....	3-74
3-33	Frequency Calibration .....	3-74
3-34	Second Stage Calibration .....	3-75
3-35	Input Gain Selection .....	3-77
3-36	IF Attenuators Calibration .....	3-78
3-37	Selection of Sideband Parameters .....	3-78
3-38	Bandwidth Compensation .....	3-82
3-39	Determining the Bandwidth Ratio of the First and Second Stages .....	3-84
3-40	Compensation For Loss or Gain .....	3-86
3-41	$T_{cold}$ Compensation .....	3-88
3-42	Oscilloscopes and Recorders to Display Data .....	3-89
3-43	Selecting an External Local Oscillator .....	3-95
3-44	Controlling External Local Oscillators .....	3-95
3-45	Writing a Custom Program For Controlling a Local Oscillator .....	3-96
3-46	Special Functions .....	3-101
3-47	Error Messages .....	3-106
3-48	Store-Recall Registers .....	3-110
3-49	Smoothing Function .....	3-110
3-50	100 kHz Display Resolution .....	3-113
3-51	Software Revisions .....	3-113

## TABLE OF CONTENTS (Continued)

<u>Paragraph</u>	<u>Title</u>	<u>Page</u>
SECTION 4 – GPIB OPERATION		
4-1	Introduction . . . . .	4-1
4-2	GPIB General Information . . . . .	4-1
4-3	GPIB Operating Modes . . . . .	4-3
4-4	Setting the GPIB Address . . . . .	4-3
4-5	GPIB Compatibility . . . . .	4-3
4-6	Remote and Local Modes . . . . .	4-4
4-7	GPIB Message Types . . . . .	4-4
4-8	Interface Bus Messages . . . . .	4-4
4-9	Device Messages . . . . .	4-8
4-10	Data Messages . . . . .	4-12
4-11	Status Messages . . . . .	4-16
SECTION 5 – PERFORMANCE VERIFICATION TESTS		
5-1	Introduction . . . . .	5-1
5-2	Test Equipment Required . . . . .	5-1
5-3	Performance Verification Procedures . . . . .	5-2
5-4	Power-On Test . . . . .	5-2
5-5	Noise Drive Voltage Test . . . . .	5-2
5-6	IF Attenuators Calibration . . . . .	5-3
5-7	Final Detector Bias Test . . . . .	5-3
5-8	Second Stage Calibration . . . . .	5-4
5-9	Final Detector Linearity Test . . . . .	5-5
5-10	Scope/Plotter Output Test . . . . .	5-7

## LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
1-1	Eaton 2075 Noise Gain Analyzer .....	1-1
2-1	AC Voltage Selection Card .....	2-2
2-2	External Relay Voltage Selection .....	2-4
2-3	Installation of Rack Mounts .....	2-5
2-4	Installation of Slide Mounts .....	2-6
2-5	GPIB Connector .....	2-8
3-1	Front Panel Controls and Indicators .....	3-4
3-2	Rear Panel Controls and Indicators .....	3-15
3-3	Uncorrected and Corrected Measurements .....	3-25
3-4	Test Configuration Downconversion Modes .....	3-30
3-5a	Test Configuration 1—Calibration .....	3-31
3-5b	Test Configuration 1—External Relays for Calibration .....	3-31
3-6	Test Configuration 1—External Relays for Calibration .....	3-31
3-7a	Test Configuration 2—Calibration—Double Sideband .....	3-34
3-7b	Test Configuration 2—Measurement—Double Sideband .....	3-34
3-8a	Test Configuration 2—Calibration—Single Sideband .....	3-38
3-8b	Test Configuration 2—Measurement—Single Sideband .....	3-38
3-9a	Test Configuration 3—Calibration .....	3-42
3-9b	Test Configuration 3—Measurement .....	3-42
3-10a	Test Configuration 4—Calibration—Double Sideband .....	3-46
3-10b	Test Configuration 4—Measurement—Double Sideband .....	4-36
3-11a	Test Configuration 4—Calibration—Single Sideband .....	3-50
3-11b	Test Configuration 4—Measurement—Single Sideband .....	3-50
3-12a	Test Configuration 5—Calibration .....	3-54
3-12b	Test Configuration 5—Measurement .....	3-54
3-13a	Test Configuration 6—Calibration .....	3-58
3-13b	Test Configuration 6—Measurement .....	3-59
3-14a	$T_{op}$ Setup—Calibration .....	3-64
3-14b	$T_{op}$ Setup—Measurement .....	3-64
3-15a	ENR Setup—Calibration .....	3-66
3-15b	ENR Setup—Measurement .....	3-66
3-16	Manual Y-Factor Measurement .....	3-69
3-17	Example of Calibrated Noise Source Data .....	3-71
3-18	ENR Table 1, 2, or 3 .....	3-73
3-19	Setup With External Relays for Calibration .....	3-76
3-20	Example 1 Sideband Selection .....	3-79
3-21	Example 2 Sideband Selection .....	3-80
3-22	Example 3 Sideband Selection .....	3-81
3-23	Example 4 Sideband Selection .....	3-81
3-24	Bandwidth Compensation Example 1 .....	3-82
3-25	Bandwidth Compensation Example 2 .....	3-83

## LIST OF ILLUSTRATIONS (Continued)

<u>Figure</u>	<u>Title</u>	<u>Page</u>
3-26	Insertion Loss Measurement With Power Meter .....	3-84
3-27	Insertion Loss Measurement With 2075 .....	3-85
3-28	Loss Compensation .....	3-87
3-29	Error Caused by $T_{\text{cold}}$ Deviation From 290 K .....	3-89
3-30	Test Pattern 2 Oscilloscope Display .....	3-91
3-31	Noise Figure and Gain Oscilloscope Display .....	3-92
3-32	Smoothing Indicator .....	3-111
4-1	General Purpose Interface Bus .....	4-2
4-2	Sample Data Output .....	4-14
4-3	Status Byte .....	4-17
4-4	Flowchart For Data Collection in Test Configuration 1 Using SRQ Data Ready ...	4-18
4-5	Programming Example For Data Collection in Test Configuration 1 Using SRQ On Data Ready With HP 85 Controller .....	4-19
4-6	Sample Results From Program of Figure 4-5 .....	4-21
4-7	Setup in Test Configuration 2 .....	4-21
4-8	Flowchart For SRQ on Ready To Tune .....	4-23
4-9	Flowchart For SRQ on Data Ready .....	4-26
4-10	Sample Program .....	4-28
5-1	Output Test Pattern 2 .....	5-8

## LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>
1-1	Equipment Supplied .....	1-3
1-2	Optional Accessories .....	1-3
1-3	Performance Specifications .....	1-4
1-4	Supplemental Specifications .....	1-6
2-1	GPIB Connector Pin-out .....	2-8
3-1	Front Panel Controls and Indicators .....	3-5
3-2	Rear Panel Controls and Indicators .....	3-15
3-3	Power-On, Preset, and Total System Reset Parameters .....	3-18
3-4	Selecting the Correct Test Configuration .....	3-29
3-5	Additional Types of Measurements .....	3-62
3-6	Output Display Special Functions .....	3-90
3-7	Control Programs For External Local Oscillators .....	3-95
3-8	ASCII Codes .....	3-99
3-9	Special Functions .....	3-102
3-10	Error Messages .....	3-107
4-1	GPIB Functional Capabilities .....	4-4
4-2	GPIB Function Reference Table .....	4-6
4-3	Eaton 2075 GPIB Device Codes .....	4-9
4-4	Eaton 2075 GPIB Front Panel Codes .....	4-11
4-5	Selection of Data Message Contents .....	4-12



## SECTION I

## GENERAL INFORMATION

## 1-1. SCOPE AND ORGANIZATION OF THE MANUAL

This manual contains information and procedures required to install and operate the Eaton 2075-2A Noise-Gain Analyzer. The manual is divided into five sections as follows:

- Section 1: General Description
- Section 2: Unpacking and Installation
- Section 3: Operation In Local Mode
- Section 4: GPIB Operation
- Section 5: Performance Verification Procedures

## NOTE

Eaton 2075 is the generic model designation for the Noise-Gain Analyzer. It was first released as the Eaton 2075-2; the most recent version is the Eaton 2075-2A. Both versions are identical in form, fit and function except that in the Eaton 2075-2A the basic input frequency range has been extended. The Eaton 2075-2 has an input frequency range of 10 MHz to 1800 MHz. The basic input frequency range of the Eaton 2075-2A is 10 MHz to 1850 MHz, per its specifications. However the unit is tunable to, and can actually be operated at, up to 1900 MHz. The actual model number is located on the identification label on the rear panel. The instrument is hereinafter referred to as the Eaton 2075.




Figure 1-1. EATON 2075 NOISE-GAIN ANALYZER

This manual has been organized to allow the new user of the Eaton 2075 to quickly and easily begin test operations. Read Section 1 to obtain a familiarity with the test instrument. Follow the procedures of Section 2 for installation.

The Eaton 2075 can be used in any of 6 test configurations, depending on the desired test application. Section 3 is organized to quickly bring the user to the correct test configuration and its procedure. Figure 3-1 and Table 3-1 may be studied to obtain a familiarity with the controls and indicators. Paragraph 3-10 and Table 3-4 guide the user in selecting the correct test configuration. Paragraphs 3-11 through 3-18 are the procedures to be used with each configuration. Each procedure includes the keystroke sequences necessary for each step. The remaining pages of Section 3 cover, in greater detail, specific subjects relevant to operation of the 2075.

Section 4 covers operation when the 2075 is controlled by an external computer via a General Purpose Interface Bus.

Section 5 includes information and procedures used to verify that the 2075 is performing correctly.

## 1-2. INTRODUCTION

This section of the manual contains a general description of the Eaton 2075 Noise-Gain Analyzer including: purpose and function, equipment requirements, available options, specifications, and safety precautions.

## 1-3. PURPOSE AND USE OF EQUIPMENT

The 2075 Noise-Gain Analyzer is a programmable, microprocessor-controlled instrument designed specifically to make precise measurements of noise and gain characteristics of RF devices. The analyzer can be controlled in its local mode using its front panel controls, or in the remote mode, by an external controller via an IEEE-488 GPIB (General Purpose Interface Bus).

The analyzer can make the following measurements:

Corrected Noise Figure and Gain	$(F + G)^*$
Uncorrected Noise Figure	$(F)^*$
Corrected Effective Input Noise Temperature and Gain	$(T_c + G)$
Effective Input Noise Temperature	$(T_c)$
Corrected Effective Operating Noise Temperature and Gain	$(T_{op} + G)$
Effective Operating Noise Temperature	$(T_{op})$
Noise Measure (includes Gain)	$(M)^*$
Y Factor	$(Y)^*$
Power	$(PWR \text{ dB})^*$
Excess Noise Ratio	$(ENR)^*$

\*Can be displayed in dB or as a dimensionless ratio

The specified input frequency range of the 2075 extends from 10 MHz to 1850 MHz. However, the unit is actually tunable and operable to 1900 MHz. In its simplest test configuration the analyzer will make measurements of RF devices with output frequencies in this range. More complex test configurations, requiring one or two stages of external downconversion, allow measurements of devices with output frequencies as high as 65.535 GHz. The 2075 has the capability for controlling the local oscillator used in the external downconversion process.

## 1-4. CALIBRATION CYCLE

At six month intervals the Performance Verification Procedures in Section 5 of this manual should be performed to ensure the continued optimum performance of the 2075.

At one year intervals the instrument should be fully calibrated using the alignment and adjustment procedures from the maintenance manual. These procedures should be performed by qualified personnel experienced in calibration and servicing of electronic instrumentation.

**1-5. EQUIPMENT SUPPLIED**

The items listed in Table 1-1 are furnished with the 2075 Noise-Gain Analyzer.

**Table 1-1.** Equipment Supplied

QTY.	DESCRIPTION	PART NO.
1	AC Power Cord, 2 meters	1-910166-001
1	External Relay Plug	1-910417-101
1	Fuse, 1.0 Amp, slow- blow (for 220V operation)	1-924000-019
1	Operation Manual	500783-385
1	Maintenance Manual	500783-386

**1-6. EQUIPMENT REQUIRED BUT NOT SUPPLIED**

One or more noise sources are required for operation of the 2075. The type needed depends on the user applications. Also, one or more GPIB cables are required to operate the 2075 if an external controller is used, or if the 2075 is used to control an external local oscillator. Noise sources and GPIB cables are listed in Table 1-2 under Optional Accessories.

In addition, filters, mixers, and one or two external local oscillators may be required if the Device Under Test is to be measured at frequencies above 1850 MHz. See Sections 3-10 through 3-18 to determine the proper setup and equipment requirements.

Test equipment is required for the performance of the Performance Verification Procedures. The required test equipment is listed in Table 5-1 of this manual.

## 1-7. OPTIONAL ACCESSORIES

## NOTE

Table 1-2 lists the optional accessories available for use with the 2075 Noise-Gain Analyzer. For further information, please contact an Eaton sales representative in your area.

Item 23, the Slide Mount Kit, must be ordered with the original purchase of the 2075. This option cannot be added later unless the unit is returned to the factory.

Table 1-2. Optional Accessories

ITEM NO.	DESCRIPTION	MODEL NO.	ITEM NO.	DESCRIPTION	MODEL NO.
1	Solid State Noise Source 10 MHz-1500 MHz	7615	13	Gas Discharge Noise Source 12.4 GHz-18 GHz, WR62 output	7091
2	Solid State Noise Source 1 GHz-12.4 GHz	7616	14	Gas Discharge Noise Source 18 GHz-26.5 GHz, WR42 output	7053
3	Solid State Noise Source 12.4 GHz-18 GHz	7617	15	Gas Discharge Noise Source 26.5 GHz-40 GHz, WR28 output	7096
4	Solid State Noise Source 1 GHz-18 GHz	7618	16	Hot/Cold Noise Standard DC-9 GHz	7009
5	Solid State Noise Source 10 MHz-18 GHz	7618E	17	GPIB Cable, 1 Meter Length (IEEE-488)	1-998094- 001
6	Solid State Noise Source 10 MHz-26.5 GHz	7626	18	GPIB Cable, 2 Meter Length (IEEE-488)	1-998094- 002
7	Solid State Noise Source with isolator, 1.2 GHz-1.4 GHz	230450-2	19	GPIB Cable, 4 Meter Length (IEEE-488)	1-998094- 003
8	Solid State Noise Source with isolator, 2.7 GHz-2.9 GHz	230450	20	Maintenance Kit for Eaton 2075 (Extender Boards and Cables)	1-006586- 001
9	System Noise Source (High ENR) 10 MHz-18 GHz (Custom Specifications)	7650	21	Anti-Static Workstation	1-998484- 001
10	System Noise Source (High ENR) 10 MHz-18 GHz (Custom Specifications)	7660	22	Rack Mount Kit	Option 11
11	Triggerable Power Supply for Gas Discharge Noise Sources	7175	23	Slide Mount Kit (see note above) (Option 11 also required)	1-998725
12	Gas Discharge Noise Source 8.2 GHz-12.4 GHz, WR90 output	7052	24	PROM ENR Table (permanent storage of ENR data for noise source)	Ordered as option with noise source

## 1-8. SPECIFICATIONS

Specifications for the 2075 are listed in Tables 1-3 and 1-4. Table 1-3 lists the basic specifications. Supplemental information consisting of non-warranted, nominal performance characteristics is listed in Table 1-4.

Table 1-3. Eaton 2075 Performance Specifications

PERFORMANCE CHARACTERISTIC	LIMIT	CONDITIONS
<b>NOISE FIGURE MEASUREMENT:</b>		
Range	0 to 30 dB	1) Noise Figure 0 to 12 dB 2) Temperature +10 to +40 ° C 3) ENR of 5 to 18 dB
Resolution	0.01 dB	
Uncertainty	± 0.05 dB	
	± 0.10 dB	1) Noise Figure > 12 dB 2) Temperature < 10 ° C > 40 ° C
<b>GAIN MEASUREMENT:</b>		
Range	-20 dB to +50 dB	
Resolution	0.01 dB	
Uncertainty	± 0.2 dB	
<b>INPUT:</b>		
Frequency Range	Specified parameters apply from 10 MHz to 1850 MHz. Unit is tunable and operable up to 1900 MHz	

Table 1-3. Eaton 2075 Performance Specifications (Continued)

PERFORMANCE CHARACTERISTIC	LIMIT	CONDITIONS
Frequency Resolution	1 MHz (test configurations 1 - 6) 0.1 MHz (test configuration 1 only)	For input power levels below -40 dBm
Tuning Accuracy	$\pm(0.5 \text{ MHz} + 0.005 \text{ times the tuned frequency})$ $\pm 3 \text{ MHz maximum}$	
Second Stage Noise Figure	7 dB + .001 dB/MHz	
Input SWR	< 1.5:1	
Reflection Coefficient	< 0.2	
Allowable Net External Gain	> 75 dB	
<b>ELECTROMAGNETIC COMPATIBILITY:</b>		
Conducted and Radiated Emissions	MIL STD 461A, CISPR Publication 11, and Messemmpfaenger-Postverfuegung 526/527/79	Conducted and radiated interference complies with MIL STD 461A, Methods CE03 and RE02, CISPR Publication 11 (1975), and Messemmpfaenger Postverfuegung 526/527/79 (Kennzeichnung Mit F-Nummer/Funkschutzzeichen)
Conducted and Radiated Susceptibility	MIL STD 461A 1968	Conducted and radiated susceptibility meets the requirements of methods CS01, CS02, CS06, and RS03 (1 Volt/meter) of MIL STD 461A 1968
<b>GENERAL:</b>		
Noise Source Drive Voltage	28.0 volts + .05 V 1.0 volt	Noise Source ON at up to 100 mA peak Noise Source OFF
Line Voltage	100 VAC $\pm 10\%$ 110 VAC $\pm 10\%$ 220 VAC $\pm 10\%$ 240 VAC $\pm 10\%$	48 to 66 Hz 48 to 66 Hz 48 to 66 Hz 48 to 66 Hz
Power Dissipation	200 VA maximum	
Operating Temperature	0 to 55 ° C	
Storage Temperature	-55 to +75 ° C	
Height	146 mm (5.75 in.)	5 ¼ in. vertical rack space
Width	425 mm (16.8 in.)	
Depth	354 mm (14.0 in.)	
Weight	11.5 kg (25.5 lbs.)	

Table 1-4. Supplemental Specifications

CHARACTERISTIC	NOMINAL OR TYPICAL VALUE
Bandwidth	5.0 MHz Noise Bandwidth
Maximum Safe Input Level	+20 dBm RF or $\pm 20$ VDC
External Relays Drive Voltages and Currents	+5 VDC , 5 VA maximum +15 VDC, 4.5 VA maximum +30 VDC, 15 VA maximum
Controller Functions	HP 8672A, HP 8350A, Wiltron 6600 Series Sweep Generators, General Format
ENR Tables Storage Capacity	3 Tables, each can store up to 31 frequencies with corresponding ENR values, plus 1 PROM table can store 1 ENR value for all frequencies (4 tables total). An additional, optional PROM table can be ordered with the noise source.
Frequency Display	Displays Frequency in MHz, 4 GPIB annunciators are: SRQ            Service Request RMT            Remote TALK          Talk LISTEN        Listen  4 Parameter Annunciators are: LO             Local Oscillator RF             Radio Frequency IF             Intermediate Frequency ENTER        Enter Frequency Prompt
Gain Display	Displays Gain and other values. The 8 Annunciators are: LOSS          Gain is less than zero dB ENR            Excess Noise Ratio T (F)          Temperature in Fahrenheit T (C)          Temperature in Centigrade T (K)          Temperature in kelvins ENTER        Enter Value Prompt dB             Units are displayed in dB RATIO        Units are displayed as Ratio
Noise Figure Display	Displays Noise Figure and other values. The 8 Annunciators are: F              Noise Figure Y              Y-Factor T <sub>e</sub> (K)        Effective Input Noise Temperature in kelvins dB PWR       Power and ENR M             Noise Measure T <sub>op</sub> Operating Noise Temperature dB             Units displayed are in dB RATIO        Units displayed as Ratio
Analog Gain Meter	Analog Indicator for Gain. Variable range is set by entering upper and lower limits.

Table 1-4. Supplemental Specifications (Continued)

CHARACTERISTIC	NOMINAL OR TYPICAL VALUE
Analog Noise Meter	Analog Indicator for Noise Figure. Variable range is set by entering upper and lower limits.
Scope/Plotter Output Connectors X, Y, Z	Rear panel connectors supply drive signals for external oscilloscope or X-Y plotter. Variable range is set by entering upper and lower limits. Output voltage range is 0 to 6 volts for X and Y. Z axis output is positive going TTL, 0 to 5 volts signal for blanking the oscilloscope.
IF Output	- 25 dBm to - 55 dBm, 5 MHz Bandwidth
DET Output	.2 volts to approx. + 5 volts, high impedance output

## 1-9. SAFETY PRECAUTIONS

### WARNING

This symbol designates precautionary actions which must be followed to avoid the possibility of injury and death.

### WARNING

1. If this instrument is to be energized via an auto-transformer for voltage reduction, make sure that the common terminal is connected to the earth pole of the power source.
2. The power cable plug shall be inserted into a socket outlet provided with a protective earth contact. The protective action must not be negated by the use of an extension cord without a protective conductor (ground).
3. Before switching on the instrument, the protective earth terminal of the instrument must be connected to the protective conductor of the power cord. This is accomplished by ensuring that the instrument's internal earth terminal is correctly connected to the instrument's chassis and that the power cord is wired correctly.
4. Whenever it is likely that the protection has been impaired, the instrument must be made inoperable and secured against any unintended operation.
5. Any interruption of the protective ground conductor inside or outside the instrument, or disconnection of the protective earth terminal is likely to make the instrument dangerous. Intentional interruption is prohibited.
6. Make sure that only fuses with the required rated voltage and current, and of the specified type (normal-blow, slow-blow) are used for replacement. The use of repaired fuses and the shortcircuiting of fuseholders must be avoided. Remove the line cord before changing fuses.
7. Any adjustment, maintenance, and repair of the opened instrument under voltage should be avoided as much as possible and, where inevitable, should be carried out only by a skilled person who is aware of the hazard involved.



8. Exercise extreme care when servicing the unit. High voltages are used.
9. Capacitors inside the instrument may still be charged even if the instrument has been disconnected from its source.

\*\*\*\*\*  
\* CAUTION \*  
\*\*\*\*\*

This symbol designates precautionary actions which must be followed to avoid damage to all or part of the instrument.

\*\*\*\*\*  
\* CAUTION \*  
\*\*\*\*\*

1. Verify that the line voltage selector card on the rear panel is in the correct position before connecting the power.
2. Verify that the socket for the power line cord is provided with a protective earth contact.
3. Any interruption of the protective (grounding) conductor inside or outside the instrument is likely to cause damage to the instrument. To avoid damage, this instrument and all line powered devices connected to it must be connected to the same earth ground.
4. Make sure that only fuses with the required rating, and of the specified type, are used for replacement. Fuse ratings are given on the rear panel of the instrument near the fuseholder.
5. To avoid the possibility of damage to test equipment, read completely through each section before starting it. Make any preliminary control settings necessary for correct test equipment operation.
6. Do not torque the RF connector to more than 2½ inch-pounds.



## SECTION 2

## INSTALLATION

## 2-1. INTRODUCTION

This section of the manual contains information required for unpacking, inspecting, and installing the Eaton 2075 Noise-Gain Analyzer.

## 2-2. UNPACKING AND PHYSICAL INSPECTION

Examine the shipping carton for damage before unpacking the equipment. If the carton has been damaged, have the carrier's agent present when the equipment is removed from the carton. Retain the shipping carton and padding material for the carrier's inspection if damage to the equipment is evident after it has been unpacked.

\*\*\*\*\*  
\* CAUTION \*  
\*\*\*\*\*

Exercise care when removing the instrument from its shipping container to ensure that no damage is incurred at this time.

See that the equipment is complete as listed on the packing slip. Visually examine the 2075 for any evidence of physical damage. If any damage is evident, or if the contents are not complete, immediately notify the carrier and also your local Eaton sales office. After completing the physical inspection, the Performance Verification Procedures in Section 5 of this manual should be performed as an operational or electrical inspection.

## 2-3. AC POWER REQUIREMENTS

Prior to shipping, the 2075 is configured to operate on 120 VAC, 60 Hz line power. The unit is easily re-configured for operation using 100, 220, or 240 VAC. Refer to Figure 2-1 below and perform the following steps to verify, or to change, the line voltage configuration:

**WARNING**

Observe all the safety precautions listed in paragraph 1-9. In particular, determine that the line voltage selector card is set to its correct position. If it is necessary to change the card setting, use the following procedure.

**NOTE**

For units with serial numbers 286 and up, it makes no difference whether the unit is configured for 100 or 120 VAC. Likewise, it makes no difference whether the unit is configured for 220 or 240 VAC.




Figure 2-1. AC VOLTAGE SELECTION CARD

1. On the rear of the unit, locate the receptacle for the line power cord. The power cord should be unplugged from the receptacle.
2. Slide the transparent fuse cover to the left, and pull the FUSE PULL lever to remove the fuse.
3. Read the voltage level printed on the voltage selector card. (This number becomes visible after the fuse is removed.)
4. The unit is normally configured for 120 VAC operation. If the unit is to be operated using this line voltage, verify that this value is visible. Verify that the fuse rating is 2.0 Amps, slow-blow, and reinsert the fuse.
5. To reconfigure for operation at 100, 220, or 240 VAC, remove the voltage selector card. A small hole is provided in the card to accommodate a hook for easy removal.
6. Rotate the card so that the desired operating voltage is visible on its upper surface. Now position the card for reinsertion with the desired voltage on the outboard edge.
7. Reinsert the card. The desired voltage should be visible.
8. Replace the fuse after verifying that its rating is correct. For 100 or 120 VAC, use the 2.0 Amp slow-blow fuse. For 220 or 240 VAC, use the 1.0 Amp slow-blow fuse.
9. Slide the transparent fuse cover back into place.
10. Plug the power cord into the receptacle.

**WARNING**

The power line cord is a 3 wire assembly to ensure that the instrument chassis is connected to the main ground. Under no conditions is this ground lead to be interrupted, or a 2 wire extension cord to be used.

**CAUTION**

Observe all the safety precautions given in paragraph 1-9.

**2-4. OPERATIONAL INSPECTION**

After verifying that the 2075 is configured for the correct line voltage, the unit should be subjected to the Performance Verification Tests in Section 5 of this manual. After completion of these tests, the unit is ready for bench-top operation.

**2-5. OPERATING TEMPERATURE**

The 2075 is designed to operate within specified performance limits over an ambient temperature range extending from 0 to 55 degrees Centigrade.

Operation outside this range for extended periods will result in degradation of electrical performance and eventual malfunction.

**2-6. SELECTION OF RELAY DC VOLTAGE**

The RELAY POWER connector on the 2075 front panel provides voltage to automatically energize external relays during Second Stage Calibration.

This voltage is jumper selectable and can be set to +5, +15, or +30 volts DC. It is set to +30 volts before the unit is shipped from the factory. Refer to Figure 2-2 and perform the following steps to select +5 or +15 volts DC.

**CAUTION**

Observe all the safety precautions given in paragraph 1-9 for protection of the instrument and of personnel.




Figure 2-2. EXTERNAL RELAY VOLTAGE SELECTION

1. Remove the AC power cord from its receptacle on the rear of the 2075.
2. Remove the single 6-32 screw which secures the top cover panel. Slide the cover to the rear of the unit and remove it.
3. Two internal covers are exposed. Remove the nine 4-40 screws which secure the right side internal cover (the RF Deck Cover) and remove the cover.
4. Locate the A4 board. Its position is shown in Figure 2-2 above.
5. Remove the three board holding screws which are located along the top edge of the board.
6. Unplug the connectors located near the top edge of the board, as necessary, so that the board can be removed. Lift the board free of its edge connector.
7. Locate the pins E1 through E6. These are located in the center of the board as shown in Figure 2-2 above. A jumper is installed between pins E3 and E4, selecting +30 volts.
8. To select +5 volts, connect the jumper between pins E5 and E6. To select +15 volts, connect the jumper between pins E1 and E2.
9. To reassemble the unit perform steps 1 through 6 in reverse.

## 2-7. EQUIPMENT MOUNTING

The 2075 comes equipped with four supporting feet to allow bench-top operation. The unit may also be mounted in a standard 19 inch equipment rack on angled support brackets or on sliding mounts.

The rack mounting kit, Option 11, consists of two front panel brackets and the necessary screws for attaching the brackets to the 2075.

The Slide Mount Kit, part number 1-998725, consists of the two slide mount assemblies and the required mounting screws. Both kits are required for mounting the unit on slides. For rack mounting on angled brackets, only Option 11 is required.

## NOTE

The Slide Mount Kit option must be ordered when the 2075 is originally purchased. The unit is shipped with the slide mounts installed.

## 2-8. RACK-MOUNTING THE 2075

Refer to Figure 2-3 to attach the rack mount brackets to the 2075. Refer to Figure 2-4 for installation of the 2075 on slide mounts in a standard equipment rack.





Figure 2-3. INSTALLATION OF RACK MOUNTS



To remove 2075 from rack or to push 2075 back into rack, lift locking latch first. Note that the adjustable bracket is the rear one.

NOTE: Slide mounts are manufactured by Grant Hardware Corporation, City of Industry, CA  
Code No. 10003; P/N SS-168-NT-18

Figure 2-4. INSTALLATION OF SLIDE MOUNTS  
(Eaton P/N 1-998725-005)



## 2-9. EQUIPMENT INTERCONNECTIONS

Refer to Figure 3-2 and Table 3-2 for the locations and additional information on the rear panel connectors discussed below. The 2075 has three BNC-type connectors on its rear panel. These provide X, Y, and Z outputs which may be used to display data on an oscilloscope or analog X-Y Plotter. Install test cables between these outputs and the corresponding oscilloscope or plotter inputs if this function is to be utilized. When an oscilloscope is being used to display data, the INT (intensity) adjustment on the rear panel should be adjusted fully clockwise initially, and then adjusted to obtain the desired difference in intensity between the noise figure and gain traces. When an X-Y plotter is being used, the Z output should be connected to the plotter pen-lift input. Refer to paragraph 3-42 for the procedures detailing usage of these functions.

The IF OUT connector is provided on the rear panel of the 2075 to allow measurement or display of the 30 MHz IF signal. This signal is the result of the second stage of internal downconversion. Install a test cable between this BNC-type connector and an appropriate measurement device, if desired for test purposes.

The DET OUT connector is provided on the rear panel to allow measurement or display of the Final Detector Output voltage. Install a test cable between this BNC-type connector and an appropriate measurement device if desired for test purposes.

The line power receptacle on the Eaton 2075 rear panel is the input connector for AC power. Connect the line power cord to this receptacle.

A 24 pin GPIB connector is provided on the rear panel of the Eaton 2075. Connect the GPIB cable to this connector when using an external computer to control the Eaton 2075, when using the Eaton 2075 to control an external local oscillator, or when transmitting data to a printer. Figure 2-5 and Table 2-1 illustrate the GPIB connector pin layout.




Figure 2-5. GPIB CONNECTOR

Table 2-1. GPIB Connector Pin-Out

PIN #	SIGNAL	PIN #	SIGNAL
1	DIO 1	13	DIO 5
2	DIO 2	14	DIO 6
3	DIO 3	15	DIO 7
4	DIO 4	16	DIO 8
5	EIO	17	REN
6	DAV	18	Signal Ground for pin 6
7	NRFD	19	Signal Ground for pin 7
8	NDAC	20	Signal Ground for pin 8
9	IFC	21	Signal Ground for pin 9
10	SRQ	22	Signal Ground for pin 10
11	ATN	23	Signal Ground for pin 11
12	SHIELD	24	Signal Ground for LOGIC

## 2-10. REFERENCE CARD

A quick reference pull-out card is located in the bottom of the 2075. This card summarizes information on special functions, test configurations, and error messages.

## 2-11. PRE-OPERATIONAL ADJUSTMENTS

The Performance Verification Procedures in Section 5 of this manual should be performed before making measurements with the 2075. These procedures constitute an operational or electrical inspection of a newly purchased unit and they can easily be performed in less than 10 minutes. Two of these procedures, the IF Attenuators Calibration (paragraph 5-6) and the Entry of Noise Source Calibration Data (ENR values and frequencies, part of paragraph 5-7) must be performed on a newly purchased unit prior to use.

No other pre-operational adjustments are required.

## SECTION 3

### OPERATION

#### 3-1. INTRODUCTION

This section of the manual contains information and procedures necessary to operate the Eaton 2075 Noise-Gain Analyzer. The 2075 is microprocessor-controlled using ROM resident firmware. It has an extremely wide range of capabilities and many of the front panel controls have multiple functions. This section of the manual is organized to simplify the process of learning how to operate the 2075, and to rapidly bring the new user to the process of making measurements.

Figure 3-1 and Table 3-1 show the front panel controls and indicators together with their functions and the corresponding keystroke sequences. Figure 3-2 and Table 3-2 show the rear panel controls and indicators together with their functions.

After inspecting and installing the 2075, use the procedure of paragraph 3-9 to enter ENR (Excess Noise Ratio) values. All necessary keystroke sequences are included in the procedure.

The 2075 is used in any of six different test configurations. The type of Device Under Test (DUT) and its output frequencies determine which test configuration is required. This section of the manual contains stand-alone procedures for making measurements in each possible test configuration. Paragraph 3-10 and Table 3-4 serve as a guide to selecting the needed configuration. Table 3-4 also directs the user to the paragraph containing the complete measurement procedure for the needed configuration. Each procedure includes the necessary steps, the control functions used, and the exact keystroke sequences to perform each function. These procedures are basic to making any automatic measurement.

The paragraphs following the test configuration procedures give detailed information on the various subjects relevant to usage of the 2075.

#### 3-2. CAPABILITIES OF THE EATON 2075

The 2075 is fully compatible with the IEEE-488 General Purpose Interface Bus (GPIB). The instrument may be operated in any of three modes: LISTENER/TALKER, TALK ONLY, and LIMITED CONTROLLER.

In LISTENER/TALKER mode, an external controller controls the 2075 via an IEEE-488 GPIB. When the instrument is powered-up, it assumes this mode and is immediately addressable by the external controller. See Section 4 of this manual.

The TALK ONLY (TALK ALWAYS) mode is used to send measurement data to a GPIB compatible printer or other listener device. In this mode no external controller is used and all control of the 2075 is accomplished via the front panel.

The LIMITED CONTROLLER mode is the mode wherein the 2075 controls the frequency and power of a GPIB compatible, external signal source which is used as a local oscillator. The 2075 can use one of several ROM resident programs to control different models of signal sources. It also allows the user to write and enter a custom program via the front panel. No external controller is used while in this mode and all control of the 2075 is accomplished through the front panel.

In any mode, the 2075 can drive an oscilloscope, X-Y plotter, or strip chart recorder to display results of gain or noise measurements. For more information see paragraph 3-42, page 3-89.

The input frequency range of the 2075 extends from 10 MHz to 1850 MHz. In the most basic test configuration, measurements can be made for devices having output frequencies in this range. Through use of one or two stages of external downconversion, measurements can also be made at RF frequencies up to 65.535 GHz (test configurations 2 through 6). Sideband parameters are user selectable allowing measurements to be made single upper sideband, single lower sideband, or double sideband.

The 2075 can make FIXED FREQUENCY or SWEPT FREQUENCY measurements.

FIXED FREQUENCY is the default mode after power-on, and it is the mode in which measurements are made at a single frequency. Before and after measurements, manual frequency increment/decrement keys can be used to tune the frequency up or down in steps. The step size is user selectable. See paragraph 3-6, page 3-21.

In SWEPT FREQUENCY mode, START FREQUENCY, STOP FREQUENCY, and SWEPT FREQUENCY STEP SIZE are entered by the user. The maximum number of measurement points in this mode is equal to the frequency range width in MHz, divided by the maximum frequency resolution. For example, if the measurement range extends from 10 MHz to 1850 MHz, giving a range width of 1840 MHz, dividing 1840 by the maximum frequency resolution of .1 MHz, gives 18,400 measurement points. See paragraph 3-7, page 3-22.

Swept frequency mode is selected by initiating either a SINGLE SWEEP or CONTINUOUS AUTOMATIC SWEEPS.

SECOND STAGE CALIBRATION is the procedure wherein the 2075 measures the noise figure of the entire measurement system, excluding the Device Under Test (DUT). The calibration data obtained is used by the instrument when making corrected (First Stage) measurements of the DUT. During SECOND STAGE CALIBRATION the 2075 can store up to 100 calibration points. The number of calibration points and their frequencies are determined by the measurement frequency parameters entered by the user. See paragraph 3-34, page 3-75.

The 2075 can make uncorrected (cascade) measurements or corrected (first stage) measurements. A cascade measurement gives a single value which includes the noise of the Device Under Test (the first stage) combined with the noise of the measurement system (the second stage). No Second Stage Calibration is necessary before making cascade measurements.

A corrected, or first stage measurement, is essentially a cascade measurement from which the noise contribution of the measurement system has been

subtracted. A Second Stage Calibration must be performed before making a corrected measurement.

After power-up, the 2075 is in the cascade measurement mode by default. Performing the Second Stage Calibration automatically places the instrument into the corrected measurement mode.

Three ENR tables allow the storage of Frequency/ENR values for up to 3 different noise sources. Each table can store the ENR data for up to 31 frequencies. A fourth table stores a single ENR value which can be used for all frequencies. A fifth table can be provided by an optional PROM chip which contains frequency and ENR values for a specific noise source. See paragraph 3-9, page 3-26, and paragraph 3-30, page 3-71.

The 2075 can make the following automatic measurements:

Noise Figure	(F)	(Cascade only)
Noise Figure and Gain (or Loss)	(F+G)	(Corrected only)
Effective Input Noise Temperature	(T <sub>e</sub> )	(Cascade or corrected)
Y-Factor	(Y)	(Cascade only)
Operating Noise Temperature	(T <sub>op</sub> )	(Cascade or corrected)
Power	(dB)	(Cascade or corrected)*
Excess Noise Ratio	(ENR)	(Cascade or corrected)*
Noise Measure	(M)	(Corrected only)

\*Cascade measurements are not recommended for these.

The following measurements can be made manually:

Corrected Noise Figure and Gain (or Loss)	(F+G)	See Paragraph 3-27, page 3-67.
Cascade Noise Figure	(F)	See Paragraph 3-27, page 3-67.
Y-Factor	(Y)	See Paragraph 3-28, page 3-69.

The 2075 can store its front panel control parameters for later retrieval and reuse. Nine sets of control parameters can be stored and then sequentially or randomly retrieved. The retrieval sequence is user programmable. See paragraph 3-48, page 3-110.

A number of special functions, each with multiple subordinate functions, extend the range of the instrument's available features beyond those of the dedicated front panel controls. See paragraph 3-46, page 3-101.

The 2075 displays error messages in the event of a procedural or hardware error. See paragraph 3-47, page 3-106.

Loss or gain compensation is available wherein the 2075 compensates for known losses or gains that cannot be included in Second Stage Calibration. See paragraph 3-40, page 3-86.

Laboratory ambient temperatures can affect the accuracy of noise measurements. The 2075 allows compensation for variations in the cold or off temperature of the noise source and thereby increases measurement accuracy. See Tcold Compensation, paragraph 3-41, page 3-88.

The bandwidth of the DUT, relative to the measurement system, can be a factor affecting measurement accuracy. The 2075 provides a method of compensating for bandwidth differences when the bandwidth of the DUT is less than the measurement bandwidth of the 2075. See Bandwidth Compensation, Paragraph 3-38, page 3-82.

The allowable external gain of the DUT is normally 50 dB. Because this parameter is bandwidth dependent, allowable external gain can be increased to as much as 70 dB. See paragraph 3-35, page 3-77.

### 3-3. CONTROLS AND INDICATORS

The controls and indicators, and their functions, are listed in Table 3-1.

Because the 2075 offers such a wide range of available functions, a single key may initiate two or more functions. The primary function of such a key is indicated by the key label or designation. For example, the key **START FREQ** is used to allow display or entry of the start frequency for a swept measurement. The primary function of a key is initiated by pressing that key once.


Where a key has a secondary function, this function is indicated by the orange lettering above or beside the key. For example, the key **START FREQ** has a secondary function which allows display or entry of an IF frequency from an external mixer. Accordingly, the orange designation, IF, is located just to the left of the key. The secondary, or shift function of a key is initiated by pressing the orange **SHIFT** key first, and then the function key. For example, to enter or display the IF frequency, press **SHIFT** and then **START FREQ**.


In addition to the primary and secondary functions, some keys have a tertiary function. The tertiary function of a key is specific to a particular mode of operation. While in that particular mode, pressing the function key initiates the tertiary function.

The 2075 front panel is designed so that where multiple keystrokes are required, the sequence is from left to right.

The keys of the numeric keypad are used for entry of numeric values. In all cases, the numeric entry is completed by pressing the **ENTER** key.

Table 3-1 lists the controls and indicators together with primary, secondary, and tertiary functions. The exact keystroke sequence for each function is also shown. Wherever functions or procedures are discussed in this manual, the applicable keystroke sequences are also included therein.





CONTROLS AND INDICATORS






Table 3-1. Front Panel Controls and Indicators














ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
1.		<p>Returns front panel control settings to preset values and stores current front panel control settings in memory register 0. Press:</p> 
2.		<p>Allows the entry of special function codes. To place the 2075 into any special function mode press:</p>   
		<p>Allows viewing of the special function table to see which special functions are set to their default (.0) values or to some active state (.1, .2, .3, etc.). To enter the viewing mode, press:</p>  <p>and use the <b>UP ARROW</b> and <b>DOWN ARROW</b> keys to move through the table.</p>
		<p>When already in this viewing mode, to change or enter a special function, enter the desired special function code by pressing:</p>   <p>This will also cause an exit from the viewing mode.</p>
		<p>To exit the special function table viewing mode without changing any settings, press:</p> 
3.		<p>Initiates the shift function (secondary function) of the next key pressed. Press:</p>   <p>If the <b>SHIFT</b> key is pressed accidentally, it can be deactivated by pressing it again.</p>

Table 3-1. Front Panel Controls and Indicators (Continued)

ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
4.	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">LOCAL</div>	<p>Switches the 2075 from REMOTE to LOCAL mode except when local lockout is in effect. When in REMOTE press:</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">LOCAL</div> <hr/> <p>Allows the GPIB address of the 2075 to be displayed or a new address to be entered when in the LOCAL mode. When in the LOCAL mode press:</p> <div style="display: flex; justify-content: center; gap: 10px; margin: 0 auto;"> <div style="border: 1px solid black; padding: 2px;">LOCAL</div> <div style="border: 1px solid black; padding: 2px;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px;">ENTER</div> </div> <hr/> <p>Allows the GPIB address of an external local oscillator to be displayed or a new address to be entered. When in LOCAL mode only, press:</p> <div style="display: flex; justify-content: center; gap: 10px; margin: 0 auto;"> <div style="border: 1px solid black; padding: 2px;">SHIFT</div> <div style="border: 1px solid black; padding: 2px;">LOCAL</div> <div style="border: 1px solid black; padding: 2px;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px;">ENTER</div> </div>
5.	<b>FREQUENCY DISPLAY</b>	<p>This LED display is also referred to as Window A. It displays the frequency, in MHz, of the function being performed. This display also has 8 annunciators. The 4 annunciators on the left refer to GPIB states. These are SRQ (service request), RMT (remote), TALK, and LISTEN. The four annunciators on the right are LO (local oscillator), IF (intermediate frequency), RF, and ENTER. A blinking ENTER annunciator signals the operator to enter a frequency value into an ENR table.</p>
6.	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">ENR</div>	<p>Initiates the entry mode for ENR versus frequency values in the ENR versus frequency tables. Press this key once to initiate the entry mode. Press it again after all the entries have been made, to exit this mode. The lamp in the center of this key is lit while in the entry mode.</p> <p>Allows entry of the value for <math>T_{hot}</math> in kelvins. Press:</p> <div style="display: flex; justify-content: center; gap: 10px; margin: 0 auto;"> <div style="border: 1px solid black; padding: 2px;">SHIFT</div> <div style="border: 1px solid black; padding: 2px;">ENR</div> </div>
7.	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">ON/OFF</div>	<p>When operating in the manual measurement mode (normally used only with a true hot/cold thermal noise source), triggers a measurement. Press:</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">ON/OFF</div> <hr/> <p>Allows entry of the value for <math>T_{cold}</math>, in kelvins. Press:</p> <div style="display: flex; justify-content: center; gap: 10px; margin: 0 auto;"> <div style="border: 1px solid black; padding: 2px;">SHIFT</div> <div style="border: 1px solid black; padding: 2px;">ON/OFF</div> <div style="border: 1px solid black; padding: 2px;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px;">ENTER</div> </div>

Table 3-1. Front Panel Controls and Indicators (Continued)





ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
7.	 (continued)	When Special Function 20.1 is in use, this key is used to display the ON voltage output from the Final Detector. If Special Function 20.2 is in use, pressing this key will display the OFF voltage output from the final detector. In either case, press:  
8.	<b>NOISE DRIVE ON INDICATOR</b>	When operating in the manual measurement mode (normally used only with a true hot/cold thermal noise source), this lamp lights to tell the operator what measurement phase is being taken or has just been completed. <b>ON = hot</b> , <b>OFF = cold</b> . This indicator is not functional in the automatic measurement mode unless enabled by Special Function 21.1.
9.	<b>NOISE DRIVE CONNECTOR</b>	Supplies +28.00 volts DC drive voltage for a solid state calibrated noise source.
10.	<b>GAIN DISPLAY</b>	This display is also referred to as Window B. It displays Gain (G) or loss, ENR values, and temperature values entered by the user. Gain, loss, and ENR values may be displayed in dB or as ratios. Temperatures may be displayed as kelvins, degrees Centigrade, or degrees Fahrenheit. The eight annunciators in this display are LOSS, ENR, T(degrees F), T(degrees C), dB, RATIO, T(K), and ENTER. The ENTER annunciator blinks when the user is required to enter an ENR value.
11.	<b>ANALOG GAIN METER</b>	Is an analog indicator for Gain. The meter range is set by entering upper and lower meter limits for Gain. See items 35 and 36 of this table.
12.		Changes the Window B unit of display for Gain or ENR from dB to a ratio or vice versa. An annunciator in the display shows which display unit is selected.  Press:  
13.	<b>NOISE FIGURE DISPLAY</b>	This display is also referred to as Window C. It displays Noise Figure, Y Factor, Effective Input Noise Temperature, Power Noise Measure, and Operating Noise Temperature. Noise Figure, Noise Measure, Y-Factor, and Power may be displayed as dB or as a ratio, depending on the unit of display selected. The eight annunciators in this display are F, Y, T <sub>e</sub> (K), dB PWR, dB, RATIO, M, and T <sub>op</sub> (K).

Table 3-1. Front Panel Controls and Indicators (Continued)










ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
14.	<b>ANALOG NOISE METER</b>	Is an analog indicator for noise figure. The meter range is set by entering upper and lower limits for the measurement desired. See items 35 and 36 of this table.
15.		<p>Changes the Window C unit of display from dB to a ratio or vice versa. An annunciator in the display indicates which is selected. Press:</p> 
16.		<p>Initiates an FCAL (frequency calibration) if Special Function 15.0 is enabled, and then a second stage calibration of the 2075. During second stage calibration the 2075 measures its own noise figures at different frequencies and stores these values for later use during corrected noise figure and gain measurements. Press:</p> 
		<p>This key also is used to abort a calibration in progress. Press:</p> 
		<p>Initiates a second stage calibration at the single fixed frequency to which the 2075 is currently tuned. Press:</p>  
17.	<b>POWER ON/OFF SWITCH</b>	Applies line voltage to the 2075 when the switch is set to ON.
18.	<b>SMOOTHING INDICATOR</b>	Shows the degree of smoothing currently in use. Each lit LED bar indicates a power of 2 increase in the smoothing factor. Smoothing factor is equal to the number of readings taken and averaged before the measurement is displayed when in the swept mode. Exponential smoothing is used during single frequency measurements.
19.		<p>Adds smoothing in increments equal to powers of 2. Press or hold:</p> 

Table 3-1. Front Panel Controls and Indicators (Continued)











ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
20.		Subtracts smoothing in decrements equal to powers of 2. Press or hold: 
21.	<b>RF INPUT CONNECTOR</b>	Is the 2075 input connector.
22.		Initiates measurement of corrected Noise Figure and Gain. Press:  *  Initiates measurement of corrected $T_e$ (Effective Noise Temperature) and Gain. Press:   *  *Requires prior Second Stage Calibration
23.		Initiates measurement of uncorrected Noise Figure. Press:   Initiates measurement of uncorrected $T_e$ (Effective Noise Temperature) in kelvins. Press:  
24.	<b>RELAY POWER ON INDICATOR</b>	This green lamp lights to indicate that the selected relay power voltage is present at the RELAY POWER OUTPUT CONNECTOR. This voltage is automatically turned on when the <b>CALIB</b> key is pressed.
25.	<b>RELAY POWER CONNECTOR</b>	This output connector provides a jumper selectable DC voltage of +5, +15, or +30 volts which may be used to actuate external relays. The external relays are used to bypass the DUT (Device Under Test) during Second Stage Calibration.

Table 3-1. Front Panel Controls and Indicators (Continued)

ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
26.	<b>DATA ENTRY KEYPAD</b> <b>0-9, -, .</b>	Used to enter numeric data for various instrument functions. Digits keyed-in are displayed but do not become effective until the <b>ENTER</b> key is pressed. Press: <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px 5px;"><i>numeric data keys</i></div> <div style="border: 1px solid black; padding: 2px 5px;">ENTER</div> </div>
27.	<div style="border: 1px solid black; padding: 2px 5px;">CLEAR</div>	Clears all numeric data which has been keyed-in but not yet terminated with the <b>ENTER</b> key. After the unwanted or erroneous numerics have been keyed-in, press: <div style="border: 1px solid black; padding: 2px 5px; margin: 10px auto;">CLEAR</div>
		When in the ENR versus Frequency entry mode, clears the Frequency/ENR pair currently displayed. Press: <div style="border: 1px solid black; padding: 2px 5px; margin: 10px auto;">CLEAR</div>
		When in the ENR versus Frequency entry mode, clears the table in use. Press: <div style="display: flex; justify-content: space-around; align-items: center; margin: 10px auto;"> <div style="border: 1px solid black; padding: 2px 5px;">SHIFT</div> <div style="border: 1px solid black; padding: 2px 5px;">CLEAR</div> </div>
28.	<div style="border: 1px solid black; padding: 2px 5px;">ENTER</div>	Completes all numeric data entries. Numeric data which has been keyed-in does not take effect until this key has been pressed. Press: <div style="display: flex; justify-content: space-around; align-items: center; margin: 10px auto;"> <div style="border: 1px solid black; padding: 2px 5px;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px 5px;">ENTER</div> </div> When entering frequency and ENR values this key can be used to toggle the blinking <b>ENTER</b> annunciator back and forth between Window A and Window B. The <b>ENTER</b> annunciator indicates which value must be entered next, frequency or ENR. Press: <div style="border: 1px solid black; padding: 2px 5px; margin: 10px auto;">ENTER</div>
29.	<div style="border: 1px solid black; padding: 2px 5px;">SEQ</div>	Causes sequential stepping through nine (1-9) of the ten front panel storage registers. The number of each register is displayed as it becomes available for access. These registers store front panel control settings for later recall and reuse. See paragraph 3-47. Press: <div style="display: flex; justify-content: space-around; align-items: center; margin: 10px auto;"> <div style="border: 1px solid black; padding: 2px 5px;">SEQ</div> <div style="border: 1px solid black; padding: 2px 5px;">ENTER</div> </div>

Table 3-1. Front Panel Controls and Indicators (Continued)


























ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
29.	 (continued)	Allows reprogramming of the stepping sequence through the 9 front panel storage registers. Key-in the entire new sequence before pressing the <b>ENTER</b> key. Press:    
30.		Causes the current front panel control settings to be stored in 1 of the 9 front panel storage registers. Press:   
31.		Causes a set of previously stored front panel control settings to be recalled from any of the 10 storage registers and made active. Press:     Continues a sweep which was stopped in progress, from the point at which it was stopped. See item 39 of this table. Press:  
32.		Allows entry of a fixed frequency to be used for a single frequency measurement. Press:     Allows entry of the frequency step size for manual frequency incrementing only. (If the frequency step size for automatic continuous sweeps or single sweeps is changed, using item 40 of this table, the manual frequency incrementing step size will automatically change to that same value.)    
33.		Causes frequency to step upward when in the fixed frequency mode. Also causes frequency to increment when viewing Frequency versus ENR tables. Press or hold: 

Table 3-1. Front Panel Controls and Indicators (Continued)

















ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
33.	 (continued)	<p>Causes incrementing through the special functions table when in the special functions viewing mode. See item 2 of this table. Press or hold:</p> 
34.		<p>Allows entry of a signal amplitude (in dBm only) for an external local oscillator. Press:</p>    
35.		<p>Causes decrementing through the special functions table when in the special functions viewing mode. Press or hold:</p> 
		<p>Allows entry of the Second Local Oscillator frequency used in DUT (Device Under Test) Configuration 6. Press:</p>    
		<p>Allows entry of the upper limit for Window C measurements. The minimum upper limit allowed is -30 and the maximum upper limit allowed is 9999. The value entered is used by the 2075 only to set the range of the ANALOG NOISE METER and to set the range for the SCOPE/PLOTTER OUTPUT. Press:</p>   



Table 3-1. Front Panel Controls and Indicators (Continued)

ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
35.	<div style="border: 1px solid black; padding: 2px; display: inline-block; text-align: center;">UPPER LIMIT</div> (continued)	<p>Allows entry of the upper limit for Gain. The maximum allowable upper limit is 80 dB and the minimum allowable upper limit is -30 dB. This value is used by the 2075 to set the ranges for the ANALOG GAIN METER and the SCOPE/PLOTTER OUTPUT. Press:</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; text-align: center;">SHIFT</div> <div style="border: 1px solid black; padding: 2px; text-align: center;">UPPER LIMIT</div> <div style="border: 1px solid black; padding: 2px; text-align: center;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px; text-align: center;">ENTER</div> </div>
36.	<div style="border: 1px solid black; padding: 2px; display: inline-block; text-align: center;">LOWER LIMIT</div>	<p>Allows entry of the lower limit for measurements displayed in Window C. The minimum allowable lower limit is -30. The maximum allowable lower limit is 9999. The value entered is used by the 2075 only to set the range of the ANALOG NOISE METER and to set the range for the SCOPE/PLOTTER OUTPUT. Press:</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; text-align: center;">LOWER LIMIT</div> <div style="border: 1px solid black; padding: 2px; text-align: center;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px; text-align: center;">ENTER</div> </div>
		<p>Allows entry of the lower limit for Gain. The minimum allowable lower limit is -30 dB. The maximum allowable lower limit is 80 dB. The value entered is used by the 2075 only to set the ranges for the ANALOG GAIN METER and the SCOPE/PLOTTER OUTPUT. Press:</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; text-align: center;">SHIFT</div> <div style="border: 1px solid black; padding: 2px; text-align: center;">LOWER LIMIT</div> <div style="border: 1px solid black; padding: 2px; text-align: center;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px; text-align: center;">ENTER</div> </div>
37.	<div style="border: 1px solid black; padding: 2px; display: inline-block; text-align: center;">START FREQ</div>	<p>Allows entry of the start frequency for frequency sweeps. Press:</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; text-align: center;">START</div> <div style="border: 1px solid black; padding: 2px; text-align: center;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px; text-align: center;">ENTER</div> </div>
		<p>Causes the 2075 to tune to the current start frequency value. The previous value for fixed frequency is lost and replaced with this current start frequency value. Press:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; text-align: center;">START FREQ</div>
		<p>Allows entry of the IF frequency from the external mixer when external downconversion is required in test configurations 2, 4, and 6. The IF frequency is the input frequency to the 2075. Press:</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; text-align: center;">SHIFT</div> <div style="border: 1px solid black; padding: 2px; text-align: center;">START FREQ</div> <div style="border: 1px solid black; padding: 2px; text-align: center;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px; text-align: center;">ENTER</div> </div>

Table 3-1. Front Panel Controls and Indicators (Continued)

ITEM	DESIGNATION	FUNCTIONS AND KEYSTROKE SEQUENCES
38.	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">STOP FREQ</div>	Allows entry of the stop frequency for frequency sweeps. Press:  <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">STOP FREQ</div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">ENTER</div> </div>
		Causes the 2075 to tune to the current value for stop frequency. The previous value for fixed frequency is lost and replaced with this current stop frequency value. Press:  <div style="border: 1px solid black; padding: 2px; margin: 0 auto;">STOP FREQ</div>
		Allows entry of a fixed Local Oscillator frequency when external downconversion is required (DUT Test Configurations 2-6). Press:  <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">SHIFT</div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">STOP FREQ</div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">ENTER</div> </div>
39.	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">SWEEP</div>	Initiates continuous automatic sweeps from start frequency to stop frequency. Each sweep is composed of incremental frequency steps across the band. Press:  <div style="border: 1px solid black; padding: 2px; margin: 0 auto;">SWEEP</div>
		Stops a sweep in progress and leaves the 2075 tuned to the frequency at which the sweep was stopped. See item 31 in this table. Press:  <div style="border: 1px solid black; padding: 2px; margin: 0 auto;">SWEEP</div>
		Initiates a single sweep from the start frequency to the stop frequency. Press:  <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">SHIFT</div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">SWEEP</div> </div>
40.	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">STEP SIZE</div>	Allows entry of the incremental frequency step size for automatic continuous or single sweeps (.1 MHz minimum). Entering this value will also change the step size for manual frequency incrementing or decrementing. Press:  <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">STEP SIZE</div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;"><i>numeric keys</i></div> <div style="border: 1px solid black; padding: 2px; margin: 0 5px;">ENTER</div> </div>




Figure 3-2. 2075 REAR PANEL

Table 3-2. Rear Panel Controls and Indicators

ITEM	DESIGNATION	FUNCTION
1.	<b>RF INPUT CONNECTOR</b>	This RF INPUT connector on the rear panel is optional when ordering the 2075. It is also possible to remove the front panel RF INPUT connector and install it on the rear panel. The internal semi-rigid coaxial cable can be reshaped to make the necessary connection.
2.	<b>DET OUT</b>	This BNC connector is the test output for the Final Detector output voltage.
3.	<b>IF OUT</b>	This BNC connector is the test output for the 30 MHz signal which is the result of the second stage of internal downconversion in the 2075.
4.	<b>RELAY POWER CONNECTOR</b>	This output connector provides a jumper selectable DC voltage of +5, +15, or +30 volts which may be used to actuate external relays. The external relays are used to bypass the DUT during Second Stage Calibration. This connector parallels the RELAY POWER connector on the front panel.

Table 3-2. Rear Panel Controls and Indicators (Continued)

ITEM	DESIGNATION	FUNCTION
5.	<b>NOISE DRIVE CONNECTOR</b>	Supplies +28.00 volts DC for the solid state calibrated noise source. Parallels the NOISE DRIVE connector on the front panel.
6.	<b>X OUTPUT</b>	This BNC connector is the output for the horizontal drive signal to the scope/plotter X axis. The X axis drives for both gain and noise figure traces are output alternately. The sawtooth waveform minimum and maximum voltages are 0 and 6 volts respectively.
7.	<b>Y OUTPUT</b>	This BNC connector is the output for the scope/plotter Y axis. The Y axis drives for both gain and noise data are output singly or alternately depending on the setting of Special Function 7. The minimum and maximum voltages are 0 and 6 volts respectively.
8.	<b>INTENSITY ADJUST</b>	This adjustment controls the brightness of the gain and noise figure traces on the oscilloscope.
9.	<b>Z OUTPUT</b>	This BNC connector is the output for the scope/plotter Z axis. This positive going signal blanks the oscilloscope during retrace or activates the pen lift on the plotter. It also decreases the intensity for the gain trace. When both gain and noise figure are being displayed on an oscilloscope, the noise trace is the brighter one. The signal minimum and maximum voltages are 0 and 5 volts.
10.	<b>GPIB</b>	This 24 pin connector is the input/output connector for the General Purpose Interface Bus (IEEE-488). Pin numbers are illustrated in Figure 2-5.
11.	<b>AC POWER</b>	This is the receptacle for the AC power cord, the holder for the AC fuse, and the receptacle for the AC voltage selector card.

### 3-4. POWER-ON CONDITIONS, PRESET, AND TOTAL SYSTEM RESET

#### Power-On Conditions

When the 2075 is powered-on, it automatically performs a series of self-tests. These check the operation of the Math Processor, RAM's, ROM's, GPIB Controller Chip, the Direct Memory Access Controller (DMAC), and the Scope/Plotter Output

Interface. Finally, the instrument performs a Frequency Calibration (FCAL) which ensures the accuracy of its frequency tuning. Immediately after placing the POWER switch in the ON position, the following correct indications will be observed:

1. All front panel red LED's and indicators light briefly.
2. The words SELF TEST appear in Windows A and B while the numbers 1 through 6 appear sequentially in Window C.
3. The message FCAL appears briefly in Window B.

When the frequency calibration is completed, the instrument restores the frequency and control parameters it had before it was last powered-off, except for the following:

The instrument is in LOCAL mode.

The instrument is in Fixed Frequency Mode and is tuned to the last frequency set prior to power-down.

The measurement mode is Uncorrected (Cascade) Noise Figure.

The instrument is in the Continuous Measurement Mode (it is continuously making measurements).

Previous Second Stage Calibration data is lost.

The SRQ (Service Request) function is disabled.


Some special functions are restored to their previous values and others revert to their default or .0 state. For a complete listing of power-on control parameters see Column 2 of Table 3-3.

## Preset

The **PRESET** key can be pressed at any time to restore certain of the control parameters to known preset values. This feature is typically used after a power-on or when previous control parameters are unknown. Some parameters and special functions are not affected by the PRESET function and will remain in their previous states. See Column 3 of Table 3-3 for a complete list of PRESET parameter values.

## Total System Reset

This is a special function which erases all previous frequency and control parameters including ENR tables. After the parameters are erased, some are automatically replaced with values from ROM. This special function is typically used as a security measure after confidential measurements have been made. It should also be performed after the 2075 has been unused for a long enough period of time that the data in battery backed-up RAM may be unreliable. To do a Total System Reset press:



After the system reset, an IF Attenuator Calibration (Special Function 19.1) must be performed. See paragraph 3-36, page 3-78.

Column 4 of Table 3-3 shows what control parameter values are in effect after the total system reset is performed.

Column 5 of Table 3-3 shows which control parameters can be stored in the STORE-RECALL registers (paragraph 3-48, page 3-110).

Table 3-3. Power-On, Preset, and Total System Reset Parameters

This is a listing of all the control parameters and special functions settings which are in effect after a Power-up, Preset, or Total System Reset via Special Function 0.9. The last column shows which control parameters can be stored in the Store-Recall registers.

PARAMETER	POWER ON	PRESET or DEVICE CLEAR	TOTAL SYSTEM RESET (SP FN 0.9)	STORABLE IN REGISTERS
<b>INPUT PARAMETERS</b>				
Tuned Frequency	N.C.	30 MHz	30 MHz	YES
Start Frequency	N.C.	10 MHz	10 MHz	YES
Stop Frequency	N.C.	1900 MHz	1900 MHz	YES
Swept Frequency Step Size	N.C.	20 MHz	20 MHz	YES
Fixed Frequency Step Size	N.C.	20 MHz	20 MHz	YES
Fixed Frequency Step Size	N.C.	20 MHz	20 MHz	YES
Ext LO 1 Frequency	N.C.	1000 MHz	1000 MHz	YES
Ext LO 2 Frequency	N.C.	1000 MHz	1000 MHz	YES
Int IF Frequency	N.C.	30 MHz	20 MHz	YES
LO Settling Time	N.C.	N.C.	100 msec	
LO Power Level	N.C.	0 dBm	0 dBm	YES
RF Frequency	N.C.	N.C.	10 MHz	
RF Start Frequency	N.C.	N.C.	10 MHz	
RF Stop Frequency	N.C.	N.C.	1900 MHz	
RF Sweep Delta	N.C.	N.C.	20 MHz	
RF Step Size	N.C.	N.C.	20 MHz	
<b>SCOPE/PLOTTER PARAMETERS:</b>				
Noise Upper Limit	30	30	30	YES
Noise Lower Limit	0	0	0	YES
Gain Upper Limit	80 dB	80 dB	80 dB	YES
Gain Lower Limit	-20 dB	-20 dB	-20 dB	YES
<b>LOSS COMPENSATION PARAMETERS:</b>				
Loss Before DUT	0 dB	0 dB	0 dB	
Loss After DUT	0 dB	0 dB	0 dB	
Temperature of Losses	290 k	290 k	290 k	
<b>BANDWIDTH COMPENSATION PARAMETERS:</b>				
Bandwidth 1	5 MHz	5 MHz	5 MHz	
Bandwidth 2	5 MHz	5 MHz	5 MHz	
ENR Table Selection (sp fn 5)	N.C.	N.C.	TABLE 0	
ENR Tables	N.C.	N.C.	CLEAR ALL	
Nom ENR Value	N.C.	N.C.	15.5 dB	
T <sub>Hot</sub> Entry	9893 k	N.C.	9893 k	YES
T <sub>Cold</sub> Entry	296.0 k	N.C.	296.0 k	

N.C. = no change from previous set value

Table 3-3. Power-On, Preset, and Total System Reset Parameters (Continued)

PARAMETER	POWER ON	PRESET or DEVICE CLEAR	TOTAL SYSTEM RESET (SP FN 0.9)	STORABLE IN REGISTERS
<b>BANDWIDTH COMPENSATION PARAMETERS (Continued):</b>				
IF Calibration Data	SAVED	SAVED	CLEARED	
Second Stage Calibration Data	CLEARED	CLEARED	CLEARED	
Store/Recall Registers	SAVED	SAVED (and the current front panel is saved in register 0)	CLEARED	
Set Sequence	SAVED	SAVED	CLEARED	
<b>SPECIAL FUNCTIONS:</b>				
1	N.C.	1.1	1.1	YES
2	N.C.	2.0	2.0	YES
3	N.C.	3.0	3.0	
4	4.0	4.0	4.0	
5	N.C.	N.C.	5.0	YES
6	6.0	6.0	6.0	
7	(7.2 OR 7.6)		7.2	
8	8.0	8.0	8.0	
9	N.C.	9.0	9.0	
10	10.0	10.0	10.0	
11	11.1*	11.0	11.0	
12	N.C.	12.0	12.0	
13	13.1*	13.0	13.0	
14	14.0	14.0	14.0	
15	15.0	15.0	15.0	
16	16.1	16.1	16.1	
17	17.0	17.0	17.0	
18	18.0	18.0	18.0	
19	19.0	19.0	19.0	
20	20.0	20.0	20.0	
21	21.0	21.0	21.0	
22	22.0	22.0	22.0	
23	23.0	23.0	23.0	
24	N.C.	24.0	24.0	
30	30.0	30.0	30.0	
31	31.0	31.0	31.0	
32	32.0	32.0	32.0	
33	33.0	33.0	33.0	

\* = is set to this value but is not active

Table 3-3. Power-On, Preset, and Total System Reset Parameters (Continued)

PARAMETER	POWER ON	PRESET or DEVICE CLEAR	TOTAL SYSTEM RESET (SP FN 0.9)	STORABLE IN REGISTERS
<b>SPECIAL FUNCTIONS (Continued):</b>				
34	34.0	34.0	34.0	
35	35.0	35.0	35.0	
36	36.0	36.0	36.0	
37	37.0	37.0	37.0	
38	38.0	38.0	38.0	
39	39.0	39.0	39.0	
40	40.0	40.0	40.0	YES
42	42.0	42.0	42.0	
43	43.0	43.0	43.0	
44	44.0	44.0	44.0	
45	45.0	45.0	45.0	
46	46.0	46.0	46.0	
47	N.C.	N.C.	47.0	YES
48	48.0	48.0	48.0	
49	N.C.	49.0	49.0	


\* = is set to this value but is not active

**3-5. CONTINUOUS MEASUREMENT MODE AND THE HOLD FUNCTION**


After the 2075 completes its power-on sequence, it goes into the Continuous Measurement Mode which is its normal mode. While in this mode, fixed frequency measurements are made at a maximum rate of 11 times per second, at the current tuned frequency.

While the user enters the various control and frequency parameters prior to making the desired measurement, the instrument will continue to make measurements in this continuous mode. Thus, measurements will be made before a complete and consistent set of parameters can be entered by the user. This may result in error messages.

A HOLD function is provided which takes the instrument out of continuous measurement mode and prevents this situation. This is a special function. To activate HOLD press:



After all the control and frequency parameters have been entered the HOLD function should be deactivated. To deactivate HOLD and restore the instrument to continuous measurement mode, press:






### 3-6. FIXED FREQUENCY OPERATION

In the Fixed Frequency Mode the 2075 makes measurements at a single frequency. The instrument is in this mode after power-on until a Swept Frequency Mode is selected by the user.

#### Fixed Frequency Value

The **FIXED FREQ** key is used to display the current fixed frequency or to enter a new fixed frequency value. Entering a fixed frequency value tunes the 2075 to that frequency. In Test Configurations 1 and 4, the allowable frequency entries are 10 MHz to 1900 MHz. In Test Configurations 2, 3, 5, and 6, the allowable entries are 10 MHz to 65.535 GHz.

To enter a Fixed Frequency value (for example, 1600 MHz) press:



#### Fixed Frequency Step Size

In the Fixed Frequency Mode a Fixed Frequency Step Size may be entered and then used for manual tuning in step size increments.

In Test Configuration 1 the smallest entry allowed is .1 MHz and the largest is 1800 MHz. An entry resolution of .1 MHz is allowed only in Test Configuration 1.

In Test Configurations 2 through 6, the smallest entry allowed is 1 MHz and the largest is 1800 MHz. In these test configurations, always enter an integer value of MHz. If a fractional value is entered, the 2075 will automatically round it off to the nearest whole number in MHz, unless Special Function 9.1 is activated. Also, if an entry is made which is too small or too large, the instrument will automatically force that entry to the smallest or largest allowable value, whichever applies.

To enter a Fixed Frequency Step Size (for example, 50 MHz) press:



Note that this procedure is different from the procedure for entering the frequency step size for swept measurements. Also, note that whenever a Swept Frequency Step Size is entered, it replaces the Fixed Frequency Step Size. See items 32 and 40 of Table 3-1, pages 3-11 and 3-14.

#### Manual Tuning

The frequency to which the 2075 is tuned may be changed by entering a new fixed frequency or by pressing the **UP ARROW** or **DOWN ARROW** keys. These keys move the tuning up or down in increments equal to the Fixed Frequency Step Size.

For example, if the instrument is currently tuned to 1600 MHz and a fixed frequency step size of 50 MHz has been entered, pressing the **UP ARROW** key once will tune the instrument to 1650 MHz. Pressing the **UP ARROW** key again will tune it to 1700 MHz. Holding the **UP ARROW** or **DOWN ARROW** key will cause continuous incrementing or decrementing. Manual tuning changes the stored value for fixed frequency by setting it equal to the new tuned frequency.

The frequency display will not display fractional frequency values (allowed only in Test Configuration 1) unless Special Function 9.1 is enabled (display 100 KHz resolution).

If the instrument is in the corrected measurement mode (a Second Stage Calibration must already have been performed) when it is tuned to a frequency point for which calibration data has not been taken, error message 110 will appear. The message indicates that measurement is being made at an uncalibrated point. This error can be avoided by pressing the **F** key to place the instrument in the uncorrected (cascade) measurement mode before tuning manually. It can also be avoided by activating Special Function 24.1 which causes calibration data to be interpolated for uncalibrated frequency points.

To perform a second stage calibration in the Fixed Frequency Mode, first tune to the desired frequency and then press:



The 2075 takes calibration data only for that frequency.


### 3-7. SWEPT FREQUENCY OPERATION

In Swept Frequency Mode, the 2075 steps from a Start Frequency to a Stop Frequency in discrete increments which are determined by the Swept Frequency Step Size. Measurements are made at the Start Frequency, at each step, and at the Stop Frequency.


In Test Configuration 1 the allowable maximum sweep range is from 10 MHz to 1900 MHz. The minimum step size allowed is .1 MHz.

In Test Configurations 2 through 6, the allowable maximum sweep range is from 10 MHz to 65.535 GHz. The minimum step size allowed is 1 MHz. These limitations are modified, in practice, by the frequency parameters of the external local oscillator, the external mixer, and the noise source in use.


To enter the Start Frequency (for example, 50 MHz) press:



To enter the Stop Frequency (for example, 1700 MHz) press:



To enter the Swept Frequency Step Size (for example, 25 MHz) press:



It should be noted that entry of a Swept Frequency Step Size also changes the Fixed Frequency Step Size to the value entered.

Two swept frequency modes are available: Single Sweep and Continuous Automatic Sweeps.

To select Single Sweep Mode and initiate a single swept measurement, press:



The 2075 executes a single sweep and then remains tuned to the Stop Frequency.

To select Continuous Automatic Sweeps, press:



The 2075 begins sweeping continuously.

To interrupt a single sweep or continuous sweeps, press:



The instrument stops and remains tuned to the last frequency point measured just before the key was pressed.

To continue the sweep from the point where it was stopped, press:



Or, to restart the sweep beginning at the Start Frequency, press:



If the final increment (Step Size) of a sweep would cause the sweep to go past the programmed Stop Frequency, the instrument tunes only a partial increment and ends that sweep at the Stop Frequency. It should be noted that the partial increment will appear as a full increment if displayed on an oscilloscope.

The Start Frequency, Step Size, and Stop Frequency values also determine the frequency points at which second stage calibration is performed. A maximum of 100 calibration points can be taken. To perform a swept frequency Second Stage Calibration, press:

CALIB

For more information on Second Stage Calibration, see paragraph 3-34, page 3-75.

After power-on, the 2075 is in the Fixed Frequency Mode until a swept mode is selected.

### 3-8. UNCORRECTED AND CORRECTED MEASUREMENTS

The 2075 allows the user to make any type of measurement and then easily go from one type to another. Figure 3-3 illustrates the relationship between the uncorrected (cascade) and corrected (first stage) measurement modes and shows what measurements can be made in each. The intent here is to show the user:

- a. how to switch back and forth from the corrected to the uncorrected mode, and
- b. how to make each type of measurement in either mode.

This is not a detailed procedure but is merely intended to give the user an overview of the basic modes and measurement types. Detailed procedures, specific to each test configuration, are given in paragraphs 3-11 through 3-18.

Before any measurements are made, these initial steps must be performed:

1. ENR values (noise source calibration data) must be entered into an ENR table. (Paragraph 3-9)
2. The correct test configuration must be selected. (Paragraph 3-10)
3. All frequency parameters must be entered. After this step the instrument is in the uncorrected (cascade) measurement mode and any uncorrected measurement can now be made. Uncorrected Noise Figure (F) is the default measurement if none is selected.
4. Perform a Second Stage Calibration. After this step the instrument is automatically in the corrected (first stage) measurement mode and any corrected measurement can be made. This step is not required unless corrected measurements are desired. Corrected Noise Figure and Gain (F+G) is the default measurement if none is selected.

The left branch of the diagram shows the choices for uncorrected measurements. The right branch shows the choices for corrected measurements. When in the left branch or the right branch, any of the measurements shown in that branch can be made in any sequence.

Pressing the **F** key changes the mode from the right branch to the left branch (corrected mode to uncorrected mode). Conversely, pressing the **F + G** key changes from the left branch back to the right branch, but only if Second Stage Calibration has been performed. Otherwise perform Step 4 to go from the left branch to the right branch.

Note that no Second Stage Calibration is necessary before making uncorrected measurements. Second Stage Calibration is always necessary before making corrected measurements.

It should be noted that after the keystroke sequence has been entered to choose a particular measurement, it is necessary to select either single sweep (**SHIFT SWEEP**) or continuous automatic sweeps (**SWEEP**) to execute the swept measurement.




Figure 3-3. UNCORRECTED AND CORRECTED MEASUREMENTS

### 3-9. ENTRY OF FREQUENCY AND ENR VALUES

After the 2075 has been installed, the first procedure that must be performed prior to operation is the entry of paired frequency and ENR values into the ENR storage table. Tables 1, 2, and 3 each allow entry of up to 31 sets of values. Thus, frequency and ENR values may be stored for as many as 3 separate noise sources. Table 0 can store only one ENR value and uses it for all frequencies. Table 0 generally is used either for fixed frequency measurements, or for swept measurements when the desired accuracy is less than the positive and negative deviations from the nominal ENR value across the frequency range of interest.



Although frequency and ENR values should have been entered into Table 1 during the Second Stage Calibration Procedure (part of the Performance Verification Procedures of Section 5), the procedure below should be performed to insure that the values in the table are those for the noise source which will be used while taking measurements. Measurements cannot be made unless ENR values have been entered.

Perform the following steps:

1. Select the noise source which will be used to make the measurements.
2. Apply AC power to the 2075.
3. Allow several seconds for the 2075 to complete its automatic power-up self-tests. These are completed when the message FCAL has appeared in, and then disappeared from, Window B.
4. Press the **PRESET** key. Wait until the new FCAL message disappears from Window B, signifying that the frequency calibration is completed. PRESET restores the control parameters to a set of known values.

5. Press:   

This calls up, or activates, Table 1. The data about to be entered will be stored in Table 1 (5.2 would have called up Table 2 and 5.3 would have called up Table 3). The error message 104 may appear indicating that no data is currently stored. If so, it may be disregarded.

6. Press:  

This places the 2075 in the mode which allows entry of the frequencies and ENR values. The red light in the center of the ENR key is illuminated. Also, the ENTER annunciator in Window A begins to blink, signifying that the operator is required to enter a frequency.

7. Enter the first calibration frequency, in MHz, from the noise source calibration data sheet (for example, 10 MHz) by pressing:



The frequency just entered appears in Window A. The ENTER annunciator in Window B begins to blink signifying that the operator is required to enter the ENR value, in dB, for the frequency just entered.

8. Read the ENR value for the frequency just entered, from the noise source calibration data sheet, or the inscribed label on the calibrated noise source. Enter this value by pressing:




The value just entered appears in Window B. This completes the entries for the first frequency. The ENTER annunciator in Window A begins to blink, indicating that the next frequency should be entered.

9. Enter the next frequency, in MHz, from the noise source calibration data sheet by pressing:



The frequency just entered appears in Window A. The ENTER annunciator in Window B begins to blink, signifying that the ENR value for that frequency should now be entered. ENR values are always entered in decibels.

10. Enter the ENR value by pressing:



The value just entered appears in Window B. Now the ENTER annunciator in Window A will start to blink again, indicating that the next frequency should be entered.

11. Continue to enter paired frequency and ENR values for all data points shown on the noise source calibration data sheet. The frequency range of the entries must equal or exceed the range over which measurements will be made. That is, measurements cannot be made at RF frequencies which are outside the lowest and highest frequencies of ENR entries. Up to 31 frequency and ENR value pairs may be entered into each of Tables 1, 2, and 3.
12. After all the entries have been made, use the **DOWN ARROW** and **UP ARROW** keys to examine the entries for correctness. Step down through the table by pressing or holding the **DOWN ARROW** key. Step up through the table by pressing or holding the **UP ARROW** key.

To clear an erroneous entry, first display it using the **UP** or **DOWN ARROW** keys and then press the **CLEAR** key. Both the frequency and the ENR value will be cleared. Then enter the correct value. The **ENTER** key can be used to toggle the ENTER annunciator back and forth between Window A and Window B. See paragraph 3-31 for more information. To clear the entire table, press:



13. Press:



This takes the 2075 out of the ENR table entry and display mode. The red light in the center of the **ENR** key will go out.

14. This completes the entry of ENR data. Because Table 1 was selected (by Special Function 5.1) to store the data, Table 1 will automatically be used by the 2075 when measurements are made. Table

1 will continue to be used until some other table is selected by entering Special Function 5.2, 5.3, 5.4, or 5.0. For more detailed information on use of ENR Tables, see paragraph 3-31.

15. Go to paragraph 3-10 on page 3-27 to select the correct test configuration for the device to be tested.

### 3-10. SELECTING THE CORRECT TEST CONFIGURATION

The 2075 may be used in any of 6 different test configurations. Generally, the type of Device Under Test and its output frequencies determine which test configuration must be used. Additional considerations are the width of the RF frequency range of the desired measurement, and availability of GPIB compatible local oscillators.

For the purpose of choosing the correct test configuration, consider that there are two basic types of DUT's. These two types may loosely be categorized as amplifier devices or receiver devices. These are defined below:

**AMPLIFIER:** Any linear device whose input and output frequencies are the same. This category includes amplifiers, filters, attenuators, isolators, PIN switches, etc.

**RECEIVER:** Any linear device (linear in terms of input and output power) whose input and output frequencies are different. This category includes receivers, tuners, mixers, etc.

When the DUT is an amplifier with an output frequency higher than 1850 MHz, external downconversion is required to produce an IF frequency below 1850 MHz. This IF is then input to the 2075. The 2075 has the capability to control the frequency and power of the external local oscillator used in this process (provided that it is GPIB compatible).

The frequency of the local oscillator can be varied by the 2075 to produce a fixed IF (Test Configuration 2). This method is used where the measurement is to be

made over a relatively wide RF frequency range. For example, the swept measurement can be made across the RF band from 5 GHz to 10 GHz and converted to a single, fixed frequency IF below 1850 MHz.

The frequency of the local oscillator can remain fixed to produce a variable frequency IF from the mixer (Test Configuration 3). This IF must not vary over a range greater than 1850 MHz or it will exceed the input frequency range of the 2075. This method can be used when the swept measurement is taken across a relatively narrow RF frequency band. In this application the local oscillator need not be GPIB compatible.

Where the DUT is a receiver device such as a mixer, the 2075 can control the frequency and power of the external local oscillator which drives the DUT. Again, the local oscillator frequency can be automatically varied to give a fixed IF output from the DUT, useful for measurement over a wide RF range (Test Configuration 4).

For narrow band measurements, the local oscillator frequency can remain fixed to give a variable IF output (Test Configuration 5).

In cases where the DUT is a receiver having an IF output frequency higher than 1850 MHz, a second stage of external downconversion is required (Test Configuration 6). Here, a fixed frequency local oscillator drives the DUT, giving a variable frequency IF. This variable IF is applied to a second mixer. The local oscillator driving the second mixer is tuned by the 2075 via the IEEE-488 Interface Bus, to give a fixed frequency IF.

Table 3-4 is used to select the correct test configuration for the device to be tested. Read the table from left to right to select the correct test configuration. Then go to the paragraph listed in Column 4 to find the test procedure for that test configuration. Although there are 6 basic test configurations available, 8 possible choices are shown. This is because Configurations 2 and 4 may be used for double sideband or single sideband measurements.

Column 1 shows the two basic types of devices which may be tested. An amplifier device is tested using Configuration 1, 2, or 3. A receiver device is tested using Configuration 4, 5, or 6.

Column 2 shows how the output frequency of the DUT affects the choice of test configuration. For an amplifier device with an output frequency below 1850 MHz, Test Configuration 1 is used. For an amplifier device with an output frequency above 1850 MHz, Test Configuration 2 or 3 is used.

For a receiver device with an IF output frequency below 1850 MHz, Test Configuration 4 or 5 is used. For a receiver device with an IF output frequency above 1850 MHz, Test Configuration 6 is used.

Column 3 shows how the width of the RF measurement range affects the choice of test configuration. Generally, if the measurements are to be taken across an RF range more than 1.6 GHz in width, Configuration 2 or 4 is used because these will support double sideband measurements. A detailed explanation of why single sideband measurements cannot be made over an RF range wider than 1.6 GHz is given in paragraph 3-37.

Column 4 shows which test configuration is required for a device which meets the conditions of Columns 1, 2, and 3, and directs the user to the paragraphs containing that procedure.

Column 5 lists additional information regarding each test configuration.

The selection process as shown in Table 3-4 is not completely inflexible. It is a guide for the new user and will hold true for most applications. The experienced user, however, will find some exceptions. More information is given at the beginning of the procedure for each test configuration.

Figure 3-4 shows, for each test configuration, whether the external local oscillator frequency is fixed or variable, and whether the IF is variable or fixed.



Table 3-4. Selecting the Test Configuration

TYPE OF DEVICE UNDER TEST	OUTPUT FREQUENCY OF DEVICE	WIDTH OF RF MEASUREMENT RANGE PARAGRAPH	TEST CONFIGURATION AND PROCEDURE	COMMENTS
AMPLIFIER	< 1850 MHz	LESS THAN 1840 MHz WIDE	1 (SPEC FUNC 1.1) GO TO PARA. 3-11	No external downconversion is used. Select no sideband.
	> 1850 MHz	MORE THAN 1.6 GHz WIDE	2 (SPEC FUNC 1.2) GO TO PARA. 3-12	Swept LO, Fixed IF. GPIB compatible local oscillator is required. Select Double Sideband.
		LESS THAN 1.6 GHz WIDE	2 (SPEC FUNC 1.2) GO TO PARA. 3-13	Swept LO, Fixed IF. GPIB compatible local oscillator is required. Select Single Sideband.
			3 (SPEC FUND 1.3) GO TO PARA. 3-14	Fixed LO, Swept IF. Local oscillator need not be GPIB compatible. Select Single Sideband.
RECEIVER	< 1850 MHz (IF)	MORE THAN 1.6 GHz WIDE	4 (SPEC FUNC 1.4) GO TO PARA. 3-15	Swept LO, Fixed IF. GPIB compatible local oscillator is required. Select Double Sideband.
		LESS THAN 1.6 GHz WIDE	4 (SPEC FUNC 1.4) GO TO PARA. 3-16	Swept LO, Fixed IF. GPIB compatible local oscillator is required. Select Single Sideband.
			5 (SPEC FUNC 1.5) GO TO PARA. 3-17	Fixed LO, Swept IF. External local oscillator need not be GPIB compatible. Select Single Side-Band.
	> 1850 MHz (IF)		6 (SPEC FUNC 1.6) GO TO PARA. 3-18	The DUT is driven by a fixed frequency local oscillator. The external mixer is driven by a variable frequency local oscillator which must be GPIB compatible. Select Single Sideband.




Figure 3-4. TEST CONFIGURATION DOWNCONVERSION MODES

**3-11. PROCEDURE FOR TEST CONFIGURATION 1**


**Description**

This configuration is used for measurements when:


1. The DUT is an amplifier-type device.
2. DUT output frequencies are between 10 and 1850 MHz. This is the only test configuration where no external downconversion is used. Note that no sideband parameter (double, single upper, or single lower) selection is required in this test configuration since the 2075 internal conversion system is true single sideband.

**Equipment Setup**


Figures 3-5a and 3-5b are the connection diagrams for calibration and measurement when external relays are not used. Figure 3-6 shows the optional setup where external relays, controlled by the 2075, are used to provide a calibration path. (Refer to Paragraph 3-34, page 3-75.)



**Figure 3-5a. TEST CONFIGURATION 1 Calibration**



**Figure 3-5b. TEST CONFIGURATION 1 Measurement**



**Figure 3-6. EXTERNAL RELAYS AUTOMATE CALIBRATION AND MEASUREMENT PATHS**


**Procedure**

This procedure is used for making corrected Noise Figure and Gain swept measurements. Immediately following the procedure, steps are given for making uncorrected Noise Figure measurements, and Fixed Frequency corrected Noise Figure and Gain measurements. In Paragraphs 3-19 through 3-28, steps are given for making other measurements such as Effective Input Noise Temperature, Y-Factor, etc.

1. Connect the test equipment as shown in the calibration setup of Figure 3-5a or the optional setup of Figure 3-6.

2. Apply AC power to the 2075.

3. Press:




This sets the front panel control parameters to preset values which also selects Test Configuration 1. (See Paragraph 3-4.)

4. Perform the procedure of Paragraph 3-9 to enter frequency/ENR values unless this has previously been done.

5. Perform the following steps if they apply:


- a. Enter the cold temperature of the noise source. (See Paragraph 3-41, page 3-88.)
- b. Enter any losses before or after the DUT. (See Paragraph 3-40, page 3-86.)
- c. Employ bandwidth compensation if required. (see Paragraph 3-38, page 3-82.)

6. Press:




This will activate the HOLD function to prevent the 2075 from making measurements before all the front panel control parameters have been entered.


7. To enter the sweep start frequency (for example, 10 MHz), press:



8. To enter the sweep stop frequency (for example, 1850 MHz), press:



9. To enter the frequency step size (for example, 20 MHz), press:




10. To calibrate the setup, press:  
(For information on smoothing, see Paragraph 3-49 on page 3-110.)



This initiates the Second Stage Calibration which measures and stores the Noise Figure of the entire setup, including the Noise Figure of the 2075. First a frequency calibration (FCAL) is done and then a CAL0, CAL1, CAL2, and CAL3. The frequency parameters entered in Steps 7, 8, and 9 determine the frequency points for the calibration. In this case the calibration is done every 20 MHz, from 10 to 1850 MHz. Where external relays are used to provide the calibration path, the 2075 automatically applies voltage to the relays when the **CALIB** key is pressed.

11. Deactivate the HOLD function by pressing:



When the HOLD is deactivated, the 2075 automatically begins making fixed frequency measurements of corrected Noise Figure and Gain at the start frequency, which in this case is 10 MHz. It makes corrected measurements, as opposed to uncorrected measurements, because the Second Stage Calibration has been performed. It makes fixed frequency measurements, as opposed to swept measurements, because the fixed frequency mode is the default mode, and swept mode has not yet been selected.

12. Insert the Device Under Test into the setup, as shown in Figure 3-5b. If external relays are being used, ignore this step. Upon completing the calibration, the 2075 removes the actuating voltage from the relays to place the DUT in the measurement path (unless Special Function 10.1 has been activated).
13. To initiate a single swept measurement, press:



As the 2075 steps through the band each RF frequency will be displayed in Window A, each Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. One single sweep is executed and when completed, the 2075 remains tuned to the stop frequency.

14. To initiate continuous swept measurements, press:



As the 2075 steps through the band each RF frequency will be displayed in Window A, each

Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. The instrument will continue to make automatic continuous sweeps. While the instrument is sweeping, it will not respond to any front panel keys except the **SWEEP** key. Continuous sweeping can be stopped by pressing the **SWEEP** key. A sweep that has been stopped can be continued from the stopping point by pressing **SHIFT RECALL**, or it can be started over from the beginning by pressing **SWEEP**.


### Uncorrected Measurement

An uncorrected measurement can be performed by eliminating the Second Stage Calibration or by pressing the **F** key before initiating the sweep.

### Fixed Frequency Measurements

To make a fixed frequency (single frequency) measurement instead of swept frequency, insert the following variations into the procedure above. (The example given is for a fixed frequency measurement at 800 MHz.)

- a. In place of Step 7, press:



- b. Do not perform Steps 8 and 9.

- c. In place of Step 10, Calibration, press:



This initiates a calibration at the fixed frequency.

### 3-12. PROCEDURE FOR TEST CONFIGURATION 2 (FOR DOUBLE SIDEBAND MEASUREMENTS)

#### Description

This configuration is used for measurements when:

1. The DUT is an amplifier-type device.

2. The DUT output frequencies are higher than 1850 MHz.
3. The RF range over which measurements will be taken is more than 1.6 GHz wide. (Measurements must be made using double sideband mode.)
4. The RF range over which measurements will be taken can be less than 1.6 GHz wide. However, the fixed IF must be low enough in frequency so that the two sidebands are close together and will approximate a single sideband measurement.

In this configuration external downconversion is required. The 2075 or an external controller sweeps

the variable local oscillator frequency to produce a fixed frequency IF from the external mixer. The local oscillator must be GPIB compatible. Paragraph 3-44 on page 3-95 contains information on PROM stored control programs for external local oscillators. Paragraph 3-45 on page 3-96 contains information on writing user-defined control programs for external local oscillators.

**Equipment Setup**

Figures 3-7a and 3-7b are the connection diagrams for calibration and measurement when external relays are not used. An optional setup can be used where external relays, controlled by the 2075, are used to provide a calibration path. (Refer to Paragraph 3-34, page 3-75.)




Figure 3-7a. TEST CONFIGURATION 2 CALIBRATION (DOUBLE SIDEBAND)




Figure 3-7b. TEST CONFIGURATION 2 MEASUREMENT (DOUBLE SIDEBAND)

**Procedure**

This procedure is used for making corrected Noise Figure and Gain swept measurements. Immediately following the procedure, steps are given for making fixed frequency corrected Noise Figure and Gain measurements. In Paragraphs 3-19 through 3-28, steps are given for making other measurements such as Effective Input Noise Temperature, Y-Factor, etc.

1. Connect the test equipment as shown in the calibration setup of Figure 3-7a or the optional setup using external relays.
2. Apply AC power to the 2075.
3. Press:

PRESET

GPIB: Device Clear or Selective Device Clear

This sets the front panel control parameters to preset values. (See Paragraph 3-4.)

4. Perform the procedure of Paragraph 3-9 to enter Frequency/ENR values, unless this has previously been done.
5. Press:

SPEC FUNC    1.2    ENTER

GPIB: D2

This selects Test Configuration 2.

6. Perform the following steps if they apply:
  - a. Enter the cold temperature of the noise source. (See Paragraph 3-41, page 3-88.)
  - b. Enter any losses before or after the DUT. (See Paragraph 3-40, page 3-86.)
  - c. Employ bandwidth compensation if required. (See Paragraph 3-38, page 3-82.)

7. Press:

SPEC FUNC    14.1    ENTER

GPIB: T1

This will activate the HOLD function which prevents the 2075 from making measurements before all the front panel control parameters have been entered.

8. To enter the sweep start RF frequency (for example, 8000 MHz), press:

START FREQ    8000    ENTER

GPIB: FA8000MZ

9. To enter the sweep stop RF frequency (for example, 12000 MHz), press:

STOP FREQ    12000    ENTER

GPIB: FB12000MZ

10. To enter the frequency step size (for example, 200 MHz), press:

STEP SIZE    200    ENTER


GPIB: SS200MZ

11. To enter the fixed IF frequency (for example, 15 MHz), press:


SHIFT    START FREQ    15    ENTER

GPIB: IF15MZ

12. To select double sideband, press:



13. To select the correct program for controlling the external local oscillator (for example, an HP 8672A local oscillator), press:




Refer to Paragraphs 3-44 and 3-45 for more information on control programs.

14. To set the local oscillator power level (Always entered in dBm. In this example it is 6 dBm.), press:




15. To enter the local oscillator settling time, which will allow the local oscillator to stabilize at each frequency before the measurement is made (Always entered in milliseconds. In this example it is 20 ms.), press:



16. To enter the GPIB address for the external local oscillator (In this example it is 17.), press:



17. To make the 2075 the controller and enable the program which will control the local oscillator, press:




18. To calibrate the setup, press:  
(For information on smoothing, see Paragraph 3-49 on page 3-110.)



This initiates the Second Stage Calibration which measures and stores the Noise Figure of the entire setup, including the internal Noise Figure of the 2075. First a frequency calibration (FCAL) is done and then a CAL0, CAL1, CAL2, and CAL3. The frequency parameters entered in Steps 8, 9, and 10 determine the frequency points for the calibration. In this case the calibration is done every 200 MHz, from 8000 MHz to 12000 MHz. When external relays are used to provide the calibration path, the 2075 automatically applies voltage to the relays when the **CALIB** key is pressed.

19. Deactivate the HOLD function by pressing:



When the HOLD is deactivated, the 2075 automatically begins making fixed frequency measurements of corrected Noise Figure and Gain at the start frequency, which in this case is 8000 MHz. It makes corrected measurements, as opposed to uncorrected measurements, because the Second Stage Calibration has been performed. It makes fixed frequency measurements, as opposed to swept measurements, because the fixed frequency mode is the default mode, and swept mode has not yet been selected.

20. Insert the Device Under Test into the setup, as shown in Figure 3-7b. If external relays are being used, ignore this step. Upon completing the calibration, the 2075 removes the actuating voltage from the relays to place the DUT in the measurement path (unless Special Function 10.1 has been activated).



21. To initiate a single swept measurement, press:



As the 2075 steps through the band each RF frequency will be displayed in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. One single sweep is executed and when completed, the 2075 remains tuned to the stop frequency.

22. To initiate continuous swept measurements, press:



As the 2075 steps through the band each RF frequency will be displayed in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. The instrument will continue to make automatic continuous sweeps. While the instrument is sweeping, it will not respond to any front panel keys except the **SWEEP** key. Continuous sweeping can be stopped by pressing the **SWEEP** key. A sweep that has been stopped can be continued from the stopping point by pressing **SHIFT RECALL** or it can be started over from the beginning by pressing **SWEEP**.


### Uncorrected Measurement

An uncorrected measurement can be performed by eliminating the Second Stage Calibration or by pressing the **F** key before initiating the sweep.

### Fixed Frequency Measurements

To make a fixed frequency (single frequency) measurement instead of swept frequency, insert the following variations into the procedure above. (The example given is for a fixed frequency measurement at 9000 MHz.)

- a. In place of Step 8, press:



- b. Do not perform Steps 9 and 10.

- c. In place of Step 18, Calibration, press:



This initiates a calibration at the fixed frequency.

### 3-13. PROCEDURE FOR TEST CONFIGURATION 2 (FOR SINGLE SIDEBAND MEASUREMENTS)

#### Description

This configuration is used for measurements when:

1. The DUT is an amplifier-type device.
2. The DUT output frequencies are higher than 1850 MHz.
3. The RF range over which measurements will be taken is less than 1.6 GHz wide. (Measurements are made using single sideband mode only.)
4. The DUT has sharp variations in noise figure across the RF band, such that even a double sideband measurement with a 10 MHz IF is too coarse to resolve the variations.

In this configuration external downconversion is required. The 2075 or an external controller sweeps the variable local oscillator frequency to produce a fixed frequency IF from the external mixer.

The local oscillator must be GPIB compatible. Paragraph 3-44, page 3-95, contains information on PROM stored control programs for external local oscillators. Paragraph 3-45, page 3-96, contains information on writing user defined control programs for external local oscillators.




Figure 3-8a. TEST CONFIGURATION 2 CALIBRATION (SINGLE SIDEBAND)




Figure 3-8b. TEST CONFIGURATION 2 MEASUREMENT (SINGLE SIDEBAND)

**Equipment Setup**

Figures 3-8a and 3-8b are the connection diagrams for calibration and measurement when external relays are not used. An optional setup can be used where external relays, controlled by the 2075, provide a calibration path. (See Paragraph 3-34, page 3-75.)

**Procedure**

This procedure is used for making corrected Noise Figure and Gain swept measurements. Immediately following the procedure, steps are given for making fixed frequency corrected Noise Figure and Gain measurements. In Paragraphs 3-19 through 3-28, steps are given for making other measurements such as Effective Input Noise Temperature, Y-Factor, etc.

1. Connect the test equipment as shown in the calibration setup of Figure 3-8a or the optional setup using external relays.
2. Apply AC power to the 2075.
3. Press:

PRESET

GPIB: Device Clear or Selective Device Clear

This sets the front panel control parameters to preset values. (See Paragraph 3-4.)

4. Perform the procedure of Paragraph 3-9 to enter Frequency/ENR values unless this has previously been done.
5. Press:

SPEC  
FUNC

1.2

ENTER

GPIB: D2

This selects Test Configuration 2.

6. Perform the following steps if they apply:
  - a. Enter the cold temperature of the noise source. (See Paragraph 3-41, page 3-88.)
  - b. Enter any losses before or after the DUT. (See Paragraph 3-40, page 3-86.)
  - c. Employ bandwidth compensation if required. (See Paragraph 3-38, page 3-82.)

7. Press:

SPEC  
FUNC

14.1

ENTER

GPIB: T1

This will activate the HOLD function and prevent the 2075 from making measurements before all the front panel control parameters have been entered.

8. To enter the sweep start RF frequency (for example, 8000 MHz), press:

START  
FREQ

8000

ENTER

GPIB: FB8000MZ

9. To enter the sweep stop RF frequency (for example, 9200 MHz), press:

STOP  
FREQ

9200

ENTER

GPIB: FB9200MZ

10. To enter the frequency step size (for example, 25 MHz), press:

STEP  
SIZE

25

ENTER

GPIB: SS25MZ

11. To enter the fixed IF frequency (for example, 1500 MHz), press:

SHIFT

START  
FREQ

1500

ENTER

GPIB: IF1500MZ

12. To select the desired single sideband parameter (In this example, lower sideband), press:


SPEC  
FUNC

2.1


ENTER

GPIB: A1

Upper sideband would be:



- To select the correct program for controlling the external local oscillator (for example, an HP8672A local oscillator), press:




(Refer to Paragraphs 3-44 and 3-45 for more information on this feature.)

- To set the local oscillator power level (Always entered in dBm. In this example it is 6 dBm.), press:




- To enter the local oscillator settling time, which will allow the local oscillator frequency to stabilize before each measurement (Always entered in milliseconds. In this example it is 20 ms.), press:



- To enter the GPIB address for the external local oscillator (In this example it is 17.), press:



- To make the 2075 the controller and to enable the program which will control the local oscillator, press:




- To calibrate the setup, press:  
(For information on smoothing, see Paragraph 3-49 on page 3-110.)



This initiates the Second Stage Calibration which measures and stores the Noise Figure of the entire setup, including the Noise Figure of the 2075. First a frequency calibration (FCAL) is done and then a CAL0, CAL1, CAL2, and CAL3. The frequency parameters entered in Steps 8, 9, and 10 determine the frequency points for the calibration. In this case the calibration is done every 25 MHz, from 8000 to 9200 MHz. When external relays are used to provide the calibration path, the 2075 automatically applies voltage to the relays when the **CALIB** key is pressed.

- Deactivate the HOLD function by pressing:



When the HOLD is deactivated, the 2075 automatically begins making fixed frequency measurements of corrected Noise Figure and Gain at the start frequency, which in this case is 8000 MHz. It makes corrected measurements, as opposed to uncorrected measurements, because the Second Stage Calibration has been performed. It makes fixed frequency measurements, as opposed to swept measurements, because the fixed frequency mode is the default mode, and swept mode has not yet been selected.

- Insert the Device Under Test into the setup, as shown in Figure 3-8b. If external relays are being used, ignore this step. Upon completing the calibration, the 2075 removes the actuating voltage from the relays to place the DUT in the measurement path (unless Special Function 10.1 has been activated).

- To initiate a single swept measurement, press:



As the 2075 steps through the band each RF frequency will be displayed in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. One single sweep is executed and when completed, the 2075 remains tuned to the stop frequency.

- 22. To initiate continuous swept measurements, press:



As the 2075 steps through the band each RF frequency will be displayed in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. The instrument will continue to make automatic continuous sweeps. While the instrument is sweeping, it will not respond to any front panel keys except the **SWEEP** key. Continuous sweeping can be stopped by pressing the **SWEEP** key. A sweep that has been stopped can be continued from the stopping point by pressing **SHIFT RECALL** or it can be started over from the beginning by pressing **SWEEP**.


**Uncorrected Measurement**

An uncorrected measurement can be performed by eliminating the Second Stage Calibration or by pressing the **F** key before initiating the sweep.

**Fixed Frequency Measurements**

To make a fixed frequency (single frequency) measurement instead of swept frequency, insert the following variations into the procedure above. (The example given is for a fixed frequency measurement at 8500 MHz.)

- a. In place of Step 8, press:



- b. Do not perform Steps 9 and 10.
- c. In place of Step 18, Calibration, press:



This initiates a calibration at the fixed frequency.

**3-14. PROCEDURE FOR TEST CONFIGURATION 3 (USING SINGLE SIDEBAND)**

**Description**

This configuration is used for measurements when:

1. The DUT is an amplifier-type device.
2. The DUT output frequencies are higher than 1850 MHz.
3. The RF range over which measurements will be taken is less than 1.6 GHz wide. (Measurements are made using single sideband mode only.)
4. The DUT has sharp variations in noise figure across the RF band, such that even a double sideband measurement with a 10 MHz IF is too coarse to resolve the variations.
5. A GPIB compatible local oscillator is not available.

In this configuration external downconversion is required. The local oscillator frequency is fixed and need not be controlled by the 2075 or by an external controller. However, if a GPIB compatible local oscillator is available, its fixed frequency and its power level can be controlled by the 2075 or an external controller. In either case, the IF output from the Device Under Test varies and must not exceed 1850 MHz.

Paragraph 3-44, page 3-95, contains information on PROM stored control programs for external local oscillators. Paragraph 3-45, page 3-96, contains information on writing user defined control programs for external local oscillators.

Equipment Setup

Figures 3-9a and 3-9b are the connection diagrams for calibration and measurement when external relays are not used. An optional setup can be used where external relays, controlled by the 2075, provide the calibration path. (See Paragraph 3-34, page 3-75.)




Figure 3-9a. TEST CONFIGURATION 3 CALIBRATION




Figure 3-9b. TEST CONFIGURATION 3 MEASUREMENT

**Procedure**

This procedure is used for making corrected Noise Figure and Gain swept measurements. Immediately following the procedure, steps are given for making fixed frequency corrected Noise Figure and Gain measurements. In Paragraphs 3-19 through 3-28, steps are given for making other measurements such as Effective Input Noise Temperature, Y-Factor, etc.

1. Connect the test equipment as shown in the calibration setup of Figure 3-9a or the optional setup using external relays for calibration.
2. Apply AC power to the 2075.
3. Press:

PRESET

-----  
 GPIB: Device Clear or Selective Device Clear  
 -----

This sets the front panel control parameters to preset values. (See Paragraph 3-4.)

4. Perform the procedure of Paragraph 3-9 to enter Frequency/ENR values unless this has previously been done.
5. Press:

SPEC  
 FUNC

1.3

ENTER

-----  
 GPIB: D3  
 -----

This selects Test Configuration 3.

6. Perform the following steps if they apply:
  - a. Enter the cold temperature of the noise source. (See Paragraph 3-41, page 3-88.)
  - b. Enter any losses before or after the DUT. (See Paragraph 3-40, page 3-86.)
  - c. Employ bandwidth compensation if required. (See Paragraph 3-38, page 3-82.)

7. Press:

SPEC  
 FUNC

14.1

ENTER

-----  
 GPIB: T1  
 -----

This will activate the HOLD function. This prevents the 2075 from making measurements before all the front panel control parameters have been entered.

8. To enter the sweep start RF frequency (for example, 5900 MHz), press:

START  
 FREQ

5900

ENTER

-----  
 GPIB: FA5900MZ  
 -----

9. To enter the sweep stop RF frequency (for example, 6500 MHz), press:

STOP  
 FREQ

6500

ENTER

-----  
 GPIB: FB6500MZ  
 -----

10. To enter the frequency step size (for example, 20 MHz), press:

STEP  
 SIZE

20

ENTER

-----  
 GPIB: SS20MZ  
 -----

11. To enter the fixed local oscillator frequency (for example, 7700 MHz), press:

SHIFT


STOP  
 FREQ

7700


ENTER

-----  
 GPIB: L07700MZ  
 -----

12. To select the desired single sideband parameter (in this example, lower sideband), press:



Upper sideband would be:



Perform Steps 13 through 16 only if the external local oscillator is under GPIB control. Otherwise, go to Step 17.

13. To select the correct program for controlling the external local oscillator (for example, an HP8672A local oscillator), press:




14. To set the local oscillator power level (Always entered in dBm. In this example it is 6 dBm.), press:



15. To enter the GPIB address for the external local oscillator (In this example it is 17.), press:



16. To make the 2075 the controller and enable the program which will control the local oscillator, press:




17. To calibrate the setup, press:  
(For information on smoothing, see Paragraph 3-49 on page 3-110.)



This initiates the Second Stage Calibration which measures and stores the Noise Figure of the entire setup, including the Noise Figure of the 2075. First a Frequency Calibration (FCAL) is done and then a CAL0, CAL1, CAL2, and CAL3. The frequency parameters entered in Steps 8, 9, and 10 determine the frequency points for the calibration. In this case the calibration is done every 20 MHz, from 5900 to 6500 MHz. When external relays are used to provide the calibration path, the 2075 automatically applies voltage to the relays when the **CALIB** key is pressed.

18. Deactivate the HOLD function by pressing:



When the HOLD is deactivated, the 2075 automatically begins making fixed frequency measurements of corrected Noise Figure and Gain at the start frequency, which in this case is 5900 MHz. It makes corrected measurements, as opposed to uncorrected measurements, because the Second Stage Calibration has been performed. It makes fixed frequency measurements, as opposed to swept measurements, because the fixed frequency mode is the default mode, and swept mode has not yet been selected.

19. Insert the Device Under Test into the setup, as shown in Figure 3-9b. If external relays are being used, ignore this step. Upon completing the calibration, the 2075 removes the actuating voltage from the relays to place the DUT in the measurement path (unless Special Function 10.1 has been activated).

20. To initiate a single swept measurement, press:





As the 2075 steps from the IF's of 1800 to 1200 MHz in steps of 20 MHz, it will display the actual RF frequencies from 5900 MHz to 6500 MHz in Window A. Each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. One single sweep is executed and when completed, the 2075 remains tuned to the stop frequency.

21. To initiate continuous swept measurements, press:



As the 2075 steps from the IF's of 1800 to 1200 MHz in steps of 20 MHz, it will display the actual RF frequencies from 5900 MHz to 6500 MHz in Window A. Each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. The instrument will continue to make automatic continuous sweeps. While the instrument is sweeping, it will not respond to any front panel keys except the **SWEEP** key. Continuous sweeping can be stopped by pressing the **SWEEP** key. A sweep that has been stopped can be continued from the stopping point by pressing **SHIFT RECALL** or it can be started over from the beginning by pressing **SWEEP**.


### Uncorrected Measurement

An uncorrected measurement can be performed by eliminating the Second Stage Calibration or by pressing the **F** key before initiating the sweep.

### Fixed Frequency Measurements

To make a fixed frequency (single frequency) measurement instead of swept frequency, insert the following variations into the procedure above. (The example given is for a fixed frequency measurement at 5900 MHz.)

- a. In place of Step 8, press:



- b. Do not perform Steps 9 and 10.

- c. In place of Step 17, Calibration, press:



This initiates a calibration at the fixed frequency.

### 3-15. PROCEDURE FOR TEST CONFIGURATION 4 (FOR DOUBLE SIDEBAND MEASUREMENTS)

#### Description

This configuration is used for measurements when:

1. The DUT is a receiver-type device.
2. The DUT output frequencies (IF) are lower than 1850 MHz.
3. The RF range over which measurements will be taken is more than 1.6 GHz wide. (Measurements must be made using double sideband mode.)
4. The RF range over which measurements will be taken can be less than 1.6 GHz wide. However, the fixed IF must be low enough in frequency so that the two sidebands are close together and will approximate a single sideband measurement.

In this configuration external downconversion is performed in the DUT. The 2075 or an external controller sweeps the variable local oscillator frequency to produce a fixed frequency IF from the Device Under Test. The local oscillator must be GPIB compatible.

Paragraph 3-44, page 3-95, contains information on PROM stored control programs for external local oscillators. Paragraph 3-45, page 3-96, contains information on writing user defined control programs for external local oscillators.

#### Equipment Setup

Figures 3-10a and 3-10b are the connection diagrams for calibration and measurement when external relays are not used. An optional setup can be used where external relays, controlled by the 2075, provide a calibration path. (See Paragraph 3-34, page 3-75.)




Figure 3-10a. TEST CONFIGURATION 4 CALIBRATION (DOUBLE SIDEBAND)




Figure 3-10b. TEST CONFIGURATION 4 MEASUREMENT (DOUBLE SIDEBAND)

**Procedure**

This procedure is used for making corrected Noise Figure and Gain swept measurements. Immediately following the procedure, steps are given for making fixed frequency corrected Noise Figure and Gain measurements. In Paragraphs 3-19 through 3-28, steps are given for making other measurements such as Effective Input Noise Temperature, Y-Factor, etc.

1. Connect the test equipment as shown in the calibration setup of Figure 3-10a or the optional setup where external relays are used to provide the calibration path.
2. Apply AC power to the 2075.

3. Press:

PRESET

GPIB: Device Clear or Selective Device Clear

This sets the front panel control parameters to preset values. (See Paragraph 3-4.)

4. Perform the procedure of Paragraph 3-9 to enter Frequency/ENR values unless this has previously been done.

5. Press:

SPEC FUNC

1.4

ENTER

GPIB: D4

This selects Test Configuration 4.

6. Perform the following steps if they apply:

- a. Enter the cold temperature of the noise source. (See Paragraph 3-41, page 3-88.)
- b. Enter any losses before or after the DUT. (See Paragraph 3-40, page 3-86.)
- c. Employ bandwidth compensation if required. (See Paragraph 3-38, page 3-82.)

7. Press:

SPEC FUNC

14.1

ENTER

GPIB: T1

This will activate the HOLD function. This prevents the 2075 from making measurements before all the front panel control parameters have been entered.

8. To enter the sweep start RF frequency (for example, 6000 MHz), press:

START FREQ

6000

ENTER

GPIB: FA6000MZ

9. To enter the sweep stop RF frequency (for example, 18000 MHz), press:

STOP FREQ

18000

ENTER

GPIB: FB18000MZ

10. To enter the frequency step size (for example, 200 MHz), press:

STEP SIZE

200

ENTER

GPIB: SS200MZ

11. To enter the fixed IF frequency (for example, 10 MHz), press:

SHIFT

START FREQ

10

ENTER

GPIB: IF10MZ

12. To select double sideband, press:


SPEC FUNC

2.0

ENTER

GPIB: AD

13. To select the correct program for controlling the external local oscillator (for example, an HP8672A local oscillator), press:




See Paragraphs 3-44 and 3-45 for information on control programs for external local oscillators.

14. To set the local oscillator power level (Always entered in dBm. In this example it is 6 dBm.), press:




15. To enter the local oscillator settling time, which allows the local oscillator to stabilize each frequency (Always entered in milliseconds. In this example it is 20 ms.), press:



16. To enter the GPIB address of the external local oscillator (in this example the address is 17), press:



17. To make the 2075 the controller and enable the program which will control the local oscillator, press:




18. To calibrate the setup, press:  
(For information on smoothing, see Paragraph 3-49 on page 3-110.)



This initiates the Second Stage Calibration which measures and stores the Noise Figure of the entire setup, including the Noise Figure of the 2075. First a frequency calibration (FCAL) is done and then a CAL0, CAL1, CAL2, and

CAL3. The frequency parameters entered in Steps 8, 9, and 10 determine the frequency points for the calibration. In this case the calibration is done at the fixed IF frequency of 10 MHz. When external relays are used to provide the calibration path, the 2075 automatically applies voltage to the relays when the **CALIB** key is pressed.

19. Deactivate the HOLD function by pressing:



When the HOLD is deactivated, the 2075 automatically begins making fixed frequency measurements of corrected Noise Figure and Gain at the start frequency, which in this case is 6000 MHz. It makes corrected measurements, as opposed to uncorrected measurements, because the Second Stage Calibration has been performed. It makes fixed frequency measurements, as opposed to swept measurements, because the fixed frequency mode is the default mode, and swept mode has not yet been selected.

20. Insert the Device Under Test into the setup, as shown in Figure 3-10b. If external relays are being used, ignore this step. Upon completing the calibration, the 2075 removed the actuating voltage from the external relays to place the DUT in the measurement path (unless Special Function 10.1 has been activated).

21. To initiate a single swept measurement, press:



As the 2075 steps through the band each RF frequency will be displayed in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. One single sweep is executed and, when completed, the 2075 remains tuned to the stop frequency.

22. To initiate continuous swept measurements, press:

**SWEEP**

**GPIB: SR**

As the 2075 steps through the band each frequency will be displayed in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. The instrument will continue to make automatic continuous sweeps. While the instrument is sweeping, it will not respond to any of the front panel keys except the **SWEEP** key. Continuous sweeping can be stopped by pressing the **SWEEP** key. A sweep that has been stopped can be continued from the stopping point by pressing **SHIFT** **RECALL** or it can be started over from the beginning by pressing **SWEEP**.

### Uncorrected Measurement

An uncorrected measurement can be performed by eliminating the Second Stage Calibration or by pressing the **F** key before initiating the sweep.

### Fixed Frequency Measurements

To make a fixed frequency (single frequency) measurement instead of swept frequency, insert the following variations into the procedure above. (The example given is for a fixed frequency measurement at 13000 MHz.)

- a. In place of Step 8, press:

**FIXED  
FREQ**

**13000**

**ENTER**

- b. Do not perform Steps 9 and 10.

- c. In place of Step 18, Calibration, press:

**SHIFT**

**CALIB**

This initiates a calibration at the fixed frequency.

### 3-16. PROCEDURE FOR TEST CONFIGURATION 4 (FOR SINGLE SIDEBAND MEASUREMENTS)

#### Description

This configuration is used for measurements when:

1. The DUT is a receiver-type device.
2. The DUT output frequencies (IF) are lower than 1850 MHz.
3. The RF range over which measurements will be taken is less than 1.6 GHz wide. (Measurements are made using single side-band mode only.)
4. The DUT has sharp variations in noise figure across the RF band, such that even a double sideband measurement with a 10 MHz IF is too coarse to resolve the variations.

In this configuration external downconversion is performed in the DUT. The 2075 or an external controller sweeps the variable local oscillator frequency to produce a fixed frequency IF from the Device Under Test.

The local oscillator must be GPIB compatible.

Paragraph 3-44, page 3-95, contains information on PROM stored control programs for external local oscillators. Paragraph 3-45, page 3-96, contains information on writing user defined control programs for external local oscillators.

#### Equipment Setup

Figures 3-11a and 3-11b are the connection diagrams for calibration and measurement when external relays are not used. An optional setup can be used where external relays, controlled by the 2075, provide the calibration path. (See Paragraph 3-34, page 3-75.)




Figure 3-11a. TEST CONFIGURATION 4 CALIBRATION (SINGLE SIDEBAND)




Figure 3-11b. TEST CONFIGURATION 4 MEASUREMENT (SINGLE SIDEBAND)

**Procedure**

This procedure is used for making corrected Noise Figure and Gain swept measurements. Immediately following the procedure, steps are given for making fixed frequency corrected Noise Figure and Gain measurements. In Paragraphs 3-19 through 3-28, steps are given for making other measurements such as Effective Input Noise Temperature, Y-Factor, etc.

1. Connect the test equipment as shown in the calibration setup of Figure 3-11a or the optional setup using external relays.
2. Apply AC power to the 2075.

3. Press:

PRESET

-----  
 GPIB: Device Clear or Selective Device Clear

This sets the front panel control parameters to preset values. (See Paragraph 3-4.)

4. Perform the procedure of Paragraph 3-9 to enter frequency/ENR values unless this has previously been done.

5. Press:

SPEC  
FUNC

1.4

ENTER

-----  
 GPIB: D4

This selects test configuration 4.

6. Perform the following steps if they apply:

- a. Enter the cold temperature of the noise source. (See Paragraph 3-41, page 3-88.)
- b. Enter any losses before or after the DUT. (See Paragraph 3-40, page 3-86.)
- c. Employ bandwidth compensation if required. (See Paragraph 3-38, page 3-82.)

7. Press:

SPEC  
FUNC

14.1

ENTER

-----  
 GPIB: T1

This will activate the HOLD function. This prevents the 2075 from making measurements before all the front panel control parameters have been entered.

8. To enter the sweep start RF frequency (for example, 8000 MHz), press:

START  
FREQ

8000

ENTER

-----  
 GPIB: FA8000MZ

9. To enter the sweep stop RF frequency (for example, 9200 MHz), press:

STOP  
FREQ

9200

ENTER

-----  
 GPIB: FB9200MZ

10. To enter the frequency step size (for example, 25 MHz), press:

STEP  
SIZE

25

ENTER

-----  
 GPIB: SS25MZ

11. To enter the fixed IF frequency (for example, 1700 MHz), press:

SHIFT

START  
FREQ

1700

ENTER

-----  
 GPIB: IF1700MZ

12. To select the desired single sideband parameter (In this example, lower sideband), press:

SPEC  
FUNC

2.1

ENTER

-----  
 GPIB: A1

Upper sideband would be:


SPEC  
FUNC

2.2

ENTER

-----  
 GPIB: A2

13. To select the correct program for controlling the external local oscillator (for example, an HP8350 local oscillator), press:




See Paragraphs 3-44 and 3-45 for information on control programs for external local oscillators.

14. To set the local oscillator power level (Always entered in dBm. In this example it is 6 dBm.), press:




15. To enter the local oscillator settling time, which allows the local oscillator to stabilize at each frequency (Always entered in milliseconds. In this example it is 20 ms.), press:



16. To enter the GPIB address for the external local oscillator (In this example it is 17), press:



17. To make the 2075 the controller and enable the program which will control the local oscillator, press:





18. To calibrate the setup, press:  
(For information on smoothing, see Paragraph 3-49 on page 3-110.)



This initiates the Second Stage Calibration which measures and stores the Noise Figure of the entire setup, including the Noise Figure of the 2075. First a frequency calibration (FCAL) is done and then a CAL0, CAL1, CAL2, and CAL3. In this case the calibration is done at the

fixed IF frequency of 1700 MHz. When external relays are used to provide the calibration path, the 2075 automatically applies voltage to the relays when the **CALIB** key is pressed.

19. Deactivate the HOLD function by pressing:



When the HOLD is deactivated, the 2075 automatically begins making fixed frequency measurements of corrected Noise Figure and Gain at the start frequency, which in this case is 8000 MHz. It makes corrected measurements, as opposed to uncorrected measurements, because the Second Stage Calibration has been performed. It makes fixed frequency measurements, as opposed to swept measurements, because the fixed frequency mode is the default mode, and swept mode has not yet been selected.

20. Insert the Device Under Test into the setup, as shown in Figure 3-10b. If external relays are being used, ignore this step. Upon completing the calibration, the 2075 removes the actuating voltage from the relays to place the DUT in the measurement path (unless Special Function 10.1 has been activated).

21. To initiate a single swept measurement, press:



As the 2075 steps through the band each RF frequency will be displayed in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. One single sweep is executed and, when completed, the 2075 remains tuned to the stop frequency.

22. To initiate continuous swept measurements, press:





As the 2075 steps through the band each RF frequency will be displayed in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. The instrument will continue to make automatic continuous sweeps. While the instrument is sweeping, it will not respond to the front panel keys except for the **SWEEP** key. Continuous sweeping can be stopped by pressing the **SWEEP** key. A sweep that has been stopped can be continued from the stopping point by pressing **SHIFT RECALL** or it can be started over from the beginning by pressing **SWEEP**.


### Uncorrected Measurement

An uncorrected measurement can be performed by eliminating the Second Stage Calibration or by pressing the **F** key before initiating the sweep.

### Fixed Frequency Measurements

To make a fixed frequency (single frequency) measurement instead of swept frequency, insert the following variations into the procedure above. (The example given is for a fixed frequency measurement at 9000 MHz.)

- a. In place of Step 8, press:



- b. Do not perform Steps 9 and 10.  
c. In place of Step 18, Calibration, press:



This initiates a calibration at the fixed frequency.

### 3-17. PROCEDURE FOR TEST CONFIGURATION 5 (SINGLE SIDEBAND)

#### Description

This configuration is used for measurements when:

1. The DUT is a receiver-type device.
2. The DUT output frequencies (IF) are lower than 1850 MHz.
3. The RF range over which measurements will be made is less than 1.6 GHz wide. (Measurements are made using single sideband mode only.)
4. A GPIB compatible local oscillator is not available.

In this configuration external downconversion is performed in the DUT. The local oscillator frequency is fixed and need not be controlled by the 2075 or by an external controller. However, if a GPIB compatible local oscillator is available, its fixed frequency and its power level can be controlled by the 2075 or an external controller. In either case, the IF output from the Device Under Test varies. The 2075 sweeps to tune to the variable frequency IF from the external mixer.

#### NOTE

When using Test Configuration 5 for lower single sideband measurements, always use a step size which gives an integral number of steps from the start frequency to the stop frequency.

#### Equipment Setup

Figures 3-12a and 3-12b are the connection diagrams for calibration and measurement when external relays are not used. An optional setup can be used where external relays, controlled by the 2075, provide the calibration path. (See Paragraph 3-34, page 3-75.)




Figure 3-12a. TEST CONFIGURATION 5 CALIBRATION




Figure 3-12b. TEST CONFIGURATION 5 MEASUREMENT

**Procedure**

This procedure is used for making corrected Noise Figure and Gain swept measurements. Immediately following the procedure, steps are given for making fixed frequency corrected Noise Figure and Gain measurements. In Paragraphs 3-19 through 3-28, steps are given for making other measurements such as Effective Input Noise Temperature, Y-Factor, etc.

1. Connect the test equipment as shown in the calibration setup of Figure 3-12a or the optional setup using external relays.
2. Apply AC power to the 2075.

3. Press:

PRESET

GPiB: Device Clear or Selective Device Clear

This sets the front panel control parameters to preset values. (See Paragraph 3-4.)

4. Perform the procedure of Paragraph 3-9 to enter Frequency/ENR values unless this has previously been done.

5. Press:

SPEC FUNC

1.5

ENTER

GPiB: 05

This selects Test Configuration 5.

6. Perform the following steps if they apply:

- a. Enter the cold temperature of the noise source. (See Paragraph 3-41, page 3-88.)
- b. Enter any losses before or after the DUT. (See Paragraph 3-40, page 3-86.)
- c. Employ bandwidth compensation if required. (See Paragraph 3-38, page 3-82.)

7. Press:

SPEC FUNC

14.1

ENTER

GPiB: T1

This will activate the HOLD function which prevents the 2075 from making measurements before all the front panel control parameters have been entered.

8. To enter the sweep start RF frequency (for example, 10010 MHz), press:

START FREQ

10010

ENTER

GPiB: FA10010MZ

9. To enter the sweep stop RF frequency (for example, 11000 MHz), press:

STOP FREQ

11000

ENTER

GPiB: FB11000MZ

10. To enter the frequency step size (for example, 20 MHz), press:

STEP SIZE

20

ENTER

GPiB: SS20MZ

11. To enter the fixed local oscillator frequency (for example, 9510 MHz), press:

SHIFT

STOP FREQ

9510

ENTER

GPiB: L09510MZ

12. To select the desired single sideband parameter (In this example, upper sideband), press:


SPEC FUNC

2.2

ENTER


GPiB: A2

Lower sideband would be:



Perform Steps 13 through 16 only if the external local oscillator is under GPIB control. Otherwise, go to Step 17.

- To select the correct program for controlling the external local oscillator (for example, a Wiltron 6600 local oscillator), press:



See Paragraphs 3-44 and 3-45 for information on control programs for external local oscillators.


- To set the local oscillator power level (Always entered in dBm. In this example it is 6 dBm.), press:



- To enter the GPIB address for the external local oscillator (In this example the address is 17), press:



- To make the 2075 the controller and enable the program which will control the local oscillator, press:




- To calibrate the setup, press:  
(For information on smoothing, see Paragraph 3-49 on page 3-110.)



This initiates the Second Stage Calibration which measures and stores the Noise Figure of the entire setup, including the internal Noise Figure of the 2075. First a frequency calibration (FCAL) is done and then a CAL0, CAL1, CAL2, and CAL3. The frequency parameters previously entered determine the frequency points for the calibration. In this case the calibration is done at the IF frequencies from 500 MHz to 1490 MHz, at 20 MHz steps. When external relays are used to provide the calibration path, the 2075 automatically applies voltage to the relays when the **CALIB** key is pressed.

- Deactivate the HOLD function by pressing:



When the HOLD is deactivated, the 2075 automatically begins making fixed frequency measurements of corrected Noise Figure and Gain at the start frequency, which in this case is 10010 MHz. It makes corrected measurements, as opposed to uncorrected measurements, because the Second Stage Calibration has been performed. It makes fixed frequency measurements, as opposed to swept measurements, because the fixed frequency mode is the default mode, and swept mode has not yet been selected.


- Insert the Device Under Test into the setup, as shown in Figure 3-12b. If external relays are being used, ignore this step. Upon completing the calibration, the 2075 removes the actuating voltage from the relays to place the DUT in the measurement path (unless Special Function 10.1 has been activated).

- To initiate a single swept measurement, press:



As the 2075 steps from the IF's of 500 to 1490 MHz in steps of 20 MHz, it will display the actual RF frequencies from 10010 MHz to 11000 MHz in Window A. Each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. One single sweep is executed and when completed, the 2075 remains tuned to the stop frequency.

- 21. To initiate continuous swept measurements press:



As the 2075 steps from the IF's of 500 to 1490 MHz in steps of 20 MHz, it will display the actual RF frequencies from 10010 MHz to 11000 MHz in Window A, each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. The instrument will continue to make automatic continuous sweeps. While the instrument is sweeping, it will not respond to any front panel keys except for the **SWEEP** key. Continuous sweeping can be stopped by pressing the **SWEEP** key. A sweep that has been stopped can be continued from the stopping point by pressing **SHIFT** **RECALL** or it can be started over from the beginning by pressing **SWEEP**.


**Uncorrected Measurement**

An uncorrected measurement can be performed by eliminating the Second Stage Calibration or by pressing the F key before initiating the sweep.

**Fixed Frequency Measurements**

To make a fixed frequency (single frequency) measurement instead of swept frequency, insert the following variations into the procedure above. (The example given is for a fixed frequency measurement at 10400 MHz.)

- a. In place of Step 8, press:



- b. Do not perform Steps 9 and 10.
- c. In place of Step 17, Calibration, press:



This initiates a calibration at the fixed frequency.

**3-18. PROCEDURE FOR TEST CONFIGURATION 6**

**Description**

This configuration is used for measurements when:

- 1. The DUT is a receiver-type device.
- 2. The DUT output frequencies (IF) are higher than 1850 MHz.

In this configuration two stages of external downconversion are performed. The first stage of external downconversion is performed in the DUT. A fixed frequency local oscillator (usually an integral part of the DUT) drives the DUT to produce a variable frequency IF output higher than 1850 MHz. This local oscillator is not controlled by the 2075.

The second stage of external downconversion is performed in an external mixer. This mixer is driven by a variable frequency local oscillator which is controlled by the 2075 or an external controller. This mixer has, as its second input, the variable IF from the DUT. The output of this mixer is a fixed IF frequency below 1850 MHz.

Note that the measurement must be either upper or lower single sideband. Therefore, if the DUT does not have the proper filtering in its front end (most receivers do), then a filter must be placed in front of the DUT to reject the unwanted image sideband. Also note that this filter is not part of the second stage, so its loss must be accounted for by using loss compensation (Section 3-40, page 3-86). The isolator in Figures 13a and 13b, prevents unwanted interaction between the mixer and the DUT, and is part of the second stage.

Paragraph 3-44, page 3-95, contains information on

PROM stored control programs for external local oscillators. Paragraph 3-45, page 3-96, contains information on writing user defined control programs for external local oscillators.

**NOTE**

When using Test Configuration 6 for lower single sideband measurements, always use a step size which gives an integral number of steps from the start frequency to the stop frequency.

**Equipment Setup**

Figures 3-13a and 3-13b are the connection diagrams for calibration and measurement when external relays are not used. An optional setup can be used where external relays, controlled by the 2075, provide the calibration path. (See Paragraph 3-34, page 3-75.)




Figure 3-13a. TEST CONFIGURATION 6 CALIBRATION




Figure 3-13b. TEST CONFIGURATION 6 MEASUREMENT

**Procedure**

This procedure is used for making corrected Noise Figure and Gain swept measurements. Immediately following the procedure, steps are given for making fixed frequency corrected Noise Figure and Gain measurements. In Paragraphs 3-19 through 3-28, steps are given for making other measurements such as Effective Input Noise Temperature, Y-Factor, etc.

1. Connect the test equipment as shown in the calibration setup of Figure 3-13a or the optional setup using external relays.
2. Apply AC power to the 2075.
3. Press:

PRESET

GPIB: Device Clear or Selective Device Clear

This sets the front panel control parameters to preset values. (See Paragraph 3-4.)

4. Perform the procedure of Paragraph 3-9 to enter Frequency/ENR values unless this has previously been done.
5. Press:

SPEC FUNC      1.6      ENTER


GPIB: D6

This selects Test Configuration 6.

6. Perform the following steps if they apply:
  - a. Enter the cold temperature of the noise source. (See Paragraph 3-41, page 3-88.)
  - b. Enter any losses before or after the DUT. (See Paragraph 3-40, page 3-86.)

c. Employ bandwidth compensation if required.  
(See Paragraph 3-38, page 3-82.)


7. Press:



GPIB: T1


This will activate the HOLD function. This prevents the 2075 from making measurements before all the front panel control parameters have been entered.

8. To enter the sweep start RF frequency (for example, 42000 MHz), press:




GPIB: FA42000MZ

9. To enter the sweep stop RF frequency (for example, 46000 MHz), press:



GPIB: FB46000MZ

10. To enter the frequency step size (for example, 100 MHz), press:



GPIB: SS100MZ

11. To enter the fixed frequency of the DUT integral local oscillator (for example, 39000 MHz), press:




GPIB: SL39000MZ

12. To enter the fixed IF output frequency from the external mixer (for example, 20 MHz), press:




GPIB: IF20MZ

13. To select the desired single sideband parameter (In this example upper sideband), press:




GPIB: A2

Lower sideband would be:



GPIB: A1

14. To select the correct program for controlling the external local oscillator (for example, a Wiltron 6600 local oscillator), press:




See Paragraphs 3-44 and 3-45 for information on control programs for external local oscillators.



15. To set the local oscillator power level (Always entered in dBm. In this example it is 6 dBm.), press:




16. To enter the local oscillator settling time, which allows the local oscillator to stabilize before each measurement is made (Always entered in milliseconds. In this example it is 20 ms.), press:



17. To enter the GPIB address for the external local oscillator, LO 1 in Figure 3-13 (in this example the address is 17) press:



18. To make the 2075 the controller and enable the program which will control the local oscillator press:



Refer to paragraphs 3-44 and 3-45 for information on control programs.



19. To calibrate the setup, press:  
(For information on smoothing, see Paragraph 3-49 on page 3-110.)



This initiates the Second Stage Calibration which measures and stores the Noise Figure of the entire setup, including the internal Noise Figure of the 2075. First an FCAL (frequency calibration) is done and then a CAL0, CAL1, CAL2, and CAL3. The frequency parameters entered previously determine the frequency points for the calibration. In this case the calibration is done at variable IF frequencies

from 3000 MHz to 7000 MHz in 100 MHz steps. When external relays are used to provide the calibration path, the 2075 automatically applies voltage to the relays when the **CALIB** key is pressed.

20. Deactivate the HOLD function by pressing:



When the HOLD is deactivated, the 2075 automatically begins making fixed frequency measurements of corrected Noise Figure and Gain at the start frequency, which in this case is 42000 MHz. It makes corrected measurements, as opposed to uncorrected measurements, because the Second Stage Calibration has been performed. It makes fixed frequency measurements, as opposed to swept measurements, because the fixed frequency mode is the default mode, and swept mode has not yet been selected.


21. Insert the Device Under Test into the setup, as shown in Figure 3-13b. If external relays are being used, ignore this step. Upon completing the calibration, the 2075 removed voltage from the relays to place the DUT in the measurement path (unless Special Function 10.1 has been activated).

22. To initiate a single swept measurement, press:



As the 2075 sweeps from the 42000 to 46000 MHz in steps of 100 MHz, it will display the actual RF frequency in Window A. Each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. One single sweep is executed and when completed, the 2075 remains tuned to the stop frequency.

23. To initiate continuous swept measurements, press:



As the 2075 sweeps from 42000 to 46000 MHz in steps of 100 MHz, it will display the actual RF frequency in Window A. Each corrected Gain value will be displayed in Window B, and each corrected Noise Figure value will be displayed in Window C. The instrument will continue to make automatic continuous sweeps. While the instrument is sweeping, it will not respond to any front panel keys except the **SWEEP** key. Continuous sweeping can be stopped by pressing the **SWEEP** key. A sweep that has been stopped can be continued from the stopping point by pressing **SHIFT RECALL** or it can be started over from the beginning by pressing **SWEEP**.


**Uncorrected Measurement**

An uncorrected measurement can be performed by eliminating the Second Stage Calibration or by pressing the **F** key before initiating the sweep.

**Fixed Frequency Measurements**

To make a fixed frequency (single frequency) measurement instead of swept frequency, insert the following variations into the procedure above. (The example given is for a fixed frequency measurement at 42500 MHz.)

- a. In place of Step 8, press:



- b. Do not perform Steps 9 and 10.  
 c. In place of Step 19, Calibration, press:



This initiates a calibration at the fixed frequency.

**3-19. ADDITIONAL TYPES OF MEASUREMENTS**

In addition to Noise Figure and Gain measurements, the 2075 can make other noise related measurements. These are listed below in Table 3-5. Note that some of these measurements can be made in cascade (uncorrected) only, some can be made as First Stage (corrected) only, and some can be made either way.

Table 3-5. Additional Measurements

MEASUREMENT	SYMBOL	MODE
Effective Input Noise Temperature	$T_e$	Cascade or First Stage
Y-Factor	Y	Cascade only
Operating Noise Temperature	$T_{op}$	Cascade or First Stage
Power	dB PWR	First Stage only
ENR	dB PWR	First Stage only
Noise Measure	M	First Stage only

The detailed measurement procedures given for each test configuration (Paragraphs 3-11 through 3-18) are the basic procedures for any automatic measurement. It is always necessary to select the correct test configuration, to enter frequency parameters, etc. Second Stage Calibration must always be performed before a corrected measurement is made. The basic difference in performing one type of noise measurement instead of another, is in the keystroke sequence which selects the type of measurement. For example, to select  $T_{op}$ , the keys **SPEC FUNC 11.2 ENTER** are pressed. To select M, the keys **SPEC FUNC 11.5 ENTER** are pressed. After the specific measurement is selected, it is executed in the same manner as in the basic procedures. That is, the **SHIFT SWEEP** or **SWEEP** keys must be pressed to execute single or continuous swept measurements. Although the basic procedures do not vary in most cases, some additional or different steps may be required for a particular type of measurement. The following paragraphs present the pertinent details and procedural differences where required for each type.

### 3-20. EFFECTIVE INPUT NOISE TEMPERATURE ( $T_e$ ) MEASUREMENT

Effective Input Noise Temperature ( $T_e$ ) is the noise temperature at the input of a noiseless equivalent of the DUT that would cause the noiseless DUT to have the same noise output as the actual DUT.  $T_e$  is always measured in kelvins. It is related to Noise Figure by the equation:

$$T_e = (F - 1) \times 290 \text{ (kelvins)}$$

Where  $F$  is the noise figure expressed as a ratio.

When measuring  $T_e$  there is no change in the basic measurement setup or procedure.

To make a cascade measurement of  $T_e$ , press:



To make a first stage (corrected) measurement of  $T_e$ , after Second Stage Calibration, press:



Then press the appropriate keys to make single or continuous swept measurement. The result is displayed in Window C and is always expressed in kelvins. Window B will display the Gain of the DUT in dB or as a ratio.


### 3-21. Y-FACTOR (Y) MEASUREMENT

Y-Factor is a ratio of the noise power output from the DUT when the noise source is ON (or hot) to the noise power output from the DUT when the noise source is OFF (or cold). It can be expressed as dB or as a ratio.

Y-Factor measurement can be made as an automatic or as a manual measurement. The automatic procedure is given below. The manual procedure is given in Paragraph 3-28. Y-Factor is always a cascade measurement and so Second Stage Calibration is not required.

When measuring Y-Factor there is no change in the basic measurement setup or procedure as given for each test configuration.

To measure Y-Factor, press:



Then press the **SWEEP** or **SHIFT SWEEP** keys to execute single or continuous swept measurement. The results will be displayed in Window C. The measurement can be displayed as dB or as a ratio by pressing the **dB/RATIO** key.

**3-22. OPERATING NOISE TEMPERATURE (T<sub>op</sub>) MEASUREMENT**

Operating Noise Temperature is a measure of the total noise of a receiving system, including the antenna noise, when it is situated in its normal operating environment. T<sub>op</sub> is related to the Effective Input Noise Temperature by the equation:

$$T_{op} = T_c + T_a$$

Where T<sub>a</sub> is the noise temperature of the antenna.

T<sub>op</sub> measurements can be made as cascade or as first stage measurements. Figures 3-14a and b below show the equipment configurations for calibration and measurement. Although the figures show an example using Test Configuration 1, any appropriate test configuration can be used.

When making T<sub>op</sub> measurements, Loss Compensation may be employed to compensate for the coupler attenuation factor. Because this coupling attenuation occurs between the noise source and the DUT, it is entered as Loss 1, using Special Function 18.1. For detailed information on Loss Compensation refer to Paragraph 3-40.


The temperature of the loss, which is the ambient temperature, is entered using Special Function 18.2.

If there is a loss following the DUT, and it is not part of the second stage, it must be entered as Loss 2. If there is a loss following the DUT, but it is part of the second stage, enter a value of 0 for Loss 2. Loss 2 is entered using Special Function 18.3


Although Special Functions 18.1, 18.2, and 18.3 must be used to enter the loss values, it is not necessary to enter Special Function 17.1 to activate the loss compensation function. It will be activated automatically when the T<sub>op</sub> measurement is done.

After the loss compensation values have been entered, perform the Second Stage Calibration (if a corrected measurement is desired).

Special Function 11.2 is entered to select the T<sub>op</sub> measurement.



**Figure 3-14a. T<sub>op</sub> SETUP-CALIBRATION**




**Figure 3-14b. T<sub>op</sub> SETUP-MEASUREMENT**

The 2075 will make a corrected or uncorrected measurement depending on which mode it is in when the measurement is performed. A single swept measurement is executed by pressing the **SHIFT** and **SWEEP** keys. Continuous swept measurements are executed by pressing the **SWEEP** key. If Second Stage Calibration has just been performed, the 2075 will be in the corrected measurement mode, and will make a first stage measurement. If no Second Stage Calibration has been performed, it will make an uncorrected measurement.


However, if the calibration has been performed, and an uncorrected measurement is desired, put the instrument back in uncorrected mode by pressing the **F** key. Then press the appropriate keys to execute the measurement. Alternately, to get back to the corrected measurement mode, press the **F + G** key. Then press the appropriate keys to make the measurement.

The following example is given to show the steps which are added to the basic measurement procedure.


1. To enter the coupler attenuation as Loss 1 (for example, 10 dB), press:




2. To enter the loss temperature (for example, 296.5 kelvins), press:



3. To enter Loss 2 (for example, 0 dB), press:



4. Perform the Second Stage Calibration in the normal manner.
5. To select the measurement, press:



6. To make the measurement, press the appropriate keys which select single sweep or continuous sweeps (per the basic procedure).

The measurement results will be displayed in Window C. The units of display are kelvins.

GPIB codes: Special Function 18.1 is L1  
                   Special Function 18.2 is L2  
                   Special Function 18.3 is L3  
                   Special Function 11.2 is OP

### 3-23. POWER (dB) MEASUREMENTS

Measurements of noise power density relative to  $-174$  dBm/Hz can be made using Special Functions 11.3 and 11.4. Minus 174 dBm is the thermal noise level at 290 kelvins for a 1 Hz bandwidth. The noise power density measurements made by the 2075 are displayed in dB, relative to this  $-174$  dBm/Hz level. The equation is as follows:

$$\text{Power (dB)} = 10 \log \frac{(T_{\text{unknown}})}{T_0}$$

Where  $T_0$  is the 290 K reference temperature and  $T_{\text{unknown}}$  equals the temperature which is proportional to the unknown power density.


This measurement can be made either as an uncorrected or a corrected measurement. The uncorrected measurements assume a nominal noise figure value of 6 dB for the second stage. Uncorrected measurements are not accurate and are not recommended.

When making a power measurement, perform the basic procedure as given for the appropriate test configuration. Perform the procedure up to and including the Second Stage Calibration. Then place the DUT in the setup and perform the following steps:

To select the measurement with the noise source OFF, press:



To select the measurement with the noise source ON, press:



Then press the appropriate key to execute the swept measurement. The measurement results, in each case, are displayed in Window C. The units of display are dB relative to 290 kelvins (-174 dBm/Hz).

The GPIB code for Special Function 11.3 is PM  
The GPIB code for Special Function 11.4 is PN

### 3-24. ENR MEASUREMENT

The 2075 can be used to measure the ENR values of a noise source. In this procedure, Second Stage Calibration is performed using a noise source with known ENR values. The noise source with unknown values is then installed in the test setup and measured using Special Function 11.6. The calculation for this measurement is:

$$ENR = 10 \log \frac{T_h - 290}{290}$$

Where  $T_h$  is the hot or ON temperature of the noise source being measured.

The calibration and measurement setups are shown in Figures 3-15a and b below. The illustrations are for Test Configuration 1, however the measurement can be performed using any configuration, as required, depending upon measurement frequency.




Figure 3-15a. ENR SETUP - CALIBRATION





Figure 3-15b. ENR SETUP - MEASUREMENT

Perform the steps as given in the detailed procedure for the appropriate test configuration up to and including the Second Stage Calibration. Then perform the following steps:

To select the ENR measurement, press:



Connect the noise source with unknown ENR values in place of the noise source with known values (Figure 3-15b).

Press the appropriate keys to make a single sweep or continuous swept measurements. The results will be displayed in Window C and the dB PWR annunciator will be lit. The units of display are dB but can be changed to a ratio by pressing the **dB/RATIO** key.

**3-25. NOISE MEASURE (M) MEASUREMENT**


Noise Measure (M) is a parameter which includes both Noise Figure and Gain. This parameter is typically used by transistor manufacturers as a figure of merit. The formula for computing M is as follows:

$$M = \frac{(F - 1)}{1 - 1/G}$$

Where F = Noise Figure of the DUT expressed as a ratio and G = Gain of the DUT expressed as a ratio.

Noise Measure can be performed only as a corrected measurement.

The basic measurement procedure does not change from those given for each test configuration. Perform the steps up to and including Second Stage Calibration and then install the DUT in the setup. Select M by pressing:



Press the appropriate keys to execute a swept measurement. The measurement results for M will be displayed in Window C. The results for Gain will be displayed in Window B.

**3-26. MANUAL MEASUREMENTS**

The 2075 can make manual measurements of Noise Figure and Gain or Y-Factor. A true hot/cold thermal noise source is generally used for manual measurement of Noise Figure and Gain. A continuously variable, precision, calibrated attenuator is required for manual Y-Factor measurements. Manual measurements can be made only at fixed frequencies.

The following paragraphs detail the procedures for manual measurement of Noise Figure and Gain, and Y-Factor.

**3-27. MANUAL MEASUREMENT OF NOISE FIGURE AND GAIN**

A true hot/cold noise source, such as the Eaton 7009, is generally used for this measurement. The following procedure is for making a corrected measurement. An uncorrected measurement of Noise Figure can be made by omitting Steps 7 through 10.

1. Enter the T<sub>hot</sub> value, in kelvins, of the hot noise source. For example, if the T<sub>hot</sub> value is 373 kelvins, press:



(The Preset value of T<sub>hot</sub> is 9893 K. The current value for T<sub>hot</sub> is displayed in Window B as soon as the **SHIFT** and **ENR** keys are pressed.)

Special Function 12 can be set to 12.1 to allow temperature entries to be made in Centigrade or it can be set to 12.2 to allow entries in Fahrenheit.


2. Enter the  $T_{cold}$  value, in kelvins, of the cold noise source. For example, if the  $T_{cold}$  value is 78 kelvins, press:




(The Preset value of  $T_{cold}$  is 296 kelvins. The current value for  $T_{cold}$  is displayed in Window B as soon as the **SHIFT** and **ON/OFF** keys are pressed.)

Special Function 12 can be set to 12.1 to allow temperature entries to be made in Centigrade or it can be set to 12.2 to allow entries in Fahrenheit.

3. Select the desired amount of smoothing by pressing the **RIGHT ARROW** or **LEFT ARROW** keys. To obtain accurate, stable measurements, it is recommended that a smoothing factor of 16 or 32 be employed (4 or 5 LED light bars lit).
4. Tune the 2075 to the desired measurement frequency (for example, 1175 MHz) by pressing:



5. Select the manual measurement mode by pressing:



Double hyphens will appear in the front panel displays.

6. Connect the hot noise source to the 2075 RF INPUT.
7. The Second Stage Calibration procedure consists of four steps. Initiate the calibration sequence by pressing:



The messages FCAL and then CAL0 will appear in Window B. Double bars will be displayed in Window C when this step is completed.

8. Continue the calibration sequence for the hot noise source by pressing:



The messages CAL1, CAL2, CAL3, and then CAL0 will appear in Window B. During this process the green NOISE DRIVE LED will light to indicate that the hot calibration is being performed and Window C will display double bars.

9. Disconnect the hot noise source and connect the cold noise source to the RF INPUT.
10. Complete the calibration sequence by pressing:



The messages CAL1, CAL2, and then CAL3 will appear in Window B. While each of these appears, its calibration noise figure data will be displayed in Window C. During this step the green NOISE DRIVE LED will be extinguished. When this step is completed, the red LED in the **F + G** key will light.

11. The 2075 is now ready to make the measurements.
12. Disconnect the cold noise source.
13. Connect the Device Under Test between the hot noise source and the RF INPUT.
14. Start the hot cycle measurement by pressing:



The hot cycle measurement is completed when the annunciators light in Windows B and C. Double bars will be displayed in Windows B and C, and the green NOISE DRIVE LED will be lit.

15. Disconnect the hot noise source and connect the cold noise source to the DUT.



16. Initiate the cold cycle measurement by pressing:



The green NOISE DRIVE LED will go out and, when the measurement is completed, the Noise Figure value will be displayed in Window C. The Gain will be displayed in Window B.

18. To perform another measurement cycle, repeat Steps 13 through 16.

There are no GPIB codes associated with the manual measurement function except for the special function codes (all special function codes can be sent to the 2075 via GPIB).

Output can be directed to a printer if the printer is in LISTEN ONLY mode and the 2075 is in TALK ONLY mode. Refer to the table of GPIB codes, Table 4-3.

### 3-28. MANUAL MEASUREMENT OF Y-FACTOR

Measurement of Y-Factor can be accomplished either automatically or manually. The automatic measurement of Y-Factor is accomplished using Special Function 11.1 and the procedure for this method is given in Paragraph 3-21.

Manual measurement of Y-Factor requires a continuously variable precision attenuator such as the Eaton 32 Series. In general, such attenuators are optimized for operation at a single frequency, typically 30 MHz. If the DUT operates at a different frequency, it will be necessary to convert the DUT output frequency to that of the attenuator. Even if frequency conversion is required, the measurement can be performed using Test Configuration 1.

This method gives a very precise result by removing the uncertainties which are due to the 2075. When making this measurement the 2075 is set to voltmeter mode by selecting Special Function 20.1. The measurement can be made only at a fixed frequency.

To make the manual Y-Factor measurement, connect the test equipment as shown in Figure 3-16 below and then perform the steps given.






Figure 3-16. MANUAL Y-FACTOR MEASUREMENT

1. Tune the 2075 to the desired frequency of measurement (for example, 70 MHz) by pressing:



2. To place the 2075 in the voltmeter mode, press:



3. Set the attenuator to some value which is greater than the expected Y-Factor measurement value (for example, 15.0 dB). Usually, 15 to 20 dB will be enough. The gain of the DUT plus this initial attenuator setting should be greater than 25 dB.
4. Increase the smoothing to its maximum, or near maximum, value by pressing:



5. To turn on the noise source voltage, press:



The green NOISE DRIVE indicator will light when the voltage is on.

6. Observe and record the exact voltage readout given in Window A. (For example, 2.9805)

7. To turn off the noise source voltage, press:




The green NOISE DRIVE indicator will go out when the voltage is off.

8. Reduce the value of the precision variable attenuator until the voltage displayed in Window A is exactly the same as it was in Step 6. (For example, the attenuator is reduced to 5.35 dB to again obtain a voltage reading of 2.9805.)
9. Compute the difference between the attenuator settings in Step 6 and Step 8. This difference is the Y-Factor in dB. (For example, 15.0 dB minus 5.35 dB. The difference is 9.65 dB and this is the Y-Factor of the DUT.)

### 3-29. CALIBRATED NOISE SOURCE


The noise source is an accurately calibrated device which, when stimulated by the NOISE DRIVE voltage, continuously generates white, broadband noise over a known frequency range. The noise source output is characterized as a series of ENR (Excess Noise Ratio) values. The calibration data for a given noise source consists of ENR values (expressed in decibels) at discrete frequency points across its band. Figure 3-17 opposite is a graphic example of calibration data for an Eaton 7618E Solid State Noise Source.




**Figure 3-17. EXAMPLE OF CALIBRATED NOISE SOURCE DATA (EATON 7618E CALIBRATED NOISE SOURCE)**

These ENR values are inscribed on the calibration label which is affixed to the noise source and are also listed on the calibration data sheet accompanying each Eaton Solid State Noise Generator. The ENR values and their associated frequencies are entered into the ENR Tables of the 2075 by the user before any measurements can be made. Each frequency entry is paired with the ENR value at that frequency. For more information see Paragraphs 3-9 and 3-31.

For especially high frequency applications, a Gas Discharge Noise Generator and a Gas Discharge Noise Generator Power Supply, such as the Eaton 7175, may be used with the 2075. In such a case, a time delay value must be entered. The time delay is always entered in milliseconds and the valid range is from 1 ms to 10 seconds (10,000 ms). To enter the time delay for a gas discharge noise source, for example 75 ms, press:



To activate the time delay, press:




Generally a time delay of 1 millisecond is sufficient.

### 3-30. NOISE DRIVE VOLTAGE AND INDICATOR

When measurements are made, the 2075 supplies pulses which turn the noise source on and off. These pulses are supplied via the front and rear panel NOISE DRIVE connectors. The ON voltage level is 28.00 volts DC,  $\pm$  .05 volts. The OFF level is less than 1.0 volt.

The green indicator located immediately above the NOISE DRIVE connector can be programmed to turn on and off synchronously with the pulses. This feature is typically used when making manual measurements requiring a true hot/cold thermal noise source.

Special Function 21.0 is the default or normal mode for the indicator. When this mode is in effect, the indicator is always off, regardless of the voltage applied to the noise source. To activate the indicator, press:



In this mode the indicator will turn on when the noise drive voltage is on, and turn off when the voltage is off. The GPIB code for this is SP 21.1 ET.

### 3-31. ENR TABLES

Before making noise measurements, it is necessary to enter noise source calibration data into an ENR table. The 2075 has 4 ENR tables in which ENR values (noise source calibration data) can be stored. An optional fifth table is available in the form of a ROM chip which can be ordered with the noise source. A complete procedure for entering ENR values is given in Paragraph 3-9 on page 3-26.

Table 0 stores only one ENR value which is used for all frequencies. At the factory, a value of 15.5 dB is entered into this table. This value may be changed by the user.

Table 1 stores up to 31 ENR values with 31 associated frequencies. Each ENR value and its associated frequency are stored as a pair.

Table 2 stores up to 31 ENR values with 31 associated frequencies. Each ENR value and its associated frequency are stored as a pair.

Table 3 stores up to 31 ENR values with 31 associated frequencies. Each ENR value and its associated frequency are stored as a pair.

Table 4 This table is an optional ROM chip which can be purchased with a matching noise source. The chip contains permanently stored ENR values and associated frequencies for the noise source.

Tables 1, 2, and 3 can be used to store calibration data for three different noise sources. In each of these tables, frequency and ENR values are stored in pairs. That is, each frequency is stored with the ENR value for that frequency. The valid range for frequency entries is 10 MHz through 65,535 MHz. The


maximum allowable ENR entry is 80 dB. However, the effective ENR at the input of the DUT cannot exceed 18 dB. The extra range (the difference between 18 and 80 dB) is to allow for losses between the noise source and the DUT.

ENR values are always entered as dB. ENR values below -9.99 dB will be automatically displayed as a ratio after entry.

#### Table Selection

A table must be selected before its contents can be viewed, before ENR values can be entered, before a Second Stage Calibration is performed, or before a measurement is made. In other words, before performing any operation which involves an ENR table, a table must first be selected by the user.

Special Function 5 is used to select the table. Table 0 is selected by Special Function 5.0. Tables 1 through 3 are selected by Special Functions 5.1 through 5.3 respectively. The optional ROM chip, Table 4, is selected by Special Function 5.4. To select Table 3, for example, press:



The 2075 always remembers which ENR table was last selected and will automatically select that table after it is switched on. If no table has ever been previously selected, the instrument selects Table 0 by default.

#### Editing Table Contents

Figure 3-18 shows how the data is organized in Tables 1, 2, or 3. Although only 9 entry pairs are shown, up to 31 can be stored.

up to ↑  
31 entries

Frequencies (MHz)		ENR values (dB)
10000	_____	15.2
8000	_____	14.8
5000	_____	15.0
3000	_____	15.3
2000	_____	15.6
1000	_____	15.4
500	_____	15.5
300	_____	15.4
100	_____	15.2
30	_____	15.1
10	_____	15.0

Pointer is moved up or down using  or  keys to display values.

Figure 3-18. ENR TABLE 1, 2 OR 3.

After a table has been selected its contents can easily be examined or edited. To get into the editing mode (this is the same as the data entry mode), press:



The red light in the **ENR** key will light. The lowest frequency in the table is displayed in Window A and the ENR value for that frequency is displayed in Window B. The ENTER annunciator in Window A begins flashing.

To step through the table and view the data, use the **UP ARROW** and **DOWN ARROW** keys. Each keystroke of the **UP ARROW** key causes the next highest frequency and its ENR value to be displayed. Holding the **UP ARROW** key will cause rapid movement through the table in ascending frequency order. When the highest frequency is reached, the table will wrap around and begin again at the lowest frequency. Pressing or holding the **DOWN ARROW** key causes movement through the table in the opposite direction.

To delete a table entry, first display the entry using the **UP ARROW** or **DOWN ARROW** keys. Then press **CLEAR**. Both the frequency and the ENR value which were displayed are deleted.

The ENTER annunciators in Windows A and B guide the user in making entries.

The ENTER annunciator in Window A blinks to indicate that a frequency may be entered. The ENTER annunciator in Window B blinks to indicate that an ENR value may be entered. After the indicated entry is made, the blinking annunciator automatically shifts to the other window.

The **ENTER** key can be used to toggle the blinking ENTER annunciator back and forth between Windows A and B. For example, if the annunciator is blinking in Window B, but the user desires to enter a new frequency value, pressing the **ENTER** key will cause the annunciator to begin blinking in Window A.

When entering a frequency and ENR value, the frequency must always be entered first. Before entering the frequency the ENTER annunciator must be blinking in Window A.

To enter a frequency (for example, 1000 MHz), press:



The frequency, 1000 MHz, will be displayed in Window A and the ENTER annunciator will begin blinking in Window B. To enter the ENR value for 1000 MHz (for example, 15.7 dB), press:



The value 15.7 will be displayed in Window B. Note that the ENTER annunciator now begins to blink in Window A again, indicating that another frequency may now be entered.

To change an existing frequency or ENR value in a table, first use the **UP ARROW** or **DOWN ARROW** keys to display the entry which is to be modified.

To delete both the displayed frequency and the displayed ENR value, press: **CLEAR**. It does not matter whether the ENTER annunciator is blinking in Window A or Window B, both will be deleted.

To change an ENR value, but not the frequency, first make sure that the blinking ENTER annunciator is in Window B. Then press the appropriate numeric keys and then the **ENTER** key to overwrite the old value with the new one. The new ENR value is stored with the displayed frequency.

A frequency cannot be modified. It must be deleted and then a new frequency and ENR value entered.

It is not necessary to enter frequency and ENR values in ascending frequency sequence. The 2075 automatically organizes all entries and stores them in order.

After completing the examination or editing of the table, press the **ENR** key. The red light in the center of the **ENR** key will go off and the instrument exits the ENR mode.

The 2075 accesses the data in the selected ENR table whenever a Second Stage Calibration is performed or when a measurement is taken. The ENR values are used during the calculation of second stage noise figures at each calibration point, and also during calculation of first stage (Device Under Test) noise figure.

During calibration and measurement, the 2075 interpolates ENR values for frequencies between those stored in the table.

GPIB code examples are given:

Table Select:	SP 5.x ET
Enable ENR entry mode:	EN
Entry pairs:	10 MZ 15.5 DB 100 MZ 14.9 DB 300 MZ 15.1 DB etc.
Exit ENR entry mode:	EN

### 3-32. CALIBRATION

During normal operation of the 2075 two types of calibration are performed by the user. These are Frequency Calibration (FCAL) and Second Stage Calibration. A third calibration, IF Attenuators Calibration, should be performed during normal recalibration procedures if the instrument has been unused for a long period of time, or if a total system reset (Special Function 0.9) has been done. These calibrations are separate and distinct from other procedures covered in the maintenance manual under Alignments and Adjustments. Alignment and adjustment procedures are those typically performed once or twice a year by a calibration facility which then issues a calibration certificate for the instrument.

The following paragraphs cover Frequency Calibration, Second Stage Calibration, and IF Attenuators Calibration.

### 3-33. FREQUENCY CALIBRATION

Frequency calibration consists of tuning the first local oscillator inside the 2075 to the first IF frequency of 2200 MHz. This automatic procedure ensures the accuracy of the displayed tuned frequency. The message FCAL is displayed on the front panel while this is in progress.

A Frequency Calibration is initiated by any of the following:

1. AC power is applied to the 2075.
2. The **CALIB** key is pressed.
3. The **PRESET** key is pressed.
4. A Total System Reset (Special Function 0.9) is performed.
5. According to the setting of Special Function 15.


Special Function 15 determines when and how often Frequency Calibration will be performed.

Special Function 15.0 is the normal and default Frequency Calibration mode. In this mode, a Frequency Calibration is automatically performed after power-on at intervals of 1 minute, 2 minutes, 4 minutes, and 8 minutes. Thereafter, it is performed every 8 minutes.

Special Function 15.1 causes one Frequency Calibration to be performed immediately. Then Special Function 15 reverts to the mode which was in effect before 15.1 was initiated (15.0 or 15.2).

Special Function 15.2 disables the periodic Frequency Calibration mode set by 15.0. In this mode, Frequency Calibration is not performed periodically nor is it performed when the **CALIB** key is pressed.

To initiate any special function setting (for example, 15.2), press:



### 3-34. SECOND STAGE CALIBRATION

SECOND STAGE CALIBRATION is the measurement of the Noise Figure of the second stage at discrete frequency points across the band. These measurements are taken at up to 100 frequency points for each of three different input gain settings.

The term SECOND STAGE refers to the 2075 and any other equipment which is part of the measurement system, following the Device Under Test. The term FIRST STAGE refers only to the Device Under Test and any components between the noise source and the DUT.

Before any corrected measurement can be made, a Second Stage Calibration must be performed to measure the Noise Figure of the second stage. Then, after the Device Under Test is connected into the system and measured, the effects of second stage noise are subtracted to achieve a highly accurate, corrected, first stage measurement.

External relays can be used to automate the Second Stage Calibration. When the calibration is performed the 2075 applies an actuating voltage to the relays which switch to the calibration path, leaving the DUT out of the circuit. When the calibration is completed, the 2075 removes the voltage from the relays thereby placing the DUT in the circuit. The relay voltage is supplied via the front panel RELAY POWER connector. This voltage can be set to +5, +15, or +30 volts DC using the procedure of Paragraph 2-6. The factory setting is +30 volts DC. Figure 3-19 illustrates a setup for Test Configuration 2, single sideband, using external relays. When Special Function 10.1 is activated, the relay power will remain on even after the calibration is completed.




Figure 3-19. SETUP WITH EXTERNAL RELAYS USED TO AUTOMATE CALIBRATION

The start frequency, stop frequency, and step size which are entered as sweep parameters determine the points at which Second Stage Calibration data is taken. In order to obtain accurate corrected measurements, the calibration points must be the same as the measurement points. Second stage calibration can be done at a maximum of 100 points. If a measurement is attempted at an uncalibrated frequency point, error message 110 will be displayed. However, enabling Special Function 24.1 causes the 2075 to interpolate additional calibration points and allows measurement at those frequencies. Such measurements are less accurate.

If calibration is attempted at more than 100 points, calibration table overflow occurs and error message 117 is displayed.

To perform a Second Stage Calibration for swept measurements, press:



The 2075 performs a frequency calibration and then the second stage calibration. During this process the front panel successively displays:

- FCAL during the Frequency Calibration (FCAL is not performed if Special Function 15 is set to 15.2)
- CAL0 during initialization of the calibration tables

- CAL1 during calibration at the first input gain setting (+25 dB)
- CAL2 during calibration at the second input gain setting (+10 dB)
- CAL3 during calibration at the third input gain setting (-5 dB)

A Second Stage Calibration in progress can be stopped by pressing the **CALIB** key.

Input gain settings are user-selectable. The default settings are +25 dB, +10 dB, and -5 dB. Where an external amplifier is part of the second stage, and its gain is greater than 20 dB, a different set of input gain settings must be selected. For more information on input gain settings see Paragraph 3-35 and Special Function 16.

To perform a single frequency Second Stage Calibration at a fixed frequency, press:



The 2075 does the FCAL, CAL0, CAL1, CAL2, and CAL3 at the single fixed frequency.

When a calibration is completed, the 2075 automatically goes into the corrected measurement mode, more specifically, the F + G mode.



Calibration data is saved until a new calibration is performed or until AC power is removed from the instrument.

The calibration process disables all front panel keys except for the **CALIB** key which may be pressed to abort a calibration.

In order to save time when a high degree of smoothing is in use, the calibration process can be stopped after CAL1 is completed. This should be done only if this first calibration range is sufficient for the measurement which is to be made. If the calibration is stopped immediately after the CAL 1 range is done, then Range 2 (CAL2) and Range 3 (CAL3) data will not be taken. Therefore, measurements made in those ranges will not be valid.

Likewise, the calibration process can be stopped after completion of the CAL2. In this case no new calibration data is taken for the CAL3 range and, therefore, a measurement requiring CAL3 data would be invalid. After a calibration is stopped prematurely, and the measurement is made, if the calibrated range is insufficient for the measurement, no error message will occur. It is the responsibility of the user to insure that when a calibration is aborted, the ranges which were performed will be sufficient for the measurement to be taken.

### 3-35. INPUT GAIN SELECTION

During Second Stage Calibration, data is taken at three different input gain settings. The input gain settings are determined by the levels of RF attenuation the 2075 places in its RF amplifier section. The greater the external gain of the second stage, the more attenuation is required.


Where an external amplifier with more than 4 dB of gain is part of the Second Stage, a group of input gain settings must be chosen by the user. The correct input gain settings will prevent the input to the 2075 from exceeding the allowable power range of the Final Detector.

There are three groups of input gain settings available and they are shown below:

ALLOWABLE SECOND STAGE EXTERNAL GAIN	INPUT GAIN SETTING GROUPS	SPECIAL FUNCTION	GPIB CODE
4 dB or less	0, -15, -30 dB	16.1	C0
4 dB to 25 dB	-15, -30, -40 dB	16.2	C1
25 dB to 38 dB	-30, -40, -55 dB	16.3	C2

The first group, 0, -15, and -30 dB, is the normal or default selection.

To select a group(for example, the second group), press:



### Gain Measurement Range

Although the 2075 specifications list the gain range as -20 to +50 dB, this maximum figure is actually a worst case situation which assumes a DUT input bandwidth of 1900 MHz or greater.

The 2075 is actually capable of measuring gains greater than 50 dB depending on the bandwidth of the Device Under Test. For instance, if the DUT bandwidth is reduced to 190 MHz, the 2075 can measure greater than 60 dB of gain. Reducing the bandwidth of the DUT to 19 MHz would further increase the available gain range to 70 dB or greater.

The total gain measurement range of the 2075 can be expressed as a function of bandwidth ratios as follows:

$$\text{Gain Measurement Range} = 10 \text{ Log} \left[ \frac{1900}{\text{BW of DUT}} \right] + 50$$

### 3-36. IF ATTENUATORS CALIBRATION

The IF Attenuators Calibration procedure is included as part of the Performance Verification Procedures covered in Section 5 of this manual. Those procedures should be performed on a new 2075, and again at six month intervals. This paragraph is included here to give additional information on IF Attenuators Calibration.

At approximately six month intervals, the IF attenuators should be calibrated to compensate for minor shifts in the attenuator values. Where the 2075 is subjected to wide variations of ambient temperature, the attenuators should be calibrated more frequently. The IF attenuators must also be calibrated after the 2075 has undergone a total system reset (Special Function 0.9).

During the IF Attenuators Calibration, the 2075 turns off the power to the noise source and measures each of the attenuators in its IF stage, using its own noise power detector. The resulting data is stored in battery backed-up memory and later used to correct gain measurements. This calibration takes only a few seconds. When it is completed, the 2075 reverts to its normal operating mode. This calibration data is erased when a total system reset is performed.

To perform an IF Attenuators Calibration, remove all devices connected to the RF input. Then, to save the present states of the front panel control parameters in front panel storage register 0, press:

PRESET

After the PRESET, press:

SPEC  
FUNC

19.1

ENTER

During the five steps, the front panel will display the following messages:

CAL0 CAL1 CAL2 CAL3 CAL4

During CAL0, all IF attenuation is removed. During CAL1, the 5 dB IF attenuator is measured. During CAL2, the 10 dB attenuator is measured. During CAL3 the 15 dB attenuator is measured, and during CAL 4, the second 15 dB attenuator is measured.

When the CAL4 message disappears, the calibration is completed.

### 3-37. SELECTION OF SIDEBAND PARAMETERS

When using Test Configurations 2 through 6, external downconversion is performed and a sideband parameter must be selected. Double sideband can be selected only in Test Configurations 2 and 4. Single sideband, either upper or lower, can be selected in Test Configurations 2 through 6.

Speaking generally, double sideband measurements are less accurate than single sideband measurements. However, if the total overall gain of the Device Under Test is 20 dB or greater, inaccuracy of double sideband measurements due to noise in the second sideband is not significant. Also, accuracy of double sideband measurements can be increased by using a low frequency IF so that the two sidebands are closer together in frequency. This reduces the differences in noise level from sideband to sideband, and improves accuracy.

During single sideband measurements, a high-pass, low-pass, or band-pass filter must be used to reject noise at unwanted image frequencies. Otherwise, noise from the image band, as well as noise from the RF measurement band, would be downconverted to the same IF band. Generally, the Device Under Test will have a different response in the RF measurement and image bands, and the actual measurement then becomes an average of the two unequal responses when no filter is used.

For a lower sideband measurement, a low-pass filter is used. For an upper sideband measurement, a high-pass filter is used. Because a low-pass filter rejects all frequencies and harmonics above its cutoff frequency, lower sideband measurements may be preferred to upper sideband. It should be noted that where a single sideband measurement is made and a filter with the needed cutoff frequency is not available, gain compensation can be used to correct for the error due to noise from the unwanted image sideband. (See Paragraph 3-40 on page 3-86.)

The width of the RF measurement range determines if measurements can be made using single or double

sideband. As indicated in Table 3-4, Selecting the Test Configuration, measurements taken over an RF range wider than 1.6 GHz must be made double sideband, and Test Configuration 2 or 4 must be used. This 1.6 GHz figure is somewhat arbitrary, but it is based on the practical problem of finding a filter with the correct cutoff frequency when making single sideband measurements. The following discussion will show how this problem affects the choice of test configuration and sideband parameters.

Figure 3-20 is an example of a measurement situation using Test Configuration 3. As shown in Table 3-4, this configuration requires a fixed frequency local oscillator which produces a variable frequency IF. Measurements are made over an RF range less than 1.6 GHz wide, and therefore a single sideband parameter is chosen. In this case, lower single sideband is used.

1. Measurements are desired from 3.7 GHz to 4.2 GHz. The RF range is 500 MHz wide.
2. The local oscillator frequency remains fixed at 5.2 GHz.

3. IF frequencies vary from 1.5 GHz to 1.0 GHz. ( $5.2 - 3.7 = 1.5$  GHz) to ( $5.2 - 4.2 = 1.0$  GHz)
4. Unfiltered image frequencies will fold into the IF frequencies. ( $6.7 - 5.2 = 1.5$  GHz) to ( $6.2 - 5.2 = 1.0$  GHz)
5. To obtain accurate measurements a low-pass filter is used to filter out the image frequencies. The cutoff frequency of the filter must be between 4.2 GHz and 6.2 GHz. It would be relatively easy to find a filter with a cutoff frequency in this range since it is 2000 MHz wide. It should be noted that the filter must not roll-off below 4.2 GHz and it should achieve 40 dB or more of rejection by 6.2 GHz.
6. It is sound engineering practice to also provide isolation between the DUT and the mixer. This prevents mixer products and local oscillator leakage through the mixer from interacting with the DUT. To accomplish this, the low-pass filter cutoff frequency must be between 4.2 GHz and 5.2 GHz, a 1000 MHz range. Thus, it is slightly more difficult to find the right filter.
7. Go to the next example to see how increasing the width of the RF measurement range increases this problem.




Figure 3-20. EXAMPLE 1 - SIDEBAND SELECTION




Figure 3-21. EXAMPLE 2 - SIDEBAND SELECTION

Figure 3-21 also shows an example using Test Configuration 3. Again, a fixed frequency local oscillator is used to produce a variable IF. Single lower sideband is used. However, the RF measurement range is expanded to 1.6 GHz wide.

much more difficult to find a filter with a cutoff frequency in this range since it is only 400 MHz wide. The filter must not roll-off below 6.6 GHz and it should achieve 40 dB or more of rejection by 7.0 GHz.

1. Measurements are desired from 5.0 GHz to 6.6 GHz. The RF measurement range is 1.6 GHz wide.
2. The local oscillator frequency remains fixed at 6.8 GHz.
3. IF frequencies vary from 1.8 GHz to 0.2 GHz. ( $6.8 - 5.0 = 1.8$  GHz) to ( $6.8 - 6.6 = 0.2$  GHz)
4. Unfiltered image frequencies will fold into the IF frequencies. ( $8.6 - 6.8 = 1.8$  GHz) to ( $7.0 - 6.8 = 0.2$  GHz)
5. To obtain accurate measurements a low-pass filter is needed to filter out the image frequencies. The cutoff frequency of the filter must be between 6.6 GHz and 7.0 GHz. It is
6. If the filter is to provide isolation between the DUT and the mixer, its cutoff frequency must fall between 6.6 MHz and 6.8 MHz. With this allowable range of only 200 MHz, it becomes very difficult to find the right filter.
7. One solution to this problem is to reduce the width of the RF measurement range and make two or more measurement sweeps. Another possibility is to make the measurement in double sideband mode using Test Configuration 2 or 4. A third alternative is to use Gain Compensation to correct for the additional noise from the unwanted sideband. (See Paragraph 3-40.)
8. Go to the next example to see how this problem is slightly different using Test Configuration 2 or 4.




Figure 3-22. EXAMPLE 3 - SIDEBAND SELECTION

Figure 3-22 is an example of a test situation using Test Configuration 2.

As shown in Table 3-4, this configuration requires a variable frequency local oscillator and produces a fixed frequency IF. Measurements are made over an RF range less than 1.6 GHz wide, and therefore a single sideband parameter is chosen. In this case, lower sideband is used.

1. Measurements are desired from 8.0 GHz to 9.2 GHz. The RF range is 1.2 GHz wide.
2. The local oscillator frequency is varied from 9.8 GHz to 11.0 GHz.
3. The IF frequency is fixed at 1.8 GHz.  
( $9.8 - 8.0 = 1.8$  GHz) to ( $11.0 - 9.2 = 1.8$  GHz)

4. Unfiltered image frequencies will fold into the IF frequencies.  
( $11.6 - 9.8 = 1.8$  GHz) to ( $12.8 - 11.0 = 1.8$  GHz)
5. To obtain accurate measurements a low-pass filter must be used to filter out the image frequencies. The cutoff frequency of the low-pass filter must be between 9.2 GHz and 11.6 GHz. It is relatively easy to find a filter having a cutoff frequency within this range since it is 2.4 GHz wide. Again, however, to isolate the DUT from mixer products would require that the filter cutoff frequency be between 9.2 and 9.8 GHz, a range of only 600 MHz.




Figure 3-23. EXAMPLE 4 - SIDEBAND SELECTION

Figure 3-23 is an example of a test situation using Test Configuration 2. Again, this configuration requires a variable frequency local oscillator and produces a fixed frequency IF. In the case below, measurements are made over an RF range which is 1.6 GHz wide, and a single sideband parameter is chosen.

1. Measurements are desired from 8.0 GHz to 9.6 GHz. The RF range is 1.6 GHz wide.
2. The local oscillator frequency is varied from 9.8 GHz to 11.4 GHz.
3. The IF frequency is fixed at 1.8 GHz.  
( $9.8 - 8.0 = 1.8$  GHz) to ( $11.4 - 9.6 = 1.8$  GHz)
4. Unfiltered image frequencies will fold into the IF frequencies.  
( $11.6 - 9.8 = 1.8$  GHz) to ( $13.2 - 11.4 = 1.8$  GHz)
5. A low-pass filter is used to filter out the image frequencies. The cutoff frequency of the filter must fall between 9.6 and 11.6 GHz, a range of

2000 MHz. If local oscillator leakage and mixer products are to be isolated from the DUT, the filter cutoff frequency would have to fall between 9.6 and 9.8 MHz, a range of only 200 MHz. Thus it can be seen how increasing the RF measurement range increases the difficulty of obtaining a filter with the correct cutoff frequency. One solution to this problem is to decrease the RF measurement range and make several swept measurements. Another solution is to make a double sideband measurement using test configuration 2 or 4. Another solution is to use gain compensation to correct for the additional noise from the unwanted sideband. See Paragraph 3-40.

6. These are only four examples. Depending on the RF frequencies of measurement, the IF frequencies, and the test configuration used, the situation will vary. This is why the 1.6 GHz figure for maximum RF range of single sideband measurements is somewhat arbitrary, but may be useful as a practical limit.




Figure 3-24. BANDWIDTH COMPENSATION - EXAMPLE 1

**3-38. BANDWIDTH COMPENSATION**

If the noise bandwidth of the Device Under Test (First Stage) is narrower than the noise bandwidth of the Second Stage, bandwidth compensation should be employed to ensure measurement accuracy. However, it should be employed only if the Gain of the Device Under Test is greater than Unity.


The term FIRST STAGE refers only to the Device Under Test. The term SECOND STAGE refers to the 2075 and any other RF devices which are part of the measurement system, excluding the DUT.

If the bandwidth of the DUT is wider than or equal to the bandwidth of the Second Stage, then no bandwidth compensation is needed. In such a case, Special Function 4.0 should be selected. This selects no bandwidth compensation and uses default values of 5.0 MHz for each bandwidth.

The nominal bandwidth of the 2075 is 5.0 MHz and this is usually the bandwidth of the Second Stage. However, where external amplifiers or mixers are used as part of the Second Stage, and one of these has a bandwidth narrower than 5.0 MHz, this narrower bandwidth is the bandwidth of the Second Stage. For example, if an external mixer is used as part of the Second Stage, and its IF bandwidth is 3.1 MHz, the Second Stage bandwidth is considered to be 3.1 MHz.

The examples given illustrate several cases.

In this first example, the BW of the First Stage is 3.0 MHz and the BW of the Second Stage is 5.0 MHz. Employ BW compensation by entering:



(Turns on BW Compensation)

Notice that Special Function 4.1 is used to enter the First Stage BW (BW1) and 4.2 is used to enter the Second Stage BW (BW2). When BW compensation is used, follow the normal procedures as given for the different test configurations, but make the entries before performing Second Stage Calibration.




Figure 3-25. BANDWIDTH COMPENSATION - EXAMPLE 2

In this second example the BW of the First Stage (DUT) is 1.3 MHz and the smallest bandwidth of the Second Stage (the amplifier) is 2.2 MHz. Make the entries as follows:

SPEC FUNC	4.1	ENTER
1.3	ENTER	
SPEC FUNC	4.2	ENTER
2.2	ENTER	
SPEC FUNC	4.3	

(To turn on BW compensation)

The GPIB code for Special Function 4.1 is N1.  
 The GPIB code for Special Function 4.2 is N2.  
 The GPIB code for Special Function 4.3 is N3.

Because, where BW compensation is required, the accuracy of measurements depends on how accurately BW1 and BW2 are known, the actual bandwidths should be measured before entry into the 2075. If the bandwidth of the DUT is not known, the procedures given in Paragraph 3-39 can be used to determine the ratio of the bandwidths. It is actually more important to know the correct ratio than it is to know the exact value for each.

Where the bandwidth of the DUT is known to be less than 5.0 MHz (the nominal value of the 2075) it is possible to eliminate the need for bandwidth compensation by employing an alternate scheme. This scheme is accomplished by adding a narrow band-pass filter to the Second Stage. The bandwidth of the filter must be less than the bandwidth of the DUT. This makes the First Stage BW wider than the Second Stage BW. It thereby eliminates the need to use BW compensation and eliminates the need to know the precise bandwidths of the two stages. Where this method is used, enter Special Function 4.0 (no bandwidth compensation) and the nominal default values of 5.0 MHz will be used for the first and Second Stage bandwidths.


**3-39. DETERMINING THE BANDWIDTH RATIO OF THE FIRST AND SECOND STAGES**

When the noise bandwidth of the First Stage is narrower than the noise bandwidth of Second Stage, bandwidth compensation must be employed to improve the accuracy of measurements. (Refer to Paragraph 3-38 on page 3-82.)

For improved accuracy it is actually more important to know the ratio of the First Stage to Second Stage bandwidth than it is to know the precise bandwidth for each. The following procedure shows how to determine this bandwidth ratio when the nominal value of 5.0 MHz is used for the Second Stage BW. It consists of:

- A. Measuring the insertion loss or gain of the DUT using a power meter.
- B. Measuring the insertion loss or gain of the DUT using the 2075.
- C. Calculating the bandwidth ratio.






**Figure 3-26.** INSERTION LOSS MEASUREMENT WITH POWER METER

To measure the insertion loss or gain of the DUT using a power meter perform the following steps:

1. Connect the DUT between the signal generator and the power meter as shown in Path A of Figure 3-26 below.
2. Tune the CW signal generator to obtain a peak reading on the power meter. Record the frequency that gives the peak reading.
3. Adjust the level of the CW signal generator to set a convenient reference level on the power meter. Record this level.
4. Remove the DUT from the setup.
5. Connect the CW signal generator directly to the power meter as shown in Path B of Figure 3-26 above.
6. Note the change in level on the power meter. The amount of increase over that noted in Step 3 is the insertion loss of the DUT. If the power meter reading decreases from that noted in Step 3, the decrease is the insertion gain of the DUT.

To measure the insertion loss or gain of the DUT using the 2075 perform the following steps:

7. Connect the noise source to the input of the 2075 as shown in Path A of Figure 3-27 below.
8. Set the Start and Stop frequencies 4 MHz above and 4 MHz below the frequency recorded in Step 2 above. Use a Step Size of .1 MHz and enter Special Function 9.1 to enable display resolution of .1 MHz.
9. Press the **CALIB** key to perform a Second Stage Calibration. Use sufficient smoothing to produce accurate results.
10. After the calibration is complete, connect the DUT as shown in Path B of Figure 3-27 below.
11. Tune the 2075 to the frequency which produces the highest gain, or the least loss. This will be the same frequency that was recorded in Step 2. Measure the Gain by pressing **F + G**.
12. Record the gain as indicated in Window B of the 2075.



**Figure 3-27.** INSERTION LOSS MEASUREMENT WITH 2075

To calculate the bandwidth ratio of the First Stage to the Second Stage use the following equations:

GP = Gain or loss measured with the power meter (Step 6)

GN = Gain or loss measured using the 2075 (Step 12).

BL = Bandwidth loss (loss due to bandwidth reduction)

GN - GP = BL and

$10^{\left(\frac{BL}{10}\right)}$  = The bandwidth of the DUT versus the bandwidth of the 2075.


**Example 1**

GP = 25 dB  
GN = 19 dB (Gain)

GN - GP = BL  
19 - 25 = -6 dB and  $10^{\left(\frac{-6}{10}\right)} = .251$

The bandwidth of the DUT is .251 of the 2075 bandwidth.

In Example 1 above, the value for the First Stage bandwidth would be entered as 1.25 MHz (.251 x 5.0MHz). This would be accomplished by pressing:




**Example 2**

GP = -3 dB  
GN = -7 dB (loss)

GN - GP = BL  
-7 - (-3) = -4 dB and  $10^{\left(\frac{-4}{10}\right)} = .398$

The bandwidth of the DUT is .398 of the 2075 bandwidth.

In Example 2 above, the value for the First Stage bandwidth would be entered as 1.99 MHz (.398 x 5.0 MHz). This would be accomplished by pressing:



In both examples, the nominal or default value of 5.0 MHz would be used for the bandwidth of the 2075.

**3-40. COMPENSATION FOR LOSS OR GAIN**

The 2075 provides a means of compensating for known losses (or gains). Loss 1 is a loss between the noise source and the Device Under Test. Loss 2 is a loss between the Device Under Test and the 2075. Typically such losses are due to test cables or other devices which are part of the First Stage and, therefore, are not in the setup during Second Stage Calibration.

When the values for Loss 1 and Loss 2 are entered, a single temperature for both losses is also entered. Loss 1 and Loss 2 are considered to have the same temperature, which is the ambient temperature of the test area. The temperature can be entered in kelvins, degrees Fahrenheit, or degrees Centigrade. If no values are entered, default values of 296.0 K for the temperature and 0 dB for the losses are assumed. Compensation can be made for only one loss (or gain), instead of two, where desired.

A negative loss equates to a gain. When compensating for a gain instead of a loss, enter a minus (-) sign before the numeric value. Only Loss 1 can be entered as a minus value (gain).

Special Functions 17 and 18 are used to enter the loss compensation parameters. The following table shows the various functions:

DESCRIPTION	SPECIAL FUNCTION	GPIB CODE
No Loss Compensation (OFF)	17.0	NS
Use Loss Compensation (ON)	17.1	L0
Enter Loss 1 (between NS and DUT)	18.1	L1
Enter Temperature For Loss 1 and 2	18.2	L2
Enter Loss 2 (between DUT and 2075)	18.3	L3




Figure 3-28. LOSS COMPENSATION

After the loss compensation parameters have been entered, all subsequent measurements will use the programmed values. Entering Special Function 17.0 will turn off the loss compensation. However the values of Loss 1, Loss 2, and the temperature, are saved and will be reused when loss compensation is used again by entering Special Function 17.1.

The example above shows the procedure for employing loss compensation.

The Device Under Test is an amplifier which has a loss of 3.03 dB in series with its input (Loss 1) and a loss of 6.11 dB in series with its output (Loss 2). The ambient temperature is 298.0 kelvins.

The measurement procedure does not change from those given in the test configuration procedures of Paragraphs 3-11 through 3-19. The only difference is that the following entries are made before the Second Stage Calibration is performed.

1. To turn on Loss Compensation, press:

SPEC FUNC	17.1	ENTER
--------------	------	-------

2. To enter Loss 1, press:

SPEC FUNC	18.1	ENTER
--------------	------	-------


3.03	ENTER
------	-------

3. To enter the temperature of the losses, press:


SPEC FUNC	18.2	ENTER
--------------	------	-------

298.0	ENTER
-------	-------


The temperature can be entered as kelvins, degrees Centigrade, or degrees Fahrenheit, using Special Function 12. When set to the default value of 12.0, the entry must be made in kelvins. Special Function 12.1 allows entry in degrees C, and Special Function 12.2 allows entry in degrees F. The 2075 will also convert from one scale to another. Simply make the entry using the correct special function and then change the special function to the scale desired for display. For example, to enter 22 degrees C and then convert to F press:



(set to Centigrade)




(enter loss temperature)




(set to Fahrenheit)

4. To enter Loss 2 press:



Then proceed normally by performing the Second Stage Calibration. The 2075 automatically turns off loss compensation while performing the Second Stage Calibration and then turns it on again when the calibration is completed.

When loss compensation is no longer desired, turn it off by entering:



Gain compensation is also useful where double sideband measurements are made because a filter with the needed cutoff frequency cannot be obtained for a single sideband measurement. In Test Configuration 4, where the DUT is a mixer, there are no sidebands during Second Stage Calibration because the mixer is not in the setup. That is, the 2075 is using single sideband for the calibration, but makes the measurement using double sideband. In such a case, enter a value of -3 for Loss 1. The 2075 will compensate for the additional unwanted noise power from the unwanted sideband when making the measurement. (This increases accuracy, assuming that the frequency response of the DUT is the same for both sidebands.)

### 3-41. $T_{cold}$ COMPENSATION

$T_{cold}$  is the OFF temperature of the noise source. It is also the ambient temperature of the test area where the measurements are being made when the noise source is a solid state unit, such as one of the Eaton 76 Series.

The default value of  $T_{cold}$  is 296.0 kelvins (23.5 ° C) when the 2075 is PRESET or RESET. When the 2075 is powered-on,  $T_{cold}$  is set to whatever previous value has been entered. While this temperature is likely to be close to the actual room temperature, accuracy can be increased by measuring and then entering the actual ambient temperature.

The level of measurement error increases as the actual value of  $T_{cold}$  deviates from 296.0 kelvins, and as the value of Noise Figure is reduced.

The following graph shows the increase in error as the actual value of  $T_{cold}$  deviates from 290 kelvins. (The graph assumes a stored value of 290 kelvins and a noise source ENR of about 15.3 dB.)




Figure 3-29. ERROR CAUSED BY  $T_{\text{COLD}}$  DEVIATION FROM 290 K

To enter the true value of  $T_{\text{cold}}$ , for example 294.0 kelvins, press:



The value for  $T_{\text{cold}}$  can be entered in units of kelvins, degrees C or degrees F by selecting the correct setting of Special Function 12.

Special Function 12.0 allows entry in kelvins. This is the default state.

Special Function 12.1 allows entry in degrees Centigrade.

Special Function 12.2 allows entry in degrees Fahrenheit.

Simply set Special Function 12 to the appropriate value before making the temperature entry.

The GPIB code for  $T_{\text{cold}}$  is TC.

In the above graph, the degree of error is derived for the following equations:

The inexact equation is  $F = \frac{T_h - 290 \text{ K}}{290 \text{ K} (Y - 1)}$

The exact equation is  $F = \frac{\left[ \frac{T_h - 290 \text{ K}}{290 \text{ K}} \right] - Y \left[ \frac{T_c}{290 \text{ K}} - 1 \right]}{Y - 1}$

### 3-42. OSCILLOSCOPES AND RECORDERS TO DISPLAY DATA

The 2075 can output measurement data for display on an oscilloscope, an X-Y plotter, or a strip chart recorder. The setup procedures are similar for all three. Data can be output to only one device at a time.

Any noise-type measurement which the 2075 can make, or any gain measurement, can be displayed on any of these output devices. The units of display at the output device will be the same as those selected for display on the 2075 front panel.

Special Function 7 is used to select the type of device to display the data, as well as the type of display. Table 3-6 shows the different display functions available under Special Function 7.

Table 3-6. Output Display Special Functions

DISPLAY DEVICE	DATA DISPLAYED	SPECIAL FUNCTION	GPIB CODE
<b>SCOPE</b>			
	Display Noise Data and Gain vs. Frequency (for F+G measurements) or Display Noise Data vs. Frequency (for F measurements)	7.0	NP
	Display Test Pattern #1	7.1	P1
	Display Test Pattern #2	7.2	P2
	Display Noise Data vs. Frequency	7.3	NQ
	Display Gain vs. Frequency	7.4	AQ
<b>PLOTTER</b>			
	Position Pen at Lower Left	7.5	LL
	Position Pen at Upper Right	7.6	UR
	Plot Noise Data vs. Frequency	7.7	FQ
	Plot Gain vs. Frequency	7.8	GQ
<b>STRIP CHART</b>			
	Noise Data from X Output and Gain from Y Output	7.9	FG

When the 2075 is powered-up or RESET, Special Function 7 is set to 7.2. When a sweep is started, the instrument changes to Special Function 7.0 unless some other state of Special Function 7 has been selected.

The procedure for setting up the 2075 to output data for display is quite simple. It consists of entering upper and lower limits for Noise Figure and Gain, connecting the display device, and adjusting its controls.

The **LOWER LIMIT** and **UPPER LIMIT** keys are used to enter the limits for noise and gain measurements. The non-shifted mode is used for entering noise measurement limits and the shifted function is used for setting Gain limits. The allowable range for noise measurements is -30 through 9999.

The allowable range for Gain is -30.0 through 80.0. After these limits are entered the 2075 will scale the display output accordingly and fit the measurement data on that scale.

The following three example procedures are given for setting up an oscilloscope, an X-Y plotter, and a strip chart recorder.

#### Output to an Oscilloscope

1. Connect the X-AXIS, Y-AXIS, and Z-AXIS rear panel outputs of the 2075 to the A, B, and Z (horizontal, vertical, and Z) inputs of the oscilloscope. Use DC coupling for the oscilloscope inputs. The oscilloscope should use a positive-going TTL level voltage for blanking from the Z input.

2. Press:

SPEC  
FUNC

72

ENTER

This will cause the 2075 to output test pattern #2 (shown below) to the oscilloscope. Adjust the scope input sensitivity controls so that the test pattern just touches the screen edges on all four sides. The top and bottom edges should overlay the top and bottom scalar lines on the scope screen so that vertical scaling will be accurate. Verify that the pattern's diagonal lines cross near the center of the screen. Adjust the INT (Intensity) control on the rear panel of the 2075 to obtain a perceptible difference in intensity between the two halves of the test pattern.

Adjust the INTENSITY Control on the 2075 rear panel to obtain a perceptible difference in intensity between the two halves of the pattern.





Figure 3-30. TEST PATTERN 2 OSCILLOSCOPE DISPLAY

3. Enter the noise measurement lower limit (in this example, 0 dB) by pressing:



When the first key is pressed, the current programmed value is displayed in Window C.

4. Enter the noise measurement upper limit (in this example, 6 dB) by pressing:



5. Enter the Gain lower limit (in this example, 0 dB) by pressing:



6. Enter the Gain upper limit (in this example, 40 dB) by pressing:



7. Make the measurement by pressing **SWEEP**. The data will be displayed on the oscilloscope as the 2075 makes continuous automatic sweeps.

The figure below is a typical oscilloscope display using Special Function 7.0. Notice that one trace is fainter than the other. When Noise Figure and Gain are displayed simultaneously, the Noise Figure trace is more intense.




Figure 3-31. NOISE FIGURE AND GAIN OSCILLOSCOPE DISPLAY



The upper and lower limits in the diagram apply to both the noise measurement and the gain measurements respectively.

As the noise measurement is stepped through the selected frequency range, the oscilloscope will emphasize the current frequency point by increasing the intensity of the corresponding dot on the CRT. This allows the observer to keep track of the measurement frequency by correlating the CRT trace with the frequency displayed on the 2075 front panel. The maximum number of dots which can be output to the scope is 256. When a swept measurement is made using more than 255 frequency steps, the 2075 automatically compresses the data to fit the space on the scope display and each dot may represent more than one data point.


When a swept measurement is made using less than 255 frequency steps, the number of segments on the scope display will be equal to the number of frequency steps.

If the step size is such that there is not an integral number of steps from the start to the stop frequency, the last frequency step will be fractional. For example, when sweeping from 400 MHz to 600 MHz, with a step size of 30 MHz, the last frequency step would be 20 MHz (580 to 600 MHz). In such a case, this last frequency step will be displayed as a full segment on the oscilloscope.

### Output to an X-Y Plotter


When measurement data is output to an X-Y plotter, swept measurements must be made using 256 frequency steps or less. Otherwise, the 2075 will not output the data.

1. Connect the X-AXIS, Y-AXIS, and Z-AXIS outputs on the rear panel to the X, Y, and pen-lift inputs of the X-Y plotter. Use DC mode for the X and Y inputs. Make certain, however, that the pen-lift input is TTL compatible (0 - 5 volt input).
2. Enter the noise measurement lower limit (in this example, 0 dB) by pressing:



When the first key is pressed, the current programmed value is displayed in Window C.

3. Enter the noise measurement upper limit (in this example, 6 dB) by pressing:




4. Enter the Gain lower limit (in this example, 0 dB) by pressing:



5. Enter the Gain upper limit (in this example, 40 dB) by pressing:




6. Press:




The 2075 will output the lower left alignment point to the plotter. Adjust the plotter sensitivity controls to position the pen on the lower left corner of the paper.

7. Press:




The 2075 will output the upper right alignment point to the plotter. Adjust the plotter sensitivity controls to position the pen on the upper right corner of the paper.

8. Repeat and recheck Steps 6 and 7 as necessary.
9. Choose the measurement to be displayed. Press:



to plot noise data versus frequency, OR

Press:



to plot Gain versus frequency.

Both of these can be plotted on the same chart by plotting one first and then selecting the other and plotting it. The pen color should be changed between plots.


- To make the measurement and plot the trace, press:



The 2075 will execute a single sweep and plot a single trace. It should be noted that if an attempt is made to initiate continuous automatic sweeps, by pressing only **SWEEP** the 2075 will sweep but not plot.


### Output to a Strip Chart Recorder

- Connect the 2075 X-AXIS and Y-AXIS outputs to the Channel 1 and Channel 2 inputs on the strip chart recorder. Noise measurements will be output on the X-AXIS and Gain will be output on the Y-AXIS.
- Enter the noise measurement lower limit (in this example, 0 dB) by pressing:



When the first key is pressed, the current programmed value is displayed in Window C.

- Enter the noise measurement upper limit (in this example, 6 dB) by pressing:




- Enter the Gain lower limit (in this example, 0 dB) by pressing:



- Enter the Gain upper limit (in this example, 40 dB) by pressing:




- Press:



The 2075 will output the lower limit alignment point to both channels. Adjust the sensitivity controls on both channels of the strip chart recorder to position the pens at the bottoms of the charts.


- Press:



The 2075 will output the upper limit alignment point to both channels. Adjust the sensitivity controls on both channels to position the pens at the tops of the charts.

- Repeat and recheck Steps 6 and 7 as necessary.

- Press:



This selects output to a strip chart recorder. Noise measurements will be plotted on Channel 1 (X-AXIS output) and Gain will be plotted on Channel 2 (Y-AXIS output).

- Where Fixed Frequency measurements are made, the strip chart recorder will plot the readings versus time.

- 11. It is possible to plot swept measurements also. These are made against frequency, however, the frequency is plotted as time on the strip chart. It should be noted that the 2075 does not always take the same amount of time for each measurement at each frequency step. Therefore, it is not possible to correlate frequency with time.
- 12. Press the appropriate key on the 2075 to make the measurement.

Cavity stabilized klystrons produce the cleanest signals but are cumbersome and are not GPIB programmable. Direct synthesizers are not desirable because of their relatively high floor noise. Indirect synthesizers, such as the Eaton 5440, are good. Ultimately, the only way to be certain that a device is a suitable external local oscillator is to try it.

- 5. GPIB compatibility where required. (Test Configurations 3 and 5 do not require a GPIB compatible local oscillator.)

**3-43. SELECTING AN EXTERNAL LOCAL OSCILLATOR**

In Test Configurations 2 through 6 the user must supply an external local oscillator for use in downconverting the DUT frequencies to frequencies within the input range of the 2075 (unless the DUT is a receiver with a built-in local oscillator and an IF lower than 1850 MHz). Care must be exercised when selecting an external local oscillator. A suitable signal generator must have the following characteristics:

- 1. Sufficient output power to drive the mixer into efficient operation.
- 2. The appropriate frequency range needed for downconversion to the allowable 2075 input frequency range.
- 3. Good frequency accuracy and repeatability. The degree of accuracy required depends on the measurement. For example, for a noise measurement made at the band edge of an amplifier that has steep skirts, a 5 MHz frequency error may be significant. Some generators can be locked to an external frequency counter to improve accuracy.
- 4. Low noise output, i.e. low phase noise and low floor noise with very low spurious output. Special care must be taken concerning this point. Heterodyne signal generators may be unsuitable. Some so-called synthesizing signal generators switch to a heterodyning process below 2.0 or 2.5 GHz.


**3-44. CONTROLLING EXTERNAL LOCAL OSCILLATORS**

In the LIMITED CONTROLLER mode, the 2075 can control an external sweep generator which is used as an external local oscillator in Test Configurations 2 through 6. Control programs for three commonly available sweep generators are stored in ROM memory. Table 3-7 below lists these devices and shows the special function which selects the control program for each one. The 2075 also allows the user to write a custom control program for a sweep generator other than those shown.

**Table 3-7. Control Programs for External Local Oscillator**

EXTERNAL LOCAL OSCILLATOR	SPECIAL FUNCTION
Hewlett Packard 8672	47.0
Wiltron 6600	47.1
Not used	47.2
Hewlett Packard 8350A	47.3
Custom Program	47.4

To select the control program for a Wiltron 6600, press:



The procedures for writing a custom program are presented in the next paragraph.

### 3-45. WRITING A CUSTOM PROGRAM FOR CONTROLLING A LOCAL OSCILLATOR

The 2075 allows the user to write a custom program for controlling an external local oscillator. The custom program is written into a 40 byte scratch pad in the instrument's RAM.

Instructions are entered in numeric form using the numeric keypad. Each instruction code is entered as the decimal numeric code equivalent for the desired ASCII character. The instructions are entered one byte at a time. As each byte is entered, its decimal form is displayed in Window A on the front panel.

The ASCII characters and their equivalent decimal forms are given in Table 3-8, US ASCII Character Codes. This table is located at the end of this subsection.

The general procedure for writing and executing a control program is shown below. Following that is a detailed sample procedure showing how to write and execute a control program for a Hewlett Packard 8673.


The general procedure is as follows:

1. Enter Special Function 48.1 to activate the user defined control program entry mode.
2. Enter the FREQUENCY PREFIX for the sweep generator by entering the decimal equivalents for the required ASCII characters.
3. Enter the ASCII character ACK (CNTRL-F) by entering the decimal equivalent for that ASCII character. (The decimal equivalent is 6.) When the program executes, the 2075 will insert the appropriate frequency, in MHz, in this location. [The ASCII character BEL (CNTRL-G) can be used to allow insertion of GHz instead of MHz.]
4. Enter the FREQUENCY TERMINATOR for the sweep generator by entering the decimal equivalents for the required ASCII characters.

5. Enter the OUTPUT POWER PREFIX for the sweep generator by entering the decimal equivalents for the required ASCII characters.
6. Enter the ASCII character SOH (CNTRL-A) by entering the decimal equivalent for that ASCII character. (The decimal equivalent is 1.) When the program executes, the 2075 will insert the output power level in this location.
7. Enter the OUTPUT POWER TERMINATOR for the sweep generator by entering the decimal equivalents for the required ASCII characters.
8. Enter the ASCII characters that disable all modulation and marker functions for that sweep generator by entering the decimal equivalents for those ASCII characters.
9. Enter the ASCII code to turn on the RF.
10. Terminate the program entry sequence.
11. Select the custom program as the desired controlling program.
12. Place the 2075 in the GPIB LIMITED CONTROLLER mode.

The following is a sample procedure illustrating the creation and execution of a custom program for controlling a Hewlett Packard 8673.

1. Activate the user defined control program entry mode by pressing:



2. To enter the frequency prefix (FR), press:



(this enters the ASCII F)



(this enters the ASCII R)

- 3. To enter the ASCII character ACK (or CNTRL-F) press:

- 4. To enter the frequency terminator (MZ) press:

(this enters the ASCII M)

(this enters the ASCII Z)

- 5. To enter the output power level prefix (PL) press:

(this enters the ASCII P)

(this enters the ASCII L)

- 6. To enter the ASCII character SOH (or CNTRL-A) press:

- 7. To enter the output power level terminator (DM) press:

(this enters the ASCII D)

(this enters the ASCII M)

- 8. To enter the codes that disable amplitude modulation (AO) press:

(this enters the ASCII A)

(this enters the ASCII O)

- 9. To enter the codes that disable frequency modulation (DO) press:

(this enters the ASCII D)

(this enters the ASCII O)

- 10. To enter the codes that disable pulse modulation (PO) press:

(this enters the ASCII P)

(this enters the ASCII O)

- 11. To enter the codes that disable frequency markers (MO) press:

(this enters the ASCII M)

(this enters the ASCII O)

12. To enter the code that turns on the RF output (R1) press:

(this enters the ASCII R)

(this enters the ASCII 1)

13. To terminate the entry sequence press:

14. To select the custom program as the control program press:

15. To put the the 2075 in the LIMITED CONTROLLER mode press:

This concludes the procedure.

ASCII Char.	EQUIVALENT FORMS				GP1B
	Dec	Binary	Oct	Hex	
@	64	01000000	100	40	TA0
A	65	01000001	101	41	TA1
B	66	01000010	102	42	TA2
C	67	01000011	103	43	TA3
D	68	01000100	104	44	TA4
E	69	01000101	105	45	TA5
F	70	01000110	106	46	TA6
G	71	01000111	107	47	TA7
H	72	01001000	110	48	TA8
I	73	01001001	111	49	TA9
J	74	01001010	112	4A	TA10
K	75	01001011	113	4B	TA11
L	76	01001100	114	4C	TA12
M	77	01001101	115	4D	TA13
N	78	01001110	116	4E	TA14
O	79	01001111	117	4F	TA15
P	80	01010000	120	50	TA16
Q	81	01010001	121	51	TA17
R	82	01010010	122	52	TA18
S	83	01010011	123	53	TA19
T	84	01010100	124	54	TA20
U	85	01010101	125	55	TA21
V	86	01010110	126	56	TA22
W	87	01010111	127	57	TA23
X	88	01011000	130	58	TA24
Y	89	01011001	131	59	TA25
Z	90	01011010	132	5A	TA26
[	91	01011011	133	5B	TA27
\	92	01011100	134	5C	TA28
]	93	01011101	135	5D	TA29
^	94	01011110	138	5E	TA30
_	95	01011111	137	5F	UNT

ASCII Char.	EQUIVALENT FORMS				GP1B
	Dec	Binary	Oct	Hex	
`	96	01100000	140	60	SC0
a	97	01100001	141	61	SC1
b	98	01100010	142	62	SC2
c	99	01100011	143	63	SC3
d	100	01100100	144	64	SC4
e	101	01100101	145	65	SC5
f	102	01100110	146	66	SC6
g	103	01100111	147	67	SC7
h	104	01101000	150	68	SC8
i	105	01101001	151	69	SC9
j	106	01101010	152	6A	SC10
k	107	01101011	153	6B	SC11
l	108	01101100	154	6C	SC12
m	109	01101101	155	6D	SC13
n	110	01101110	156	6E	SC14
o	111	01101111	157	6F	SC15
p	112	01110000	160	70	SC16
q	113	01110001	161	71	SC17
r	114	01110010	162	72	SC18
s	115	01110011	163	73	SC19
t	116	01110100	164	74	SC20
u	117	01110101	165	75	SC21
v	118	01110110	166	76	SC22
w	119	01110111	167	77	SC23
x	120	01111000	170	78	SC24
y	121	01111001	171	79	SC25
z	122	01111010	172	7A	SC26
{	123	01111011	173	7B	SC27
	124	01111100	174	7C	SC28
}	125	01111101	175	7D	SC29
~	126	01111110	176	7E	SC30
DEL	127	01111111	177	7F	SC31

Table 3-8. US ASCII Character Codes

ASCII Char.	EQUIVALENT FORMS				GP18
	Dec	Binary	Oct	Hex	
NUL	0	00000000	000	00	
SOH	1	00000001	001	01	GTL
STX	2	00000010	002	02	
ETX	3	00000011	003	03	
EOT	4	00000100	004	04	SDC
ENQ	5	00000101	005	05	PPC
ACK	6	00000110	006	06	
BEL	7	00000111	007	07	
BS	8	00001000	010	06	GET
HT	9	00001001	011	09	TCT
LF	10	00001010	012	0A	
VT	11	00001011	013	0B	
FF	12	00001100	014	0C	
CR	13	00001101	015	0D	
SO	14	00001110	016	0E	
SI	15	00001111	017	0F	
DLE	18	00010000	020	10	
DC1	17	00010001	021	11	LLO
DC2	18	00010010	022	12	
DC3	19	00010011	023	13	
DC4	20	00010100	024	14	DCL
NAK	21	00010101	025	15	PPU
SYNC	22	00010110	026	16	
ETB	23	00010111	027	17	
CAN	24	00011000	030	18	SPE
EM	25	00011001	031	19	SPD
SUB	26	00011010	032	1A	
ESC	27	00011011	033	1B	
FS	28	00011100	034	1C	
GS	29	00011101	035	1D	
RS	30	00011110	038	1E	
US	31	00011111	037	1F	

ASCII Char.	EQUIVALENT FORMS				GP18
	Dec	Binary	Oct	Hex	
space	32	00100000	040	20	LA0
!	33	00100001	041	21	LA1
"	34	00100010	042	22	LA2
#	35	00100011	043	23	LA3
\$	36	00100100	044	24	LA4
%	37	00100101	045	25	LA5
&	38	00100110	046	26	LA6
'	39	00100111	047	27	LA7
(	40	00101000	050	28	LA8
)	41	00101001	051	29	LA9
*	42	00101010	052	2A	LA10
+	43	00101011	053	2B	LA11
,	44	00101100	054	2C	LA12
-	45	00101101	055	2D	LA13
.	46	00101110	056	2E	LA14
/	47	00101111	057	2F	LA15
0	48	00110000	080	30	LA16
1	49	00110001	081	31	LA17
2	50	00110010	062	32	LA18
3	51	00110011	063	33	LA19
4	52	00110100	064	34	LA20
5	53	00110101	065	35	LA21
6	54	00110110	066	36	LA22
7	55	00110111	067	37	LA23
8	56	00111000	070	38	LA24
9	57	00111001	071	39	LA25
:	58	00111010	072	3A	LA26
;	59	00111011	073	3B	LA27
<	60	00111100	074	3C	LA26
=	61	00111101	075	3D	LA29
>	62	00111110	076	3E	LA30
?	63	00111111	077	3F	UNL


Table 3-8. US ASCII Character Codes (Continued)



### 3-46. SPECIAL FUNCTIONS

Special Functions extend the range of the instrument's available functions beyond those normally selectable by dedicated front panel keys. Special Functions are selected by entering numeric special function codes using the front panel numeric keypad.

For example, to select Special Function 2.1 press:



This will set Special Function 2 to 2.1 regardless of its previous state.

For each special function code, the integer value to the left of the decimal selects the special function itself, and the number to the right of the decimal selects the state to which that special function will be set.

Each special function has a basic state which is denoted by a 0 to the right of the decimal. For example, the basic states for Special Functions 2 and 3 are 2.0 and 3.0. The only exceptions to this rule are Special Functions 1 and 16 which have no .0 states. For these two, the basic states are denoted by 1.1 and 16.1 respectively.

The non-basic states are indicated by a number other than 0 to the right of the decimal. For example, 2.1 and 2.2 are non-basic states for Special Function 2.

When the 2075 is powered-on, some special functions assume the basic state and some assume the last state they were in before the instrument was powered-off. For a listing of power-on states see Table 3-3. However, after a PRESET or a Total System Reset is performed, most special functions assume their basic states. Refer to Table 3-3 or 3-9.

Some special functions can be stored along with front panel control parameters in the Front Panel Storage Registers. These storable special functions are indicated in Table 3-3.

The current state for each special function is stored in a Special Functions Table in the 2075. To call up this table for examination, press:



Then use the **UP ARROW** and **DOWN ARROW** keys to move up and down through the table to view the current state of each special function. To exit the Table Viewing Mode press the **SPEC FUNC** key again or complete the keystroke sequence for making a special function entry, *numeric keys* and then **ENTER**. Note that only one special function may be changed or entered while in the viewing mode, and this causes an exit from the mode.

The easiest way to edit the table is to enter the viewing mode and note any changes which are desired. Then simply enter the new special functions.

Table 3-9 lists all special functions, their numeric codes, and the corresponding GPIB codes. The table also shows which special functions revert to their basic states upon power-on and which ones assume their previous states. Special functions which are storable in the Front Panel Storage Registers are also indicated.

For any 2075 with Software Update (SU-6), all special function codes can be sent to the 2075 over the GPIB. The GPIB code for special function is SP. The GPIB code and format to send any special function over the bus is:

SP XX.X ET

Insert the appropriate numeric code for the special function in place of the X's. For example, to set Special Function 14.1 over the bus the code would be SP 14.1 ET. The ET is the terminator (GPIB code for ENTER).

Some special functions also have an alphanumeric code (device message code) which can be sent over the GPIB. These special functions can be sent by using the format above, or by sending the alphanumeric character code. For example, Special Function 15.1 can be sent over the GPIB as:

SP 15.1 ET

Or it can be sent as:

FC CR LF

FC is the alphanumeric code, or device message code, for Special Function 15.1. The CR LF is a carriage return, line feed, and is the general line terminator when sending device messages to the 2075. See Paragraph 4-9 for more information on device messages.

Table 3-9. Special Functions Table

Function Type	SF Code	Power Up	S/R	GPiB Code	Function Description
Total System Reset	0.0 0.9	0.0	N	N/A	Normal measurement Erase BBU RAM data
Select Test Configuration	1.1 1.2 1.3 1.4 1.5 1.6	1.1	Y	D1 D2 D3 D4 D5 D6	DUT Configuration 1 (Standard default) DUT Configuration 2 (fixed IF; varbl LO) DUT Configuration 3 (varbl IF; fixed LO) DUT Configuration 4 (fixed IF; varbl LO) DUT Configuration 5 (varbl IF; fixed LO) DUT Configuration 6 (2 LO's; fixed & varbl)
Sideband Selection	2.0 2.1 2.2	2.0  A2	Y	A0 A1	Double Sideband (no offset) Lower Single Sideband Upper Single Sideband
Settle Time or Delay Time	3.0 3.1	3.0	N	N/A ST	Normal Measurement Display/Enter Ext LO settling time or time delay to ignite gas discharge NS
Bandwidth Compensation	4.0 4.1 4.2 4.3	4.0	N	N0 N1 N2 N3	Disable bandwidth compensation Display/Enter DUT bandwidth & go to 4.0 Display/Enter 2nd stage BW & go to 4.0 Enable bandwidth compensation
ENR Table Selection	5.0 5.1 5.2 5.3 5.4	PREV	Y	B0 B1 B2 B3 B4	Use nominal value of ENR Use ENR Table 1 (user must enter) Use ENR Table 2 (user must enter) Use ENR Table 3 (user must enter) Use ROM ENR Table. (Special ROM required)
Measurement Mode	6.0 6.1	6.0	N	N/A N/A	Normal Measurement Manual Noise Figure Measurement
X/Y Output Configurations	7.0 7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9	7.2  or  7.5	N	NP P1 P2 NQ AQ LL UR FQ GQ FG	Display NF and Gain vs Frequency on scope Display test pattern #1 on scope Display test pattern #2 on scope Display NF only vs frequency on scope Display Gain only vs frequency on scope Move plotter pen to lower left Move plotter pen to upper right Plot NF vs frequency on plotter* Plot Gain vs frequency on plotter* Plot on strip chart, X-out = NF/Y-out = G
Display Revision	8.0 8.1	8.0	N	N/A N/A	Normal Measurement Display software update number
Frequency Resolution	9.0 9.1	PREV	N	RF RN	Normal 1 MHz frequency resolution 100 KHz frequency resolution

S/R = Store/Recall Capability – can be stored in front panel storage registers. Y = yes, N = no

PREV = Previous value used before power down

\* = Activated by single sweep

Table 3-9. Special Functions Table (Continued)

Function Type	SF Code	Power Up	S/R	GPIB Code	Function Description
Drive for External Relays	10.0				External relay drive voltage ON only during Second Stage Calibration
	10.1				Relay drive voltage continuously ON
Measurement Selection	11.0	11.0	N	NF	Cascade NF measurement (normal mode)
	11.1			YF	Y-Factor measurement
	11.2			OP	Operating Noise Temperature (K) msmnt
	11.3			PM	Power measurement (NS off)
	11.4			PN	Power measurement (NS on)
	11.5			NE	"Noise measure" measurement
Temperature Units Selection for $T_{hot}$ , $T_{cold}$	12.0	PREV	N	SK	Temperature units in kelvins
	12.1			SC	Temperature units in Centigrade
	12.2			SF	Temperature units in Farenheit
Display ENR In Use	13.0	13.0	N	CO	Normal measurement
				CE	Display ENR in use at the fixed frequency
Hold and Trigger Measurement	14.0	14.0	N	T0	Normal continuous measurement
	14.1			T1	Hold measurement cycle
	14.2			T2	Execute one measurement cycle and hold
Frequency Calibration Interval Selection	15.0	15.0	N	AF	Normal automatic frequency calibration
	15.1			FC	Do an FCAL and return to 15.0
	15.2			DF	Disable auto freq calibration function
Second Stage Calibration Input Gain Selection	16.1	16.1	N	C1	Use calibration setting #1 ( 0, 15, 30 dB)
	16.2			C2	Use calibration setting #2 (15, 30, 40 dB)
	16.3			C3	Use calibration setting #3 (30, 40, 55 dB)
Loss Compensation Select	17.0	17.0	N	NS	No loss compensation
	17.1			LC	Use loss compensation (use with SF 18)
Display and Enter Loss Data	18.0	18.0	N	L0	Normal measurement
	18.1			L1	Enter loss before the DUT (dB)
	18.2			L2	Enter temperature of DUT before loss
	18.3			L3	Enter loss after the DUT (dB)
IF Atten Calibration	19.0	19.0	N	N/A	Normal measurement
	19.1			IC	Do IF atten calibration and go to 19.0
Voltage/Atten Display Mode	20.0	20.0	N	V0	Normal measurement
	20.1			V1	Display E-off voltage in window A; RF attenuator setting in window B; IF attenuator setting in window C;
	20.2			V2	Display E-on voltage in window A; RF attenuator setting in window B; IF attenuator setting in window C; (with auto attenuation)
Noise Drive Indicator Function	21.0	21.0	N	LD	Noise source lamp is off
	21.1			LE	Lamp is ON when NS power is ON and OFF when NS power is OFF

Table 3-9. Special Functions Table (Continued)

Function Type	SF Code	Power Up	S/R	GPIB Code	Function Description
Display Blanking	23.0	23.0	N	DE	Normal measurement
	23.1			DD	Blank all displays during measurement (for GPIB operations only)
Interpolation Selection	24.0	24.0	N	MC	Prohibits NF/G measurements at non-calibrated points
	24.1			MN	Uses interpolation for measurements at non-calibrated points (low accuracy)
Special Functions, 30 thru 39 are service functions for use by qualified service personnel only.	30.0	30.0	N	N/A	Return for NF measurement
	30.1			N/A	Hysteresis calibration test
	30.2			N/A	Zero frequency adjust
	30.3			N/A	Low frequency adjust
	30.4			N/A	High frequency adjust
	30.5	N/A	Digital latch test		
	31.0	31.0	N	N/A	Return to NF measurement
	31.1			N/A	Display test
	31.2			N/A	Keyboard test
	32.0	32.0	N	N/A	Return to NF measurement
	32.1			N/A	Memory board RAM test
	32.2			N/A	CPU board RAM test
	32.3			N/A	Scope/Plotter RAM test
	33.0	33.0	N	N/A	Return to NF measurement
	33.1			N/A	ROM-1 checksum
	33.2			N/A	ROM-2 checksum
	33.3			N/A	ROM-3 checksum
	33.4			N/A	ROM-4 checksum
	33.5			N/A	ROM-5 checksum
	33.6			N/A	ROM-6 checksum
	33.7	N/A	Total checksum of ROM's 1-6		
	34.0	34.0	N	N/A	Return to normal measurement
	34.1			N/A	DMAC chip test
	34.2			N/A	GPIB chip test
	34.3			N/A	Math chip test
	35.0	35.0	N	N/A	Normal measurement
	35.1			N/A	RF Gain peak search
36.0				Not used	
37.0	37.0	N	R0	Auto RF attenuator	
37.1			R1	Fixed RF attenuator at 0 dB	
37.2			R2	Fixed RF attenuator at 15 dB	
37.3			R3	Fixed RF attenuator at 30 dB	
37.4			R4	Fixed RF attenuator at 40 dB	
37.5			R5	Fixed RF attenuator at 55 dB	

Table 3-9. Special Functions Table (Continued)

Function Type	SF Code	Power Up	S/R	GPIB Code	Function Description
Service Functions (continued)	38.0	38.0	N	I0	Auto IF atten (mutually exclsv with 39.x)
	38.1			I1	Fixed IF attenuator at 0 dB
	38.2			I2	Fixed IF attenuator at 5 dB
	38.3			I3	Fixed IF attenuator at 10 dB
	38.4			I4	Fixed IF attenuator at 15 dB
	38.5	I5	Fixed IF attenuator at 20 dB		
	39.0	39.0	N	N/A	Auto IF atten (mutually exclsv with 38.x)
	39.1			I6	Fixed IF attenuator at 25 dB
	39.2			I7	Fixed IF attenuator at 30 dB
	39.3			I8	Fixed IF attenuator at 35 dB
39.4	I9			Fixed IF attenuator at 40 dB	
39.5	IA	Fixed IF attenuator at 45 dB			
SRQ Configuration (for GPIB)	40.0	40.0	Y	N/A	Normal addressable talker/listener mode
	40.1			N/A	Talk-only mode
	40.2			N/A	Controller mode (addressing external LO)
	41.0				Not used
	41.1				
Service Request	42.0	42.0	N	NI	All SRQs disabled
	42.1			RA	SRQ on "data ready"
Service Request	43.0	43.0	N	NI	All SRQs disabled
	43.1			RC	SRQ on "calibration complete"
	44.0				Not used
	44.1				
Service Request	45.0	45.0	N	NI	All SRQs disabled
	45.1			RT	SRQ on "ready to tune"
Service Request	46.0	46.0	N	NI	All SRQs disabled
	46.1			RI	SRQ on instrument error
External LO Control Program Selection	47.0	PREV	Y	N/A	Control program for HP 8672 LO
	47.1			N/A	Control program for Wiltron 6600 Sweeper
	47.2			N/A	Not used
	47.3			N/A	Control program for HP 8350A
	47.4			N/A	Control program written by user (48.1)
External LO Control Program Parameters	48.0	48.0	N	N/A	Normal measurement
	48.1			N/A	Enter user defined control program for external LO
GPIB Output Format Selection	49.0	PREV	N	F0	Output Window C data only to GPIB
	49.1			F1	Output Window B data only to GPIB
	49.2			F2	Output Window A data only to GPIB
	49.3			F3	Output Window A and B data to GPIB
	49.4			F4	Output Window A and C data to GPIB
	49.5			F5	Output Window B and C data to GPIB
	49.6			F6	Output Window A, B, and C data to GPIB

On a front panel PRESET (GPIB Device Clear) condition, the special functions in this table will assume the same status as given in the "Power Up" column.

On a Total System Reset (Special Function 0.9), all of the special functions in this table will assume the zero condition. For example, SF 2.x will revert to 2.0; SF 4.x will revert to 4.0, etc. The only exceptions to this are:

Special Function 1.x will revert to 1.1.

Special Function 5.x will revert to its previous setting.

Special Function 7.x will revert to 7.2 or 7.6.

Special Function 16.x will revert to 16.1.

Special Function 47.x will revert to its previous setting.

### 3-47. ERROR MESSAGES

The 2075 generates error messages to provide the user with information concerning incorrect keyboard entries, operating errors, and hardware errors. There are two basic categories of error messages: Transitory and Continuous (Regeuerative).

Transitory messages are displayed for two seconds and then disappear. The instrument reverts to its normal activities. Transitory messages usually indicate the denial of some illegal request on the part of the operator.

Continuous messages remain displayed until the error condition is corrected and the 2075 can function normally.

The error messages are divided into ten groups as follows:

10x	ENR Table errors
11x	Calibration errors
12x	Special Function errors
13x	Range errors
14x	RF Hardware errors
15x	Digital Hardware errors
16x	GPIB errors
17x	Measurement Data errors (GPIB)
505	System errors
9xx	System errors

All messages within a particular group will begin with the same two digits. For example, 101, 102, and 103 all belong to the first group.

When the error occurs, the 2075 front panel displays Err xxx, where xxx is the message number.

Table 3-10 lists all the error messages, their meanings, and the necessary corrective actions. Error messages are also listed on the information pull-out card in the bottom of the 2075.

Table 3-10. Error Message Table

ERROR CODE	MEANING	CORRECTIVE ACTION
101	ENR table does not exist (is cleared or empty)	Enter Frequency and ENR values or select correct ENR table. See Paragraph 3-9.
102	Attempt to modify ENR ROM table	Only tables from 5.1 - 5.3 can be modified.
103	ENR table overflow--more than 31 points entered	Enter no more than 31 calibration points in the table.
104	ENR table empty--no calibration data	Enter ENR data in the table before using it.
105	Frequency too low	Increase the frequency so that it is not lower than the lowest ENR table frequency or else enter the ENR value for that frequency.
106	Frequency too high	Decrease the frequency so that it is not higher than the highest ENR table frequency or else enter the ENR value for that frequency.
107	ENR value greater than 18 dB	Only use ENR value greater than 18 dB with proper loss compensation.
110	Measurement at non-calibrated point	Use 24.1 to override but result will be less accurate.
111	Frequency lower than calibration table	Increase the frequency so that it is within the Second Stage Calibration range or re-calibrate.
112	Frequency higher than calibration table	Decrease the frequency so that it is within the Second Stage Calibration range or re-calibrate.
113	IF attenuators not calibrated or data is wrong	Use Special Function 19.1 to re-calibrate. See Paragraph 3-36.
114	Cannot find peak during frequency calibration	Try again using Special Function 15.1. Repeated failure means hardware problem. Contact service center.
115	Calibration data not available	Do Second Stage Calibration before attempting a Noise Figure and Gain measurement.
116	Calibration error, uncalibrated RF range	DUT Gain is greater than 2075's ability to measure. Reduce Gain of DUT or measure Noise Figure only.
117	Calibration table overflow--more than 100	Calibrate with 100 or fewer points (use narrower frequency range or larger step size).

Table 3-10. Error Message Table (Continued)

ERROR CODE	MEANING	CORRECTIVE ACTION
118	Calibration error, due to RF overload	Select different range using SF 16 or check the hardware. Contact service center.
119	Cannot start a frequency calibration	Try again using Special Function 15.1. Repeated failure means hardware problem. Contact service center.
121	Special function does not exist	Use valid special function.
122	Sequence not stored	Use set sequence procedure to set the sequence before using this feature.
123	DUT Configuration has conflicting parameters	Check parameters and try again.
124	Invalid to plot Gain-only while in F-only mode	Check parameters and try again.
131	Frequency range error (Stop frequency is smaller than start frequency)	Enter appropriate frequencies.
133	The IF tuning frequency is beyond 10 to 1900 MHz	Check the DUT configuration.
134	The external LO frequency is out of range	Check the RF and IF combination.
141	RF overload (RF input too high)	Reduce the RF input power.
143	Detector overload (unable to attenuate the detector to proper level)	May have hardware problem. Contact service center.
151	Battery backup RAM error—data may be lost	Re-enter 2075 GPIB address and ENR table data. Perform IF CAL. Check to see if battery is OK.
152	RAM board error	Check board using SF 32.1.
153	ROM board error	Check board using SF 33.x.
154	GPIB board error	Check board using SF 34.2.
155	DMAC board error	Check board using SF 34.1.
156	Scope RAM error	Check board using SF 32.3.
157	A/D converter error	Use Spec Funct 20.1/20.2 to investigate.




Table 3-10. Error Message Table (Continued)

ERROR CODE	MEANING	CORRECTIVE ACTION
158	Math processor error	Check board using SF 34.3.
166	Illegal GPIB mode	Conflict between DUT configuration and GPIB mode.
170	Measured data is out of range	Check measurement setup.
171	Data not available	The requested data is not available in this mode.
505	System error	Check power supply voltage: +5 to +5.25 volts. If OK and errors persist, then instrument requires service.
901	System error	Check power supply voltage: +5 to +5.25 volts. If OK and errors persist, then instrument requires service.
910	System error	Check power supply voltage: +5 to +5.25 volts. If OK and errors persist, then instrument requires service.
911	System error	Check power supply voltage: +5 to +5.25 volts. If OK and errors persist, then instrument requires service.
912	System error	Check power supply voltage: +5 to +5.25 volts. If OK and errors persist, then instrument requires service.
913	System error	Check power supply voltage: +5 to +5.25 volts. If OK and errors persist, then instrument requires service.
914	System error	Check power supply voltage: +5 to +5.25 volts. If OK and errors persist, then instrument requires service.
920	System error	Check power supply voltage: +5 to +5.25 volts. If OK and errors persist, then instrument requires service.

**3-48. STORE-RECALL REGISTERS**


The 2075 can save the current front panel control parameters and then recall them for re-use at a later time. Nine front panel storage registers (Register 1 through Register 9) are available for storing up to nine sets of control parameters. A tenth register, Register 0, saves current control parameters when a PRESET is done. The parameters which are stored are listed in Column 4 of Table 3-3.

To store a set of control parameters, in Register 3 for example, press:



The control parameters currently in use are stored in Register 3 and they also remain as the active parameters.

To recall a previously stored set of control parameters, from Register 8 for example, press:




The control parameters which were stored in Register 8 immediately become the active control parameters.

The 2075 can also recall sets of previously stored control parameters in any sequence. The normal recall sequence is from Register 1 through Register 9. To recall in sequence press:



The next register in sequence is recalled and its number is displayed in Window A.

To program a new recall sequence press:



For example, if the new desired sequence is 1,2,3,1,2,3,1,2,3 then the keystroke sequence is:



Any sequence can be programmed up to a maximum of 9 digits in length.

**3-49. SMOOTHING FUNCTION**

Smoothing can be employed to reduce "jitter" in displayed noise and gain measurements. When smoothing is not in use, each measurement result is displayed immediately. Small, random variations in readings can appear as very rapid changes in the least significant digits of the displayed values.

Smoothing is an averaging function. When smoothing is employed, each measurement is made many times and the results are averaged together. Then the average value is displayed on the front panel. Increasing the amount of smoothing increases the number of measurements made and averaged together, before the average value is displayed.

To increase smoothing press the **RIGHT ARROW** key. Each time the key is pressed, smoothing is increased by one increment. Depress and hold the **RIGHT ARROW** key to add multiple increments. To decrease smoothing, use the **LEFT ARROW** key in similar fashion.

Smoothing is increased or decreased in powers of two. The smoothing indicator is a group of ten LED light bars. The leftmost bar represents 2 to the 0 power. The rightmost bar represents 2 to the 9th power. When minimum smoothing is in use, only the leftmost bar is lit and this indicates that 2 to the 0 power (1) readings are taken and averaged before the result is displayed. Each additional bar, when lit, indicates an increase, by a power of two, in the number of readings taken and averaged before displaying the result. When all the bars are lit, 2 to the 9th power (512) readings are taken and averaged together before the result is displayed. See Figure 3-32.




Figure 3-32. SMOOTHING INDICATOR

The term SMOOTHING NUMBER refers to the number of LED bars that are lit. If all 10 bars are lit, the smoothing number is 10.

The term SMOOTHING FACTOR refers to the number of measurements taken and averaged before the result is displayed. The smoothing factor is equal to 2 raised to that power which is equal to the smoothing number minus 1. See the equation below:

$$\text{Smoothing Factor} = 2^{(\text{Smoothing Number} - 1)}$$

The 2075 uses two different methods of calculating the displayed value. When swept measurements are made, an arithmetic method is used. In this method, the number of readings taken is equal to the smoothing factor and the readings are averaged to produce the displayed value. The formula for this method is shown:

$$\text{Displayed Value} = \frac{\text{Sum of } S \text{ measurements}}{S}$$

Where S is the smoothing factor.

In arithmetic smoothing, the display is updated every time that S readings have been taken.

When fixed frequency measurements are made, the smoothing factor is applied exponentially. This smoothing algorithm is designed to give progressively greater weight to prior measurements as the smoothing factor is increased. The formula for the exponential method is as follows:

$$\text{Displayed Value} = \frac{P(S-1) + D}{S}$$

Where: P is the Previous Data Value (the cumulative previous displayed average)

D is the Present Data Value (the single reading just taken)

S is the Smoothing Factor in use

As an example, assume a smoothing factor of 32. The above formula becomes:

$$\text{Displayed Value} = \frac{P(32-1) + D}{32} \text{ or } \frac{31P + D}{32}$$

The process of taking S number of readings is referred to as a measurement cycle. For exponential smoothing, the value of P is cumulative through the measurement cycles. Thus, as more measurement cycles are made, the displayed value becomes even more stable.

Note that as the smoothing factor is increased, the displayed value becomes quite stable. Of course, as the smoothing factor is increased, more time is required for the display to show a change.

The following table shows this effect. Column 1 shows the numeric sequence of the measurements. That is, 10 measurements are shown and the sequence is from 1 to 10 (or top to bottom). Column 2 shows the actual reading for each single measurement. The remaining 5 columns show what average value is actually displayed on the front panel when a given smoothing factor is in use. For example, in Column 3, which is for a smoothing factor of 1, each displayed value is exactly the same as the single measurement just taken. In Column 4, which is for a smoothing factor of 2, each displayed value is the average of the last reading just taken and the previous average. To illustrate, the second entry in Column 4 is 2.50 which is the average of the first 2 measurements; 2.52 and 2.48 from column 1. The third entry in Column 4 is 2.53 and this is the average of 2.56 and 2.50.

Measurement Number	Actual Measurement	DISPLAYED VALUE				
		Smoothing Factor				
		1	2	4	8	128
1	2.52	2.52	2.52	2.52	2.52	2.52
2	2.48	2.48	2.50	2.51	2.52	2.52
3	2.56	2.56	2.53	2.52	2.52	2.52
4	2.53	2.53	2.53	2.52	2.52	2.52
5	2.49	2.49	2.51	2.52	2.52	2.52
6	2.45	2.45	2.48	2.50	2.51	2.52
7	2.44	2.44	2.46	2.48	2.49	2.52
8	2.45	2.45	2.46	2.48	2.49	2.52
9	2.45	2.45	2.45	2.47	2.49	2.52
10	2.44	2.44	2.45	2.46	2.48	2.52

### 3-50. 100 KHZ DISPLAY RESOLUTION


The normal frequency display resolution of the 2075 is 1 MHz. This resolution can be increased to .1 MHz by Special Function 9.1.

When normal 1 MHz resolution is in use, the frequency display does not show a decimal place. A frequency of 100.9 MHz, for example, will be displayed as 100 MHz. When .1 MHz resolution is in use, one decimal place is shown and the example frequency displayed is 100.9 MHz.


Because Test Configuration 1 operates within the basic 10 MHz to 1900 MHz range of the instrument, use of .1 MHz resolution is practical in this configuration. In Test Configurations 2 through 6, which operate at much higher frequencies, this feature is not practical and cannot be used.

It is important to note that even if .1 MHz display resolution is not in effect, the user can still increment the frequency in steps as small as .1 MHz. In such a case, the display will not show the fractional steps. For instance, if the frequency is incremented in .1 MHz steps, from 100.0 MHz to 101.0 MHz, the display will continue to show 100 MHz while the frequency is changing from 100 MHz through 100.9 MHz.

To select .1 MHz resolution press:



To select 1 MHz resolution press:




The GPIB code to select .1 MHz resolution is RN.

The GPIB code to select 1 MHz resolution is RF.

### 3-51. SOFTWARE REVISIONS

A special function is used to display the software update level of the 2075. To determine the software update level press:



The update level is displayed in Window A as SU-X, where X is the update level number. Software Update Level 6 would be displayed as SU-6.

This manual is written to software update 6. The following changes have been incorporated in SU-6:

1. The maximum input frequency that can be measured at the input port is now 1900 MHz (specifications apply up to 1850 MHz).
2. There is no minimum allowable entry for ENR values. The maximum allowable ENR value is now 80 dB.

The maximum usable effective ENR is 18 dB. That is, values of up to 80 dB can be entered. However, these can be used by the 2075 during calculations, only if sufficient loss compensation (Loss 1) is employed so that ENR (dB) minus Loss 1 (dB) is no greater than 18 dB.

#### NOTE


ENR is always entered as dB, however it may be displayed as dB or as a ratio. When entering a value down to -9.99 dB, the display will show dB. However when entering a value below -9.99 dB, the display will automatically show the value as a ratio.

3. The maximum allowable frequency for an ENR value is now 65,535 MHz.
4. The maximum RF frequency measurable is now 65,535 MHz.
5. The allowable range of entries for  $T_{hot}$  is now 0 to 18,588 kelvins.
6. Special Function 15.2 disables the automatic periodic FCAL and also disables the FCAL at the beginning of Second Stage Calibration.
7. During any Test Configuration the 2075 can be placed in any GPIB mode.
8. During Second Stage Calibration, pressing the **CALIB** key stops the calibration but the calibration data taken up to that point is retained. However, the CAL1 step must have been


completed before the **CALIB** key was pressed. When this is done the instrument goes into uncorrected mode. However, it can be returned to corrected mode by pressing the **F + G** key.

Where heavy smoothing is in use, performing all the steps of Second Stage Calibration can take a long time. This feature avoids the need to complete all three steps (CAL1, CAL2, and CAL3) of the Second Stage Calibration. However, the user must be sure that when the measurement is made, the DUT gain is flat enough so that the 2075 does not need to use a different input gain setting. Otherwise the instrument will use old calibration data for that gain setting and the measurement will be erroneous.

9. When manual Noise Figure measurements are made, the instrument can now be operated in Talk Only Mode for outputting data to a printer.
10. When a Gas Discharge type noise source is used, the delay time can be entered by the user and its allowable range is from 1 msec to 10 seconds. The value is always entered in milliseconds. As an example, to enter a delay time of 2 seconds, press:



To activate usage of this delay time, press:



## NOTE

Where an external local oscillator is used, the value entered under Special Function 3.1 is used for the local oscillator settling time. This same value is also used for the trigger delay time if Special Function 22.1 has been activated.

11. The user defined control program for external local oscillators now has an additional control character: Control G = decimal 7 = ASCII BEL. The 2075-2A will interpret this character to mean that the frequency units for the external LO are in GHz.
12. A new special function has been added; Special Function 10.0. Special Function 10.0 causes voltage to be applied to external relays only during Second Stage Calibration. Special Function 10.1 causes voltage to be always applied to the external relays.
13. A new GPIB code has been added which allows any special function to be set via the bus. This new code is SP. To set any special function over the bus, send:

SP XX.X ET

Where XX.X is the numeric code for that special function.

14. The absolute need to send the UNTALK command to the 2075-2A after it has been ADDRESSED TO TALK and then has finished talking, is no longer necessary.

## SECTION 4

### GPIB OPERATION

#### 4-1. INTRODUCTION

This section of the manual provides information related to operation of the 2075 over the General Purpose Interface Bus. Whereas operating procedures in general are covered in Section 4 of this manual, this section provides the necessary additional information to accomplish those procedures over a GPIB. This section assumes that the user has some familiarity with operation and programming of GPIB devices.

#### 4-2. GPIB GENERAL INFORMATION

This paragraph is included to provide some basic information and concepts related to operation of the General Purpose Interface Bus.

The GPIB is a standardized digital interface system which allows the exchange of digital data and commands between programmable electronic instruments. The GPIB was first established as a standard by the Standards Board of the Institute of Electrical and Electronic Engineers (IEEE) in 1975. The defining document, IEEE-488 1975, was published in that year. After minor editorial revisions, the document was re-published in 1978 as IEEE-488 1978.

The IEEE standard was adopted by the American National Standards Institute (ANSI) in 1976 and was published as ANSI Standard MC 1.1. The user should refer to either of these documents for detailed information regarding operations of the GPIB.

As many as 15 devices can be connected to the bus at one time. There are 4 basic types of devices and these are classified according to the 3 basic bus functions which they perform: CONTROLLER, TALKER, LISTENER, and TALKER/LISTENER. The CONTROLLER manages the bus and tells the other devices when to talk and when to listen. Only the controller can send commands but it can also send and receive data. A TALKER can send data. A LISTENER can receive data. A TALKER/LISTENER can send and receive data.

The CONTROLLER commands a device to talk by sending an ADDRESS TO TALK command to that device. The CONTROLLER commands a device to listen by sending an ADDRESS TO LISTEN command. Since an address is used as part of the command, only the device having that address will comply with that command.

There can be only one active controller on the bus. Some GPIB applications use two or more controller devices, but in such cases active control of the bus is switched back and forth between them. Thus, there is still only one active controller at any given time.

At any one time, only one device on the bus can be the talker. However, when a device is talking there can be several listeners at the same time.

The GPIB is a 24 wire interface. Of the 24, eight wires are common return lines and 16 wires are signal lines. The 16 signal lines are grouped as 8 data lines, 5 bus control lines, and 3 handshake lines. These are shown in Figure 4-1.




Figure 4-1. GENERAL PURPOSE INTERFACE BUS

The bus is operated in two basic modes: Command Mode and Data Mode. The controller places the bus in Command Mode by setting the ATN line to TRUE. In this mode the controller can transmit multiline commands on the 8 data lines or it can transmit single line commands by setting the states of the bus control lines. Commands belong to either the Universal Command Group (UCG) or the Addressed Command Group (ACG). All devices on the bus respond to a UCG command. Only the addressed device will respond to an ACG command. Both the ADDRESS TO TALK and the ADDRESS TO LISTEN command are ACG commands.

The controller places the bus in Data Mode by setting the ATN line to FALSE. In Data Mode, data is transmitted on the 8 data lines and it is normally encoded in 7 bit ASCII format with the 8th bit used for parity. Data transmission occurs in a byte serial, bit parallel mode. Any talker can place data on the bus, but only after it has been addressed to talk by the controller.

The 3 handshake lines carry the signals DAV, NRFD, and NDAC. These three lines are used to establish the correct timing of the asynchronous data exchanges between all devices. The states of these lines can be read or set by any device as part of the handshake process.



The 5 bus control lines carry the signals ATN, REN, IFC, SRQ, AND EOI. Only the controller can set the states of the ATN, REN, and IFC lines. The SRQ line can be set by any device (except the controller) when it requests service from the controller. The EOI line state can be set by any device, including the controller, when it is being a talker. The 5 bus control lines are used to send single line messages.


For more detailed information on GPIB operation refer to IEEE-488 1978 or ANSI MC 1.1.

### 4-3. GPIB OPERATING MODES


The 2075 can be operated in three different and mutually exclusive GPIB modes which are Normal TALKER/LISTENER, TALK ONLY (TALK ALWAYS), and LIMITED CONTROLLER. Special Function 40 is used to select the mode.

Normal TALKER/LISTENER is the mode used when the 2075 is controlled by an external GPIB compatible controller. The 2075 assumes this mode upon power-up. However, it is still in local mode and is controllable from the front panel until the external controller sends the first ADDRESS TO LISTEN command. Upon receipt of this command the 2075 goes into remote mode, control reverts to the external controller, and the front panel is locked out (except for the LOCAL key). The 2075 can LISTEN or TALK while in this mode.


To select this mode press:



TALK ONLY (or TALK ALWAYS) mode is a local mode, in which the front panel controls are used to operate the 2075. This mode is used to send measurement data to a GPIB compatible printer, when no external controller exists. To select this mode press:



LIMITED CONTROLLER mode is used when the 2075 controls the operation of an external local oscillator and no external controller exists. This is a local mode and control is therefore accomplished from the front panel. To select this mode press:



### 4-4. SETTING THE GPIB ADDRESS

The GPIB address of the 2075 can be entered through the front panel when the unit is in a local mode. To enter the address (for example, 15), press:



The current address can be displayed by pressing only the LOCAL key.

The GPIB address is saved when the unit is powered-off. It is also saved when the unit is preset by pressing the PRESET key. When a total system reset is performed (Special Function 0.9) the current address is lost and it is set to the default value of 8.

### 4-5. GPIB COMPATIBILITY

The 2075 can interface with any GPIB compatible controller or computer. The GPIB functional capabilities of the 2075, as defined by IEEE-488 1978, are shown in Table 4-1.

Table 4-1 GPIB Functional Capabilities

AH1	Complete acceptor handshake
SH1	Complete source handshake
T5	Complete talker
L4	Complete listener, except no LISTENER ONLY
SR1	Complete Service Request
RL1	Complete Local/Remote
PPO	No parallel poll
DC1	Complete Device Clear
DT1	Complete Device Trigger
C1	System Controller
C3	Capable of sending REN
C28	Capable of sending interface message only

Note that the mnemonic codes are not control codes for the 2075.

For a more detailed explanation of the codes above refer to IEEE-488 1978 or ANSI Standard MC 1.1.

**4-6. REMOTE AND LOCAL MODES**

When the 2075 is in the LOCAL mode, all control is accomplished via the front panel keys. When the 2075 is in the REMOTE mode, it is controlled by an external controller and the front panel keys are locked out. However, the LOCAL key on the front panel is not locked out unless the controller has sent a local lockout message.

The 2075 is always in local mode when it is in the TALK ONLY (TALK ALWAYS) or LIMITED CONTROLLER mode.

When the instrument is powered up it assumes the normal TALKER/LISTENER mode by default, and it is also in local mode. The 2075 goes into the remote mode only when it is in normal TALKER/LISTENER mode, and only after the external controller has placed it in remote. To do this, the controller first sets the REN (Remote enable) line TRUE, and then sends an ADDRESS TO LISTEN command to the 2075. If no external controller exists, the unit will remain in local mode.

The RMT (REMOTE) annunciator in Window A is lit when the unit is in the remote mode.

The 2075 can always communicate via the GPIB regardless of the mode it is in. However, it can receive data or commands from an external device only when in the normal TALKER/LISTENER mode.

**4-7. GPIB MESSAGE TYPES**

The 2075 communicates on the GPIB interface by sending or receiving four basic categories of messages. These are:

INTERFACE BUS MESSAGES

DEVICE MESSAGES

DATA MESSAGES

STATUS MESSAGES

**4-8. INTERFACE BUS MESSAGES**

These are commands sent by the controller to the devices on the bus when the bus is in the Command Mode (ATN line is TRUE). Most of these are multiline messages and all belong to either the ACG or UCG. These messages are defined by IEEE-488 1978 and all are device independent. That is, the manner in which the message is transmitted does not vary from one type of device to another. These messages are listed in Table 4-2 on page 4-6.

### DEVICE CLEAR Message

The DEVICE CLEAR message clears the current control parameters from the 2075 and causes it to assume the PRESET control parameters. That is, the CLEAR command has the same effect as depressing the front panel **PRESET** key. The CLEAR or PRESET control parameters are listed in Table 3-3.

The 2075 also responds to the SELECTIVE DEVICE CLEAR command (an ACG command) when it is addressed to listen. It will respond to the DEVICE CLEAR command (a UCG command) whether addressed or not.

### TRIGGER Message

The GROUP EXECUTE TRIGGER Message causes the 2075 to execute one complete measurement cycle according to its previously programmed parameters. The 2075 must be addressed to listen to receive this multiline message.

The program message, T2, causes the same response as the GROUP EXECUTE TRIGGER message. However, the 2075 must previously have been set to the HOLD mode by the program message T1.

### REMOTE Message

The REMOTE message places the 2075 in the remote mode. The REMOTE message is sent in two steps: first, the REN line is set to TRUE by the controller, and second, the ADDRESS TO LISTEN command is sent. The 2075 does not actually switch into remote until it receives the ADDRESS TO LISTEN command.

When the instrument switches from local to remote, none of the front panel control parameters are changed. However, the front panel keys, except **LOCAL** are disabled. When in the remote mode, the RMT annunciator is lit and any changes in control parameters must come from the controller.

### LOCAL Message

The LOCAL message is the GO TO LOCAL (GTL) bus command. When the 2075 is in remote mode and it receives this message from the controller, it will respond by going to local mode. Control is returned to the front panel keys.

If the instrument is in LOCAL LOCKOUT when the LOCAL message is received, front panel control is still returned but the LOCAL LOCKOUT is not cleared. This means that the next time the 2075 is placed back into remote, the **LOCAL** key will be disabled. This can be avoided by sending the CLEAR LOCKOUT/SET LOCAL message when commanding the instrument to go to local.

Changing the instrument from remote to local mode does not change any of the control parameters.

When the 2075 is in the remote mode and local lockout is not in effect, it can be returned to local by pressing the **LOCAL** key. It is possible, however, for this action to cause the loss of any data message currently being sent. This can be avoided by enabling local lockout, and by returning the instrument to local using the appropriate command from the controller.

### LOCAL LOCKOUT Message

If the 2075 is in the remote mode, the LOCAL LOCKOUT command causes it to disable the front panel **LOCAL** key.

If the 2075 is in local and the REN (Remote Enable) line is set to TRUE, the LOCAL LOCKOUT will not cause any immediate change. However, the first time it is addressed to listen, it will switch into remote mode and the **LOCAL** key will be locked out.

When local lockout is in effect the 2075 can be returned to local mode by any of the following:

- a. the LOCAL message
- b. the CLEAR LOCKOUT/SET LOCAL message
- c. setting the POWER switch to OFF and then back to ON
- d. removing the GPIB cable

**CLEAR LOCKOUT/SET LOCAL Message**

The controller sends the CLEAR LOCKOUT/SET LOCAL message by setting the REN line to FALSE. The 2075 responds to this command by returning to local mode, clearing the local lockout, and restoring control to the front panel keys. The transition from remote to local does not change any of the instrument control parameters.

**INTERFACE CLEAR Message**

The controller sends the IFC (UCG) message by setting the IFC (Interface Clear) bus control line to TRUE. Upon receipt of this command, the 2075 and all other devices on the bus stop talking or listening, and return to LOCAL.

**Table 4-2. GPIB Function Reference Table**

GPIB MESSAGE	RESPONSE	RELATED COMMANDS & CONTROLS	INTERFACE FUNCTIONS
Interface Clear	The Noise-Gain Analyzer stops talking or listening and returns to LOCAL.	IFC (UCG)	ALL
Device Clear	The Noise-Gain Analyzer is set to the same conditions established by pressing the PRESET key. Refer to Table 3-3.	DCL(ACG) SDC(UCG)	DC1
Clear Lockout/ Set Local	The Noise-Gain Analyzer returns to local (front panel control) and local lockout is cleared when the REN bus control line goes FALSE. When entering local mode, no instrument settings or functions are changed.	DISABLE REN (UCG)	RL1
Local	The Noise-Gain Analyzer returns to local mode (front panel control). It responds equally to the GTL bus command and the front panel LOCAL key. When entering the local mode, no instrument settings or functions are changed.	GTL(ACG)	PL1
Local Lockout	Disables the LOCAL key so that only the controller can return the Noise Gain Analyzer to local.	LLO(UCG)	RL1
Remote	The instrument is allowed to enter the Remote mode when the REN bus control line is TRUE. However, remote mode is not entered until the first time it is addressed to listen. The front panel REMOTE annunciator lights when the instrument is actually in the remote mode. When entering the remote mode, no instrument settings or functions are changed, but all front panel keys except LOCAL are disabled. All instrument control now comes from GPIB.		RL1 L4

\* Commands, Control Lines, and Interface Functions are defined in IEEE-488, 1978. Knowledge of these may not be necessary if your controller's manual describes programming in terms of the GPIB Messages shown in the left column, or a similar program command.

\* ACG = Addressed Command Group. UCG = Universal Command Group.

Table 4-2. GPIB Function Reference Table (Continued)

GPIB MESSAGE	RESPONSE	RELATED COMMANDS & CONTROLS	INTERFACE FUNCTIONS
Require Service	The Noise-Gain Analyzer sets the SRQ bus control line TRUE to request service for the controller based on certain conditions specified in Special Functions 41 through 45.	SRQ	SR1 T5
Serial POLL	The Noise-Gain Analyzer responds to a Serial Poll Enable (SPE) bus command by sending an 8 bit byte when addressed to talk. If the instrument is holding the SRQ control line TRUE (issuing Require Service message), bit 7 (RQS bit) in the Status Byte, and the bit representing the condition causing the Require Service message to be issued, will both be TRUE. The bits in the Status Byte are latched but can be cleared by:  1. Removing the causal condition, and 2. Reading the Status Byte.	SPE(ACG) SPD(ACG)	T5
Trigger	If in remote and addressed to listen, the Noise-Gain Analyzer makes one measurement according to the previously programmed setup. It responds equally to bus command GET and program code T2, Trigger Execute (a Data Message). Before using Trigger, the instrument should first be set to a Hold mode using program code T1.	GET(UCG)	DT1

\* Commands, Control Lines, and Interface Functions are defined in IEEE-488, 1978. Knowledge of these may not be necessary if your controller's manual describes programming in terms of the GPIB Messages shown in the left column, or a similar program command.

\* ACG = Addressed Command Group. UCG = Universal Command Group.

4-9. DEVICE MESSAGES

These are the messages or codes used to remotely program the 2075 to set up and then execute measurements. Some of these messages are parameter codes which are used to enter numeric values, such as start frequency, stop frequency, etc. to be used during the measurement. Others are mode commands which tell the 2075 to set some mode or special function which is to be used during the measurement. Still others are used to execute some function such as calibration or measurement.

These are all device dependent messages which are specific to the 2075. Each of these messages is a two character (two byte) code and the 2075 must be addressed to listen in order to receive these codes. The controller sends these messages to the 2075 when the bus is in the Data Mode (the ATN line is set to FALSE by the controller).

The device messages are listed in Tables 4-3 and 4-4.

Device Message Formats

Device messages are sent either as single messages (one at a time) or as multiple messages (a group of messages). The format for single messages is slightly different from that for multiple messages. A multiple message may have a separator between each single message in the group and uses a line terminator only at the end of the group. A single message has no separators but is also ended with a line terminator.

Single messages are formatted as follows:

	Header	Data	Data Terminator	Line Terminator
Example:	SS	150	MZ	[CR] [LF]

Note that the example above is a single message which requires a numeric data entry and therefore has a data terminator. For a single message which requires no numeric data entry, the format is as follows:

	Header	Line Terminator
Example:	DG	[CR] [LF]

Note that the line terminator for the message is Carriage Return/Line Feed.

A multiple message is formatted as follows:

	Header	Data	Data Terminator	Separator	Line Terminator
Example:	FA	10	MZ	,	
	FB	10	MZ	,	
	SS	10	MZ		[CR] [LF]

Note that the separator in the above example is a comma and that the line terminator is Carriage Return/Line Feed. A space could have been used for the separator instead of a comma. The terms are explained below.

The Header is the two character code that corresponds to a front panel key or special function. These are listed in Table 4-3 and 4-4. Some examples are SS (Step Size) and FA (Start Frequency).

Data is the numeric value representing the quantity associated with the header. Some headers do not require a data value.

The Data Terminator must follow every data entry. The data terminator usually defines the quantity which is represented by the numeric value. The allowable data terminators are MZ (Megahertz), DB (Decibels), DG (Temperature), and ET (the ENTER key). No other data terminator is acceptable.

The Separator is a convenience feature which makes a multiple message easier to read by separating its individual messages. The separator may be a comma or a space. If preferred, a separator need not be used at all. The following examples show three different ways of entering the same multiple message. The example message sets Start Frequency to 10 MHz, Stop Frequency to 100 MHz, Step Size to 10 MHz, Gain Upper Limit to 40 dB, and Gain Lower Limit to 0 dB.

Comma as separator  
FA 10MZ,FB 100MZ,SS 10MZ,UG 40DB,LG 0DB [CR] [LF]

Space as separator  
FA 10MZ FB 100MZ SS 10MZ UG 40DB LG 0DB [CR] [LF]

No separators  
FA 10MZFB 100MZSS 10MZUG 40DBLG 0DB [CR] [LF]

The Line Terminator is the delimiter used to indicate the end of a message. It is the Carriage Return/Line Feed sequence. Depending on how the controller is programmed, the Line Feed may be sent with the EOI line set TRUE or FALSE. Either method is acceptable to the 2075. In a computer where the program is written in some higher level language such as BASIC, the terminators are inserted automatically and will not appear in the program line.

Table 4-3. Table of GPIB Codes

GPIB CODE	PARAMETER
A0	Double Sideband
A1	Lower Single Sideband
A2	Upper Single Sideband
AF	Normal automatic frequency calibration
AQ	Display gain (only) vs. frequency on scope
B0	Use ENR TABLE 0 with nominal values
B1	Use ENR Table 1. User must enter
B2	Use ENR Table 2. User must enter
B3	Use ENR Table 3. User must enter
B4	Use ROM ENR Table. Special ROM required
C1	Use calibration setting #1
C2	Use calibration setting #2
C3	Use calibration setting #3
CA	Second Stage Calibration
CE	Display ENR in use
CO	Normal measurement
CT	Clear ENR table in ENR mode
D1	DUT Configuration 1
D2	DUT Configuration 2
D3	DUT Configuration 3
D4	DUT Configuration 4
D5	DUT Configuration 5
D6	DUT Configuration 6
D8	Terminator for dB unit entries
DD	Blank all displays during measurement
DE	Normal measurement
DF	Disable automatic frequency calibration
DG	Terminator for degree unit entries
EF or EN	Disable ENR entry mode
EN only	Enable ENR entry mode
ET	General entry terminator code

Table 4-3. Table of GPIB Codes (Continued)

GPIB CODE	PARAMETER
F0	Output window C data only
F1	Output window B data only
F2	Output window A data only
F3	Output window A & B data
F4	Output window A & C data
F5	Output window B & C data
F6	Output window A, B & C data
FA	START FREQ prefix
FB	STOP FREQ prefix
FC	Do a frequency calibration
FF	Front panel FIXED FREQ key
FG	X-out = NF/Y-out = gain (on strip chart)
FQ	Plot NF vs frequency on plotter
GD	Front panel Gain RATIO/dB key at dB setting
GF	Normal measurement (no time delay)
GQ	Plot gain vs frequency on plotter
GR	Front panel Gain RATIO/dB key at RATIO setting
GS	Time delay to ignite gas source (1 msec)
I0	IF Autorange
I1	IF attenuator setting 1
I2	IF attenuator setting 2
I3	IF attenuator setting 3
I4	IF attenuator setting 4
I5	IF attenuator setting 5
I6	IF attenuator setting 6
I7	IF attenuator setting 7
I8	IF attenuator setting 8
I9	IF attenuator setting 9
IA	IF attenuator setting 10
IC	Execute IF attenuator calibration
IF	IF FREQ prefix
L0	Normal measurement
L1	Enter loss before the DUT (dB)
L2	Enter temperature of the losses
L3	Enter the loss after the DUT (dB)
LC	Use loss compensation (use with SF 18)
LD	Noise drive indicator disable
LE	Noise drive indicator enable
LG	Lower gain limit
LL	Move plotter pen to lower left
LN	LOWER LIMIT (NOISE) prefix
LO	LO FREQ prefix

Table 4-3. Table of GPIB Codes (Continued)

GPIB CODE	PARAMETER	GPIB CODE	PARAMETER
MC	Prohibit NF/G measurements at non-calibrated points	S0	Smoothing factor = 1
MN	Use interpolation at non-calibrated points	S1	Smoothing factor = 2
MZ	Terminator for MHz unit entries	S2	Smoothing factor = 4
N0	Disable bandwidth compensation	S3	Smoothing factor = 8
N1	Bandwidth #1 prefix	S4	Smoothing factor = 16
N2	Bandwidth #2 prefix	S5	Smoothing factor = 32
N3	Enable bandwidth compensation	S6	Smoothing factor = 64
ND	Front panel NF RATIO/dB on dB setting	S7	Smoothing factor = 128
NE	Measure noise measure (M)	S8	Smoothing factor = 256
NF	Measure cascade noise figure	S9	Smoothing factor = 512
NG	Measure first stage noise figure and gain	SC	Temperature units in degrees Centigrade
NI	All SRQs disabled	SF	Temperature units in degrees Fahrenheit
NP	Normal oscilloscope (NF and Gain vs Freq)	SG	SWEEP SINGLE
NQ	Display NF (only) vs Freq on oscilloscope	SK	Temperature units in kelvins
NR	Front panel NF RATIO/dB in RATIO setting	SL	SECOND LO FREQ
NS	Loss compensation off	SN	SWEEP off
OP	Measure operating noise temperature	SP	SPECIAL FUNCTION
P1	Display test pattern #1 on oscilloscope	SR	SWEEP AUTO
P2	Display test pattern #2 on oscilloscope	SS	STEP SITE prefix
PM	Power measurement (NS off)	ST	Settling time
PN	Power measurement (NS on)	TO	Normal continuous measurement
R0	RF auto-range	TI	Hold measurement
R1	RF attenuator setting 1	T2	Execute one measurement cycle and hold
R2	RF attenuator setting 2	TC	$T_{cold}$ (K) prefix
R3	RF attenuator setting 3	TE	$T_e$ measurement mode
R4	RF attenuator setting 4	TG	$T_e + G$ measurement mode
R5	RF attenuator setting 5	TH	$T_{hot}$ (K) prefix
RA	SRQ on data ready	UG	UPPER LIMIT GAIN prefix
RC	SRQ on calibration complete	UN	UPPER LIMIT NOISE prefix
RF	1 MHz frequency resolution	UR	Move plotter pen to upper right
RI	SRQ on instrument error	V0	Normal measurement
RN	100 KHz frequency resolution	V1	Display E-off in window A; RF attenuator setting in window B; IF attenuator setting in window C
RT	SRQ on ready to tune	V2	Display E-on in window A; RF attenuator setting in window B; IF attenuator setting in window C
		YF	Y-factor for noise figure



Table 4-4. Front Panel Keys and Equivalent GPIB Codes

KEY #	NON-SHIFTED FUNCTION	GPIB CODE	SHIFTED FUNCTION	GPIB CODE
1	PRESET	DC or SDC*	N/A	
2	SPEC FUNC	N/A	N/A	
3	SHIFT	N/A	N/A	
4	LOCAL	N/A	EXT LO ADDRESS	
6	ENR	EN	T <sub>hot</sub> (K)	TH
	Toggle ENR OFF	EF	N/A	
7	ON/OFF Cycle	N/A	T <sub>cold</sub> (K)	TC
12	RATIO or dB (Gain)	GR/GD	N/A	
15	RATIO or dB (NF)	NR/ND	N/A	
16	CALIB	CA	SINGLE FREQ calibration	
19	Incr Smoothing	S0 thru S9		
20	Decr Smoothing	No direct equivalent		
22	F + G	NG	T <sub>e</sub> + G	TG
23	F	NF	T <sub>e</sub>	TE
	0	0	N/A	
	1	1	N/A	
	2	2	N/A	
	3	3	N/A	
	4	4	N/A	
	5	5	N/A	
	6	6	N/A	
	7	7	N/A	
	8	8	N/A	
	9	9	N/A	
	- (MINUS)	-	N/A	
	. (dec point)	.	N/A	
27	CLEAR Entry	N/A	CLEAR ENR table	CT
28	ENTER	ET,MZ,DB,DG	N/A	
29	SEQuence	N/A	SET SEQUENCE	N/A
30	STORE	N/A	N/A	
31	RECALL	N/A	N/A	
32	FIXED FREQ	FF	Manual STEP SIZE	N/A
33	Increment	N/A	EXT LO AMPLITUDE	N/A
34	Decrement	N/A	SECOND LO FREQ	SL
35	UPPER LIMIT NOISE	UN	UPPER LIMIT GAIN	UG
36	LOWER LIMIT NOISE	LN	LOWER LIMIT GAIN	LG
37	START FREQ	FA	IF FREQ	IF
38	STOP FREQ	FB	LO FREQ	LO
39	SWEEP AUTO	SR	SWEEP SINGLE	SG
39	Toggle SWEEP Off	SN	N/A	
40	STEP SIZE	SS	N/A	

\*DC = Device Clear. SDC = Selective Device Clear. Refer to the manual for the controller to see how to do this.

"Key #" is the number of the key on the front panel per Figure 3-1 and Table 3-1.

4-10. DATA MESSAGES

These messages consist of data which is the result of a measurement performed by the 2075. These messages are sent by the 2075 to the active listener on the bus. The 2075 can send data messages in Normal TALKER/LISTENER or TALK ONLY (TALK ALWAYS) mode.

A measurement message can consist of the data from Window A (the Frequency display), Window B (the Gain display), and Window C (the Noise Figure display). The user selects which data is to be output to the GPIB by setting Special Function 49. The possible choices are shown below:

Table 4-5. Selection of Data Message Contents


DATA OUTPUT TO GPIB	SPECIAL FUNCTION CODE	GPIB CODE
Output Window C data only	49.0	F0
Output Window B data only	49.1	F1
Output Window A data only	49.2	F2
Output Windows A and B data	49.3	F3
Output Windows A and C data	49.4	F4
Output Windows B and C data	49.5	F5
Output Windows A, B, and C data	49.6	F6

Outputting Data Messages in TALK ONLY Mode


The TALK ONLY (TALK ALWAYS) mode is used specifically to allow the 2075 to send its data to a GPIB compatible printer when there is no external controller and when there is no external local oscillator being controlled by the 2075. When in this mode, the 2075 can be configured to output data at the completion of each measurement cycle or to output data only during a Single Swept measurement. It can also be configured to send Second Stage Calibration data.

Use this procedure to output data at the end of each measurement cycle when in the TALK ONLY mode:

1. Select the data message content by entering the appropriate subordinate function of Special Function 49. For example, to select "Output of data from Windows A, B, and C", press:




2. Set the printer to LISTEN ONLY (LISTEN ALWAYS) mode.
3. Set the 2075 to TALK ONLY mode by pressing:




The 2075 will send measurement data out to the printer at the end of each measurement cycle until it is reset by entering Special Function 40.0. If the printer is not ready to receive the data, the 2075 will pause and wait until the data is received. Then it will go on to make its next measurement cycle.

If continuous output to the printer is not desired, the 2075 can be configured to output data only during a single sweep by performing the following procedure:

1. Select the data message content by entering the appropriate subordinate function of Special Function 49. For example, to select, "Output of data from Windows A and B", press:



2. Set the printer to LISTEN ONLY (LISTEN ALWAYS) mode.
3. Set the 2075 to TALK ONLY mode by pressing:



4. Initiate a single sweep by pressing:



The 2075 will output data to the printer only during the time period of the single sweep.

Note that if the Start and Stop frequencies are made the same, the instrument will output one set of data to the printer when a single sweep is initiated.

To configure the 2075 to send Second Stage Calibration data, use the following procedure:

1. Select the data message content by entering the appropriate subordinate function of Special Function 49. For example, to select, "Output of data from Windows A, B, and C", press:

2. Set the printer to LISTEN ONLY (LISTEN ALWAYS) mode.
3. Enable the HOLD function by pressing:

4. Set the 2075 to TALK ONLY mode by pressing:

5. To perform the calibration and output the data to the printer, press:

The 2075 will output data to the printer only during the calibration. Where Special Function 49.6 has been entered to choose data from Windows A, B, and C, the printer will print out the frequency, calibration step number, and the noise figure. An example of this output is shown in Figure 4-2.

Frequency	Calibration Step	Second Stage Noise Figure	
100	CAL1	4.93	CALIBRATION DATA
150	CAL1	5.38	
200	CAL1	5.33	
250	CAL1	5.43	
300	CAL1	5.67	
350	CAL1	5.84	
400	CAL1	5.74	
450	CAL1	5.81	
500	CAL1	6.07	
100	CAL2	8.82	
150	CAL2	10.20	
200	CAL2	9.89	
250	CAL2	9.72	
300	CAL2	10.27	
350	CAL2	10.93	
400	CAL2	10.41	
450	CAL2	11.49	
500	CAL2	11.83	
100	CAL3	22.75	
150	CAL3	24.03	
200	CAL3	23.74	
250	CAL3	23.64	
300	CAL3	23.96	
350	CAL3	25.39	
400	CAL3	24.40	
450	CAL3	25.67	
500	CAL3	25.77	

Frequency	Gain	Noise Figure	
100	-0.03	-0.06	MEASUREMENT DATA
150	-0.03	-0.01	
200	-0.04	-0.01	
250	-0.04	0.02	
300	-0.04	-0.03	
350	-0.02	-0.13	
400	-0.03	-0.06	
450	-0.05	0.07	
500	-0.03	0.01	

Figure 4-2. SAMPLE DATA OUTPUT


**Outputting Data Messages in Normal TALKER/LISTENER Mode**

The Normal TALKER/LISTENER mode is the GPIB operating mode in which the 2075 is controlled by an external controller or computer. In this mode, for data messages to be output to a listener device, the controller performs two steps:

1. The controller sends an ADDRESS TO LISTEN command to the device that will receive the data messages.
2. The controller sends an ADDRESS TO TALK command to the 2075. Then the data message transmission occurs as would any normal data exchange.

To configure the 2075 to send data messages while in this mode, use the following steps:

1. Set the 2075 to Normal TALKER/LISTENER mode by pressing:



This step is not necessary if the 2075 has just been powered-on because 40.0 is the default mode after power-on.

2. Send the necessary GPIB codes (device messages) to the 2075 to configure it for the desired measurement. Refer to paragraph 4-9 and Tables 4-3 and 4-4.
3. Send the appropriate GPIB code (F0 through F6) to select the desired format and contents of the data messages. Refer to Table 4-3.
4. Determine the correct program statement needed by the controller to receive data from the 2075.
5. After the data is received, unaddress the 2075. If this is not done, it will remain in the active talker state and repeatedly try to output data to the bus after each measurement cycle.

The following program example illustrates the correct procedure using an HP 85 controller programmed in BASIC. The 2075 address is 8 and it is tuned to 100 MHz. Special Function 40.0 is already in effect.

```
100 OUTPUT 708 ;"F0" (Send F0 for output
                       from Window C only)
110 ENTER 708 ; N    (Enter 708 - 1 message)
120 SEND 7 ; UNT     (Untalk)
```

The above 3 lines correspond to steps 3, 4, and 5 of the preceding procedure.

**Data Message Format**

Data messages are sent either as single messages (Special Functions 49.0, 49.1 or 49.2) or as multiple messages (Special Functions 49.3, 49.4, 49.5, or 49.6). The format for single messages is slightly different from that for multiple messages. A multiple message may have a separator between each single message in the group and uses a line terminator only at the end of the group. A single message has no separators but is also ended with a line terminator.

Single messages (GPIB codes F0, F1, or F2) are formatted as follows:

	Data	Line Terminator
Example:	5.65	[CR] [LF]

Note that the line terminator for the message is Carriage Return/Line Feed.

A multiple message (GPIB codes F3, F4, F5, or F6) is formatted as follows:

	Data	Separator	Data	Separator
Example:	10	,	45.23	,
	Data	Line Terminator		
	4.75	[CR] [LF]		

Note that the separator in the above example is a comma. The line terminator is Carriage Return/Line Feed. These are generated by the 2075. The terms are explained below.

Data is the numeric value in scaled decimal format with a fixed decimal point and no exponents. The units of measurement are implied by the current settings of the 2075. Frequency is always MHz, Gain or Noise Figure is dB or Ratio as previously selected, T<sub>e</sub> is kelvins, and Y-Factor is dB or Ratio.

The Line Terminator is the delimiter used to indicate

the end of a message. It is the Carriage Return/Line Feed sequence sent with the BOI line set TRUE.

The Separator is used to separate the individual data messages within the multiple message. Any ASCII character or string of characters can be selected to be the separator. This allows the normal comma (default) separator to be replaced to meet the requirements of any type of controller. If the data output is to a printer, for example, it would be convenient to define the separator as a string of spaces.

The program message ' ' (apostrophe/space/apostrophe) defines a space as the separator. The program message '##' would define two ##'s as the separator. It should be noted that some controllers accept only a comma as a data separator. Insure that any other separator which may be used is acceptable to the controller.

**Error Messages**

In situations where the measured data is invalid, the data message will contain an error message. The general form of the error message is XXXE10. The controller may change the form to X.XXE10. In some cases this type of message may be used as an end code.

Some examples of data messages which contain error messages are:

100,1.71+E10,5.55 The error message is Error 171 (Data not available for Gain)

350,1.70+E10,5.4 The error message is Error 170 (Measured data out of range)

Refer to Table 3-10 for a complete listing of error messages.

**4-11. STATUS MESSAGES**

Status messages are sent to the controller in the form of a Status Byte. The sequence of events is:

1. Some device on the bus initiates a Service Request by setting the SRQ (Service Request) line to TRUE.

2. The controller conducts a serial poll by having each device on the bus send a Status Byte. The controller reads each Status Byte to determine what device initiated the Service Request and why the device needs servicing.
3. The controller goes into a subroutine to service the device.

**Service Request Message**

When the 2075 requires service it sends the Service Request message to the controller by setting the SRQ line to TRUE. A special function determines what condition will cause the 2075 to request service from the controller. The table shown below lists the special function codes which determine what condition will cause the 2075 to request service. These special functions are mutually exclusive, that is, only one should be selected.

SPECIAL FUNCTION	GPIB CODES	CONDITION CAUSING SRQ
42.0	NI	All SRQ's are disabled
42.1	RA	SRQ on DATA READY
43.0	SRQ	Disable
43.1	RC	SRQ on CALIBRATION COMPLETE
45.0	SRQ	Disable
45.1	RT	SRQ on READY TO TUNE
46.0	SRQ	Disable
46.1	RI	SRQ on INSTRUMENT ERROR

The 2075 will not generate an SRQ unless one of these has been selected. To select one of these, send the appropriate GPIB code to the 2075. To disable, set the special function to its .0 value or send the equivalent GPIB code. It is recommended that the 2075 be placed in HOLD (GPIB code: T1) prior to enabling an SRQ

condition. This will prevent the 2075 from sending an SRQ before the controller is ready to handle it. After the SRQ condition has been enabled, send the GPIB code T0 to return the 2075 to continuous measurement cycle.

**Status Byte**

When the 2075 requires the attention of the controller it sets the SRQ line TRUE. The controller then conducts a serial poll and reads the Status Byte from each device on the bus. After reading all the Status Bytes, the controller knows what device set the SRQ line TRUE, and what condition in that device requires servicing.

The format of the Status Byte of the 2075 is shown:

The appropriate bits are set to 1 when the condition is TRUE.


After the status message (Status Byte) has been sent it will be cleared if the 2075 receives one of the following messages from the controller:

- SERIAL POLL DISABLE
- ABORT
- CLEAR

The flowchart of Figure 4-4 shows how data is collected using the Data Ready SRQ in Test Configuration 1.

Figure 4-5 is a sample program used for data collection in Test Configuration 1 with SRQ on Data Ready and an HP 85 as the system controller.

Figure 4-6 gives an example of measurement results obtained from running the program in Figure 4-5.



**Figure 4-3. STATUS BYTE**




Figure 4-4. FLOWCHART SHOWING DATA COLLECTION IN TEST CONFIGURATION 1 USING DATA READY SRQ



```
10 ! PROGRAM TO DEMO SRQ
20 ! ON DATA READY
30 ! TRIGGERED MEASUREMENT
40 !
50 !
60 ! NORMAL NOISE MEASUREMENT
70 ! FREQUENCY OF MEAS 500 MHZ
75 ! AND 600 MHZ
80 ! SMOOTHING = 32
90 ! DISPLAYS A AND C READ
100 ! PRINT DATA TO THERM PRT
110 !
120 ! FIRST STEP:
130 ! SET UP INTERRUPT
140 ! INITIALIZE OF HP 85
150 ON INTR 7 GOSUB 1000
160 ENABLE INTR 7;8
170 !
180 ! SECOND STEP:
190 ! CONFIGURE 2075 MEASUREMENT
200 !
210 ! TUNE TO 500 MHZ
220 OUTPUT 708 ;"FR 500 MZ"
230 !
240 ! SET SMOOTHING FACTOR
250 !
260 OUTPUT 708 ;"S5"
270 !
280 ! MEASURE NOISE FIGURE

290 OUTPUT 708 ;"NF"
300 !
310 ! SET DATA OUTPUT FORMAT
320 !
330 OUTPUT 708 ;"F4"
340 ! SEND TRIGGER CODE(HOLD)
350 !
360 OUTPUT 708 ;"T1"
370 !
380 !
390 ! WE ARE NOW READY TO MAKE
400 ! OUR MEASUREMENTS
410 !
420 ! STEP 3 SEND SRQ ON DATA RD
Y430 !
430 !
440 OUTPUT 708 ;"RA"
450 !
460 ! SEND TRIGGER MESSAGE
470 ! AND PROCESS OTHER ROUTINES
480 ! UNTILL SRQ CAUSES INTERRUPT
490 OUTPUT 708 ;"T0"
495 T=1
500 IF T<3 THEN GOTO 500
510 END
```

Figure 4-5. PROGRAMMING EXAMPLE FOR DATA COLLECTION IN TEST CONFIGURATION 1 USING SRQ ON DATA READY WITH HP85 CONTROLLER

```

520 |
530 |
540 |
900 | SRQ SERVICE ROUTINES
910 | IF SRQ THEN:
920 | WHO SENT SRQ ?
930 | WHY WAS SRQ SENT?
940 | PROCESS INFORMATION AS
950 | NECESSARY
960 |
970 |
980 | STEP 1: WHO SENT SRQ
990 | DO SERIAL POLL
1000 S=SPOLL(708)
1010 IF BIT(S,6)=1 THEN GOTO 200
      0
1020 | ELSE POLL OTHER DEVICES
1030 | ON BUSB
1040 GOTO 6050
2000 PRINT "2075 SENT SRQ"
2010 PRINT "TESTING CAUSE"
2020 IF BIT(S,1)=1 THEN GOTO 300
      0
2030 | TEST OTHER BITS FOR
2040 | OTHER POSSIBLE SRQ
2050 | CAUSES
3000 PRINT "2075 SENT DATA READY
      SRQ"
3010 PRINT "READING 2075 DATA"
3020 ENTER 708 ; F,N
3030 SEND 7 ; UNT
3032 | DISABLE DATA RDY SRQ
3034 OUTPUT 708 ; "NI"
3040 PRINT "DATA RECORD"
3050 PRINT "FREQ=",F
3060 PRINT "NOISE FIG=",N
3080 | INITIALIZE HP 85 STATUS
3090 STATUS 7,1 ; S1
4000 ENABLE INTR 7;8
4010 IF T=1 THEN GOTO 6000
5000 IF T=2 THEN GOTO 6030
6000 | TUNE TO NEXT FREQ AND
6010 | RE ENABLE SRQ ON DATA
6020 | READY
6030 T=T+1
6032 IF T=3 THEN GOTO 6050
6035 OUTPUT 708 ; "FR 600 MZ"
6040 IF T=2 THEN OUTPUT 708 ; "RA
      "
6050 RETURN

```

Figure 4-5. PROGRAMMING EXAMPLE FOR DATA COLLECTION IN TEST CONFIGURATION 1 USING SRQ ON DATA READY WITH HP85 CONTROLLER (Continued)

```


2075 SENT SRQ
TESTING CAUSE
2075 SENT DATA READY SRQ
READING 2075 DATA
DATA RECORD
FREQ=                500
NOISE FIG=           6.06
2075 SENT SRQ
TESTING CAUSE
2075 SENT DATA READY SRQ
READING 2075 DATA
DATA RECORD
FREQ=                600
NOISE FIG=           6.38
    
```

**Figure 4-6.** SAMPLE RESULTS FROM RUNNING PROGRAM IN FIGURE 4-5

**Synchronizing the Controller and the External Local Oscillator**

When an external controller is used to control the 2075 and the external local oscillator tuning, as may be done in Test Configurations 2, 4, and 6, it is necessary to synchronize the controller with the measurement cycle of the 2075. This synchronization is accomplished by the structure of the controller program, and varies according to the type of SRQ being used. Using Special Functions 42.0 through 46.0, the 2075 can be configured to initiate an SRQ on Data Ready, Calibration Complete, or Ready to Tune. The following information shows how the program must be structured to achieve synchronization when the 2075 is configured for SRQ on Ready to Tune. Following that, information is given to show the correct program structure when the 2075 is configured for SRQ on Data Ready.

Figure 4-7 shows a typical swept measurement setup for Test Configuration 2.



**Figure 4-7.** SETUP IN TEST CONFIGURATION 2

The following steps illustrate the general form of the controller program when the 2075 is configured to initiate an SRQ on Ready to Tune. (SRQ on Ready to Tune means that the 2075 will send a service request to the controller when the 2075 is ready to tune to the next frequency step of a sweep.) This form is also shown in the flowchart of Figure 4-8.

General form of the controller program for SRQ on Ready to Tune is:

1. Place the 2075 in HOLD mode (T1).
2. Send all parameters required to do the measurement to the 2075.
3. Send the required settling time (T settle) to the 2075. T settle should be equal to the local oscillator settling time (the time required for the LO to settle after tuning to a new frequency) plus any overhead time taken by the controller to set up the external local oscillator frequency. It is a good idea to include some extra time in T settle to allow some margin.
4. Send the code that configures the 2075 for SRQ on Ready to Tune (RT).

5. Send the single sweep command to the 2075.
6. If sweep is not completed, wait for the SRQ from the 2075.
7. Upon receiving the SRQ, read the Status Byte of the 2075. If Bit 4 of the Status Byte is set to 1, then send the command to tune the external local oscillator to the new frequency. (Any SRQ sets Bit 6 of the Status Byte and the Ready to Tune SRQ also sets Bit 4.)
8. Address the 2075 to Talk and then read the measurement data.
9. If sweep is completed then end. Otherwise, return to step 6.

The main point in the above steps is that after the Status Byte is read, the 2075 will wait for the amount of time determined by T settle, and then make the next measurement. The flowchart of Figure 4-8 illustrates the correct program structure.




Figure 4-8. FLOWCHART FOR SRQ ON READY TO TUNE




Figure 4-8. FLOWCHART FOR SRQ ON READY TO TUNE (Continued)

When the 2075 is configured to generate an SRQ on Data Ready, the form of the controller program must be different from the form used with SRQ on Ready to Tune. The following steps show how the program should be structured to achieve the correct synchronization of the controller and the 2075 when using SRQ on Data Ready. (SRQ on Data Ready means that the 2075 will send a service request to the controller when the data from the measurement just made is ready to be transmitted.) This example applies to Test Configurations 2, 4 or 6. An example of Test Configuration 2 is shown in Figure 4-7.

1. Place the 2075 in the HOLD mode (T1).
2. Send all parameters required to do the measurement to the 2075.
3. Send the required settling time (T settle) to the 2075. T settle should be equal to the local oscillator settling time (the time required for the LO to settle after tuning to a new frequency) plus any overhead time taken by the controller to set up the external local oscillator frequency. It is a good idea to include some extra time in T settle to allow some margin.
4. Send the code that configures the 2075 for SRQ on Data Ready (RA).
5. Send the code that tunes the external local oscillator to the sweep start frequency.
6. Send the single sweep command to the 2075.
7. Wait for the SRQ from the 2075.
8. Upon receiving the SRQ, read the Status Byte of the 2075. If Bit 1 of the Status Byte is set to 1, then proceed with the next step. (Any SRQ sets Bit 6 of the Status Byte and the Data Ready SRQ also sets Bit 1.)
9. Send the command to tune the external local oscillator to the next frequency.
10. Address the 2075 to talk and then read the measurement data. The data being read in this step is from the previous measurement that was executed before step 9 was done.
11. If sweep is completed then end. Otherwise, return to step 7.

The main point in the above is that the data from the previous measurement frequency is ready to be read when the 2075 sends the SRQ to the controller. If the controller program does not do step 8 before doing step 9, the controller and the 2075 will go into a race with each other.

The flowchart of Figure 4-9 illustrates the correct program structure to synchronize the controller and the 2075 when using SRQ on Data Ready.

The sample program of Figure 4-10 synchronizes the controller and the 2075 during calibration using the SRQ on Ready to Tune. It synchronizes the two instruments during measurement using the SRQ on Data Ready.




Figure 4-9. FLOWCHART FOR SRQ ON DATA READY






Figure 4-9. FLOWCHART FOR SRQ ON DATA READY (Continued)

```

10 DISP "THIS IS THE MEASUREMENT PROGRAM"
20 DISP "FOR A MICROWAVE AMPLIFIER USING"
30 DISP "THE SWEPT LO, DSB TECHNIQUE"
40 DISP @ DISP "SET THE 2075 BUS ADDRESS TO 8"
50 DISP @ DISP "SET THE 6600 BUS ADDRESS TO 19"
60 DISP @ DISP "PRESS K4, 'CONT' WHEN READY"
70 ON KEY# 4, "CONT" GOTO 100
80 KEY LABEL
90 GOTO 90
100 CLEAR @ BEEP
110 DISP "START FREQUENCY(MHZ)="
;
120 INPUT F1
130 DISP @ DISP "STOP FREQUENCY(MHZ)=";
140 INPUT F2
150 DISP @ DISP "STEP SIZE(MHZ)=";
;
160 INPUT F0
170 DISP @ DISP "IF (MHZ)=";
180 INPUT I
190 DISP @ DISP "LO POWER(DBM)="
;
200 INPUT P0
210 IF P0>10 THEN 270
220 DISP @ DISP "SMOOTHING INCREMENT=";
;
230 INPUT E
240 GOSUB 300
250 GOSUB 500
260 GOTO 570
270 CLEAR @ BEEP
280 DISP "MAX LO POWER IS +10DBM"
"
290 GOTO 190
300 S=SPOLL(708)
310 OUTPUT 708 ; "NI,T1,LE,NF,F5,
D2,A0,N0,P2,B1,RF,C1,NS,GF,D
F"
320 OUTPUT 708 ; "FA";F1;"MZ"
330 OUTPUT 708 ; "FB";F2;"MZ"
340 OUTPUT 708 ; "SS";F0;"MZ"
350 OUTPUT 708 ; "IF";I;"MZ"
360 OUTPUT 708 ; "ST50ET"
370 IF E=0 THEN E$="S0"
380 IF E=1 THEN E$="S1"
390 IF E=2 THEN E$="S2"
400 IF E=3 THEN E$="S3"
410 IF E=4 THEN E$="S4"
420 IF E=5 THEN E$="S5"
430 IF E=6 THEN E$="S6"
440 IF E=7 THEN E$="S7"
450 IF E=8 THEN E$="S8"
460 IF E=9 THEN E$="S9"
470 OUTPUT 708 ;E$
480 OUTPUT 708 ;"T0"
490 RETURN

```

This program uses Test Configuration 2 - Double Sideband. The Controller is on HP 85 and the External Local Oscillator is a Wiltron 6600 series sweep generator.

During Calibration, the Controller synchronizes the L.O. tuning and the 2075 using the READY TO TUNE SRQ interrupt (RA).

During measurement the Controller synchronizes the L.O. tuning and the 2075 using the DATA READY SRQ interrupt (RT).

User enters measurement parameters.

Depends on L.O. used

Clear 2075 Status Register (optional here)

Set up the 2075

Figure 4-10. SAMPLE PROGRAM

```

500 OUTPUT 719 ; "RF0,IL1,FM0,MK0"
510 F=F1
520 OUTPUT 719 ; "CF0"
530 OUTPUT 719 ; "F0";F;"MH"
540 OUTPUT 719 ; "LVL";P0;"OM"
550 OUTPUT 719 ; "RF1"
560 RETURN
570 F=F1 @ C=1
580 STATUS 7,1 ; S
590 ENABLE INTR 7;8
600 ON INTR 7 GOTO 720
610 CLEAR @ BEEP
620 DISP "CONNECT THE NOISE GENERATOR TO"
630 DISP "THE MIXER INPUT"
640 DISP @ DISP "PRESS k4, 'CONT' WHEN READY"
650 ON KEY# 4, "CONT" GOTO 680
660 KEY LABEL
670 GOTO 670
680 CLEAR @ DISP @ DISP @ DISP @ DISP
690 DISP "#2nd STAGE NOISE CAL IN PROGRESS"
700 OUTPUT 708 ; "RT,CA"
710 GOTO 710
720 S=SPOLL(708)
730 IF BIT(S,4)=0 THEN GOTO 820
740 OUTPUT 719 ; "CF0,F0";F;"MH"
750 F=F+F0
760 IF F=F2+F0 THEN C=C+1 @ F=F1
770 IF F>F2 THEN F=F2
780 IF C=4 THEN GOTO 880
790 STATUS 7,1 ; S
800 ENABLE INTR 7;8
810 GOTO 810
820 CLEAR @ BEEP
830 DISP "NO SRQ"
840 DISP "SOMETHING SCREWED UP"
850 DISP "CHECK CABLES, ADDRESS, ETC."
860 DISP @ DISP "PRESS k4, 'CONT' TO RESTART"
870 ON KEY# 4, "CONT" GOTO 10
880 CLEAR @ BEEP
890 DISP "#2nd STAGE CAL COMPLETE"
900 WAIT 1000
910 OUTPUT 708 ; "NI"
920 S=SPOLL(708)
930 F=F1
940 OUTPUT 719 ; "CF0,F0";F;"MH"
950 DISP @ DISP "CONNECT THE OUT BETWEEN THE"
960 DISP "NOISE GENERATOR AND THE MIXER"
970 DISP @ DISP "PRESS k4, 'CONT' WHEN READY"
980 ON KEY# 4, "CONT" GOTO 1010
990 KEY LABEL
1000 GOTO 1000
1010 PRINT @ PRINT @ CLEAR
1020 PRINT " ** AMPLIFIER TEST DATA **"

```

Set up the L.O.

Clear HP 85 Status Register

Enable READY TO TUNE SRQ and begin Calibration

READY TO TUNE SRQ sets bit 4 of the status register

"C" is a pointer which keeps track of which RF attenuator state is being calibrated. (Alternately, could enable (RC) which sends SRQ interrupt when Calibration is complete. Sets bit 2 of the status register)

Error routine

Disable SRQ's

Clear 2075 status register (optional here)

Prepare for measurement

Figure 4-10. SAMPLE PROGRAM (Continued)

```

1030 PRINT @ PRINT "FREQ
      GAIN      NOISE FIG"
1040 PRINT "(Mhz)          (dB)
      (dB)"
1050 F=F1
1060 OUTPUT 719 ; "CF0.F0":F;"MH"
1070 STATUS 7,1 ; S
1080 ON INTR 7 GOTO 1120
1090 ENABLE INTR 7;8
1100 OUTPUT 708 ; "T1,RA,SG"
1110 GOTO 1110
1120 S=SPOLL(708)
1130 IF BIT(S,1)=0 THEN GOTO 820
1140 F=F+F0
1150 IF F>F2 THEN F=F2
1160 OUTPUT 719 ; "CF0.F0":F;"MH"
1170 WAIT 50
1180 ENTER 708 ; X,Y,Z
1190 SEND 7 ; UNT
1200 IMAGE 50,7X,M20.20,9X,20.20
1210 PRINT USING 1200 ; X,Y,Z
1220 IF F=F2+F0 OR X=F2 THEN GOT
      O 1260
1230 STATUS 7,1 ; S
1240 ENABLE INTR 7;8
1250 GOTO 1250
1260 OUTPUT 708 ; "NI,NG,T0"
1270 PRINT @ PRINT @ PRINT @ PRI
      NT @ PRINT @ PRINT
1280 OFF KEY# 4
1290 CLEAR @ BEEP
1300 DISP "TEST COMPLETE"
1310 DISP "PRESS THE APPROPRIATE
      KEY BELOW"
1320 DISP "FOR NEXT ACTION"
1330 DISP
1340 DISP "k1";TAB(10);"REPEAT T
      EST"
1350 DISP "k2";TAB(10);"RECAL 2n
      D STAGE"
1360 DISP "k3";TAB(10);"NEW TEST
      "
1370 DISP "k4";TAB(10);"END TEST
      ING"
1380 ON KEY# 1,"REPEAT" GOTO 1440
1390 ON KEY# 2,"RE-CAL" GOTO 1470
1400 ON KEY# 3,"NEW" GOTO 1500
1410 ON KEY# 4,"END" GOTO 1530
1420 KEY LABEL
1430 GOTO 1430
1440 OFF KEY# 1 @ OFF KEY# 2 @ 0
      FF KEY# 3 @ OFF KEY# 4
1450 CLEAR @ BEEP
1460 GOTO 950
1470 OFF KEY# 1 @ OFF KEY# 2 @ 0
      FF KEY# 3 @ OFF KEY# 4
1480 CLEAR @ BEEP
1490 GOTO 570
1500 OFF KEY# 1 @ OFF KEY# 2 @ 0
      FF KEY# 3 @ OFF KEY# 4
1510 CLEAR @ BEEP
1520 GOTO 100
1530 END

```

Clear Controller Status Register

Enable DATA READY SRQ. Single Sweep allowed in measurement hold mode. Data Ready sets bit 1 of 2075 Status Register

Update L.O. frequency before reading data from 2075. 2075 will not make another measurement until data has been read.

Tell 2075 to stop sending status register.

Figure 4-10. SAMPLE PROGRAM (Continued)

## SECTION 5

## PERFORMANCE VERIFICATION TESTS

## 5-1. INTRODUCTION

This section of the manual contains Performance Verification Tests which are used to verify that the 2075 is functioning in accordance with the specification requirements listed in Section 1. These procedures are normally performed upon receipt of the instrument, after repair or adjustment, or when the performance of the 2075 is suspect. These procedures should also be performed every six months to verify the continued optimum performance of the 2075.

and model number is shown where appropriate. Minimum or critical parameters are also shown. Generally, it is desirable to use equipment with an accuracy four times greater than the parameter being tested. However, for the most part, these tests are internal checks performed by the 2075 and, therefore, accuracy of other test equipment is not important except for the Digital Voltmeter.

Test equipment warm-up is not critical for the first tests in this group. However, the 2075 should be warmed-up for at least 10 minutes before performing the Final Detector Linearity Test.

## 5-2. TEST EQUIPMENT REQUIRED

The test equipment required for conducting the performance verification tests is listed in Table 5-1. For each item listed, the recommended manufacturer

Table 5-1. Test Equipment Requirements for Performance Verification Testing

INSTRUMENT	MINIMUM PARAMETERS	RECOMMENDED MODEL
Digital Voltmeter	5½ digits	Fluke 8840A
Dual Channel Oscilloscope	Z-Axis blanking on positive-going TTL input	Tektronix 2213A
Calibrated Noise Source		EATON 7618E or 7626
Test Cables with BNC Connectors		

**5-3. PERFORMANCE VERIFICATION PROCEDURES**

The Performance Verification Procedures are listed in Table 5-2. It is recommended that they be performed in the sequence listed. Access to the interior of the 2075 is not required for performance of these procedures. All tests are to be done at room temperature.

**Table 5-2.** Performance Verification Tests

PROCEDURE	PARAMETER OR FUNCTION VERIFIED
Power-on Test	Self-Test Functions
Noise Drive Voltage Test	Noise Drive Voltage Level
IF Attenuators Calibration	Calibration of IF Attenuators
Final Detector Bias Test	Bias Voltage Level
Second Stage Calibration	Noise Figure versus Calibration Steps
Final Detector Linearity Test	Detector Linearity

**5-4. POWER-ON TEST**

This is a series of internal self-checks performed by the 2075 upon power-up. The unit checks the operation of its Math Processor, RAM, ROM, GPIB Controller, and its DMAC (Direct Memory Access Controller). Finally, the 2075 performs an FCAL (Frequency Calibration) to ensure the accuracy of its frequency tuning. No test equipment is required for this procedure.

Perform the following steps:

- I. Connect the 2075 to an AC power source of the appropriate voltage.

2. Remove any devices connected to the RF INPUT.
3. Place the POWER switch in the ON position.
4. The following correct indications should be observed:
  - a. All front panel red LED's and indicators light briefly.
  - b. The words SELF and TEST appear in Windows A and B respectively, while the numbers 1 through 6 appear sequentially in Window C.

**NOTE**

Window A is the rectangular display on the left which is labeled FREQUENCY MHz. Window B is the display in the middle and is labeled GAIN. Window C is the one on the right labeled NOISE FIGURE.


- c. The message FCAL appears for several seconds in Window B.
- d. A frequency value is displayed in Window A and some numeric value will flash in Window C.
5. Press the **PRESET** key. The message FCAL will appear momentarily in Window B and then the frequency value in Window A may change.
6. After these steps have been completed, if no error messages have appeared, the 2075 has successfully completed the Power-up Test.

**5-5. NOISE DRIVE VOLTAGE TEST**

This procedure measures the DC voltage at the NOISE DRIVE output connector on the front panel of the 2075. This voltage should be +28.00 volts plus or minus .050 volts.

A 5½ digit, digital voltmeter is required.

1. Set the POWER switch to the ON position.
2. Remove any devices connected to the RF INPUT.
3. Press:



This special function causes the 2075 to apply the noise drive voltage to the BNC connector. The green NOISE DRIVE LED will light.


4. Connect the DVM leads to the NOISE DRIVE connector and take the voltage reading.
5. The voltage should be + 28.00 volts DC  $\pm$  .050 volts.
6. Press the ON/OFF key.
7. Verify that the green NOISE DRIVE LED is off and that the voltage at the NOISE DRIVE connector is less than + 1.0 volt DC.
8. This concludes the Noise Drive Voltage Test.

**5-6. IF ATTENUATORS CALIBRATION**

In this procedure the 2075 measures the changes in gain caused by adding different levels of internal IF attenuation and then stores those attenuator values.

No test equipment is required for this procedure.

1. Place the POWER switch in the ON position.
2. Remove any devices connected to the RF INPUT.
3. Press:



4. The word CAL0 appears in Window B and the letters IF appear in Window C.
5. The words CAL1, CAL2, CAL3 and CAL4 will appear sequentially in Window B while the unit

continues to calibrate its IF stages.


6. When a frequency value appears in Window A, and some numeric value begins flashing in Window C, this calibration procedure is successfully completed.

**5-7. FINAL DETECTOR BIAS TEST**

This procedure measures the bias voltage on the final detector.


No test equipment is required for this procedure.

1. Place the POWER switch in the ON position.
2. Press:



This causes the 2075 to place 55 dB of attenuation in its RF stage.


3. The value 55 dB should appear in Window B, and 0 dB should appear in Window C.
4. Press:




This causes the 2075 to place 45 dB of attenuation in its IF stages.

5. The value 45 dB will appear in Window C.
6. The value of the detector bias voltage is displayed in Window A. This voltage must be between .016 and .024 volts (16 to 24 millivolts). If the least significant digits of the display are changing too rapidly to read, add smoothing by pressing the **RIGHT ARROW** key several times.
7. The test is complete at this point but the 2075 must be taken out of the test mode by completing the following steps.

8. Press:



9. Press:



10. Press the **F** key.

11. This concludes the Detector Bias Test procedure.

**5-8. SECOND STAGE CALIBRATION**


In the first part of this procedure frequencies and corresponding noise source ENR values are entered into an ENR table of the 2075 by the operator. Then the 2075 measures its own second stage noise figure at different frequencies and gain levels, and stores these values.

A calibrated noise source is required for this procedure.

Perform the following steps:

1. Select the noise source which will be used to make the measurements.
2. Apply AC power to the 2075.
3. Allow several seconds for the 2075 to complete its automatic power-up self tests. These are completed when the message FCAL has appeared in, and then disappeared from, Window B.
4. Press the **PRESET** key. Wait until the new FCAL message disappears from Window B, signifying that the frequency calibration is completed. Preset restores the control parameters to a set of known values.

5. Press:



This calls up, or activates, Table 1. The data about to be entered will be stored in Table 1 (5.2 would have called up Table 2 and 5.3 would have called up Table 3). The error message 104 may appear indicating that no data is currently stored. If so, it may be disregarded.

6. Press:




This places the 2075 in the mode which allows entry of the frequencies and ENR values. The red light in the center of the ENR key is illuminated. Also, the ENTER annunciator in Window A begins to blink signifying that the operator is required to enter a frequency.

7. Enter the first calibration frequency, in MHz, from the noise source calibration data sheet (for example, 10 MHz) by pressing:




The frequency just entered appears in Window A. The ENTER annunciator in Window B begins to blink signifying that the operator is required to enter the ENR value, in dB, for the frequency just entered.

8. Read the ENR value for the frequency just entered from the noise source calibration data sheet, or the inscribed label on the calibrated noise source. Enter this value by pressing:



The value just entered appears in Window B. This completes the entries for the first frequency. The ENTER annunciator in Window A begins to blink, indicating that the next frequency should be entered.


9. Enter the next frequency, in MHz, from the noise source calibration data sheet by pressing:



The frequency just entered appears in Window A. The ENTER annunciator in Window B begins to blink, signifying that the ENR value for that frequency should now be entered. ENR values are always entered in decibels.



10. Enter the ENR value by pressing:



The value just entered appears in Window B. Now the ENTER annunciator in Window A will start to blink again, indicating that the next frequency should be entered.

11. Continue to enter paired frequency and ENR values for all data points shown on the noise source calibration data sheet.
12. After all the entries have been made, use the **DOWN ARROW** and **UP ARROW** keys to examine the entries for correctness. Step down through the table by pressing or holding the **DOWN ARROW** key. Step up through the table by pressing or holding the **UP ARROW** key.

To clear an erroneous entry, first display it using the up or down arrow keys and then press the **CLEAR** key. Both the frequency and the ENR value will be cleared. Then enter the correct value. The **ENTER** key can be used to toggle the ENTER annunciator back and forth between Window A and Window B. See paragraph 3-31 for more information.

To clear the entire table, press:



13. Press:



This takes the 2075 out of the ENR table entry and display mode. The red light in the center of the **ENR** key will go out. This completes the entry of ENR data. Continue with the following steps to perform the Second Stage Calibration.

14. Connect the noise source to the RF INPUT connector and the NOISE DRIVE connector. Press:



15. The 2075 will now display an FCAL, CAL0, CAL1, CAL2, and CAL3 as it performs these steps of the calibration process.
16. During the CAL1, while the unit takes 20 MHz steps, verify that the noise figure displayed in Window C is less than  $7.0 \text{ dB} \pm .001 \text{ dB/MHz}$  from 10 MHz to 1850 MHz. The noise figure at 1850 MHz should be less than 8.85 dB. As the 2075 steps up to 1900 MHz, the noise figure may go above 8.85 dB.
17. During the CAL2, while the 2075 takes 20 MHz steps across the frequency band, verify that the noise figure displayed in Window C is less than 13.0 dB from 10 MHz to 1850 MHz.
18. During the CAL3, while the unit takes frequency steps across the band, verify that the noise figure displayed in Window C is less than 28.0 dB from 10 MHz to 1850 MHz.
19. After the 2075 has completed the CAL3, it will return to the start frequency and display values for corrected noise figure and gain. Since nothing has been inserted between the calibrated noise source and the RF INPUT, these values should be 0, with slight random variations.

This concludes the Second Stage Calibration Procedure.

### 5-9. FINAL DETECTOR LINEARITY TEST

This procedure measures the linearity of the final detector by adding different levels of IF attenuation. For each level, the 2075 measures its own noise figure and the output voltage of the final detector.

A calibrated noise source is required for this test.

The 2075 must be warmed-up for at least 10 minutes before performing this test.

1. Place the POWER switch in the ON position.
2. Connect the calibrated noise source to the RF INPUT.

3. Tune the 2075 to 30 MHz by pressing:




Window A will display 30 MHz.

4. Press the **F** key. This puts the 2075 into the uncorrected noise figure mode.

5. Press the **RIGHT ARROW** key four or five times to add smoothing and slow the random changes of the noise figure value now displayed in Window C.

6. Record the noise figure value displayed in Window C. This value should be less than 6 dB.

7. Press:



8. The value now displayed in Window A is the output voltage of the final detector. Verify that this value is less than 4.98 volts. Window B displays a 0 indicating that no attenuation is being applied to the RF stage. Window C displays some value which is the amount of attenuation being applied to the IF stages, usually 5 or 10 dB.

8a. Press the **ON/OFF** key.

The green NOISE DRIVE light will go out.


8b. Verify that the voltage now displayed in Window A is greater than .20 volts.

8c. Note the value of IF attenuation displayed in Window C. Use the following table to determine which special function will be required to enable the next higher value of IF attenuation.

SPECIAL FUNCTION	IF ATTENUATION
38.0	Auto-ranging
38.1	0 dB
38.2	5 dB
38.3	10 dB
38.4	15 dB
38.5	20 dB
39.0	Auto-ranging
39.1	25 dB
39.2	30 dB
39.3	35 dB
39.4	40 dB
39.5	45 dB

8d. If the value displayed in Window C is 5, then enter Special Function 38.3 to enable the 10 dB IF attenuator.

9. Press:



This will place 10 dB of IF attenuation in the line. Window C displays a 10.

10. Verify that the detector voltage displayed in Window A is less than 4.98 volts.

11. Press the **ON/OFF** key.

The green NOISE DRIVE light will go out.


12. Verify that the voltage now displayed in Window A is greater than .20 volts.

13. Press the **F** key.

This returns the 2075 to the Noise Figure measurement mode. The green NOISE DRIVE light will begin to blink.

14. Record the noise figure value displayed in Window C. This value should be virtually equal to the value recorded in Step 6.

15. Press:



This places 15 dB of IF attenuation in line. Window C will display 15 dB.

16. Verify that the detector output voltage, displayed in Window A, is less than 4.98 volts.

17. Press the **ON/OFF** key.

This turns off the noise drive voltage and causes the green light to go out.

18. Verify that the detector output voltage displayed in Window A is greater than .20 volts.


19. Press the **F** key.

This returns the 2075 to the noise figure measurement mode.

20. Record the noise figure value displayed in Window C.

This value should be virtually the same as those recorded in Steps 6 and 14.

21. Press:



This will place 20 dB of IF attenuation in the line. Window C will display 20 dB.

22. Verify that the detector output voltage displayed in Window A is less than 4.98 volts.

23. Press the **ON/OFF** key.


This turns off the noise drive voltage.

24. Verify that the detector output voltage displayed in Window A is greater than .20 volts.

25. Press the **F** key.

26. Record the noise figure value displayed in Window C. This value should be virtually equal to the values recorded in Steps 6, 14, and 20.

27. Press:



This returns the 2075 to its attenuation auto-ranging mode.

This concludes the Final Detector Linearity Test.

## 5-10. SCOPE/PLOTTER OUTPUT TEST

This test verifies the proper functioning of the X, Y, and Z outputs which are used to drive an external oscilloscope or plotter.

This procedure requires either a dual channel oscilloscope with an X-Y mode or an X-Y plotter.

1. Locate the BNC connectors marked X, Y, and Z on the rear panel of the 2075. Install test cables between these and the X, Y, and Z inputs of the oscilloscope.
2. Locate the INT (INTENSITY) adjustment on the rear panel on the Eaton 2075. Rotate it fully clockwise.
3. Place the 2075 POWER switch in the ON position. Upon power-up the 2075 will automatically output a test pattern.
4. Adjust the amplitude controls on the oscilloscope so that the test pattern fills the display. It may be necessary to adjust the INT control on the rear of the 2075 to obtain a visible pattern.

### NOTE

For this test to work properly, the oscilloscope must reduce its intensity with a positive-going TTL signal applied to its Z input.

5. Adjust the INT potentiometer on the 2075 to dim half the test pattern.
6. The displayed test pattern should look like the one shown in Figure 5-1.

Difference in intensity is obtained by adjusting the 2075 rear panel INTENSITY control.





Figure 5-1. OUTPUT TEST PATTERN 2


7. Disconnect the test cable from the Z input of the oscilloscope.

8. Press:



9. A dot will appear in the lower left corner of the oscilloscope display. This is the first alignment point used for aligning an X-Y plotter.

10. Press:



11. A dot will now appear in the upper right corner. This is the second alignment point used for aligning an X-Y plotter.

This concludes the oscilloscope/plotter output test.

This concludes the performance verification tests.