


KENWOOD TH-25AT

EXPANDED RF

1. Disconnect the power and antenna.
2. Remove the volume, squelch and tuning control knobs
3. Remove the nuts from the volume control and tuning controls.
4. Remove screw located by the PTT switch.
5. Remove screw by the speaker jack
6. Remove two screws from the battery plate.
7. Carefully pull the front panel from the radio. Do not break any wires.
8. Gently lift the top panel from the radio by pulling it forward and then upwards. The O ring on the BNC connector will cause some tension.
9. Rotate the top panel towards the front of the radio to expose the .75" X .75" board.
10. Remove chip resistors R19, R20 & R21.
11. Reassemble the radio.
12. RESET the CPU. Hold down [M] and turn power on.



Caution

These modifications have not been tested. The Author, Publisher and all other parties takes NO responsibility or liability for any damage or violation resulting from these modifications. Performing any modification may be a Violation of FCC Rules and will void the warranty of the radio. Use of any modified radio may be a violation of FCC rules. If you have any doubts, DO NOT PERFORM THIS MODIFICATION.

© 1991 artsci inc. all rights reserved. (818) 843-4080 Fax: (818) 846-2298