


# KENWOOD TH-26A

## EXPANDED RF

1. Disconnect the power and antenna.
2. Remove 3 screws from the case and 2 from the battery plate.
3. Open the radio.
4. Remove jumper JP1. Use a soldering iron the remove the jumper. Do not pull the jumper or overheat the board.
5. Unsolder and remove chip resistor R56.
6. Reassemble the radio. Carefully re-seat the O-Ring on the BNC connector.
7. Reset the microprocessor. (Press and hold the [F] key and turn the power on.)

Note: Automatic offset selection will be disabled when this mod is performed.



Caution

These modifications have not been tested. The Author, Publisher and all other parties takes NO responsibility or liability for any damage or violation resulting from these modifications. Performing any modification may be a Violation of FCC Rules and will void the warranty of the radio. Use of any modified radio may be a violation of FCC rules. If you have any doubts, DO NOT PERFORM THIS MODIFICATION.

© 1991 artsci inc. all rights reserved. (818) 843-4080 Fax: (818) 846-2298