


KENWOOD TH-27A

EXPANDED RF

1. Disconnect the Power and antenna.
2. Remove 4 screws from the back panel.
3. Open the bottom of the front panel first and slide the panel downward.
4. Open the radio being careful not to break the flex cable.
5. Move the tone board out of the way to expose the green jumper wire located inside the front panel assembly.
6. Cut the GREEN Jumper wire.
7. Remove chip resistor R337. (Disables AM receive & auto offset)
8. Reassemble the radio. Carefully re-seat the O-Ring on the BNC connector.
9. Reset the Microprocessor. (Press and hold the [M] key and turn the power on.)



Caution

These modifications have not been tested. The Author, Publisher and all other parties takes NO responsibility or liability for any damage or violation resulting from these modifications. Performing any modification may be a Violation of FCC Rules and will void the warranty of the radio. Use of any modified radio may be a violation of FCC rules. If you have any doubts, DO NOT PERFORM THIS MODIFICATION.

© 1991 artsci inc. all rights reserved. (818) 843-4080 Fax: (818) 846-2298