


KENWOOD TH-75A

EXPANDED RF

1. Disconnect the battery and antenna.
2. Remove the three case screws and two battery plate screws.
3. Lift front panel from radio. Do not disconnect flex cables.
4. Cut the GREEN JUMPER WIRE, located on left side of the CPU.
5. Remove the diode. (see drawing)
6. Reassemble the radio.
7. RESET the CPU. Press and hold the M Key while turning on the radio.



Caution

These modifications have not been tested. The Author, Publisher and all other parties takes NO responsibility or liability for any damage or violation resulting from these modifications. Performing any modification may be a Violation of FCC Rules and will void the warranty of the radio. Use of any modified radio may be a violation of FCC rules. If you have any doubts, DO NOT PERFORM THIS MODIFICATION.

© 1991 artsci inc. all rights reserved. (818) 843-4080 Fax: (818) 846-2298