


KENWOOD TM-221

EXPANDED RF M/C

1. Disconnect the power and antenna.
2. Remove the top and bottom covers.
3. Locate the control unit (X53-3040-XX). It is the board closest to the front.
4. Remove R25 and Place it in the position of R24.
5. Reassemble the radio.
6. RESET the CPU. (Press and hold [VFO/M] & [M.IN] and turn power on)



TX Range 142 MHz - 154 MHz



Caution

These modifications have not been tested. The Author, Publisher and all other parties takes NO responsibility or liability for any damage or violation resulting from these modifications. Performing any modification may be a Violation of FCC Rules and will void the warranty of the radio. Use of any modified radio may be a violation of FCC rules. If you have any doubts, DO NOT PERFORM THIS MODIFICATION.

© 1991 artsci inc. all rights reserved. (818) 843-4080 Fax: (818) 846-2298