


# KENWOOD TS-711

## EXPANDED RF

1. Disconnect the power and antenna.
2. Remove the covers.
4. REMOVE D30
5. Reassemble the radio.
6. RESET the CPU.



Caution

These modifications have not been tested. The Author, Publisher and all other parties takes NO responsibility or liability for any damage or violation resulting from these modifications. Performing any modification may be a Violation of FCC Rules and will void the warranty of the radio. Use of any modified radio may be a violation of FCC rules. If you have any doubts, DO NOT PERFORM THIS MODIFICATION.

© 1991 artsci inc. all rights reserved. (818) 843-4080 Fax: (818) 846-2298