


YAESU FT-ONE

EXPANDED RF

1. Unplug the power from the radio.
2. Open radio and locate the CONTROL UNIT.
3. Locate and **install a Jumper between Point A and point B.** No Jumper to point C.
4. **Remove any jumper to point D.** (Transmit range point)
5. Reassemble radio.



RX Range 150 kHz - 30 MHz
TX Range 1.8 MHz - 30 MHz