


KENWOOD TW-4100

REPEATER MOD

1. Remove power and antenna.
2. Remove 4 screws securing the top cover.
3. Remove 10 screws securing the bottom cover.
4. Solder a wire jumper connecting the two RP Pins. (see drawing)
5. Reassemble the radio.



CROSS BAND REPEATER PROCEDURES

The VFO and a Memory channel (except 8 & 9) must be used. Select the proper frequencies, offsets & tone. (VFO simplex operation must use DUP with a 0 offset.)

TURN ON - Enter frequencies in a memory and VFO and press [Shift].

Turn power off. Press and hold [REV] and turn radio on.

TURN OFF - Turn Power off.



Caution

These modifications have not been tested. The Author, Publisher and all other parties takes NO responsibility or liability for any damage or violation resulting from these modifications. Performing any modification may be a Violation of FCC Rules and will void the warranty of the radio. Use of any modified radio may be a violation of FCC rules. If you have any doubts, DO NOT PERFORM THIS MODIFICATION.

© 1991 artsci inc. all rights reserved. (818) 843-4080 Fax: (818) 846-2298