


- 1/ Remove the NDT2955 MosFET from the board.
- 2/ Bridge the pads with wire that were originally connected to the MosFET Gate & Drain connections.
- 3/ This mod will allow the switching of Linear Amplifiers that require a grounded input to switch to TX mode.



## EME166 MOD FOR LINEAR AMPLIFIER SWITCHING

COPYRIGHT 2013

DRAWN	MINI-KITS
DATE	31-5-2013
PROJECT	TRANSVERTER SEQUENCER
FILE	EME166 P-CH Mosfet.SKF