



NOTE: AT TRANSMIT CONDITION ALL VOLTAGE MEASUREMENTS SHOULD BE TAKEN AT THE POWER SUPPLY IN ORDER TO AVOID THE EFFECTS OF VOLTAGE SWING. EXCESS OF VOLTAGE SHOULD BE CORRECTED BY ADJUSTING THE POTENTIOMETER SHOULD BE CORRECTED AND ALL WIRE SHOULD BE ADJUSTED TO THE CORRECT POSITION.