



**• KENWOOD TH-D7(A) (E) PROGRAMMING CABLE •**  
**~ PG-4W ~**

< Cable End to Computer <

> Cable End to TH-D7 >



**DB9 Connector**  
**[Signal From Computer]**



**2.5 mm Stereo Plug**  
**[Signal From Radio]**

by:  
 YO3HJV