



MC<sup>2</sup> Audio

E45 Power Output Stage PCB710 (main), PCB715, 716 & 717. Channel A shown.  
Channel B has same circuit but main PCB references start with 2. (Eg. R241)

10th Feb 2004 (Updated June 06 - Phase change)

Drwng. No.

SCH\_E45 Iss2

Sheet 3 of 4