

A1 - A7 PIN SELECTOR

L1 Power

B1 - B7

C1 - C7

D1 - D7

E1 - E7

F1 - F7

G1 - G7

H1 - H7

J2 - J7

K3, K4, K7

FIL 1 & FIL 2

G16 120V

F16 80V

E16 60V

D16 50V

C16 40V

B16 30V

A16 20V

A11 10V

L11 Connector

B11 9V

C11 8V

D11 7V

E11 6V

F11 5V

G11 4V

H11 3V

J11 2V

K11 1V

K9 Connector

J9 .9V

H9 .8V

G9 .7V

F9 .6V

E9 .5V

D9 .4V

C9 .3V

B9 .2V

A9 .1V