



050-1627-00

M45176, M54400

S1150 (TIME/CM SWITCH) REPLACEMENT

For TEKTRONIX® 465 Oscilloscopes

Serial Numbers B250000 - Up

Cam Actuator Switch assembly, pn 263-1086-02, replaces Cam Actuator Switch assembly (S1150), pn 263-1086-01, which is no longer available.

The new switch is a direct replacement for the old switch, but not identical, in that the lockout mechanism has been eliminated.

NOTE

For replacement of S1150 in instruments with serial numbers below B250000, use pn 105-0366-00.

Copyright © 1982
Tektronix, Inc.
All Rights Reserved

28-MAY-1987
Supersedes: 22-MAR-1983

page 1

KIT PARTS LIST:

Ckt. Number	Quantity	Part Number	Description
S1150	1 ea	263-1086-02	Switch, cam actuator assy. TIME/CM
	1 ea	-----	Label, 050-kit

INSTRUCTIONS:

NOTE

These instructions are not provided to facilitate replacement of the TIME/CM switch (S1150), only to inform the user that the lockout mechanism has been removed. Refer to the Manual Modification Insert provided with this kit.

WARNING

To avoid electric shock hazard, disconnect the instrument from all other electrical equipment and the power source before proceeding.

The following instructions are for use by qualified service personnel only. To avoid personal injury, do not perform any of the following procedure unless you are qualified to do so.

- () 1. Remove the cabinet.

CAUTION

When removing the TIME/CM switch, use special care. The switch contacts beneath the cam drum are quite delicate.

- () 2. Replace S1150 with the switch assembly provided in the kit.
- () 3. Verify correct instrument performance.
- () 4. Install the cabinet.

- () 5. Remove the protective backing from the 050-kit label, included in the kit, and place the label on a flat surface of the rear panel to indicate this kit has been installed.
- () 6. For future reference, attach the following modification insert in the Service Manual.

RH:rh