

JP-8 SERVICE NOTES

Second Edition
December, 1982

This Notes makes First Edition obsolete and consists of two parts:

Part 1 Previous First Edition pp.1-31

Part 2 Mainly applicable to JP-8 units with Serial Numbers

171700 and above pp.32-46

Parts List Change p.47

Appendix pp.48-50


BEFORE READING

PLEASE CHECK FOR CHANGE INFORMATION
AND CONTENTS AT PAGES 32 AND 33
OF THIS NOTES.

SPECIFICATIONS

Keyboard: 61 Note, 5 Octaves
VCO
VCO-2 Fine Tune Range: ± 50 Cents
VCF
Slope: 12/Octave, 24/Octave
Key Follow: 0 - 120%
ENV
ENV-1, 2
Attack Time: 1ms - 5s
Decay Time: 1ms - 10s
Sustain Level: 0 - 100%
Release Time: 1ms - 10s
LFO
Rate: 0.05 - 40Hz
Delay Time: 0 - 4s
Master Tunable Range: $\pm 50\%$

Arpeggio
Rate: 1 - 20Hz
Audio Outputs
Upper: 0dBm, 600 Ohm, Balanced
0dBm/-20dBm, 1k Ohm, Unbalanced
0dBm, 600 Ohm, Balanced
0dBm/-20dBm, 1k Ohm, Unbalanced
Lower:
Highest Note Output
CV: 0 - 5V
Gate: Off - 0V, On - +15V
Dimensions: 1063(W) x 485(D) x 120(H)mm
Weight: 22kg
Power Consumption: 90W



2Wi x II (13149103) 115V
2Wi II (13149104) 220V

SSB-022-12RN (13159118)

Slide switch SSB-023-12RN (13159117)

CANON connector socket
HA16R-3P (13439851)

Jack
SG-7716 (13449123)

Slide switch
SSB-042-12PN (13159116)

Jack
SG-7630 (13449107)

Heatsink H22
(048H022)


DIN connector
TCS 0250-1-1 (13429608)

JP-8 PANEL PARTS LIST

1	Pot.	GM70R-K20B54 (50KB x 2) (13219812)
2	Pot.	GM70R-K20AC54 (50KA, C) (13219811)
3	Pot.	LFE9R-C16A55 (500KA) (13339414)
4	Switch	SRM1034-K15 (13119301)
5	Switch	SLE622-18PS (13139137)
6	Pot.	VM10R-K20B14 (10KB) (13219225)
7	Pot.	LFE9R-C16B14 (10KB) (13339415)
8	Switch	SOPR-24-12P (13159503)
9	Pot.	LFE9R-C16B54 (50KB) (13339413)
10	Pot.	MFE9R-C16B54 (50KB x 2) (13359302)
11	Pot.	VM10R-K20A55 (500KA) (13219231)
12	Pot.	VM10R-K20C54 (50KC) (13219243)
13	Switch	SLE623-18P (13139135)
14	Switch w/key top	KEH10003 (13129717) See Parts List for Key top and Switch
15	Bender assy	PB-4 (029-022)
16	Cover LED	H80 (065H080) LN526RA (15029404)
17	Switch	KHC11901 (13169601)
	Buttons	
	No.1, 38	RED (016H018)
	No.2-5, No.34-37	ORANGE (016H012)
	No.6-9, No.30-33	YELLOW (016H017)
	No.10-13, No.21-28	WHITE (016H010)
	No.14, 15, 29	GREEN (016H014)
	No.16-18, No.39-41	BLUE (016H013)
	No.19, 20	DARK BLUE (016H011)
18	Pot.	VM10A-K15B54 (50KB CT) (13229131)
19	Switch	SLE-622-18P (13139136)
	All rotary knobs	No.68 (016-078)
	All slider knobs	H4 (016H004)


DISASSEMBLY

Remove screws ①, ② and ③.





NOTE:

Preparation of a stay and a prop is recommended for a stable top panel rest.



PRECAUTIONS

1. Do not pinch flat cables in the pcbs when closing panel assemblies. Prongs on PCBs will pierce humped cable, causing circuits to malfunction. Stretch rolling cable out.
2. Do not expose your workbench directly to fans, heaters, air-conditioners, etc. especially after disassembling, PCBs are temperature-sensitive.



MOD A B
MOD C D

1	B M 1
2	OUT B
3	GND
4	OUT A

1	B M 1 2
2	OUT A
3	GND
4	OUT B
5	GND
6	OUT C
7	GND
8	OUT D

1	B M 2
2	OUT D
3	GND
4	OUT C

1	B M 2
2	OUT D
3	GND
4	OUT C

MOD CON
U L

BENDER

TUNE CONT

EXT JACK

1	A N
2	COMPUTUNE
3	VCO1 BEND
4	VCO2 BEND
5	VCOB LFO U
6	VCF MOD U
7	LFO U
8	LFO L
9	PORTA VR
10	PORTA U
11	PORTA L
12	GND
13	GND
14	GND

1	A T
2	TUNE VR ①
3	" " ②
4	GND

1	A J 1
2	GND
3	DIN SW RET
4	ARP CLK DIN
5	VCF PEDAL
6	EXP PEDAL
7	PORTA SW
8	HOLD

1	A J 2
2	GND
3	MEM.PROTECT
4	LOAD
5	DUMP
6	EXT CV
7	EXT GATE
8	DIN CLK IN
9	DIN START/STOP

1	A B
2	N.C.
3	ARP CLK EXT
4	" " RET
5	" " INT
6	MONO
7	STEREO
8	ARP RATE VR 1
9	" " 2

1	A L 1
2	TUNE
3	VCO1 BEND
4	VCO2 BEND
5	VCOB LFO
6	VCF PEDAL
7	VCF MOD
8	EXP PEDAL
9	LFO L SEMD
10	LFO U
11	GND

1	A L 2
2	TUNE
3	VCO1 BEND
4	VCO2 BEND
5	VCOB LFO
6	VCF PEDAL
7	VCF MOD
8	EXP PEDAL
9	LFO L SEMD
10	LFO U
11	GND

EXT JACK

1	B J 1
2	GND
3	BAL OUT Lt.
4	" " L-
5	GND
6	BAL OUT Ut.
7	" " U-
8	GND
9	PHONES

PANEL B

1	B J 2
2	GND
3	U OUT
4	L OUT
5	GND
6	MIX OUT

1	A C 1
2	VCO1 RANGE-1
3	" " -φ
4	" " PWM-φ
5	" " MOD-φ
6	" " -1
7	LFO WAVE-φ
8	" " -1
9	N.C.

1	A D 1
2	ENV 2 R
3	POLARITY
4	ENV 1 R
5	VCA LFO MOD-1
6	" " -φ
7	LFO WAVE-φ
8	ENV 1/2
9	SLOPE
10	N.C.

PANEL A

1	A C 2
2	SOURCE MIX
3	VCO2 FINE
4	" " RANGE
5	VCO MOD CROSS
6	" " PWM
7	" " ENV
8	" " LFO
9	LFO DELAY T
10	VR. SUP
11	GND
12	GND

1	A D 2
2	ENV 2 R
3	" " S
4	" " D
5	" " A
6	ENV 1 R
7	" " S
8	" " D
9	" " A

1	A E 1
2	SW DATA -5
3	" " -4
4	" " -3
5	" " -2
6	" " -1
7	" " φ
8	LED DATA -5
9	" " -4
10	" " -3
11	" " -2
12	" " -1
13	" " φ

1	A F 1
2	NUM DATA -7
3	" " -6
4	" " -5
5	" " -4
6	" " -3
7	" " -2
8	" " -1
9	" " φ

1	A G 1
2	+5V
3	FSK LED
4	SW DATA -5
5	" " -4
6	" " -3
7	" " -2
8	" " -1
9	" " φ
10	LED DATA -5
11	" " -4
12	" " -3
13	" " -2
14	" " -1
15	" " φ

1	A I
2	FUNC SW
3	DIGITAL IN 1
4	DIGITAL IN 2
5	DIGITAL IN 3
6	DOT LED
7	NUM LED
8	MATRIX
9	ANALOG SEL
10	GND
11	GND
12	VR DATA
13	VR DATA
14	GND
15	GND
16	GND
17	φ 2
18	φ 3
19	φ 4
20	φ 5
21	φ 6
22	φ 7
23	GND
24	COMPUTUNE
25	PORTA VR
26	PORTA F.SW
27	PORTA L
28	PORTA L
29	SPLIT
30	HOLD
31	ARP CONT.
32	ARP CLK
33	EXT GATE
34	GND
35	EXT CV
36	GND
37	DUMP
38	LOAD
39	GND
40	MEM.PROTECT

MODE F
MOD G H

1	B M 3
2	OUT F
3	GND
4	OUT E
5	GND

1	B M 3 4
2	OUT E
3	GND
4	OUT F
5	GND
6	OUT G
7	GND
8	OUT H
9	GND

1	B M 4
2	OUT H
3	GND
4	OUT G
5	GND

1	A C 3
2	VCO2 WAVE-1
3	" " -φ
4	VCO2 LF/NORM
5	SYNCHRO
6	VCO1 WAVE-1
7	" " -φ

1	A D 3
2	VCA LEVEL
3	VCF KEY FOLLOW
4	LFO
5	ENV
6	RESO
7	CUTOFF
8	HPF
9	VR.SUP
10	GND
11	GND
12	GND

1	A E 2
2	MATRIX BUS-φ
3	" " -1
4	" " -2
5	" " -3
6	" " -4
7	N.C.

1	A F 2
2	NUM BUS -7
3	" " -6
4	" " -5
5	" " -4
6	" " -3
7	" " -2
8	" " -1
9	" " φ

1	A G 2
2	MATRIX BUS-4
3	" " -5
4	" " -6
5	" " -7

PANEL C

PANEL D

PANEL E

PANEL F

PANEL G

INTERFACE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

HM2	
1	VCO C-1
2	" C-2
3	GND
4	VCO D-1
5	" D-2
6	GND

HM1	
1	VCO A-1
2	" A-2
3	GND
4	VCO B-1
5	" B-2
6	GND

LM1	
1	-13V
2	-13V
3	GND
4	GND
5	+13V
6	+13V
7	-5V
8	-5V
9	NOISE
10	+10V
11	+10V
12	VCO1 MOD
13	VCO2 WF-Φ
14	VCO1 MOD SW
15	VCO2 WF-1
16	VCO2 MOD
17	SYNCHRO
18	VCO2 MOD SW
19	VCO1 WF-Φ
20	VCO LFO MOD
21	VCO1 WF-1
22	VCO ENV MOD
23	VCO1 LEVEL
24	CROSS MOD
25	VCO2 LEVEL
26	LFO
27	VCF KEY FOLLOW
28	PWM SEL
29	RESONANCE
30	PW/PWM
31	H PF
32	PWM LEVEL
33	ENV2 R FOLLOW
34	ENV 2 A
35	VCO1 RANGE
36	ENV 2 D
37	ENV 1/2
38	ENV 2 R
39	LEVEL
40	ENV 2 S
41	VCF 24dB
42	ENV1 K FOLLOW
43	VCF 12dB
44	ENV 1 A
45	VCF ENV MOD
46	ENV 1 D
47	VCF CUTOFF
48	ENV 1 R
49	ENV1 POLA
50	ENV 1 S

H L	
1	T. GATE L
2	T. GATE U
3	GND
4	GND
5	DB 4
6	DB 5
7	DB 6
8	DB 7
9	GND
10	GND
11	A5
12	A4
13	A3
14	A2
15	A1
16	AΦ
17	GND
18	WR
19	RAM CS L
20	RAM CS U

MOD. CD

LM1

MOD. AB

MOD. CON. UPPER

IM2	
1	KCV C-1
2	GND
3	KCV C-2
4	GND
5	KCV D-1
6	GND
7	KCV D-2
8	GND
9	GATE C
10	GATE D

IM1	
1	KCV A-1
2	GND
3	KCV A-2
4	GND
5	KCV B-1
6	GND
7	KCV B-2
8	GND
9	GATE A
10	GATE B

IM	
1	KCV A-1
2	GND
3	KCV A-2
4	GND
5	KCV B-1
6	GND
7	KCV B-2
8	GND
9	GATE A
10	GATE B
11	KCV C-1
12	GND
13	KCV C-2
14	GND
15	KCV D-1
16	GND
17	KCV D-2
18	GND
19	GATE C
20	GATE D
21	KCV E-1
22	GND
23	KCV E-2
24	GND
25	KCV F-1
26	GND
27	KCV F-2
28	GND
29	GATE E
30	GATE F
31	KCV G-1
32	GND
33	KCV G-2
34	GND
35	KCV H-1
36	GND
37	KCV H-2
38	GND
39	GATE G
40	GATE H

IM4	
1	KCV G-1
2	GND
3	KCV G-2
4	GND
5	KCV H-1
6	GND
7	KCV H-2
8	GND
9	GATE G
10	GATE H

IM3	
1	KCV E-1
2	GND
3	KCV E-2
4	GND
5	KCV F-1
6	GND
7	KCV F-2
8	GND
9	GATE E
10	GATE F

LM2	
1	-13V
2	-13V
3	GND
4	GND
5	+13V
6	+13V
7	-5V
8	-5V
9	NOISE
10	+10V
11	+10V
12	VCO1 MOD
13	VCO2 WF-Φ
14	VCO1 MOD SW
15	VCO2 WF-1
16	VCO2 MOD
17	SYNCHRO
18	VCO2 MOD SW
19	VCO1 WF-Φ
20	VCO LFO MOD
21	VCO1 WF-1
22	VCO ENV MOD
23	VCO1 LEVEL
24	CROSS MOD
25	VCO2 LEVEL
26	LFO
27	VCF KEY FOLLOW
28	PWM SEL
29	RESONANCE
30	PW/PWM
31	H PF
32	PWM LEVEL
33	ENV2 R FOLLOW
34	ENV 2 A
35	VCO1 RANGE
36	ENV 2 D
37	ENV 1/2
38	ENV 2 R
39	LEVEL
40	ENV 2 S
41	VCF 24dB
42	ENV1 K FOLLOW
43	VCF 12dB
44	ENV 1 A
45	VCF ENV MOD
46	ENV 1 D
47	VCF CUTOFF
48	ENV 1 R
49	ENV1 POLA
50	ENV 1 S

MOD. GH

LM2

MOD. EF

MOD. CON. LOWER

HM4	
1	VCO G-1
2	" G-2
3	GND
4	VCO H-1
5	" H-2
6	GND

HM3	
1	VCO E-1
2	" E-2
3	GND
4	VCO F-1
5	" F-2
6	GND

H L	
1	T. GATE L
2	T. GATE U
3	GND
4	GND
5	DB 4
6	DB 5
7	DB 6
8	DB 7
9	GND
10	GND
11	A5
12	A4
13	A3
14	A2
15	A1
16	AΦ
17	GND
18	WR
19	RAM CS L
20	RAM CS U

INTERFACE

IK1	
1	K BUS Φ
2	" 1
3	" 2
4	" 3
5	" 4
6	" 5
7	" 6
8	" 7

IK2	
1	K READ Φ
2	" 1
3	" 2
4	" 3
5	" 4
6	" 5
7	" 6
8	" 7

KEYBOARD

1 2 3 4 5 6 7 8 9 10 11 12 13

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

HM12	
1	VCO A-1
2	" A-2
3	GND
4	VCO B-1
5	" B-2
6	GND
7	VCO C-1
8	" C-2
9	GND
10	VCO D-1
11	" D-2
12	GND

H		I	
1	Φ	2	GND
3	RΦ	4	I/O REQ
5	WR	6	RFSH
7	MREQ	8	RESET
9	M1	10	NMI
11	BUSREQ	12	BUSAK
13	GND	14	GND
15	Φ	16	Φ 1
17	Φ 2	18	Φ 3
19	Φ 4	20	Φ 5
21	Φ 6	22	Φ 7
23	GND	24	GND
25	A Φ	26	A 1
27	A 2	28	A 3
29	A 4	30	A 5
31	A 6	32	A 7
33	A 8	34	A 9
35	A 10	36	A 11
37	A 12	38	A 13
39	A 14	40	A 15
41	MEM. PROTECT	42	TAPE OUT
43	TAPE READ	44	FSK LED
45	N.C.	46	N.C.
47	T. GATE L	48	T. GATE U
49	+5 V	50	+5 V


CPU BOARD

HM34	
1	VCO E-1
2	" E-2
3	GND
4	VCO F-1
5	" F-2
6	GND
7	VCO G-1
8	" G-2
9	GND
10	VCO H-1
11	" H-2
12	GND

WIRING DATA TABLE

CONNECTOR	PINS	PCB		
		from	to	
AB	8	PANEL A	PANEL B	
AC1	9	"	PANEL C	
AC2	12	"	"	
AC3	6	"	"	
AD1	8	"	PANEL D	
AD2	8	"	"	
AD3	10	"	"	
AE1	12	"	PANEL E	
AE2	6	"	"	
AF1	8	"	PANEL F	
AF2	5	"	"	
AG1	14	"	PANEL G	
AG2	4	"	"	
AI	40J	"	INTERFACE	
AJ1	10	"	EXT JACK	
AJ2	9	"	"	
AL1	10	"	MOD CON U	
AL2	10	"	MOD CON L	
AN	14	"	BENDER	
AP	6	"	POWER	
BJ1	8	PANEL B	EXT JACK	
BJ2	6	"	"	
BM12	8 [4	PANEL B	MODULE AB	
BM2	4		"	CD
BM34	8 [4	PANEL B	"	
BM3	4		"	EF
BM4	4	"	GH	
BP	6	PANEL B	PANEL A	
HI	50J	CPU	INTERFACE	
HL	20J	"	MOD CON	
HM12	12 [6	CPU	MODULE AB	
HM1	6		"	CD
HM2	6	"	"	
HM34	12 [6	CPU	"	
HM3	6		"	EF
HM4	6	"	GH	
HP	8	CPU	POWER	
IK1	8	INTERFACE	KEYBOARD	
IK2	8	"	"	
IM	40J [10J	INTERFACE	MODULE AB	
IM1			"	CD
IM2			"	EF
IM3			"	GH
IM4	10J	"	"	
IP	8	INTERFACE	POWER	
LM1	50J	MOD CON U	MODULE ABCD	
LM2	50J	" L	MODULE EFGH	
LP1	8	" U	POWER	
LP2	8	" L	"	
MP1	6	MODULE AB	MOD CON U	
MP2	6	" CD	"	
MP3	6	" EF	MOD CON L	
MP4	6	" GH	"	
NP	6	BENDER	PANEL A	
AT	4	PANEL A	TUNE VR	

JP-8 FUNCTIONAL DIAGRAM




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T


SAVE
LOAD

POWER SUPPLY BOARD A,B,C

22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 4




MODULE BOARD BLOCK DIAGRAM



D BLOCK DIAGRAM


DESTINATION MODULE BOARD.




PANEL BOARD BLOCK DIAGRAM

OCT.10, 1981


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26



CPU BOARD BLOCK DIAGRAM



MOD-CON BOARD BLOCK DIAGRAM
ALL ARROWS HAVING NO DESTINATION IDENTIFIER CONNECT TO MODULE BOARD.




INTERFACE BOARD BLOCK DIAGRAM

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

IC33: FACTORY ADJ. ONLY

CPU BOARD




- IC14 CPU 8780C-1 (280A 4MHZ)
- IC21 GMOS RAM CHIP SELECT
- IC22 ROM ADDRESS DECODER
- IC34-36 ROM ADDRESS DECODER
- IC11 CLK GEN
- IC26 INT CONT
- IC25 WAIT CONT
- IC10 FSK DEMODULATOR
- IC41 RESET

Highest Ref Pcs are R32, C50, D3
 TR6, IC 41, RA3, L1, F1, VR1, X1


IC9: 24, 37, IC11: 7474 IC25: 26,
 IC27: 7400 IC50: 4574
 IC10: LS14 IC17: 7407






IC1: LS86 IC31: 32,
 IC8: 39, 4251
 IC21: 2253, LS307
 IC16: LS174 IC39: 4251
 IC2: LS244 IC15: LS245
 IC40: 8253



CPU BOARD OPH121(149H121)(pcb 052H267)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S



-  R25J
-  25C1815-GR Ⓢ
- LC-2S
-  SR19R
-  .52473
-  RMB-103K


Refer to Page 38 for:
 CPU CHANGE INFORMATION
 CAUTIONS ON MODULE CONTROLLER BOARD REPLACEMENT
 RAM (MOD CON BOARD) REPLACEMENT
 CPU BOARD WILL BE AFFECTED BY THESE REPLACEMENTS

MODULE CONTROLLER


OPH123(149H123) (pcb 052H269)



SN 090600-192099

REFER TO PAGES
49-50 for SN up to 090599
36-37 for SN 202100-up
37-38 for PCB or RAM REPLACEMENT




- selected on current leakage
white dot
- R50J
- 1/4w carbon R25
- 1/4w metal film CRB25FX
- polyester ERS-C33 G561
- 1S2473
- zener diode
- 5R19R
- ET-6P
- 25A1015-GR
- 25C1815-GR
- 25C945 selected for Noise
- 25K30A-GR
- 25K117-GR
- 25B605
- 25D571
- BA662
- Resistor array
- BA662A selected on offset
- bi-polar
- test point LC-2-5






- IC 7A, 1B, 5, 9A, 9B, 1A, 21, 30, 33, 37, 40 : 4558
 IC 2, 10 : 4559
 IC 3A, 3B, 4A, 4B, 11A, 11B, 12A, 12B, 35A, 35B, 38A, 38B : TL080
 IC 6A, 6B, 13A, 13B, 2A : TL082
 IC 7, 1A : 40E2
 IC 8A, 8B, 15A, 15B, 18A, 18B, 20A, 20B, 22A, 22B, 25A, 29B, 26A, 26B, 28A, 28B, 31A, 31B, 32A, 32B, 34A, 34B : BA662
 IC 16, 17, 23 : 4053
 IC 24 : TR2109
 IC 27A, 27B : TL558 or LM458PDD
 IC 35A, 35B, 37A, 37B : TR301
- All PNP TR : 2SA1015-GR
 TR 3A, 4A, 9A, 9B, 11A, 11B : 2SC732-Y
 Outp. NPN TR : 2C1815-GR
 TR 2A, 28A, 8A, 8B : 2SK35A-GR
 Other PNP : 1534-13
 All Diode

MODULE BOARD CIRCUIT DIAGRAM
MODULE BOARD





















There are two different GND lines. * is not connected to # on this PCB.
Highest Ref. Dns are IC36C, TR268, D399, C60, R223, VR233, VR238, VR239, VR240, VR241, VR242, VR243, VR244, VR245, VR246, VR247, VR248, VR249, VR250, VR251, VR252, VR253, VR254, VR255, VR256, VR257, VR258, VR259, VR260, VR261, VR262, VR263, VR264, VR265, VR266, VR267, VR268, VR269, VR270, VR271, VR272, VR273, VR274, VR275, VR276, VR277, VR278, VR279, VR280, VR281, VR282, VR283, VR284, VR285, VR286, VR287, VR288, VR289, VR290, VR291, VR292, VR293, VR294, VR295, VR296, VR297, VR298, VR299, VR300, VR301, VR302, VR303, VR304, VR305, VR306, VR307, VR308, VR309, VR310, VR311, VR312, VR313, VR314, VR315, VR316, VR317, VR318, VR319, VR320, VR321, VR322, VR323, VR324, VR325, VR326, VR327, VR328, VR329, VR330, VR331, VR332, VR333, VR334, VR335, VR336, VR337, VR338, VR339, VR340, VR341, VR342, VR343, VR344, VR345, VR346, VR347, VR348, VR349, VR350, VR351, VR352, VR353, VR354, VR355, VR356, VR357, VR358, VR359, VR360, VR361, VR362, VR363, VR364, VR365, VR366, VR367, VR368, VR369, VR370, VR371, VR372, VR373, VR374, VR375, VR376, VR377, VR378, VR379, VR380, VR381, VR382, VR383, VR384, VR385, VR386, VR387, VR388, VR389, VR390, VR391, VR392, VR393, VR394, VR395, VR396, VR397, VR398, VR399, VR400, VR401, VR402, VR403, VR404, VR405, VR406, VR407, VR408, VR409, VR410, VR411, VR412, VR413, VR414, VR415, VR416, VR417, VR418, VR419, VR420, VR421, VR422, VR423, VR424, VR425, VR426, VR427, VR428, VR429, VR430, VR431, VR432, VR433, VR434, VR435, VR436, VR437, VR438, VR439, VR440, VR441, VR442, VR443, VR444, VR445, VR446, VR447, VR448, VR449, VR450, VR451, VR452, VR453, VR454, VR455, VR456, VR457, VR458, VR459, VR460, VR461, VR462, VR463, VR464, VR465, VR466, VR467, VR468, VR469, VR470, VR471, VR472, VR473, VR474, VR475, VR476, VR477, VR478, VR479, VR480, VR481, VR482, VR483, VR484, VR485, VR486, VR487, VR488, VR489, VR490, VR491, VR492, VR493, VR494, VR495, VR496, VR497, VR498, VR499, VR500, VR501, VR502, VR503, VR504, VR505, VR506, VR507, VR508, VR509, VR510, VR511, VR512, VR513, VR514, VR515, VR516, VR517, VR518, VR519, VR520, VR521, VR522, VR523, VR524, VR525, VR526, VR527, VR528, VR529, VR530, VR531, VR532, VR533, VR534, VR535, VR536, VR537, VR538, VR539, VR540, VR541, VR542, VR543, VR544, VR545, VR546, VR547, VR548, VR549, VR550, VR551, VR552, VR553, VR554, VR555, VR556, VR557, VR558, VR559, VR560, VR561, VR562, VR563, VR564, VR565, VR566, VR567, VR568, VR569, VR570, VR571, VR572, VR573, VR574, VR575, VR576, VR577, VR578, VR579, VR580, VR581, VR582, VR583, VR584, VR585, VR586, VR587, VR588, VR589, VR590, VR591, VR592, VR593, VR594, VR595, VR596, VR597, VR598, VR599, VR600, VR601, VR602, VR603, VR604, VR605, VR606, VR607, VR608, VR609, VR610, VR611, VR612, VR613, VR614, VR615, VR616, VR617, VR618, VR619, VR620, VR621, VR622, VR623, VR624, VR625, VR626, VR627, VR628, VR629, VR630, VR631, VR632, VR633, VR634, VR635, VR636, VR637, VR638, VR639, VR640, VR641, VR642, VR643, VR644, VR645, VR646, VR647, VR648, VR649, VR650, VR651, VR652, VR653, VR654, VR655, VR656, VR657, VR658, VR659, VR660, VR661, VR662, VR663, VR664, VR665, VR666, VR667, VR668, VR669, VR670, VR671, VR672, VR673, VR674, VR675, VR676, VR677, VR678, VR679, VR680, VR681, VR682, VR683, VR684, VR685, VR686, VR687, VR688, VR689, VR690, VR691, VR692, VR693, VR694, VR695, VR696, VR697, VR698, VR699, VR700, VR701, VR702, VR703, VR704, VR705, VR706, VR707, VR708, VR709, VR710, VR711, VR712, VR713, VR714, VR715, VR716, VR717, VR718, VR719, VR720, VR721, VR722, VR723, VR724, VR725, VR726, VR727, VR728, VR729, VR730, VR731, VR732, VR733, VR734, VR735, VR736, VR737, VR738, VR739, VR740, VR741, VR742, VR743, VR744, VR745, VR746, VR747, VR748, VR749, VR750, VR751, VR752, VR753, VR754, VR755, VR756, VR757, VR758, VR759, VR760, VR761, VR762, VR763, VR764, VR765, VR766, VR767, VR768, VR769, VR770, VR771, VR772, VR773, VR774, VR775, VR776, VR777, VR778, VR779, VR780, VR781, VR782, VR783, VR784, VR785, VR786, VR787, VR788, VR789, VR790, VR791, VR792, VR793, VR794, VR795, VR796, VR797, VR798, VR799, VR800, VR801, VR802, VR803, VR804, VR805, VR806, VR807, VR808, VR809, VR810, VR811, VR812, VR813, VR814, VR815, VR816, VR817, VR818, VR819, VR820, VR821, VR822, VR823, VR824, VR825, VR826, VR827, VR828, VR829, VR830, VR831, VR832, VR833, VR834, VR835, VR836, VR837, VR838, VR839, VR840, VR841, VR842, VR843, VR844, VR845, VR846, VR847, VR848, VR849, VR850, VR851, VR852, VR853, VR854, VR855, VR856, VR857, VR858, VR859, VR860, VR861, VR862, VR863, VR864, VR865, VR866, VR867, VR868, VR869, VR870, VR871, VR872, VR873, VR874, VR875, VR876, VR877, VR878, VR879, VR880, VR881, VR882, VR883, VR884, VR885, VR886, VR887, VR888, VR889, VR890, VR891, VR892, VR893, VR894, VR895, VR896, VR897, VR898, VR899, VR900, VR901, VR902, VR903, VR904, VR905, VR906, VR907, VR908, VR909, VR910, VR911, VR912, VR913, VR914, VR915, VR916, VR917, VR918, VR919, VR920, VR921, VR922, VR923, VR924, VR925, VR926, VR927, VR928, VR929, VR930, VR931, VR932, VR933, VR934, VR935, VR936, VR937, VR938, VR939, VR940, VR941, VR942, VR943, VR944, VR945, VR946, VR947, VR948, VR949, VR950, VR951, VR952, VR953, VR954, VR955, VR956, VR957, VR958, VR959, VR960, VR961, VR962, VR963, VR964, VR965, VR966, VR967, VR968, VR969, VR970, VR971, VR972, VR973, VR974, VR975, VR976, VR977, VR978, VR979, VR980, VR981, VR982, VR983, VR984, VR985, VR986, VR987, VR988, VR989, VR990, VR991, VR992, VR993, VR994, VR995, VR996, VR997, VR998, VR999, VR1000.



MODULE BOARD
OPH124(149H124)
 (pcb 052H270)


SEE PAGE 48
For SN up to 090599

-  R25G
 selected on slew rate
 TLO80 8PCS
 CR2 5PCS
-  Carbon R25
-  metal film RB25FX
-  POSISTERS-C33G561
-  polystyrene 5P102
-  2521015-GR
-  25C215-GR
-  25C152-Y
-  25K30A-GR
-  NF510
-  152473
-  BA66Z
-  ET-6P
 A or B
 selected on VF (gm)
 replacement should be
 of the existing
-  Selected on offset
 10 PCS
 white dot
-  SR19
-  test point LC-28 (TP-4:400)
-  polystyrene film
-  bi-polar

INTERFACE BOARD

OPH122(149H122)(pcb 052H268)


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V



See pp. 34-35 for SN171700 and up

CAUTION
When replacing Interface board bearing edition no. 052H268 (and below) with PCB of 052H268 (and above), refer to pp. 34 and 35 for PROMs versions of CPU board.


- R25J
- CR8 25 FX
- POCIS 50R
- ERS-C33G561
- R50J
- ET-6P
- T10B2
- Selected on cement leakage
- 25C1815-GR
- 25A1015-GR
- 25K30A-GR
- 1S2473
- 1S352
- LED GL-BARI



D1 ~ D81: 1S1588 x 61


by TORU.M. SEP.1980

INTERFACE




SARE R91, C45, D13, TR9, IC31, VR2, L1, SW1

mc11920.



By Tom H. SEP. 1980



- AI-11 DATA
- AI-12 LASER
- AD3-10 SUPPLY
- AB-7 P. R. VPO
- AB-4 APP. CLK INT
- AB-3 APP. V. R. VPO
- AB-2 APP. CLK
- AB-1 APP. CLK
- AI-10 SPLIT
- AI-9 LFO V/L
- AI-8 LFO V/L
- AI-7 VCF MOD U
- AI-6 VCF MOD U
- AI-5 VCO2 REND
- AI-4 VCO2 REND
- AI-3 VCO2 REND
- AI-2 VCO2 REND
- AI-1 TUNE
- AI-241 COMP
- AI-23 COMP
- AI-22 COMP
- AI-21 TUNE
- AI-20 TUNE
- AI-19 TUNE
- AI-18 TUNE
- AI-17 TUNE
- AI-16 TUNE
- AI-15 TUNE
- AI-14 TUNE
- AI-13 TUNE
- AI-12 TUNE
- AI-11 TUNE
- AI-10 TUNE
- AI-9 TUNE
- AI-8 TUNE
- AI-7 TUNE
- AI-6 TUNE
- AI-5 TUNE
- AI-4 TUNE
- AI-3 TUNE
- AI-2 TUNE
- AI-1 TUNE

- VCO2 RANGE AC2-3
- ENV MODU AC2-3
- ENV MODU AC2-3
- PWM AC2-3
- VCO1, CROSS MODU AC2-3
- VCO2, FINE AC2-3
- SOURCE MIX AC2-3
- VCF, CUTOFF FREQ AC2-3
- VCF, RESONANCE AC2-3
- ENV1, SUSTAIN AC2-3
- ENV2, AC2-3
- LFO, RATE AC2-3
- HPF, CUTOFF FREQ AC2-3
- VCF, LFO MODU AC2-3
- VCF, KEYFOLLOW AC2-3
- VCF, LATCH AC2-3
- ENV1, ATTACK AC2-3
- ENV2, ATTACK AC2-3
- ENV1, RELEASE AC2-3
- ENV2, RELEASE AC2-3

- DRW3 AI-1
- AI-2
- AI-3
- AI-4
- AI-5
- AI-6
- AI-7
- AI-8
- AI-9
- AI-10
- AI-11
- AI-12
- AI-13
- AI-14
- AI-15
- AI-16
- AI-17
- AI-18
- AI-19
- AI-20
- AI-21
- AI-22
- AI-23
- AI-24
- AI-25
- AI-26
- AI-27
- AI-28
- AI-29
- AI-30
- AI-31
- AI-32
- AI-33
- AI-34
- AI-35

- LFO, WAVEFORM AC1-7
- VCO MODU, FREQ MODU AC1-7
- PW/PWM AC1-7
- VCO1, RANGE AC1-7
- VCF, CUTOFF FREQ AC1-7
- VCF, KEYFOLLOW AC1-7
- VCF, LATCH AC1-7
- ENV1, ATTACK AC1-7
- ENV2, ATTACK AC1-7
- ENV1, RELEASE AC1-7
- ENV2, RELEASE AC1-7



- AX-1
- AX-2
- AX-3
- AX-4
- AX-5
- AX-6
- AX-7
- AX-8
- AX-9
- AX-10
- AX-11
- AX-12
- AX-13
- AX-14
- AX-15
- AX-16
- AX-17
- AX-18
- AX-19
- AX-20
- AX-21
- AX-22
- AX-23
- AX-24
- AX-25
- AX-26
- AX-27
- AX-28
- AX-29
- AX-30
- AX-31
- AX-32
- AX-33
- AX-34
- AX-35

- VCO2, SYNC AC3-6
- VCF, RANGE AC3-6
- VCF, SLOPE AC3-6
- VCF, ENV MODU AC3-6
- ENV1, KEY FOLL AC3-6
- ENV2, POLARITY AC3-6
- ENV3, KEY RAIL AC3-6











- IC13 - 74ALS174
- IC10, 10-11
- IC14 - 74ALS567
- IC16 - 74ALS175
- IC17 - 74ALS178
- IC15 - 74ALS273
- IC5 - 6.7
- IC6 - 4051
- IC7 - 4051

- IC8-13 - 74ALS174
- IC9-10-11
- IC12-14 - 74ALS567
- IC15 - 74ALS273
- IC16 - 74ALS175
- IC17 - 74ALS178
- IC4 - 4051
- IC5 - 6.7
- IC6 - 4051
- IC7 - 4051



Highest Ref Des are R40, C21, D16, TR36, IC17, RA5



PANEL BOARD A OPH125(149H125) (pcb 052H271)

- | | | |
|---|---|--|
|  A1015 Y or GR |  D571 KA |  R25J |
|  C1815 Y or GR |  K30A GR |  CR025FX |
|  C1815 GR |  152473 |  Resistor Array |
|  B605 KA | | |




Component side



PANEL-A 052H271

PANEL-A 052H271

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z




Note: IC 1,3 TLO82 IC 2,4,5 4558
 TR 1,4-7 2SA1015-GR
 TR 2,3 2SA798 G
 TR 8 2SK30A-GR
 Highest Ref. Des : IC5, TR8, D1, C5, R43, VR8, SW7

BENDER BOARD
OPH132(149H132)
(pcb 052H278)


- Ⓚ 2SA733 Q P K
- Ⓚ 2SK30A GR Y
- Ⓚ 2SA778 G
- Ⓚ 1S2473
- Ⓚ SR19R
- Ⓚ R25-J

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z




IC1 - 4558 TR1 - DS71 KA
IC2 3,4 - 4556 TR2 - B605 KA
TR3, 4, 5, 6 - K30A




SLE-622-RP

PANEL BOARD B
OPH126(149H126)
(pcb 052H272)


- R25J
- 1S2473
- 25K30A
- 25C1815 GR




LEVEL SELECT BOARD
OPH139(149H139)
(pcb 052H330)



SSB042-12PN




All sliders: LFB9RC16B14 All rotary pots: VM10RK20B14 All rotary switches: SRM1034-K15




All sliders: LFB9RC16B14 All lever switches: SLE622-18PS

PANEL BOARD D
OPH128(149H128)
(pcb 052H274)
View from foil side



All switches: KHC11901 with LED






PANEL BOARD E
OPH129(149H129)
(pcb 052H275)
View from foil side




All switches: KHC11901 with LED

PANEL BOARD G
OPH131(149H131)
(pcb 052H277)
View from foil side


A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M
 N
 O
 P
 Q
 R
 S
 T
 U
 V
 W
 X
 Y
 Z
 0
 1
 2
 3
 4
 5
 6
 7
 8
 9



PANEL BOARD F
OPH130 (149H130) (pcb 052H276B)




POWER SUPPLY BOARD A
PSH059(146H059)(pcb 052H279)



POWER TRANSFORMER SECONDARY RATINGS
±20.5VDC @ 1.3A 4700mfd 1N
+8.5VDC @ 1.3A 4700mfd 1N


POWER SUPPLY BOARD B
PSH061(146H061) 100/117V
PSH062(146H062) 220/240V



100/117V 220/240V
F1 MGPO003 (3.0A) CEE T1.6A
F2 CEE T5.0A
F3 none
F4

μPD780 C/D-1
8 BIT MICROPROCESSOR

(Top View)



This is an 8 bit parallel CPU and is compatible with Z-80A and LH0800A.

- * Instruction sets: 158
- * Instruction cycle: 1.0μs (4.0MHz)
- * Internal registers: 17
- * address bus: 16 bit
- * Data bus: 8 bit

PIN FUNCTIONS

ADDRESS BUS Transfers 16 bits to memory address decoders (CPU board - IC21, 22 and 23) for controlling the followings:
on CPU board - ROM, CMOS, RAM, N-ch RAM, TAPE and TUNE reading.
on MOD CON board - RAM, UP, LO and VCO select.

Lower 8 bits are transferred to I/O Address decoders (Interface board - IC1, 2, 3, 4 and 8) for controlling the followings:
IN - Function sws, Digital IN (1, 2 and 3), Key IN, A/D.
OUT - Dot LED, Num LED, Matrix, Analog sel, Key out.
D/A Up/Lo, KCV sel, Gate out, EXT synch, Tune.

DATA BUS Used to transfer 8 bit instructions and data between CPU and memories or I/O device.

φ Square wave, 4 Mhz. Derived from X-tal oscillator's 8 Mhz, divided-by-two through frequency divider.

MRQ (Memory Request) Indicates that Address bus holds a valid memory address for a memory read and memory write.

IORQ (I/O Request) Indicates the presence of I/O Device number at pins A8-A7 during I/O write/read cycle.

RD (Memory read) Indicates that CPU wants to read data from memory or I/O device. The addressed memory or I/O device outputs data onto the CPU data bus at positive transition of RD.

WR (Memory write) Indicates that the CPU data bus holds valid data to be stored in the addressed memory or I/O device which latches the data off of the bus at positive transition of WR.

INT (Interrupt Request) Whenever \overline{INT} (ϕ , frequency divided by Counter-2, 1040) is fed to CPU every 1ms via IC26, it accepts \overline{INT} upon finishing processing job then starts executing Panel LED lighting program, generating INT Acknowledge as an TORQ in M1 cycle.

WAIT Lengthens read or write cycle until data on the data bus becomes valid during the presence of address signal for timing CPU access time to memory or I/O device.

RESET Initializes CPU circuits upon power on for the JP-8 or when DC voltages drop below specified value.



REGISTERS

MAIN REG SET		ALTERNATE REG SET	
ACCUMULATOR A	FLAGS F	ACCUMULATOR B	FLAGS G
B	C	B	C
D	E	D	E
H	L	H	L



GENERAL PURPOSE REGISTERS

INTERRUPT VECTOR	MEMORY REFRESH
INDEX REGISTER IX	SPECIAL PURPOSE REGISTERS
INDEX REGISTER IY	
STACK POINTER SP	
PROGRAM COUNTER PC	

BLOCK DIAGRAM






μPD444C
1024 X 4 BIT STATIC RAM CMOS RAM




μPD2716D
16K (2K x 8) UV ERASABLE PROM



(Top View)





Am6012
12-Bit High-Speed Multiplying D/A Converter




μPD2101ALC
1024 BIT (256x4) STATIC MOS RAM




μPD2114LC/D
1024 X 4 BIT STATIC RAM



IR3R01



TC40H000P QUAD 2-INPUT NAND GATE



ADJUSTMENTS

DISASSEMBLY

Follow procedure on page 2. Preparation of a STAY (chain or string) and prop is advisable for a stable top panel rest.


PRECAUTIONS

Do not expose your workbench directly to fans, heaters, air-conditioners, etc. especially after disassembling, most circuits are temperature-sensitive.

The adjustments on the JP-8 should not be done more than necessary. Adjustments merely attempted on a particular module (VOICE) might cause sound balance away from entire VOICES and can, in an extreme case, require the same procedures to be done fifteen times for the remainder.

DESIGNATION - TEST POINT, TRIMMER, PCB -

For PCBs that are identical in circuit configuration, most adjustment steps, test points and trimmers do not refer to a particular PCB or module (VOICE), they may be read as ones on a PCB to be adjusted.





Four module boards, each consisting of two voices, are identical in all aspects, having the same designators with A or B suffix for the same components of two VOICES, e.g. VR1A (VOICE A) and VR1B (VOICE B). Note that each voice contains two VCOs, VCO-1 and VCO-2.

ADJUSTING ORDER

The adjustments proceed from paragraph 1, DC Supply assuming that the JP-8 is completely unadjusted. When adjusting a specific section, begin with lower numbered para. in the relative adjustment section, e.g. first No. 7 BAL, then, No. 8 DEPTH, as directed.

TEST MODES

Adjustments on the JP-8 proceed in TEST MODEs. Although three TEST MODEs are available for the adjustments, TEST MODE (3) is chosen in this manual unless otherwise specified. (For more details refer to TEST MODE in Circuit Description - separate copy.)



Below confines description to the point inevitably necessary for performing the adjustments.


To put the JP-8 into TEST MODE 3

See figure above 3. With power off, throw SW-1-2 on Interface board from OPEN to TEST-1 or -2 (on some early models the switch is oriented opposite, so are labels TEST-1/2 on PCB, left hand one is always SW-1-2 and OPEN position is at label "OPEN" on the SW).

In the TEST MODE 3

The JP-8 has the following functions that are different from those in NORMAL MODE:

All VCOs are uncompu-tuned, i.e. their pitches are left deviated slightly until "TUNE" is pressed.



- * Among key assignments, POLY-1 only changes assigning order - tapping single key (same key) will assign modules from A to H one by one, repeating the order. This is convenient in comparing 8 modules sounds (timbre, pitch, etc.) sequentially at a note.
- * Computer provides FSK adjustment (para. 26) program and outputs test signal at SAVE (DUMP) jack when VERIFY is pressed.
- * Integrated PATCH NUMBER LEDs serve as module (VCO) indicator for visible checking, identifying VCO(s) being directed by key(s) has been depressed or being held down.

SW-1-1, LED switch, in close position, allows LEDs (TEST LED) located right to it to be energized regardless of MODE (NORMAL or TEST) when gate signals are fed to them individually. The LEDs function as assignment indicator just as Patch Number LEDs do. Test LEDs find extended application for learning and checking the assignments varying to MODEs (KEY, PANEL and ASSIGN) in Normal mode.


Patch Number LEDs are lit automatically in sequence immediately after TUNE is touched, representing module A VCO-1 (leftmost LED), A VCO-2 (No.2 LED) and so on; the first cycle for Upper modules' and the second for Lower. Their lighting period is proportional to degree of VCO detune from standard pitches. An LED staying on and won't pass illumination to the next one claims checking of its mated VCO having been far out of computer controllable range.

TEST MODEs 2 and 3 are identical to each other in function, but any panel disassembly is required for mode 2 if the purpose is only to check Key Assignment or VCO detune.

FOR SATISFACTORY SERVICE WORK

1. Dump user's preset memory on tape before attempting adjustments and troubleshooting.
2. If TUNE was pressed in previous adjustments, be sure to power off and on the JP-8 before making adjustment which must be done without compu-tune.
3. Plural keying and miskeying will disorder key assignment sequence. Push HOLD or ASSIGN MODE to off and again to on, as appropriate, to restore the order. Use monitor amp to detect erroneous key assignment that LED does not distinguish.
4. Make a practice of pushing MANUAL after changing PANEL MODEs.
5. Restore SW-1-1 and SW-1-2 to OPEN and load back the data on tape before return the unit to the customer.

12. VCO LEVEL
MODULE (MOD)



See appendices for adjustment locations and glossary.


1. Connect scope to MOD TP-4.

CAUTION On early product, legends for some VR's are incorrect. Refer to PCB layout in appendix.

2. Press A2 key, adjust VR13 for 10V p-p reading.
3. Rotate SOURCE MIX to VCO-2 and adjust VR15 for 10V p-p.

13. VCF KEY FOLLOWER

MODULE (MOD) MODULE CONTROLLER (MOD CON)



See appendices for adjustment locations and glossary.

This adjustment must be followed by para. 14-17.

CAUTION

On early product, legends for some VR's are incorrect. Refer to PCB layout in appendix.

1. Place ground to CON TP-4 or D20 cathode.
2. Connect scope to MOD TP-6 or R166 lead.
3. Turn MOD VR14 fully clockwise. The VCFs resonate.
4. Press C2 key, adjust scope timebase and VCF FREQ to display one complete cycle. (across the graticules, same for the rest para.) MOD VR20 may be used for fine adjustment.


5. Press C4 key, adjust VR16 to display 4 complete cycles.

NOTE:

VR14 and VR20 will be readjusted in later para.

14. VCF WIDTH

MODULE (MOD) MODULE CONTROLLER (CON)



Para. 13-17 must be performed in sequence.

On JP-8's S/N **0600 and subsequent, read figures in parentheses.

1. With scope to MOD TP-6 set timebase to 1ms (2ms)/div.
2. Press C2 key, adjust VCF ENV MOD and MOD VR20 to display one complete cycle.
3. Set CO FREQ to 10, scope timebase to 5μs/div (20μs/div). Adjust VR19 to display one complete cycle (5 cycles).

Steps 2 and 3 interact, repeat steps as required.

15. VCF ENV MOD

MODULE (MOD) MODULE CONTROLLER (CON)

Para. 13-17 must be performed in sequence.

Change para. 14 setup: VCF ENV MOD to 0, scope timebase to 0.2ms/div.

1. Press C2 key, adjust CO FREQ and MOD VR20 to display exactly one complete cycle.

2. Reset VCF ENV MOD to 10, timebase to 50μs/div. Adjust VR21 to display 16 complete cycles.

16. VCF TUNE

MODULE (MOD) MODULE CONTROLLER (CON)

Para. 13-17 must be performed in sequence.

Change setup in para. 15 step 2: ENV MODE to 0; CO FREQ to 5 (S/N **0600 - 4); scope to MOD TP-6 with A-442 reference fed to H IN.

1. Press a key, adjust VR20 for 1:1 Lissajous.


17. RESONANCE LEVEL

MODULE (MOD)

Para. 13-17 must be performed in sequence.


Change setup in para. 16: SOURCE MIX to VCO-1; CO FREQ to 10; Scope to INT TRIG.

1. Press A2 key (S/N **0600 - E3 key), adjust VR14 for the figure:



18. VCA LEVEL

MODULE (MOD) MODULE CONTROLLER (CON) (early JP-8)



See appendices for adjustment locations and glossary.

Although CON VR5 is included in part 1, the trimpot is replaced by 10k resistor on later products. When adjusting MOD replacement, ignore VR5 trimming, following Part 2.

Connect scope to TP-6 or R166 lead.

PART 1


1. Set MOD VR18 wiper to midpoint.
2. Press C2 key and adjust CON VR5 for 3V p-p.
3. Adjust VR18 of the remainder Voices for 3V p-p.

PART 2

1. Press C2 key and adjust VR18 for 3V p-p.

19. VCA BALANCE

MODULE (MOD) MODULE CONTROLLER (CON)




See appendices for adjustment locations and glossary.

1. Place ground to CON TP-4 or D20 cathode.
2. Connect scope to MOD TP-6 or R166. Switch scope to DC coupling, vertical range to 20mV/div.
3. While tapping a key, adjust VR17 so that DC variations are minimized.

20. ENVELOPE TOTAL TIME

MODULE (MOD)





See appendices for adjustment locations and glossary.

This adjustment proceeds on the assumption that all VOICES' ENVs are unadjusted. When adjusting particular module, start from step 3 with scope V IN connected to TP-8 of well calibrated module.

ENV-1

1. Connect scope to MOD GH R183B lead or TP-8B.
2. While holding a key, time Attack period on scope. Adjust MOD H VR22 for 6-sec attack period.
3. Switch scope timebase to 20ms/div. Trigger scope from TR16 collector of any module.
4. Press and hold a key repeatedly, adjust both ENV-1 ATTACK (around 4-5) and timebase VARI or vernier so that envelope's falling edge is centered on the screen.
5. Shift V lead to TP-8 of the module to be adjusted. Adjust the VR22 for centered falling edge.




ENV-2

The procedure is similar to those in ENV-1, but connect scope to R189 lead or TP-7 and adjust ENV-2 ATTACK and VR23.

7.1. ENV-1 S OFFSET
MODULE CONTROLLER (CON)

Applicable to the PCB equipped with VR9




This adjustment must be followed by para. 7. See appendices for adjustment locations and glossary.

1. Connect scope to CON TP-7.
Set scope V to 20mV/div.
2. Adjust CON VR9 for 0V reading.

7. VCO ENV MOD BAL
MODULE (MOD)

On JP-8 mounting CON with VR9, this adjustment must follow para. 7-1.



See appendices for adjustment locations and glossary.

1. Push TUNE.
2. Connect scope to MOD TP-4 with A-442 reference to H IN.
3. Press A2 key, adjust MASTER TUNE for still Lissajous.
4. Slide MOD ENV up to 10. Without additional keying, adjust MOD VR8 for still Lissajous. (Frequency is same as in step 3.)

8. VCO ENV MOD DEPTH
MODULE (MOD)


This adjustment must follow para. 7. See appendices for adjustment locations and glossary.

Change from para. 7 setup: ENV-1 S to 10; VCO-1 to 2; VCO MOD ENV to 0.

The adjustment sets maximum voltage of modulating waveform to the value by which VCO's can be shifted within a 3-octave range.

1. Press A0 key, adjust MASTER TUNE for motionless Lissajous.
2. Set VCO-1 to 16; VCO MOD ENV to 10. Leaving A0 key open, adjust MOD VR9 for the same waveform as in step 1.

9. VCO CROSS MOD BALANCE (X-MOD)
MODULE (MOD) MODULE CONTROLLER (CON)



This adjustment must be followed by para. 10. See appendices for adjustment locations and glossary.

1. Connect scope to MOD TP-4 with A-442 reference fed to H IN. Place a ground to CON TP-4 or D-20. Push TUNE.
2. Press A2 key, adjust MASTER TUNE for still Lissajous.
3. Leaving A2 key open, set VCO-1 CROSS MOD to 10. Adjust MOD VR10 for the same Lissajous displayed in step 2.

10. VCO CROSS MOD DEPTH (X-MOD LEVEL)
MODULE (MOD) MODULE CONTROLLER (CON)


This adjustment must follow para. 9. See appendices for adjustment locations and glossary.

The adjustment sets modulating voltage to the value by which VCO-1 frequency is shifted by 3 octaves when CROSS MOD is set at 5, and VCO-1 RANGE at 2.

Change from para. 9 setup: VCO-1 CROSS MOD to 5; VCO-2 SYNC to on; VCO-2 RANGE to LOW FREQ.

1. Press A0 key, adjust MASTER TUNE so that Lissajous is 1:1.
2. Switch VCO-2 WAVE to square; VCO-1 to 16; Adjust MOD VR11 to display Lissajous observed in step 1.

11. PULSE WIDTH MOD LEVEL (P.W.M.)
MODULE (MOD)




On JP-8's S/N **0600 and subsequent, waveform is up side down.

See appendices for adjustment locations and glossary.

1. Connect scope to MOD TP-4 or R130 lead. Trigger on the negative edge (positive S/N **0600).
2. Press C2 key, adjust MOD VR12 for 30μs space width.

NOTE:
VR12's interact to each other. Check other voices for mark/space ratio. Readjust as necessary.




BEFORE STARTING ADJUSTMENTS

ALLOW AT LEAST 30 MINUTES FOR WARUP PERIOD

**1. DC SUPPLY
POWER SUPPLY BOARD**

1. Connect Digital voltmeter (DVM) to -15V (terminal 9, 10, 11).
2. Adjust VR1 for -15V±10mV reading.
3. +15V should be +15V±500mV.
4. +5V should be 5V±400mV.



**2. DC SUPPLY (VCO)
MODULE, MODULE CONTROLLER**

See appendices for adjustment locations and glossary.

MODs A, B, C and D

1. Connect DVM to MOD AB IC1 pin 4 (-VDD).
2. Adjust upper CON VR4 for -13V±5mV.
3. IC1 pin 8 should read +13V±200mV.

MODs E, F, G and H

1. Disconnect flatcables at upper CON LM1 and HL. Observe the note in CON Layout, appendix.
2. Perform step 1-3 above for lower PCBs.

**3. PANEL POTs VOLTAGES
INTERFACE (INT) PANEL BOARD A**


See appendices for locations and glossary.

1. Connect DVM to INT TP-3 or R83 (10k) lead facing outside. (See Fig. below right.)
2. Depress MANUAL.
3. Turn all the pots on the panel illustrated fully cw, or to 10. Incomplete settings result in a fluctuating reading or dips on a screen if observed with scope.
4. Set VR1 (Panel board A) for +5V±2mV.


**4. DAC
INTERFACE (INT)**

See appendix for glossary.

1. Connect DVM to OUTPUT CV jack.
2. Press KEY MODE WHOLE.
3. Press C0 key, adjust VR2 for 0.000V reading.
4. Press C5 key, adjust VR1 for 5.000V reading.
5. Check C0-C5 keys for scaling, that those voltages are 1V/oct increments ±2mV.




**5. VCO MOD BAL
MODULE (MOD)**




See appendices for adjustment locations and glossary.

1. Connect DVM to MOD TP-3 or R107 lead.
2. Adjust MOD VR7 for 0.000V reading.

**6. VCO TUNE
MODULE (MOD)**



See appendices for adjustment locations and glossary.



Compu-tuned VCO needs to be re-calibrated only if it or associated components have been replaced. If a VCO is excessively out of tune right after compu-tune, first check MOD BAL, para. 5 and KCV OUT (INT terminals IM-1, IM-3, etc.) for voltage. Seconds, isolate possible causes before attempting VCO adjustments.

As is usual with tuning, several instruments may be used for determining frequency. The calibration proceeds by Lissajous figures with A-442 reference fed to scope's horizontal input.


1. Connect scope to MOD TP-4 or R130 lead.
2. Turn SOURCE MIX fully to VCO-1 or 2 accordingly.

NOTE:

Make sure that the JP-8 is in the test mode without initially compu-tuned upon power on. To ensure this, turn power off and on. Then, push UNISON, etc. See "TEST MODE" on the first page of this section.

3. Press A3 key, adjust trimpot T for 884Hz.
4. Press A1 key, adjust trimpot W for 221Hz.
5. Repeat steps 3-4 until waveforms are stationary on both keys.
6. With RANGE set in 2', press A3 key and adjust L for 3536Hz.
7. These trims interact to each other, repeat steps 3-6 until three notes are on the right frequency.

12. VCO LEVEL
MODULE (MOD)



See appendices for adjustment locations and glossary.

1. Connect scope to MOD TP-4.


CAUTION On early product, legends for some VR's are incorrect. Refer to PCB layout in appendix.

2. Press A2 key, adjust VR13 for 10V p-p reading.

3. Rotate SOURCE MIX to VCO-2 and adjust VR15 for 10V p-p.

13. VCF KEY FOLLOWER

MODULE (MOD) MODULE CONTROLLER (MOD CON)



See appendices for adjustment locations and glossary.

This adjustment must be followed by para. 14-17.

CAUTION

On early product, legends for some VR's are incorrect. Refer to PCB layout in appendix.

1. Place ground to CON TP-4 or D20 cathode.

2. Connect scope to MOD TP-6 or R166 lead.

3. Turn MOD VR14 fully clockwise. The VCFs resonate.

4. Press C2 key, adjust scope timebase and VCF FREQ to display one complete cycle. (across the graticules, same for the rest para.) MOD VR20 may be used for fine adjustment.


5. Press C4 key, adjust VR16 to display 4 complete cycles.

NOTE:

VR14 and VR20 will be readjusted in later para.

14. VCF WIDTH

MODULE (MOD) MODULE CONTROLLER (CON)



Para. 13-17 must be performed in sequence.

On JP-8's S/N **0600 and subsequent, read figures in parentheses.

1. With scope to MOD TP-6 set timebase to 1ms (2ms)/div.

2. Press C2 key, adjust VCF ENV MOD and MOD VR20 to display one complete cycle.

3. Set CO FREQ to 10, scope timebase to 5μs/div (20μs/div). Adjust VR19 to display one complete cycle (5 cycles).

Steps 2 and 3 interact, repeat steps as required.

15. VCF ENV MOD

MODULE (MOD) MODULE CONTROLLER (CON)

Para. 13-17 must be performed in sequence.

Change para. 14 setup: VCF ENV MOD to 0, scope timebase to 0.2ms/div.

1. Press C2 key, adjust CO FREQ and MOD VR20 to display exactly one complete cycle.

2. Reset VCF ENV MOD to 10, timebase to 50μs/div. Adjust VR21 to display 16 complete cycles.

16. VCF TUNE

MODULE (MOD) MODULE CONTROLLER (CON)

Para. 13-17 must be performed in sequence.

Change setup in para. 15 step 2: ENV MODE to 0; CO FREQ to 5 (S/N **0600 - 4); scope to MOD TP-6 with A-442 reference fed to H IN.

1. Press a key, adjust VR20 for 1:1 Lissajous.


17. RESONANCE LEVEL

MODULE (MOD)

Para. 13-17 must be performed in sequence.


Change setup in para. 16: SOURCE MIX to VCO-1; CO FREQ to 10; Scope to INT TRIG.

1. Press A2 key (S/N **0600 - E3 key), adjust VR14 for the figure:



18. VCA LEVEL

MODULE (MOD) MODULE CONTROLLER (CON) (early JP-8)



See appendices for adjustment locations and glossary.

Although CON VR5 is included in part 1, the trimpot is replaced by 10k resistor on later products. When adjusting MOD replacement, ignore VR5 trimming, following Part 2.

Connect scope to TP-6 or R166 lead.

PART 1


1. Set MOD VR18 wiper to midpoint.
2. Press C2 key and adjust CON VR5 for 3V p-p.
3. Adjust VR18 of the remainder Voices for 3V p-p.

PART 2

1. Press C2 key and adjust VR18 for 3V p-p.

19. VCA BALANCE

MODULE (MOD) MODULE CONTROLLER (CON)




See appendices for adjustment locations and glossary.

1. Place ground to CON TP-4 or D20 cathode.
2. Connect scope to MOD TP-6 or R166. Switch scope to DC coupling, vertical range to 20mV/div.
3. While tapping a key, adjust VR17 so that DC variations are minimized.

20. ENVELOPE TOTAL TIME

MODULE (MOD)





See appendices for adjustment locations and glossary.

This adjustment proceeds on the assumption that all VOICES' ENVs are unadjusted. When adjusting particular module, start from step 3 with scope V IN connected to TP-8 of well calibrated module.

ENV-1

1. Connect scope to MOD GH R183B lead or TP-8B.
2. While holding a key, time Attack period on scope. Adjust MOD H VR22 for 6-sec attack period.
3. Switch scope timebase to 20ms/div. Trigger scope from TR16 collector of any module.
4. Press and hold a key repeatedly, adjust both ENV-1 ATTACK (around 4-5) and timebase VARI or vernier so that envelope's falling edge is centered on the screen.
5. Shift V lead to TP-8 of the module to be adjusted. Adjust the VR22 for centered falling edge.





ENV-2

The procedure is similar to those in ENV-1, but connect scope to R189 lead or TP-7 and adjust ENV-2 ATTACK and VR23.

21. LFO MODULATION


MODULE (MOD) MODULE CONTROLLER (CON)



See appendices for adjustment locations and glossary.

1. Connect scope to CON TP-5 Or R59 lead. Set timebase to 10ms/div.

2. Adjust CON VR3 to display exactly 3 complete cycles on the scope.





3. Adjust CON VR2 for slope straightness as shown in Fig. right.

4. Shift scope to TP-4 of (Upper - MOD A; Lower - MOD E).

Repeatedly holding a key, adjust CON VR8 so that VCO becomes being modulated approx. 4 sec after the key first depressed.

22. VCO LEO MODULATION

MODULE (MOD) MODULE CONTROLLER (CON)



See appendices for adjustment locations and glossary.


1. Connect scope (with A-442 into H IN) to TP-4 of (Upper-MOD A; Lower - MOD E).

2. Press A2 key, adjust MASTER TUNE for 1:1 Lissajous.

3. Set VCO LFO MOD to 10. Lissajous ratio is now changing up and down in sympathy with LFO rate. Adjust CON VR6 so that Lissajous becomes 2:1 at the highest pitch. Note that LFO modulated VCO swing equals 2 oct's.

23. VCF LFO MOD LEVEL

MODULE CONTROLLER (CON)



See appendices for adjustment locations and glossary.

1. Connect scope to TP-6 of (Upper - MOD A; Lower - MOD E).

2. Press C2 key (S/N **0600 - C4 key), adjust CON VR7 for 50 percentage modulation.



JUPITER-8

24. NOISE

MODULE CONTROLLER (CON)

See appendices for adjustment locations and glossary.

1. Switch VCO-2 RANGE to NORMAL. Connect scope to CON TP-4.

2. Adjust CON VR1 so that dense signal peaks are approx. 5V p-p.



3. Switch RANGE to LOW FREQ, check peaks for clip.

NORMAL RANGE LOW FREQ



25. BENDER OFFSET

BENDER MODULE (MOD)



See appendices for adjustment locations and glossary.

1. Connect scope to TP-4 of (Upper - MOD A; Lower - MOD E) with A-442 reference to H IN.

2. Press A2 key, adjust MASTER TUNE for stationary Lissajous.



3. Set VCO MOD switch to on, adjust VR1 (Upper) or VR2 (Lower) for stationary Lissajous.

NOTE: On JP-8 S/N **0700-, next comes para. 25-1, BENDER LEVEL.

25-1. BENDER LEVEL

BENDER MODULE (MOD)

APPLICABLE S/N with **0700 and SUBSEQUENT



VR3 BENDER ADJ

1. Connect scope to TP-4 of any MOD. Press A2 key, adjust timebase and vernier (VARI) to display one complete cycle.

2. Press A3 key. Sway and hold BENDER Lever at extreme left, adjust VCO BEND to display 1 cycle.

3. Press A1 key. Sway and hold BENDER at extreme right, set VR3 for complete 1 cycle.

26. FSK

CPU

See appendices for glossary.

1. Join TAPE MEMORY LOAD and DUMP jacks via cable.



NOTE: DUMP is renamed as SAVE on later products.

2. Connect scope to CPU TP-7.

3. Push VERIFY. Be sure that the JP-8 is in test mode, this is displayed in PATCH NUMBER window as -|-|-|-|.


4. Set CPU VR1 for 50% duty cycle.

5. Push VERIFY again at the end of adjustment.




APPENDIX I

CIRCLED NUMBERS AROUND PCB LAYOUT CORRESPOND TO PARAGRAPH NUMBERS



MODULE CONTROLLER BOARD




APPENDIX II MODULE BOARD

GLOSSARY

- DVM Digital Voltmeter
- SCOPE Oscilloscope
- CPU CPU Board
- MOD Module Board
- Module (VOICE)
- CON Module Controller Board
- INT Interface Board

On early PCBs, legends for VR13, 14, 15, 16 are incorrect. Follow this arrangement.



CIRCLED NUMBERS AROUND PCB LAYOUT CORRESPOND TO PARAGRAPH NUMBERS

PARTS LIST


CHASSIS		PCB	
061H117	Chassis H117 (main)	149H121	CPU board OPH121 (etch mask 052H267)
061H118	Chassis H118 (power trans)		
061H116	Chassis H116 (jack)	149H122	INTERFACE board OPH122 (etch mask 052H268)
063H040	Plate (side panel) H40 (right)	149H123	MODULE CONTROLLER OPH123 (etch mask 052H269)
063H041	Plate (side panel) H41 (left)	149H124	MODULE board OPH124 (etch mask 052H270)
PANEL		149H125	PANEL board A OPH125 (etch mask 052H271)
072H078	Panel H78 (upper)	149H126	PANEL board B OPH126 (etch mask 052H272)
072H079	Panel H79 (bender)	149H127	PANEL board C OPH127 (etch mask 052H273)
072H080	Panel H80 (right end block)	149H128	PANEL board D OPH128 (etch mask 052H274)
HOLDER		149H129	PANEL board E OPH129 (etch mask 052H275)
064H055B	Holder H55B (pot-pcb)	149H130	PANEL board F OPH130 (etch mask 052H276)
064H092	Holder H92 (key sw)	149H131	PANEL board G OPH131 (etch mask 052H277)
064H100	Holder H100	149H132	BENDER board OPH132 (etch mask 052H278)
064H101	Holder H101	149H139	LEVEL SELECT board OPH139 (etch mask 052H330)
064H094	Holder H94	146H059	POWER SUPPLY board A PSH059 (etch mask 052H279)
KEYBOARD		146H061	POWER SUPPLY board B (100/117) PSH061 (etch mask 052H302)
004H008	SK-361C	146H062	POWER SUPPLY board B (220/240) PSH062 (etch mask 052H302)
KNOB		146H060	POWER SUPPLY board C PSH060 (etch mask 052H303) Tr pr T
016-078	Knob NO. 78	JACK	
016H004	Knob H4	13449107	S-G7630 (mono)
12479703	KT3-2 (key top) (ivory)	13449123	S-G7716 (stereo)
SWITCH		FUSE	
13149103	2Wi XII (115V) power sw		GHS 1/4A (CPU board)
13149104	2Wi I (220V) power sw	12559137	MGP0003 (3.0A) prim. 100/117V
SLIDE SWITCH		12559521	CEE TT1.6A prim. 220/240V
13159118	SSB 022-12RN	12559518	CEE T5.0A sec. 220/240V
13159117	SSB 023-12RN		
13159116	SSB 042-12PN	SEMICONDUCTOR	
13159503	SQPR-24 12P	IC (* CMOS)	
DIP SWITCH		15159114HO	* TC4062BP Dual 4-channel multiplexer
13169606	J-S8719-02	15159131	* TC4053BP Triple 2-channel multiplexer
LEVER SWITCH		15159128T0	* TC4050BP Hex buffer non-inverting type
13139136	SLE-622-18P	15159113HO	* TC4051BP Single 8-channel multiplexer
13139137	SLE-622-18PS	15159115HO	* TC4066BP Quadrate bilateral switch
13139135	SLE-623-18P	15159132	* TC40175BP Quadrate D-type flip-flop
ROTARY SWITCH		15179308	uPD2101ALC 1024 bit static RAM
13119301	SRM1034-K15	15179111	uPD780C-1 CPU
PUSH SWITCH		15179605NO	uPD2716D 16384 bit erasable PROM
13169601	KHC 11901 w/LED	15179305	uPD444C 4096 bit static RAM
KEY SWITCH UNIT		15179309	uPD2114C 4096 bit static RAM
13129717	KEH 10003 w/key top KT3-2	15179110NO	uPD8253C Triple programmable interval timers
13129714	KEH10903 switch proper	15149106	CA3046 Transistor arrays
13129719	Guide pin CHC32801A	15190109NO	uPC78L05 Three terminal voltage regulator
2226920800	Cushion rubber CK42602A	15189111NO	uPC311C Comparator
BUTTON		15189105	uPC4558C OP amp
016H010	white	15189132JO	NJM4556C OP amp
016H011	dark blue	15189105XO	TL458C OP amp
016H012	orange	15189116	TL080CP OP amp
016H013	blue	151891160A	TL080CP OP amp (selected)
016H014	green		
016H017	yellow		
016H018	red		

15189117	TL081CP	OP amp
151891180A	TL082CP	OP amp
	(selected)	
15229801	IR3109	VDR
15229807	IR3R01	ADSR
15229802	BA862A or B	VCA
152298020A	BA862A (VF selected)	white dot only
152298020B	BA862A (Offset selected)	color dot
15169301HO	74LS00	Quadrate 2-input NAND gates
15169303HO	74LS02	Quadrate 2-input NOR gates
15169304HO	74LS04	Hex inverters
15169341	74LS14	Hex schmitt-trigger inverters
15169311HO	74LS74	Dual D-type flip-flops
15169313HO	74LS86	Quadrate 2-input exclusive-OR gates
15169318HO	74LS138	3-line to 8-line decoders
15169319HO	74LS139	Dual 2-line to 4-line decoders
15169342	74LS156	Dual 2-line to 4-line decoders
15169321HO	74LS161	Synchronous 4-bit binary counters
15169322HO	74LS174	Hex D-type flop-flops
15169323HO	74LS175	Quadrate D-type flop-flops
15169343	74LS240	Octalbuffers/line drivers with 3-state outputs
15169331XO	74LS244	Octalbuffers/line drivers with 3-state outputs
15169324CO	74LS245	Octal bus transceivers with 3-state outputs
15169325CO	74LS273	Octal D-type flip-flop
15169327HO	74LS367	Hex bus drivers
15169329HO	74LS393	Dual 4-bit binary counters
15169101XO	7400	Quadrate 2-input NAND gates
15169116	7474	Dual D-type flip-flops
15169102XO	7406	Hex inverters with open-collector
15169117	7407	Hex buffers/drivers with open-collector
15219109HO	HA-17555C	Precision timer
15159503	* TC401H000P	Quad 2-input NAND gate
15219105	LM565	Phase locked loop
15219118	Am6012A	12-bit multiplying D/A converter
TRANSISTOR		
15119113	2SA1015-GR	
15119108	2SA798-G	
15119105	2SC743-G or P, K	
15119601	2SB605-G	
017-163	2SB605-KA	
15119813	2SB754-Y	
15129114	2SC1815-GR	
15129128	2SC752-Y	
15129108	2SC945-P	
151291080A	2SC945 (Selected)	
15129600	2SD571-L	
017-164	2SD571-KA	
15129606	2SD844-Y	
15129816	2SD880-Y	
15139106	2SK117-GR	
15139103	2SK303A-GR	
15139110	NF510 or 2N4392	
15019103	1S2473	
15019628	05Z-5.6U	
15019629	05Z-6.2L	
15012626	05Z-11U	
15019624	1S2-52	
16029110	GL-3AR1 or TLR124, SLP-135 (LED)	
15029103	TLR124 (LED)	
15029404	LN526RA (LED)	
15019248	6D4B41 (6A 200V)	
15019247	GP-30G (Hi-Fi special)	

POTENTIOMETER	
SLIDER	
13339414	LF9E9-C16A55 (500KA)
13339415	LF9E9-C16B14 (10K8)
13339413	LF9E9-C16B54 (50K8)
13369302	MF9E9-C16B54 (50KKA x 2)
ROTARY	
13219811	GM70R-K20AC54P (50KAC)
13219812	GM70R-K20B54P (50KB x 2)
13219225	VM10R-K20B14 (10K8)
13219243	VM10R-K20C54 (50KC)
13219231	VM10R-K20A55 (500KA)
13229131	VM10A-K15B54 (50KA CT)
TRIMMER	
SR19R	
13299114	10K
13299116	47K
13299117	100K
	CR44R
329-601	100K
	ET-6P
13299551	1K
13299550	2K
13299549	5K
13299562	100K
	EVTR4SA00B15
13299102	100K
BENDER UNIT	
029-022	PB-4
RESISTOR	
13769138DO	390 Ohm
13769151DO	1.2K
13769153DO	1.5K
13769158DO	2.4K
13769262DO	2.5K
13769159DO	2.7K
13769160DO	3K
13769161DO	3.3K
13769163DO	3.9K
13769165DO	4.7K
13769167DO	5.6K
13769171DO	8.2K
13769173DO	10K
13769255DO	19K
13769181DO	22K
13769182DO	24K
13769254DO	25K
13769183DO	27K
13769189DO	47K
13769191DO	56K
13769194DO	75K
13769197DO	100K
13769201DO	150K
13769205DO	220K
13769213DO	470K
13769219DO	820K
13769221DO	1M
13769253DO	2.2M
	MO-4S
13839143FO	0.33 3W
13839144FO	150 3W
13839188FO	0.5 5W

POTENTIOMETER		
15229909	560	ERS-833G561
15229910	1.2K	ERS-833G122
15229911	1K	TSP102J
ARRAY		
13910106	10K x 8	RM6-103K
13829821	10K x 8	RM6-103K
13910105	22K x 8	RM6-223K
CAPASITOR		
13639942MO	ECFA-11N010S	1u 50V bi-polar
13569575FO	CO09S-1H-10000-J5	1000PF styrol
POWER TRANSFORMER		
022H039J	100V	
022H039C-A	117V	
022H039D	220/240V	
COIL		
244021500	SN8D500	
IC SOCKET		
13429511	IC-49-2406#2 (24P)	
CONNECTOR		
13429608	TCSD250-1.1 (DIN)	
13439120	5045-04A	
13439122	5045-06A	
13439124	5045-08A	
13439126	5045-10A	
13439155	5045-12A	
13439131	5046-04A	
13439132	5046-05A	
13439133	5046-06A	
13439169	5046-06A	
13439135	5046-09A	
13439136	5046-10A	
13439171	5046-12A	
13439172	5046-14A	
13439173	5274-06A	
13439106	5272-08A	
13439174	FCN-724P010-AU/O.L.	10pin
13439175	FCN-724P020-AU/O.L.	20pin
13439176	FCN-724P040-AU/O.L.	40pin
13439177	FCN-724P050-AU/O.L.	50pin
13439851	HA16R-3P (canon)	
FLAT CABLE		
053H125	Flat cable H125	
053H126	Flat cable H126	
053H127	Flat cable H127	
053H128	Flat cable H128	
053H129	Flat cable H129	
NOISE FILTER		
12449219	ZGB1201-11 (100/117V)	
12449220	ZMB2201-13 (220/240V)	
OTHERS		
048H022	Heat sink H22	
2215050100	Long nut #1 10mm	
2215050300	Long nut #3 18mm	
2215051100	Long nut #13 22mm	

SEE PP. 40 and 47
For Parts Change
INFORMATION



KEYBOARD PARTS
JP-8 SK-361C (004H008)

NO.	PART NO.	DESCRIPTION
1	106H026	Natural key C F
1	106H027	Natural key D
1	106H028	Natural key E B
1	106H029	Natural key G
1	106H030	Natural key A
1	106H031	Natural key C' F'
2	106H032	Sharp key black
3	070H029	Key spring H29
4	061H086A	Chassis HB6A
5	068H004	Guide bushing H4
6	101H141	Level felt H41
7	071H404	Contact leaf H44
8	071H051	Busbar SP H51
	071H054	Busbar LP H54
9	043H007	Switch unit 12P H7
	043H008	Switch unit 13P H8
10	104H029	Busbar holder H29
11	062H024	Chassis bracket H24
12	098H006	Key stopper H6
13	052H283-5	Matrix board H283-5
14	107H059	Dushion H59

NOTE:
Although Roland has employed 8-10 digit coding, old ones (6 digit and 6 digit with H) are still applied to some parts.



HOW TO IDENTIFY PROM VERSION

CPU BOARD

Version is indicated by hand written number or marking on the label as shown below.
Version can be displayed in PATCH NUMBER window (LOWER). Turn the JP-8 on while pressing PATCH NUMBER buttons 1 and 3.

NOTES:

In 0.7 or 1.0 version, displayed number will change quickly from 07 (10) to 13.
In 3.2 (A, B, C) and 3.3D (3.4) arrangement, number 33 (34) will change to 32 if PROM D is removed.



PROM VERSION PROGRAM

0.7 1.0	12-BIT DAC FIXED KEY SPLIT POINT
2.0	12-BIT DAC VARIABLE KEY SPLIT POINT
2.1D	DIGITAL COMMUNICATION INTERFACE
3.1	14-BIT DAC VARIABLE KEY SPLIT POINT
3.2 2)	14-BIT DAC VARIABLE KEY SPLIT POINT
3.3D (3.4D)	DIGITAL COMMUNICATION INTERFACE

- 1) This is a special version. Replace each with the same one, or replace all four with a set of 3.2 and 3.4D version.
- 2) Co-operates with 3.3D or 3.4D for Digital Communication Interface.

PROM REPLACEMENT

When replacing PROMs A, B and C with different version, replace them in a set.

Version 3.2 can replace 3.1, 1.0 and 0.7
Version 3.1 can replace 1.0 and 0.7
The reverse does not hold true.

ROM 3.4 can replace 3.3D and vice versa.

NOTES:

PROM D is required only when OC-8 or DCB BOARD is present.
PROM D must be used together with A, B, C of 3.2 version and up.
PROM D contains diagnostic programs.
Refer to P.46 for test procedure.
Difference between 3.3D and 3.4D is that the latter has debugged diagnostic program.

When need arises to modify the JP-8 or to replace parts:
First consult the table below, then refer to the right as necessary.

INTERFACE BOARD	p. 34
MODULE CONTROLLER BOARD	pp. 37, 38
RAM IC49 of MOD CON BOARD	p. 38
CPU BOARD (in relation to RAM IC 49)	p. 38
OC-8	OP-8 (OC-8) Service Notes

SERIAL NUMBER	PROM VERSION				DISPLAY	The JP-8 may be or may have	Features of the JP-8	When new feature is required, replace existing part(s) with the one indicated by ●.				
	A	B	C	D				Addable new feature	PROM A, B, C 3.2	VERSION D 3.3 or 3.4	INTERFACE BOARD w/14-bit DAC	by-product
PROTOTYPE	0.7				07	as produced	DAC 12-bit KEY SPLIT POINT Fix	DA 14-bit SPLIT POINT Variable	●	●	●	Variable Split point
030100	1.0				10	as produced	OC-8 less	OC-8 built in	●	●	●	Variable Split point
	JP-8 2.1D				21	OC-8: installed at the factory	DAC 12-bit KEY SPLIT POINT Variable	DA 14-bit	●	●	●	
171699	(3.2)				33 or 34	OC-8: built in as option	OC-8 built in		●	●	●	
171700 181899	3.1				31	as produced	DA 14-bit KEY SPLIT POINT Variable	OC-8 built in	●	●	●	
181900 282879	3.2				32	as produced	OC-8 less		●	●	●	
171700-272829 2828800	(3.2)				34	OC-8: built in as option DCB: built in as a standard feature	DA 14-bit KEY SPLIT POINT Variable OC-8 (DCB) built in		●	●	●	

INTERFACE BOARD OPH122A


(149H122A) (pcb 052H268)

SN 171700 and higher

MAJOR CHANGES

D/A CONVERTER 14BIT

KEY SPLIT POINT PROGRAMMABLE



This board can replace 12-bit INTERFACE BOARD when PROMs of CPU board are of correct version. See right below.

Besides suffix (A, B, etc.), the PCBs occasionally bear marks "●" and/or "○" above its code number to show the edition.

● stands for 1, and ○ for 5.

Example: ○*** = 8th edition

The D/A Converter IC14 is changed from 12-bit Am6012 to 14-bit ITS80141 with this PCB version. Along with the change the following parts are also changed.

PART	From	To
Latch	LS273 (TTL, IC13)	40H273 (CMOS, IC15)
	LS175 (TTL, IC15)	40H174 (CMOS, IC13)
Multiplexer	LS175 (TTL, IC11)	40H175 (CMOS)
	4051 (IC25, IC26)	HD14051 (Hitachi only)
Flip-flop	74LS74 (IC9)	TC4013
		(SN212330-UP TC40H74)
Gate	LS02 (IC22)	TC4001

Prepare PROMs for CPU board:

A, B, C

3.1 version

or

3.2 version (inevitable when OC-8 exists)

for IC34-IC36

D (when OC-8 is built in)

3.3 or 3.4 version for IC33

Replace existing PROMs with these PROMs.

Adjust DAC circuit, referring to "4. DAC" on p.25 of this book.


SUBSTITUTING THIS BOARD FOR 12-BIT DAC BOARD

NOTES:

This interchange does not affect adjustment procedures except that the letter "PLL" are displayed in PATCH NUMBER window after -1-1-1 during FSK adjustment steps.

At the end of Computune cycle(s), defective VCO that has not "tuned-in" is indicated in MANUAL and PATCH NUMBER or PRESET buttons.

See p.39 for indicators and difference in computuning between 12-bit and 14-bit systems.






... Non connection.

IC31, VR2, L1, SW1

IC91, C45, D13, TR9

- to Panel A
- to CPU
- to Keyboard
- to Modules





Connector
 AI → to Panel A
 HI → to CPU
 IK → to Keyboard
 IM → to Modules
 M.C. ... Non-connection.

Highest Ref Des are R91, C45, D13, TR 9.

IC1: 40H175

IC10: LS240

To Keyboard Assy SK-361C

TTL IC Power supply pin

14P LS00 LS02 LS74
 1406 7407


16P LS48 LS1M LS175
 LS156 LS387

20P LS240 LS273

KEY IN A/B/C/M/P
 KEY OUT
 DATA UP
 DATA LOW
 KCV SEL
 DATE OUT
 EXT SYNTH
 TUNE

IC1: 74LS156
 IC2: 74LS157
 IC3: 74LS158
 IC4: 74LS159
 IC5: 74LS160
 IC6: 74LS161
 IC7: 74LS162
 IC8: 74LS163
 IC9: 74LS164
 IC10: 74LS165
 IC11: 74LS166
 IC12: 74LS167
 IC13: 74LS168
 IC14: 74LS169
 IC15: 74LS170
 IC16: 74LS171
 IC17: 74LS172
 IC18: 74LS173
 IC19: 74LS174
 IC20: 74LS175
 IC21: 74LS176
 IC22: 74LS177
 IC23: 74LS178
 IC24: 74LS179
 IC25: 74LS180
 IC26: 74LS181
 IC27: 74LS182
 IC28: 74LS183
 IC29: 74LS184
 IC30: 74LS185
 IC31: 74LS186
 IC32: 74LS187
 IC33: 74LS188
 IC34: 74LS189
 IC35: 74LS190
 IC36: 74LS191
 IC37: 74LS192
 IC38: 74LS193
 IC39: 74LS194
 IC40: 74LS195
 IC41: 74LS196
 IC42: 74LS197
 IC43: 74LS198
 IC44: 74LS199
 IC45: 74LS200
 IC46: 74LS201
 IC47: 74LS202
 IC48: 74LS203
 IC49: 74LS204
 IC50: 74LS205
 IC51: 74LS206
 IC52: 74LS207
 IC53: 74LS208
 IC54: 74LS209
 IC55: 74LS210
 IC56: 74LS211
 IC57: 74LS212
 IC58: 74LS213
 IC59: 74LS214
 IC60: 74LS215
 IC61: 74LS216
 IC62: 74LS217
 IC63: 74LS218
 IC64: 74LS219
 IC65: 74LS220
 IC66: 74LS221
 IC67: 74LS222
 IC68: 74LS223
 IC69: 74LS224
 IC70: 74LS225
 IC71: 74LS226
 IC72: 74LS227
 IC73: 74LS228
 IC74: 74LS229
 IC75: 74LS230
 IC76: 74LS231
 IC77: 74LS232
 IC78: 74LS233
 IC79: 74LS234
 IC80: 74LS235
 IC81: 74LS236
 IC82: 74LS237
 IC83: 74LS238
 IC84: 74LS239
 IC85: 74LS240

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z



MODULE CONTROLLER

GUIDES ON REPLACEMENT

MODULE CONTROLLER BOARD


(For early 500 units, see p.48)

When replacing OPH123 with OPH123A, be sure to proceed the following.


Check IC49 on the both PCBs (being replaced and replacement) for name. If 2101 is on the existing PCB and 5101 on the replacement, take the modification illustrated below.

When replacing Upper board or Lower only:

Adjust VR1 (NOISE LEVEL) of unchanged MOD CON board to match the noise level of new board which omits the adjustment. Reconnect R21 of unchanged MOD CON, referring to drawing to the right. This will eliminate possible loudness differences between U and L voices.



Disconnect R21 lead at negative end and solder it to the nearest ground foil.



IC49 OF MOD CON BOARD (MODIFICATION ON CPU BOARD)

(RAMs 2101 and 5101)

Below, two minor modifications (independent of RAM change) are also indicated:


Reconnection of IC37 and addition of 10UF at IC30 pin 8

Insertion of 5101 into a place previously occupied by 2101 requires pin 5 of IC23 on CPU board to be grounded. This reconnection as illustrated is to protect the data on panel control from garbled — while a control is being reset, some of other controls

are also detected as moving; in extreme case no voice would sound. This is due to the fact that two RAMs differently respond to the same timing signal.

This modification has no adverse effect on 2101.

Factory modification SN 202210-UP



MODULE CONTROLLER BOARD SN 202100 and UP
OPH123A (149H123A) (pcb 052H269)

IMPORTANT
 When replacing MOD CON BOARD or RAM IC49,
SEE PAGE 38 (P.48 for early 500 units).

CHANGE INFORMATION

(Each heading is followed by address to the circuit diagram.)

1. NOISE GENERATOR (D-H, 18-27)

IC3: from TL082 to BA662 having AGC.
 NOISE LEVEL VR1: omitted

SAMPLING SIGNAL

Previous circuit:

Only white noise is routed to S/H circuit regardless of VCO-2 RANGE position.

New circuit:

Pink noise is selected for S/H when RANGE is in LOW position.

2. D/A CONVERTER (O-R, 23)

Ladder Resistors: from discrete to resistor array

3. NOISE KILLER SWITCH (D-E, 28)

Newly attached for cutting off noise signals. Used in particular adjustments. Close this switch when step states "Place a ground to MOD CON TP-4".

4. RESONANCE SWITCH (M,33)

To emphasis regeneration to the point of oscillation. Used for factory adjustment only.

5. LFO DELAY CONTROL (R, 33)

From TR25 and TR26 to single paired-transistor TR25 to have U and L delay times synchronize with each other.

6. LFO RATE (V,33)

From TR11 and TR12 to single paired-transistor TR11. To minimize speed difference between U and L LFOs.

7. Add D29 and C95 to +B pin of IC7 (S, 36) to stabilize the supply voltage

8. Add RC filters on EXT CV lines (L, 43; S, 41; E, 35; D, 33)

To filter out noise induced into EXT CV.

9. VCO LEVEL (J, 33-34)

Apply a ground to pin 5 of IC2 through R21, previously -15V. Change resistors values in this section

To set VCO-1 and VCO-2 audio levels to an equal amount when SOURCE MIX is set at 12 o'clock position.

To have the same volume changes in VCO-1 and VCO-2 sounds, that is, the change in volume of VCO-1 when SOURCE MIX is being rotated toward VCO-1 is the same as that of VCO-2 when S.M. being toward VCO2.

10. VCA MOD (O, 38-39)

Add C97 across pins 1 and 2 of IC13

To eliminate click noises at positive or negative going transient.

11. Add TP-8 (Q, 36-37)

For factory adjustment only.


IC49, RAM 2101 and 5101 SN 202210-UP

Often, RAM 2101 is substituted by 5101 upon manufacturing or shipping replacement because of procurement problem.

RAMs of these models have different characteristics in timing response.




To make both RAMs compatible, factory modification on CPU board started with above Serial number. (See p.38 for detail.)

NOTE:
 Beside suffix (A, B, etc.), the PCBs occasionally bear marks "w" and/or "o" above its code number to show the edition stands for 1, and o for 5, example: o... 8th edition.



CHANGES, MODIFICATIONS, ADDITIONS


INVOLVED IN IMPLEMENTING DCB
(Digital Communication Bus) BOARD
pp.40-47



Holder (064H184)

DCB Connector
57-40140R (13429611)
Holder (064H153A)

Slide Switch
SSB-022-12RN (13159118)



CIRCUIT DESCRIPTION


This circuit description applies to the JP-8 with serial numbers 171700 and up where DAC changed from 12- to 14-bit version, and concentrates on computune program which is revised in line with the change.

This description makes reference to pages 6 and 7 "WIDTH" and "KCV" of the Circuit Description of First Edition issued separately.

WIDTH

P. 6 Change title to WIDTH & TUNE

The coverage of the JP-8 keyboard is expandable to 96 keys using footage selector (RANGE SWITCH). In the following, KCV and key designation are defined as below.



In this mutual arrangement any KCV (VKnx) at a key (Knx) is obtained from the equations:


$$VKnx = VKno + W(WIDTH) \times Knx \quad (1)$$

$$\text{OR } VKnx = T(TUNE) - W(84 - Knx) \quad (2)$$

where, $W = 1/12(V)$

— voltage steps per half tone


$$T = VKn84$$



In the following computuning, T is a reference voltage in calculating every KCVs to the equation (2) above.

Upon power on for the JP-8, computune program starts frequency measurements at two points with MOD.A VCO-1 by applying KCV of Kn24(3V) and VKn84(8V) to it. If the VCO output is 20 cents higher than expected pitch at 3V KCV, and 30 cents lower at 8V as shown in the figure right, the factor W is given by:

$$\frac{8 - 3(V)}{9570 - 3620(\text{cent})} = 0.084$$



Substituting 0.084 for W in equation (2) above would provide the VCO with KCVs for every keys, and the VCO will oscillate in 1V/oct steps with most of pitches slightly out of tune.

To bring each note in tune, the program first adds fine tune voltage (bias) ... $0.084 \times \frac{30}{100}(\text{cent}) = 0.0252V$ — to T. Then, finds KCVs for every notes by applying equation (2).

$$\text{Example: } VKn24 = 8.025(T) - 0.084(W) \times (84 - 24) = 2.985V.$$

When compare this WIDTH with the WIDTH determined by previous 12-bit system, the new system provides more precise resultant because of wider measurement range.

INITIAL TUNING UPON POWER ON

When the power is first turned on for the JP-8, thermally unstalbe VCO tends to oscillate on frequencies which are greatly deviating from the expected frequency so that computune circuitry will not be able to determine exact pitch error at a time. If a program encounters such a VCO, the program ceases measurement for that VCO but retains the data, then proceeds to the next VCO. After all the VCOs have been measured, the program resumes operation from the first VCO, depending on the previous data. However, the process is repeated only two times per oscillator, regardless of the frequency deviation. Properly functioning VCOs will be brought into tolerance at the second time.

Most VCOs outside tolerances after completion of the second execution might be brought closer and closer to desired pitches if the computune program is forced to repeat the operation by manual triggering of TUNE button. (See next paragraph.)


Tuning sequence is visually confirmed on flashing LEDs in the PATCH buttons.

VCO BEING MEASURED

PATCH NO.	1st cycle		2nd cycle	
	MODULE	VCO	MODULE	VCO
1	A	1	E	1
2	A	2	E	2
3	B	1	F	1
.
.
.
8	D	2	H	2

However, when one PATCH LED stays on while MANUAL LED is flashing, they are indicating failure in that VCO. The computune program cannot correct such a VCO as is indicated by a PATCH button as below, and does not proceed to the next VCO unless one of function switches is touched.

MODULE
VCO



COMPUTUNE WITH TUNE BUTTON

When the computune program is triggered manually with TUNE button (after power-on-tune), it runs only once for each VCO since the program already had data on fine tune, and drastical change in VCO frequencies is likely to occur. If the program fails to compensate frequency drift, iterative tapping of "TUNE" will bring VCO closer to correct pitch. Relying on this method is preferable only in an emergency; the cause of out of tune must be eliminated as early as possible.

KCV (INTERFACE BOARD)

P. 7 Lines 9 and 10: Delete

Lines 11-17: Reads as follows.


Each KCV data is represented in 14-bit format and is divided into two pieces—MS (most significant) 8-bit is latched by IC15 followed by LS 6-bit into IC13. DAC output has a range of 0-10V against 14 bits, thus resolution is $10V \div 2^{14}(\text{bit}) = 0.6mV$, nearly equals 0.7 cents in pitch. Durig I/V conversion in $\frac{1}{2}IC24$, CV for EXT. jack is scaled 1V/oct.

CORPECTION


CIRCUIT DESCRIPTION

P. 11: PUSH SWITCH SCANNING

Push switches (function switches with LED) are read every approximately 25ms (not 1ms). See timing chart on page 3 of the Circuit Description. LEDs are lit every 1ms when INT signal is applied from IC26 which in turn is timed by the signal generated at pin 17 of IC40. Failure of INT signal causes no LED driving signal, but has no relation to the switch reading performance.








POWER SUPPLY BOARD A, B, C




DCB BOARD

OPH220 (149H220) (pcb 052H380B)


FCN724PC50-AU/L



DCB BOARD




DCB CONNECTOR ASS'Y




DCB PIN ASSIGNMENT

PIN	DESCRIPTION	PIN	DESCRIPTION
1	RX BUSY	8	NC
2	* DATA	9	VCA UPPER
3	* CLOCK	10	VCF LOWER
4	GND	11	VCF LOWER
5	TX BUSY	12	VCO-2
6	* DATA	13	VCO-2
7	* CLOCK	14	VCO-1



DCB (Digital Communication Bus)




MODULE CONTROLLER BOARD



Circuits Changes related to DCB Board Installation






PANEL BOARD A



CPU BOARD

JUMPER 3
CAPACITOR (100P) 1

CUT JUMPER



DIAGNOSTIC PROGRAM IN PROM D

On the CPU board (of JP-8 furnished with the OC-8 or DCB board) located is IC33 (3.3D or 3.4D) which contains not only digital communication program, but also diagnostic program. The program, when executed in the TEST mode, simplifies testing and fault isolation of some of the ICs and their associated circuits listing to the right. For this program to run, the remaining PROMs (IC34-IC36) of CPU board must be of 3.2 version.

PRECAUTIONS

Allow plenty of time for warm-up (approx. 30 minutes).
If the CPU, PROMs or other circuits fail to perform their basic functions, the program will not start.

STEPS

1. Turn the JP-8 OFF.
2. To put the JP-8 into the TEST mode, either;
 - a) Turn the power ON while pressing PATCH NUMBER buttons 1 and 3.
 - or
 - b) Set SI-1 and SI-2 of the interface board to TEST, then turn the power ON.

The test program is executed in the order listed and is stopped wherever it encounters a defective IC (or a problem pertaining to a particular IC), and displays the suspected IC number in the window.

To resume the program, press any touch button. (For example, MANUAL.)

At the end of program, the window displays both the PROM D version and the DAC's bit format, for example;

```
33 12 -- 3.3D, 12-bit DAC
34 14 -- 3.4D, 14-bit DAC
```

1C 36	IC 3 6	PROM A
1C 35	IC 3 5	PROM B
1C 34	IC 3 4	PROM C
1C 33	IC 3 3	PROM D
1C 06	IC 6	RAM
1C 05	IC 5	RAM
1C 20	IC 2 0	RAM
1C 19	IC 1 9	RAM
1C 04	IC 4	RAM
1C 18	IC 1 8	RAM
1A 00	Module A VCO-1, KGV=0, etc.	
1A 01	IC14, IC15	D/A MSB
1A 02	IC14, IC15	D/A B2
1A 03	IC14, IC15	D/A B3
1A 04	IC14, IC15	D/A B4
1A 05	IC14, IC15	D/A B5
1A 06	IC14, IC15	D/A B6
1A 07	IC14, IC15	D/A B7
1A 08	IC14, IC15	D/A B8
1A 09	IC14, IC13	D/A B9
1A 10	IC14, IC13	D/A B10
1A 11	IC14, IC13	D/A B11
1A 12	IC14, IC13	D/A B12
1A 13	IC14, IC13	D/A B13
1A 14	IC14, IC13	D/A B14

NOTES FOR TABLE

1. 3.3D doesn't check IC5 and IC6.
2. Because of misprogramming, 3.3D will display these IC numbers in reverse order. If displayed, read; IC20 as IC19, and IC19 as IC20.
3. Output from Module A VCO-1 is applied to the DAC Check. Consequently, if this VCO fails, all the remaining tests will not be performed.
Push any button, and the version with 00 is displayed.
4. IC13 and IC15 on the 12-bit interface board are inversely numbered.
Read; IC13 as IC15, and IC15 as IC13.
5. If the 13-bit line malfunctions in the 14-bit D/A, the CPU concludes that the D/A is 12-bit, and skips the 13th and 14th bits.

DESCRIPTION OF CONNECTION CABLES

In the below, SN refers to Serial Number of OP-8.

• For serial numbers up to and including SN220269, the OP-8 was provided with Flat Cable H146 for connecting the OP-8 to the JP-8.

• Effective from serial number SN230270, the OP-8 unit can be connected to the JP-8 through the Flat Cable H146 provided with the OC-8 unit, or to the JUNO-60 through the DCB Cable H165 provided with the OP-8 unit.

• Roland provides not only DCB Cable H165 but also DCB Cable H172 for interconnecting JP-8 or JUNO-60 as shown here.





• DCB Cable H172 is uni-directional, with the signal-flow direction shown by the arrow on the connector.

When connecting two JUNO-60 or JP-8 units, be sure to connect the cable so that the arrow points away from the JUNO-60 or JP-8 unit to be played, and towards the JUNO-60 or JP-8 unit to be controlled.


Also, when controlling the JUNO-60 with the OP-8, DCB Cable H172 can be used to connect the OP-8 to the JUNO-60.

Be sure to connect the cable so that the arrow points away from the OP-8 and towards the JUNO-60. Otherwise, the JUNO-60 may operate incorrectly.


On the other hand, DCB Cable H165 is a bi-directional cable in which sent from the TX-terminal on a unit returns to the RX-terminal on the unit, causing regeneration.




DCB CABLE H172 (Length: 3m)



DCB CABLE H165 (Length: 1.5m)



DCB Pin Configurations



(View from Rear Panel)

- | | | |
|----------|------|---------------|
| 1. BUSY |) RX | 8. UNREG |
| 2. DATA | | 9. VCA LOWER |
| 3. CLOCK | | 10. VCA UPPER |
| 4. GND | | 11. VCF LOWER |
| 5. BUSY |) TX | 12. VCF UPPER |
| 6. DATA | | 13. VCO-2 |
| 7. CLOCK | | 14. VCO-1 |

APPENDIX

PCB EDITION

Dot and circle above PCB code are indicative of edition; "•" stands for 1, and "o" for 5. Example: o• = 6th edition.

Illustrated on pp. 48-50 is information on MODULE and MODULE CONTROLLER Boards mounted on the JP-8 models with serial numbers up to 090599. For circuit diagram, refer to p.11 or p.12 although some small discrepancies may exist.

CAUTION ON REPLACEMENT OF PCBs IN THIS SECTION

Although terminal for terminal compatible, when mix used, new and old PCBs process signals in slightly different way, reproducing voices that are distinguishable from each other. Therefore, when replacing MODULE or MOD CON board in this section, use a set of PCBs of the same edition group as described below.

NOTE: Replacement of MODULE board can be made independently of MOD CON board, and vice versa.

MODULE CONTROLLER BOARD	MODULE BOARD	When replacements for MOD CON are of group B, check IC49 (RAM) for name. If it is 5101, see p.38 for necessary modification.
group A	group B	
o•52H269 or o52H269	o52H269-up o52H270-up	

Listing below are descriptions of surface mounting, jumper wire, and conductive foil cut made on the MOD COM boards up to the abovementioned serial numbers, shown on the next page.

ABBREVIATIONS

C-pattern cut Di-diode R-resistor J-jumper M-mylar cap

Serial numbers


1B-050199 2A-050200 2B-060299 3A-060300 4A-070400 5A-080500 5B-090599

No.	Part	SN	No.	Part	SN
1	C	up to 2B	10	R	5A-up
2	C	3A-5B	11	R	3A-5B
3	C				
4	D	up to 1B	12	D 2xC	3A-5B
5	R	3A-5B	13	M.R.C	2A-up
6	J	up to 2B	14	J.C	4A-5B
7	J.C	4A-5B	15	M	4A-5B
8	J	5A-up	16	J.C	2A-5B
9	R	up to 2B	17	M	3A-5B

MODULE CONTROLLER BOARD

(PCB o•52H269, o52H269, o52H269, o52H269)

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U



PARTS LIST CHANGE

PART. SERIAL NO.	FROM	TO	PART NO.
INTERFACE BOARD			
SN 171700 PCB Ass'y PCB D/A Converter (IC14) Latches	OPH122 052H268 Am6012 LS273 LS175 LS175 TC4051	OPH122A 052H268 ITS80141 TC40H273 (IC15, CMOS) TC40H174 (IC13, CMOS) TC40H175 (IC11, CMOS) HD 14051 (CMOS) (Hitachi only) TC4001 4013BP (CMOS)	149H122A 15219127 15159507 15159511 15159512 15159113H0
IC25, IC26			
IC22 IC9	LS02 74LS74		15159101T0 15159105T1
SN 212330 IC9	4013 ICs: ALL INCOMPATIBLE	TC40H74P	15159510

CPU BOARD

SN 171700 IC34-IC36	μPD2716 (version 1.0)	μPD2716-JP8-A (IC36) μPD2716-JP8-B (IC35) μPD2716-JP8-C (IC34)	15179609 (version 3.x) 15179610 (version 3.x) 15179611 (version 3.x) (version 3.x = 3.1 or 3.2)
------------------------	--------------------------	--	--

MODULE CONTROLLER BOARD

SN 202100 PCB Ass'y PCB IC3 Ladder Resistor TRs, 11, 12, 25 TR26 Switches	OPH123 052H269 TL082 Discrete 2SA1015 2SC1815	OPH123A 052H269 BA662A R601611 (RA6) 2SA798-G (TR11) 2SA798-G (TR25) SSB212 (SWs 1, 2)	149H123A 15229802 15119108 15119108 13159123
SN 202210 IC49 RAM	2101 only (Compatible with minor modification. See pp. 37, 38.)	2101 or 5101	15179303

PANEL BOARD F

LED (display) SN 242750	LN526RA	LN5260A	15029409
(Compatible but different in brightness and color; mix use should be avoided.)			

PANEL BOARD E PANEL BOARD G

SN 272850 Switches (LEDs)	KHC11901 (AR3432S)	KHC11026 (SEL2210R)	13169610
(Switch proper remains unchanged. The new LED has better off-axis luminous density. Mix use should be avoided.)			

SN 282880-UP JP-8 WITH DCB BOARD

PART NAME	FROM	TO	PART NO.
Top Panel Chassis (jack) Holder (rear)	Panel H78B Chassis H116	Panel H78C Chassis H116A Holder H184	072H078C 061H116A 064H184

DCB BOARD

PCB Ass'y Holder IC1 IC3 Flat Cable Flat Cable H126 (INTFACE-CPU)	OPH220 Holder H185 74LS21 μPD8251AC Flat Cable H213 (INTERFACE-CPU-DCB)	149H220 (pcb 052H380B) 064H185 15169350 15179112 053H213
DCB Connector Holder Slide Switch	57-40140R Holder H153 SSB-022-12RN	13429611 064H153 13159118

CPU BOARD

IC33	μPD2716-JP8-D	15179612 (version 3.4)
------	-------	---------------	------------------------

In order to expedite delivery of products or because of procurement problem, the factory is occasionally forced to make minor substitution of ICs. Such substitutions will work satisfactorily and compatible with the initial IC unless otherwise noted in related sections (circuit diagram, parts list, etc.).




PART NUMBER

Usually, equivalent semiconductors are assigned to the same part number as initial component with two-letter suffix identifying the manufacturer. For example, TO - Toshiba, ZO - Motorola. In ordering such ICs, uncertain suffix can be omitted from the part number, and the factory will supply suitable ones with notes or cautions, as necessary.


Parts on the PARTS LIST	Equivalent
TC4052BP	HD 14052BP
TC4051BP	HD 14051BP
TC40175BP	μPD4175BC
μPD2101ALC	M5L2101AP-4 μPD5101LC M5L5101LP-1
μPD780C-1	LH0080A
μPD2716D	M5L2716K MB8516
μPD444C	M58981P-45
μPD2114C	M5L2114LP
μPD8253C	M5L8253P-5
TL082CP	NJM082DR μPC4082C
74LS Series	M74LS series
74 . . Series (exp. 7406	M532 . . series M53206)

MODULE BOARD OPH124

SN 030100-090599 (pcb 052H270 or 052H270)



PATTERN-CUTS ON MOD CON



PATTERN-CUTS & SURFACE-MOUNTINGS ON MOD CON

