

Technical Bulletin

Amateur Division
AM-080304-EU10



IC-703

Keyer update

The IC-703 will sometimes lock in TX mode when operating in CW mode with an external key. To solve this problem, run a solder “jumper” from the key ground to the ground on the bottom of the main board board, bypassing the chokes as indicated below.

Install solder “jumper” here, between key ground and board ground.

