


KENWOOD TS-940

EXPANDED RF

1. Disconnect the power and antenna.
2. Remove case screws and case.
3. Locate Digital Unit B. This is the board that is in the enclosure where the VS-1 is mounted. Digital Unit B is the board closest to the Front Panel.
4. Cut Diodes D130 & D135. Located near IC-109.
5. Reassemble the radio
6. Turn the radio on, Press and Hold the [A=B] Switch and turn off and back on the radio.

TS-940



Caution

These modifications have not been tested. The Author, Publisher and all other parties takes NO responsibility or liability for any damage or violation resulting from these modifications. Performing any modification may be a Violation of FCC Rules and will void the warranty of the radio. Use of any modified radio may be a violation of FCC rules. If you have any doubts, DO NOT PERFORM THIS MODIFICATION.

© 1991 artsci inc. all rights reserved. (818) 843-4080 Fax: (818) 846-2298