



NOTES -

L1 - 52 Turns #26 Enameled wire on a T50-2 core
Set Vtune to 1 volt and remove turns until output
frequency is between 3.08 and 3.14 MHz.

Use NPO capacitors for C7, C9 and C16

Assemble the circuit so that the components are rigid with good mechanical stability.

FIGURE 4

VFO BOARD SCHEMATIC DIAGRAM	
Document Number WA2EUJ 40M XCVR - TAK-40 VERSION 1.0	Rev 1.0
Date: Sunday, July 29, 2007	Sheet 5 of 5