

This obsolete manual file is provided as a courtesy to you by Ten-Tec, Inc.

Ten-Tec's service department can repair and service virtually everything we have built going back to our first transceivers in the late 1960's. It is our ability to continue offering service on these rigs that has led to their re-sale value remaining high and has made a major contribution to our legendary service reputation.

Printed and bound copies of all manuals are available for purchase through our service department if you would prefer not to use this copy as your transceiver manual.

We can repair or service your Ten-Tec equipment at our facility in Sevierville, TN. We also offer support via telephone for all products via during usual business hours of 8 a.m. to 5 p.m. USA Eastern time, Monday through Friday. We have a large supply of parts for obsolete products. Repairing a transceiver or amplifier yourself? Contact us for parts pricing information.

Service department direct line: (865) 428-0364
Ten-Tec office line: (865) 453-7172
Service department email: service@tentec.com
Address: 1185 Dolly Parton Parkway, Sevierville, TN 37862 USA

We have found it is most effective for us to help you troubleshoot or repair equipment with a consultation via telephone rather than by email.

Suggested contact methods are:

Troubleshooting or repairing equipment – call (865) 428-0364 Other inquiries – call (865) 428-0364 or email service@tentec.com

THANK YOU AND 73 FROM ALL OF US AT TEN-TEC

RX-321 DSP Receiver

Ten-Tec, Inc 1185 Dolly Parton Parkway Sevierville, TN 37862



Rx-321 Receiver


The RX-321 receiver was deisgned by Ten-Tec for OEM applications. It was manufactured by Ten-Tec under agreement with third parties and never produced with the Ten-Tec brand name. The RX-321 is based on the RX-320D receiver. Addional circuitry to support integration with a transmitter was added, along with an RF preselector and 600 Ohm audio output.


GENERAL DESCRIPTION


The Rx-321 is a general coverage receiver capable of receiving AM, SSB, and CW signals from 100kHz to 30MHz. The receiver is controlled by an external computer via a serial connection (see www.rfsquared.com to download the Rx-320D PC-GUI and programmers reference guide which will provide more information on controlling and programming the Rx-321). The Rx-321 is powered from any DC power supply operating in the range of 12-28VDC and capable of supplying at least 800mA of current (please observe the correct polarity as shown on rear panel). The antenna connection is designed for a 50-ohm antenna and is an SO239 type connector. The speaker connection is also available on the rear panel and is clearly marked. Please connect a 4 to 8 ohm speaker (again, please observe the correct polarity as shown). Finally, there is also a 9-pin connector on the rear panel labeled REMOTE. This connector provides an optional 600ohm audio output and a mute pin that allows the AGC circuit to be turned off when used with an external transmitter (this keeps the external transmitter from loading up the AGC and causing receive recovery problems). Please see the schematic description of the 9-pin connector labeled remote for the pin out of this connector and DC voltage levels to apply to the mute pin when using an external transmitter.


SCHEMATIC DESCRIPTION


The receive signals from the antenna pass through one of eight preselector filters that are selected based on the band in which the receiver is tuned. From there, the selected signals go through a preamp stage before passing through an IF notch filter and on to the first mixer. The first mixer translates the tuned signal to 45MHz. The 45MHz signal then passes through a 45MHz IF filter and gain stage before going to the second mixer. The second mixer translates the signal to 455kHz. The 455kHz signal then pass through a 455kHz IF filter and gain stage before going to the third mixer. The third mixer translates the signal to 12kHz where the signal is then passed on to the AD1847 codec and ADSP-2101 DSP processor for decoding and translating to a low-level audio signal. The low level audio signal is then passed on to an audio amplifier which amplifies the signal and passes it on to the external speaker connector provided at the rear panel. An external speaker can be connected and the received signal can be heard.




















OMNI-VII. It's that simple.


So sit back in your chair and relax. The Omni-VII not only has top of the line receiver performance and everything else you need in a high-end tranceiver -- it's also very easy to use. Spend your time on the air instead of reading the operator's manual. For complete information on the Omni-VII and our Amateur Radio product line, visit our website or call (800) 833-7373 for our current catalog.


Proudly made in Sevierville, Tennessee USA





1185 Dolly Parton Pkwy., Sevierville, TN 37862. Sales: 800-833-7373 M-F 8:00-5:30 (Eastern Time) sales@tentec.com. Office: (865) 453-7172. FAX: (865) 428-4483. Service: (865) 428-0364 M-F 8:00-5:00 (Eastern Time), service@tentec.com. We accept Visa, MC, American Express and Discover.











RF BOARD

GW320 Revised: December 2, 1999

Revision:

Bill Of Materials December 16, 1999 11:12:13 Page 1

Item Quantity Reference Part

- 1 16 C1,C3,C18,C75,C76,C77, .001MF C82,C88,C94,C148,C151, C152,C153,C168,C170,C184 2 2 C2,C108 220PF 3 56 C4,C5,C6,C7,C13,C14,C16, .1MF C17,C21,C22,C25,C28,C34, C36,C37,C38,C39,C44,C72, C74,C84,C87,C100,C103, C104,C105,C107,C110,C111, C116,C117,C118,C123,C124, C128,C129,C134,C135,C139,
 - C140,C144,C145,C146,C149, C150,C155,C159,C171,C176,
 - C185,C187,C188,C189,C190,
 - C191,C192
- 4 21 C8,C10,C12,C15,C19,C20, .01MF C24,C49,C50,C51,C54,C55, C56,C57,C58,C66,C67,C70, C83,C89,C106
- 5 7 C9,C68,C80,C109,C113, 68PF C137,C163
- 6 7 C11,C52,C53,C85,C162, 470PF C182,C183
- 7 5 C23,C78,C91,C95,C99 33/16
- 8 7 C26,C112,C119,C125,C130, 1/20 C136,C141
- 9 6 C27,C31,C32,C33,C90,C172 10/16
- 10 1 C29 33PF
- 11 1 C30 4.7/50
- 12 5 C35,C47,C98,C101,C154 10PF
- 13 1 C40
- 56PF 270PF
- 15 1 C42

14

82PF

100PF

- 16 4 C43,C114,C121,C156
- 17 1 C45 10-60PF
- 18 1 C46

2 C41,C132

- 18PF
- 19 2 C48,C164
- **22PF**



20	2	C59,C61	.0082MF
21	1	C60	.022MF
22	4	C62,C63,C64,C6	
23	2		100/35
24	1	C71	2.2PF
25	2	C79,C81	39PF
26	1	C86	5-30PF
27	1	C92	.1MFD
28	1	C93	.47MFD
29	1	C96	.01MFD
30	1	C97	.047MFD
31	1	C102	4.7PF
32	1	C102 C115	15PF
33	3	C120,C122,C161	
34	4	C126,C122,C101	
35	2	C120,C131,C133 C127,C142	150PF
36	1	C127,C142	560PF
37	2	C156 C167,C143	820PF
38	3	C147,C143	
39	3	C147,C100,C181	
40	1	C157,C100,C103	.0039MF
41	7		
42			BA679
42	2 2	*	
43 44		,	BAT68_04
44 45	2	D12,D13 D14	RLS135 MMSZ5231BT1
	_		
46	11		20,D21,D22, BA982
47	4	D23,D24,D25,D26	
48	1	D28,D29,D30,D3	RL CMR1-10
49	2	D34,D35	6.8V
50	1	FL1	45MONO
	_		LTW33-455D
51 52	1	FL2	
52 53	2	J1,J2 L1	TMP
			.25UH
54 55	3	L2,L11,L49	.12UH
55 56	1	L3	BIF
56	16	, , ,	,L31,L32, 100UH
		L33,L34,L50,L52,I	_39,L00,
57	_	L67,L68,L72,L73	271111
57 59	3	L5,L6,L38	.27UH
58 50	2	L7,L8	15UH
59	3		.56UH
60 61	3	, ,	.47UH
61	1	L12	.19uH
62	1	L13	.342uH



```
63
     2 L14,L15
                         .047UH
64
     1
        L16
                       .15UH
65
     1
        L17
                       .1UH
66
     2 L18,L25
                         1.0UH
67
     1
       L19
                       1.5UH
68
     1
       L20
                       25UH
69
     7 L21,L22,L23,L24,L40,L46, 4.7UH
      L47
70
     3 L27,L42,L64
                           3.9UH
     5 L35,L37,L57,L58,L61
71
                              1UH
72
     2 L36,L43
                         6.8UH
73
     2 L39,L69
                         2.2UH
74
     1
       L41
                       39UH
75
       L44
     1
                       47UH
76
     1
       L45
                       8.2UH
77
     2
                         .18UH
       L51,L63
78
     2 L53,L54
                         .33UH
79
     1
       L60
                       1.8UH
80
     1
        L62
                       1.2UH
81
     1
       L65
                       2.7UH
82
     1
       L71
                       820UH
83
       P1
                       CONNECTOR DB9
     1
84
     16 Q1,Q2,Q4,Q6,Q8,Q18,Q20, MMBT3904LT1
       Q21,Q22,Q23,Q24,Q26,Q27,
       Q28,Q31,Q32
85
     12 Q3,Q12,Q13,Q14,Q15,Q16, MMBFJ310LT1
       Q17,Q19,Q25,Q33,Q34,Q35
86
        O5
                       BF998
     1
87
     4 Q7,Q29,Q30,Q36
                             MMBT3906LT1
88
     2 R1,R3
                        8.2K
89
     2 R2,R32
                         6.8K
90
     12 R4,R5,R46,R47,R64,R68,
                                10K
       R70,R75,R77,R92,R96,R156
91
     9 R6,R16,R17,R34,R35,R38, 47K
       R66,R76,R93
92
     40 R7,R11,R12,R22,R23,R26, 100
       R29,R30,R31,R33,R37,R48,
       R49,R53,R62,R65,R72,R78,
       R80,R81,R82,R89,R94,R95,
       R102,R103,R110,R115,R118,
       R119,R120,R123,R124,R125,
       R126,R127,R128,R144,R145,
       R146
93
     6 R8,R18,R71,R97,R99,R154 4.7K
94
     5 R9,R14,R51,R100,R157
95
     9 R10,R85,R107,R108,R109, 47
```



	R	111,R112,R1	13,R122
96	5	R13,R21,R7	3,R79,R135 1.0K
97	4	R15,R24,R6	7,R69 150
98	10	R19,R25,R1	14,R116,R117, 330
	R	R121,R136,R1	.37,R150,R152
99	1	R20	1.0M
100	2	R87,R27	3.3K
101	1	R28	470
102	2	R36,R61	100 TRIM
103	1	R50	2.2K
104	1	R52	100K
105	9	R55,R56,R5	57,R58,R59,R74, 1.5K
	R	90,R91,R98	
106	2	R63,R88	220
107	1	R83	82K
108	1	R84	680K
109	1	R86	10
110	1	R101	27
111	2	R104,R106	1K PCPOT
112	1	R105	10M
113	3	R147,R148,	R149 33
114	1	R151	15
115	3	R153,R155,	R158 1K
116	1	SP1	SPARK
117	1	S 3	2AMP
118	2	S4,S5	4AMP
119	6	T1,T2,T5,T	7,T9,T10 3BAL
120	2	T3,T4	455IF
121	1	T8	2BAL
122	2	U1,U2	TLO82
123	1	U3	600 XF
124	1	U4	74LS390
125	1	U5	NJM7810FA
126	1	U6	MC145170
127	1	U7	MC7805CD2T
128	1	U8	4.67MHz
129	1	U9	14.8475MHz
130	1	U10	A6810XLW



DSP BOARD

DSP SHORTWAVE RADIO Revised: September 30, 1999

Revision:

Bill Of Materials September 30, 1999 15:08:31 Page 1

Item Quantity Reference Part Ten-Tec Part Number

_

```
30103
1
     1
        R13
                        1
2
     2
                          3.3
        R18,R17
                                   30109
3
     1
        R19
                        68 SM
                                   30648
4
     1
        R3
                       100 SM
                                   30650
5
     1
        R27
                        1k SM
                                   30662
6
     3
        R5,R6,R12
                          4.7k SM
                                       30670
7
     4
        R4,R11,R14,R28
                             10k SM
                                         30674
     1
                       100k SM
8
        R2
                                    30686
9
     1
        R15
                        470k SM
                                    30694
                        RFC
        L2
10
     1
                                  21179
11
     1
        U2
                        LM7805
                                     25095
12
     1
        U11
                        TDA2611A
                                       25299
13
     1
        D2
                        5.1v SM
                                    28127
     2
14
        J1.J4
                        MT2
                                   35065
15
     1
        J6
                       MT3
                                  35066
16
     2 J5,J2
                        MT4
                                   35067
17
     4 C12,C13,C32,C33
                              18pF SM
                                           23465
18
     1 C27
                        220pF SM
                                     23478
19
     1 C18
                        560pF SM
                                     23483
20
     23 C1,C2,C3,C4,C5,C8,C9,C10, .1uF SM
                                               23488
       C11,C15,C16,C28,C29,C37,
       C41,C43,C45,C46,C47,C48,
       C51,C52,C53
21
     2 C30,C19
                          .33uF FILM
                                        23329
22
     5 C14,C26,C31,C34,C35
                                1uF
                                          23264
23
     1
        C39
                        4.7uF
                                   23310
24
     3 C6,C36,C44
                            10uF
                                      23266
25
     1
        C40
                        33uF
                                   23308
                                   23189
26
     1
        C7
                        100uF
        C21
27
     1
                        220uF
                                   23202
28
      1
        C42
                        470uF
                                   23228
29
        U3
                                   25394
     1
                        00 SM
30
                                    25412
     1
        Q3
                        2N7002
31
     1
        Y1
                                     48209
                        16.66MHz
32
     1
        Y2
                                      48239
                        24.576MHz
33
        U6
                        74HC14 SM
                                      25403
```



34	1	U5	74HC574 SM 25404
35	1	U7	93LCS66 SM N/A
36	1	U10	AD1847-PLCC 25402
37	1	U8	ADSP-2101 KP66 25411
38	1	U4	AT27C512 25329
39	1	L1	BEAD 21027
40	1	P1	CONNECTOR DB9 35242
41	1	U1	MAX232 SM 25410
42	1	D1	MMSD914 28124
43	1	J3	TMP 35225


DC DISTRIBUTION BOARD

Revised: October 4, 1999

Revision:

Bill Of Materials October 4, 1999 11:45:52 Page 1

Item	Qua	ntity Reference	Part Ten-Tec Part Number
1	1	L1	RFC 21179
2	1	U2	LM7805 25095
3	1	U1	LM7810 25400
4	1	D1	6A10 28098
5	2	J3,J2	MT3 35066
6	1	C1	.1uF 23261
7	1	C4	10uF 23266
8	1	C3	100uF 23189
9	1	C2	1000uF AX 23042
10	1	J1	12-28v 35065
11	1	S1	POWER 35065



This obsolete manual file is provided as a courtesy to you by Ten-Tec, Inc.

Ten-Tec's service department can repair and service virtually everything we have built going back to our first transceivers in the late 1960's. It is our ability to continue offering service on these rigs that has led to their re-sale value remaining high and has made a major contribution to our legendary service reputation.

Printed and bound copies of all manuals are available for purchase through our service department if you would prefer not to use this copy as your transceiver manual.

We can repair or service your Ten-Tec equipment at our facility in Sevierville, TN. We also offer support via telephone for all products via during usual business hours of 8 a.m. to 5 p.m. USA Eastern time, Monday through Friday. We have a large supply of parts for obsolete products. Repairing a transceiver or amplifier yourself? Contact us for parts pricing information.

Service department direct line: (865) 428-0364
Ten-Tec office line: (865) 453-7172
Service department email: service@tentec.com
Address: 1185 Dolly Parton Parkway, Sevierville, TN 37862 USA

We have found it is most effective for us to help you troubleshoot or repair equipment with a consultation via telephone rather than by email.

Suggested contact methods are:

Troubleshooting or repairing equipment – call (865) 428-0364 Other inquiries – call (865) 428-0364 or email service@tentec.com

THANK YOU AND 73 FROM ALL OF US AT TEN-TEC