

TECHNICAL LIBRARY

Model: FT-897

File Nr.:	FT897.doc	Serial Number Range:	All
Date of issue:	August 30, 2002	Page:	1

(X=Jumper)

Type	TX Frequency Range			RX Frequency Range			JUMPER (J10**)						Remarks	
	HF	VHF	UHF	HF	VHF	UHF	O1	O2	O3	O7	O8	O9	FM CH step	RPT Shift
B1	BAND 1	144-146	430-440	0.1-30/50-54/87.5-108	144-146	430-440	X	X	X	X	X		12.5/25 kHz	0.1/0/0.6/7.6 MHz
B2	BAND 1	144-146	430-440	0.1-33/33-56/76-108	118-164	420-470	X	X			X		12.5/25 kHz	0.1/0/0.6/7.6 MHz
B3	BAND 2	137-164	420-470	0.1-33/33-65/76-108	118-164	420-470	X				X		12.5/25 kHz	0.1/0/0.6/7.6 MHz
C1	BAND 3	144-146	430-440	0.1-30/50-54/87.5-108	144-146	430-440	X	X	X		X		12.5/25 kHz	0.1/0.5/0.6/1.6 MHz
C2	BAND 3	144-146	430-440	0.1-33/33-56/76-108	118-164	420-470	X	X			X		12.5/25 kHz	0.1/0.5/0.6/1.6 MHz
C3	BAND 2	137-164	420-470	0.1-33/33-56/76-108	118-164	420-470	X				X		12.5/25 kHz	0.1/0.5/0.6/1.6 MHz
D1	BAND 4	144-146	432-438	0.1-30/50-54/87.5-108	144-146	432-438	X	X	X	X	X		12.5/25 kHz	0.1/0/0.6/1.6 MHz
D2	BAND 4	144-146	432-438	0.1-33/33-56/76-108	118-164	420-470	X	X		X	X		12.5/25 kHz	0.1/0/0.6/1.6 MHz
E1	BAND 5	144-146	430-440	0.1-30/50-54/87.5-108	144-146	430-440	X	X	X			X	12.5/25 kHz	0.1/0/0.6/1.6 MHz
E2	BAND 5	144-146	430-440	0.1-33/33-56/76.0-108	118-164	420-470	X	X				X	12.5/25 kHz	0.1/0/0.6/1.6 MHz
E3	BAND 2	137-164	420-470	0.1-33/33-56/76.0-108	118-164	420-470	X					X	12.5/25 kHz	0.1/0/0.6/1.6 MHz

BAND	160 m	80 m	40 m	30 m	20 m	17 m	15 m	12 m	10 m	6 m
1	1.815 - 1.890	3.500 - 3.800	7.000 - 7.100	10.100 - 10.150	14.000 - 14.350	18.068 - 18.168	21.000 - 21.450	24.890 - 24.990	28.000 - 29.700	50.000 - 52.000
2	1.800 - 2.000	3.500 - 4.000	7.000 - 7.500	10.000 - 10.500	14.000 - 14.500	18.000 - 18.500	21.000 - 21.500	24.500 - 25.000	28.000 - 30.000	50.000 - 54.000
3	1.800 - 2.000	3.500 - 3.800	7.000 - 7.100	10.000 - 10.150	14.000 - 14.350	18.068 - 18.168	21.000 - 21.0450	24.890 - 24.990	28.000 - 29.700	50.000 - 52.000
4	1.820 - 1.850	3.500 - 3.800	7.000 - 7.100	10.100 - 10.150	14.000 - 14.350	18.068 - 18.168	21.000 - 21.450	24.890 - 24.990	28.000 - 29.700	50.200 - 52.000
5	1.810 - 1.850	3.500 - 3.801	7.000 - 7.100	10.100 - 10.150	14.000 - 14.350	18.068 - 18.168	21.000 - 21.450	24.890 - 24.990	28.000 - 29.700	50.200 - 51.200

Reset:

Press and hold [F] and [V/M] keys at the same time then turn power on.

Strictly confidential information, not for distribution.