

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE									TUBE TYPE									TUBE TYPE								
Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.		Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.		Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	
OA3	50 38	*70	2	11	3	5	1		1DN5	2 41	54 75	7 1	12 12	6 4	1 1		2BA2	2 40	88 52	4 5	12 12	1 1	1 1			
*Normally shows short on position 11. *Normally shows grid emission.									1DY4	1 41	*24	4 3	2 2	6 6	1 1		2BJ2	2 24	52							
OA3A	50 38	*70	2	11	3	5	1		*Normally shows short position 1-7.									2BN4	2 41	*33	4 3	2 7	1 1			
*Normally shows short on position 11. *Normally shows grid emission.									1F1	1 41	58 7	1 5	6 6	1 1		*Normally shows short position 1-6.										
OB3	50 38	*69	2	11	3	5	1		1F2	1 41	55 7	1 5	6 6	1 1		2BU2	2 45	*80	1 12	12 10	1 1					
*Normally shows short on position 11. *Normally shows grid emission.									1F3	1 41	55 7	1 5	6 6	1 1		*Tube good if it reads 30 or more.										
OC3	50 38	*85	2	11	3	5	1		1F5	2 38	48 7	2 12	5 5	1 1		2C51	6 39	29 9	1 12	3 3	1 1					
*Normally shows short on position 11. *Normally shows grid emission.									1F7	2 38	54 7	2 12	10 10	4 1		2CN3A	2 32	30								
OC3A	50 38	*85	2	11	3	5	1				67 7	2 12	5 5	1 1		2CW4	2 43	*87	10 12	12 2	1 1					
*Normally shows short on position 11. *Normally shows grid emission.									1FD1	1 41	58 7	1 12	6 6	1 1		*For grid emission, Turn D Switch to position 4.										
OD3	50 38	*99	2	11	3	5	1		1FD9	1 41	56 7	1 12	6 6	1 1		2CY5	2 1	54								
*Normally shows short on position 11. *Normally shows grid emission. *Tube good if it reads 60 or more.									1G3	1 32	55					2D21	6 41	32 4	3 5	1 1	1 1					
OD3A	50 38	*99	2	11	3	5	1		1G6	1 38	55 7	2 12	5 5	1 1		2DL4	2 39	*85	4 5	7 8	1 1					
*Normally shows short on position 11. *Normally shows grid emission. *Tube good if it reads 60 or more.									1H2	1 24	58					*Normally shows short position 1-3-6-9.										
OZ4	6 31	8					1 2		1H5	1 38	55 7	2 12	10 10	1 1		2DS4	2 43	*87	10 12	12 2	1 1					
IA3	2 41	*70	7 1	2 6	1 1			1H6	2 38	54 7	2 12	6 6	1 1		2DX4	2 41	*62	3 4	1 7	1 1						
*Normally shows short on position 5-11.									1J3	1 32	88					*Normally shows short position 2-6.										
IA5	2 38	53 7	2 12	5 7				1J6	2 38	53 7	2 12	4 4	1 1		2DY4	2 41	*24	4 3	2 6	1 1						
IA7	2 38	54 7	2 12	5 1				1K3	1 32	90					*Normally shows short position 1-7.											
IA8	1 41	54 7	1 12	4 1				1L4	2 41	52 7	1 5	6 6	1 1		2DZ4	2 41	*31	3 4	6 2	1 1						
IA6	1 41	54 7	1 12	4 1				1L6	2 41	56 7	1 12	4 1		*Normally shows short position 1-7.												
IA6	1 41	48 7	1 12	4 1				1LA4	2 37	53 8	1 12	6 6	1 1		*Normally shows short position 4-6.											
IA6	1 41	48 7	1 12	4 1				1LA6	2 37	58 8	1 12	4 1		2EA5	2 1	80										
IA6	1 45	*99	1 12	10 1				1LB4	2 37	53 8	1 12	6 6	1 1	2EG4	2 43	*72	10 12	12 2	1 1							
IA6	1 41	50 7	1 5	6 1				1LC5	1 37	54 8	1 5	6 6	1 1	*For grid emission turn D switch to position 4.												
IA6	1 41	58 7	1 12	6 1				1LC6	2 37	59 8	1 12	4 1		2EN5	2 41	35 3	4 12	2 1	1 1							
IA6	1 41	58 7	1 12	6 1				1LD5	2 37	53 8	1 12	6 6	1 1	35 3	4 12	7 1										
IA6	1 41	58 7	1 12	6 1				1LE3	1 37	63 8	1 12	4 1		2ER5	2 41	33 4	3 1	2 1	1 1							
IA6	1 41	58 7	1 12	6 1				1LG5	2 37	50 8	1 5	6 6	1 1	2ES5	2 41	33 4	3 1	2 1	1 1							
IA6	1 40	*100	5 4	12 1	1 1			1LH4	2 37	52 8	1 12	6 6	1 1	2EV5	2 1	57										
*Tube good if it reads 20 or more.									1LN5	2 37	50 8	1 5	6 6	1 1	2FH5	2 41	33 4	3 1	2 1	1 1						
IA6	1 32	95						1N2-A	1 32	53					2FS5	2 1	99									
IA6	1 24	93						1N5	2 38	53 7	2 12	10 10	1 1	2FQ5	2 41	33 4	3 1	2 1	1 1							
IA6	1 39	95	1 9	12 10	1 1			1P5	2 38	53 7	2 12	10 10	1 1	2FQ5A	2 41	31 4	3 1	2 1	1 1							
*Connect two leads from 1AY2 bottom pins to pin holes No. 1 and 9 of Socket No. 39.									1P10	3 41	*48	7 1	5 3	1 1	2FV6	2 1	54									
IB3	1 32	55						*Normally shows short position 2-6.									2FY5	2 41	33 4	3 1	2 1	1 1				
IB7	1 38	55 7	2 12	5 1				1P11	3 41	45 7	1 5	6 6	1 1	2GK5	2 41	25 4	3 1	2 1	1 1							
IB2	1 24	57						1Q5	2 38	40 7	2 12	5 1		2GU5	2 41	27 3	4 2	1 1	1 1							
IB2	1 40	*75	4 5	1 10	1 1			1R4	2 37	60 8	1 12	4 1		2GW5	2 41	29 3	4 6	2 1	1 1							
*Insert leads into pins 4 & 5 of socket 40.									1R5	2 41	53 7	1 5	4 1		2HA5	2 5	56									
Top cap goes to top lead. *Tube good if it reads 20 or more.									1S2-A	1 24	35					2HK5	2 5	56								
1B2	1 39	95	1 9	12 10	1 1			1S4	2 41	*44	7 1	5 3	1 1	2HM5	2 5	57										
*Connect two leads from solder lugs of the 1B2 to pin holes No. 1 and 9 of Socket No. 39.									1S5	2 41	54 7	1 5	6 6	1 1	2HQ5	2 5	55									
1B2	1 39	95	1 9	12 10	1 1			*Normally shows short position 2-6.									2HR8	2 39	33 4	5 2	9 1	1 1				
1B2	1 39	95	1 9	12 10	1 1			1T4	2 41	50 7	1 5	6 6	1 1	2T4	2 41	*33	4 3	2 6	1 1							
1B2	1 39	95	1 9	12 10	1 1			1T5	1 38	54 7	2 12	5 1		*Normally shows short position 1-7.												
1B2	1 39	95	1 9	12 10	1 1			1U4	2 41	49 7	1 5	6 6	1 1	3A2	3 24	35										
1B2	1 39	95	1 9	12 10	1 1			1U5	2 41	54 7	1 12	6 6	1 1	3A3	3 32	54										
1B2	1 39	95	1 9	12 10	1 1			1V2	1 40	99 5	4 12	1 1		3A3A	3 32	54										
1B2	1 39	95	1 9	12 10	1 1			1X2	1 24	56				3A4	3 41	*36	7 1	5 4	1 1							
1B2	1 39	95	1 9	12 10	1 1			2AF4	2 41	*24	4 3	2 6	1 1	*Normally shows short position 2-6.												
1B2	1 39	95	1 9	12 10	1 1			*Normally shows short position 1-7.									3A5	3 41	45 7	1 4	3 3	1 1				
1B2	1 39	95	1 9	12 10	1 1			2AH2	2 45	99 1	12 12	10 1		3A8	3 38	54 7	2 1	10 1	1 1							
1B2	1 39	95	1 9	12 10	1 1			2AS2	2 45	99 1	12 12	10 1		*Normally shows short position 1-7.												
1B2	1 39	95	1 9	12 10	1 1			2AV2	2 40	*99	4 5	12 1	1 1	3AJ8	3 39	85 5	4 12	1 1	1 1							
1B2	1 39	95	1 9	12 10	1 1			*Tube good if it reads 55 or more.									3AL5	3 41	33 3	3 4	12 7	1 1				
1B2	1 39	95	1 9	12 10	1 1			2AZ2	2 24	35				3AT2	3 45	96 1	12 12	10 1	1 1							
1B2	1 39	95	1 9	12 10	1 1			2B3	2 32	30				3AU6	3 1	82										
1B2	1 39	95	1 9	12 10	1 1			*Tube good if it reads 20 or more.									3AV6	3 6	88							
1B2	1 39	95	1 9	12 10	1 1									3AW2	3 45	91 1	12 12	10 1	1 1							

*Normal Shorts Refer to Position of "D" Switch.

OA3-3AW2

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
3AW3	3	32	55					1	3GK5	3	41	25	4	3	1	2	1	4CS6	4	1	94					1
3B2	3	32	72					1	3GK6	3	9	40					1	4CY5	4	1	54					1
3B7	3	37	45	8	1	4	3	1	3GS8	3	21	95					1	4DE6	4	1	61					1
3BA6	3	1	78	8	1	4	6	1	3GU5	3	41	27	3	4	2	1	1	4DK6	4	1	61					1
3BC5	3	1	74					1	3GW5	3	41	29	3	4	6	2	1	4DL4	4	39	*85	4	5	7	8	1
3BE6	3	1	91					1	3GY5	3	36	*25	1	12	5	9	1	*Normally shows short position 1-3-6-9.								
3BL2	3	45	85	1	12	12	10	1	*Normally shows short position 1-3-4-7-10.								4DT6	4	1	91					1	
3BM2	3	45	85	1	12	12	10	1	3HA5	3	5	56					1	4EH7	4	9	40					1
3BN2	3	45	*99	1	12	12	10	1	3HE7	3	36	27	1	12	10	2	1	4EJ7	4	9	58					1
3BN4	3	41	*33	4	3	2	7	1	*Normally shows short position 3-4-6-8-10-11.								4ER5	4	41	33	4	3	1	2	1	
3BN6	3	7	75					1	3HF5	3	36	*25	1	12	9	5	1	4ES8	4	8	30					1
3BS2	3	45	87	1	12	12	10	1	3HK5	3	5	56					1	4EW6	4	1	77					1
3BS2A	3	45	87	1	12	12	10	1	3HM5	3	5	57					1	4GJ7	4	22	62					1
3BT2	3	45	*80	1	12	12	10	1	3HM6	3	9	68					1	4GK5	4	41	25	4	3	1	2	1
3BU8	3	21	92					1	3HQ5	3	5	55					1	4GM6	4	1	64					1
3BW2	3	45	*80	1	12	12	10	1	3HS8	3	21	99					1	4GS7	4	14	80					1
3BX6	3	9	76					1	3HT6	3	9	60					2	4GS8	4	21	95					1
3BY6	3	1	91					1	3IC6	3	9	65					1	4GW5	4	41	29	3	4	6	2	1
3BY7	3	9	62					1	3IC6A	3	9	59					1	4GX6	4	1	85					1
3BZ6	3	1	61					1	3ID6	3	9	61					1	4GX7	4	22	76					1
3C2	3	32	22					1	3KF8	3	21	92					2	4GZ5	4	41	26	3	4	2	5	1
3C4	2	41	48	7	1	5	6	1	3KT6	3	9	52					1	4HA5	4	5	56					1
3CA3	3	32	55					1	3L35	3	41	*36	7	1	5	4	1	4HA7	4	36	35	1	12	5	9	1
3CB6	3	1	64					1	3LF4	3	37	43	8	1	7	6	1	4HC7	4	36	*35	1	12	5	9	1
3CE5	3	1	62					1	3M-P26	3	7	81					1	*Normally shows short position 7-10.								
3CF6	3	1	60					1	3Q4	3	41	*42	7	1	5	3	1	4HG8	4	39	25	4	5	3	2	1
3CN3	3	32	30					1	3Q5	3	38	45	7	2	8	5	1	4HK5	4	5	56					1
3CN3A	3	32	30					1	3S4	3	41	*48	7	1	5	3	1	4HM5	4	5	57					1
3CS6	3	1	94					1	*Normally shows short position 2-6.								4HM6	4	9	68					1	
3CU3	3	32	20					1	3V4	3	41	45	7	1	5	6	1	4HQ5	4	5	55					1
3CX3	3	38	*88	3	8	4	10	1	4AB8	4	39	37	5	4	12	9	1	4HR8	4	39	33	4	5	2	9	1
3CY5	3	1	54					1	4A06	4	1	82					1	4HS8	4	21	99					1
3CZ3	3	32	35					1	4A08	4	12	59					1	4HT6	4	9	60					2
3D6	2	37	43	8	1	7	6	1	4AV6	4	6	91					2	4JC6	4	9	65					1
3DB3	3	32	60					1	4BA6	4	1	78					2	4JC6A	4	9	59					1
3DC3	3	32	*13					1	4BC5	4	1	74					1	4JD6	4	9	61					1
3DF3	3	38	*75	3	8	5	10	1	4BC8	4	8	53					1	4JH6	4	1	64					1
3DG4	3	38	26	1	3	12	5	1	4BE6	4	1	91					2	4JK6	4	1	61					1
3DJ3	3	32	*30					1	4BL8	4	11	66					1	4JL6	4	1	23					1
3DK6	3	1	61					1	*Normally shows short position 2-6.								4KE8	4	11	88					1	
3DT6	3	1	91					1	4BN4	4	41	*33	4	3	2	7	1	4KF8	4	21	92					2
3DX4	3	41	*62	3	4	1	7	1	*Normally shows short position 1-6.								4KN8	4	39	86	4	5	12	1	1	
3DY4	3	41	*24	4	3	2	6	1	4BN6	4	7	75					1	4KT6	4	9	52					1
3DZ4	3	41	*31	3	4	6	2	1	4BQ7	4	8	54					1	4LJ8	4	14	85					1
3EA5	3	1	80					1	*Normally shows short position 1-7.								4MK8	4	21	98					2	
3EH7	3	9	40					1	4BS8	4	8	54					1	4M-P12	4	1	60					1
3EJ7	3	9	58					1	4BU8	4	21	92					2	4M-P26	4	7	81					1
3ER5	3	41	33	4	3	1	2	1	4BX6	4	9	76					1	4R-HH2	4	8	53					1
3ES5	3	41	33	4	3	1	2	1	4BX8	4	39	33	5	4	12	2	1	4R-HH8	4	39	86	4	5	12	1	1
3EV5	3	1	57					1	4BZ6	4	1	61					1	5AF4	5	41	*24	4	3	2	6	1
3FH5	3	41	33	4	3	1	2	1	4BZ7	4	8	53					1	*Normally shows short position 1-7.								
3FQ5	3	41	33	4	3	1	2	1	4BZ8	4	8	55					2	5AF11	5	36	31	1	12	12	11	1
3FQ5A	3	41	31	4	3	1	2	1	4CB6	4	1	64					1	31	1	12	12	6	1			
3FS5	3	1	99					1	4CE5	4	1	62					1	35	1	12	12	3	1			
3FY5	3	41	33	4	3	1	2	1	4CM4	4	40	29	4	5	3	6	1									1

*Normal Shorts refer to position of "D" Switch.

3AW3-5AF11

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
5AM8	5	39	30	5	4	12	2	1	5EH8	5	12	71					1	5U9	5	42	28	5	6	12	3	1
			30	5	4	12	8	1				54					2				32	5	6	12	10	1
5AN8	5	13	62					1	5ES8	5	8	30					1	5V3	5	33	15					1
			61					2				30					2				15					2
5AQ5	5	3	77					1	5EU8	5	39	32	5	4	12	7	1	5V4	5	33	12					1
5AR4	5	33	10					1				32	5	4	12	2	1				12					2
			10					2	5EW6	5	1	77					1	5V6	5	29	79					1
5AS4	5	33	17					1	5FG7	5	14	68					1	5V9	5	42	31	5	6	12	3	1
			17					2				56					2				30	5	6	12	8	1
5AS8	5	39	31	5	4	12	2	1	5FV8	5	14	65					1	5W4	5	33	32					1
			32	5	4	12	6	1				54					2				32					2
5AT8	5	14	77					1	5GH8	5	11	68					1	5X4	5	38	47	8	7	12	3	1
			55					2				56					2				47	8	7	12	5	1
5AU4	5	33	16					1	5GH8A	5	11	68					1	5X8	5	12	73					1
			16					2				56					2				61					2
5AV8	5	39	40	4	5	6	2	1	5GJ7	5	22	62					1	5X9	5	42	30	5	6	12	3	1
			34	4	5	1	6	1				78					2				30	5	6	12	10	1
5AW4	5	33	17					1	5GM6	5	1	64					1	5Y3	5	33	32					1
			17					2	5GS7	5	14	80					1				32					2
5AZ4	5	37	53	8	2	12	4	1				53					2	5Y4	5	38	52	8	7	12	3	1
			53	8	2	12	6	1	5GX6	5	1	85					1				52	8	7	12	5	1
5B8	5	39	30	4	5	6	2	1	5GX7	5	22	76					1	5Z4	5	33	12					1
			28	4	5	1	6	1				73					2				12					2
5BC3	5	44	*33	1	3	6	5	1	5HA7	5	36	35	1	12	5	9	1	5Z10	5	33	16					1
			**33	1	3	8	9	1				35	1	12	5	11	1				16					2
								1	5HB7	5	22	75					1	6A8	6	38	45	7	2	1	5	1
								2				75					2	6A4	6	2	83					1
5BE8	5	14	72					1	5HC7	5	36	*35	1	12	5	9	1	6A7	6	30	74					1
			55					2				*35	1	12	5	11	1	6A8	6	39	37	5	4	12	9	1
5BK7	5	8	55					1									1				44	5	4	12	2	1
			55					2									2	6AC5	6	38	40	7	2	12	5	1
5BQ5	5	23	68					1	5HG8	5	39	24	4	5	3	2	1	6AC7	6	30	60					1
5BQ7	5	8	54					1				25	4	5	1	6	1	6AC9	6	36	28	1	12	3	9	1
			54					2	5HZ6	5	1	83					1				45	1	12	3	2	1
5BR8	5	14	72					1	5J6	5	2	60					1				35	1	12	2	3	1
			55					2				60					2	6AC10	6	36	32	1	12	12	7	1
5BS8	5	8	54					1	5JK6	5	1	61					1				32	1	12	12	9	1
			54					2	5JL6	5	1	23					1	6AD7	6	38	32	1	12	12	11	1
5BT8	5	39	33	5	4	12	8	1	5KD8	5	11	68					1				54	7	2	12	5	1
			54	5	4	12	1	1	5KE8	5	11	88					1				62	7	2	12	1	1
			54	5	4	12	2	1				53					2	6AD10	6	36	30	1	12	12	3	1
5BW8	5	39	33	5	4	2	6	1	5KZ8	5	39	26	4	5	12	2	1				33	1	12	12	8	1
			34	5	4	7	1	1				26	4	5	12	9	1	6AF3	6	15	12					1
			34	5	4	7	3	1	5LJ8	5	14	85					1	6AF4	6	41	*24	4	3	2	6	1
5BZ7	5	8	53					1				60					2									1
			53					2	5MB8	5	14	84					1									1
5CG8	5	14	73					1				61					2	6AF9	6	42	27	5	6	7	1	1
			57					2	5MF8	5	36	35	1	12	6	7	1				27	5	6	2	8	1
5CL8	5	14	69					1				34	1	12	6	10	1	6AF11	6	36	31	1	12	12	11	1
			51					2	5M-HH3	5	2	56					1				31	1	12	12	6	1
5CM6	5	16	64					1				56					2				35	1	12	12	3	1
5CM8	5	39	33	5	4	12	2	1	5M-K9	5	41	30	3	4	12	5	1	6AG5	6	1	80					1
			38	5	4	12	9	1	5MQ8	5	11	65					1	6AG7	6	30	38					1
5CQ8	5	11	72					1				66					2	6AG9	6	36	30	1	12	12	5	1
			55					2	5N1039A	6	1	63					1				28	1	12	12	11	1
5CR8	5	39	*32	5	4	12	2	1	5R4	5	33	22					1	6AG11	6	36	28	1	12	12	8	1
			*34	5	4	12	9	1				22					2				28	1	12	12	5	1
								1	5RDDH1	5	39	41	5	4	12	8	1				33	1	12	12	10	1
5CU4	5	38	28	8	2	12	4	1				35	5	4	12	1	1	6AH4	6	38	33	7	2	12	1	1
			28	8	2	12	6	1				33	5	4	12	6	1	6AH6	6	1	58					1
5CZ5	5	16	60					1	5R-K16	5	39	27	4	5	12	1	1	6AH7	6	38	48	8	7	12	1	1
5DB4	5	33	16					1				27	4	5	12	8	1				48	8	7	12	5	1
			16					2	5T4	5	33	16					1	6AH9	6	36	37	1	12	5	2	1
5DH8	5	14	61					1				16					2				30	1	12	5	6	1
			73					2	5T8	5	17	90					1	6AJ4	6	39	*84	8	7	1	5	1
5DJ4	5	33	16					1				63					2									1
			16					2	5U4	5	33	16					1									1
5EA8	5	11	71					1				16					2	6AJ5	6	41	36	4	3	2	1	1
			56					2	5U8	5	11	79					1	6AJ7	6	30	60					1
								2				55					2	6AJ8	6	39	85	5	4	12	1	1
								2									2				38	5	4	12	9	1

*Normal Shorts refer to position of "D" Switch.

5AM8-6AJ8

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.
6AJ9	6	42	29	5	6	12	3	1	6AU8	6	12	56					1	6BE8	6	14	72					1
6AK5	6	1	63	5	6	12	10	1				72				2				55						2
6AK6	6	1	82					1	6AV5	6	28	62					1	6BF5	6	3	40					1
6AK7	6	30	38					1	6AV6	6	6	91					1	6BF6	6	6	85					1
6AK8	6	17	90					1				78				2				80						2
6AK9	6	36	33	1	12	6	10	1	6AV11	6	36	30	1	12	12	7	1	6BF8	6	39	25	4	5	12	1	1
			63					2				30	1	12	12	9	1				25	4	5	12	2	1
6AK10	6	36	33	1	12	6	3	1	6AW8	6	12	44					1				25	4	5	12	3	1
			35	1	12	6	8	1				78					2				25	4	5	12	7	1
			31	1	12	6	8	1	6AX2	6	24	88					1				25	4	5	12	8	1
6AL3*	6	40	30	5	4	7	3	1	6AX3	6	36	30	1	12	10	4	1	6BF11	6	36	25	1	12	12	3	1
			32	1	12	12	9	1	6AX4	6	34	13					1				25	1	12	12	8	1
*If no test, use alternate settings.			32	1	12	12	11	1	6AX5	6	38	44	7	2	1	5	1	6BG6	6	26	66					1
6AL3	6	40	30	5	4	3	7	1	6AX7	6	8	*85					1	6BH3	6	44	27	5	4	7	2	1
6AL5	6	41	33	3	4	12	2	1				*85				2	6BH3A	6	44	27	5	4	7	2	1	
			33	3	4	12	7	1	*Tube good if it reads 22 or more.								6BH6	6	1	89					1	
6AL9	6	36	28	1	12	12	5	1	6AX8	6	11	73					1	6BH8	6	12	59					1
			28	1	12	12	11	1				54				2	6BH11	6	36	27	1	12	12	4	1	
6AL11	6	36	31	1	12	12	3	1	6AY3	6	44	27	5	4	7	2	1				27	1	12	12	6	1
			27	1	12	12	8	1	6AY3B	6	44	27	5	4	7	2	1				27	1	12	12	8	1
6AM4	6	39	*96	8	7	1	5	1	6AY11	6	36	30	1	12	12	5	1	6BJ3	6	36	26	1	12	4	10	1
*Normally shows short position 3-4-6-9.			30	1	12	12	8	1				30	1	12	12	8	1	6BJ6	6	1	81					1
6AM5	6	41	34	4	3	12	1	1	6AZ8	6	39	30	1	12	12	10	1	6BJ7	6	39	33	5	4	12	2	1
6AM6	6	41	30	4	3	12	1	1				30	1	12	12	10	1				33	5	4	12	6	1
6AM8	6	39	30	5	4	12	2	1	6B4	6	38	35	7	2	12	5	1				33	5	4	12	8	1
			30	5	4	12	8	1	6B6	6	38	37	7	2	12	10	1	6BJ8	6	39	38	5	4	12	8	1
6AN4	6	41	*30	4	3	2	6	1				58	7	2	12	4	1				34	5	4	12	1	1
*May show short position 1-7.			52	7	1	12	3	1	6B8	6	38	58	7	2	12	5	1	6BK4▲	6	38	78	7	2	6	5	1
6AN5	6	1	26					1				58	7	2	12	5	1	6BK4A▲	6	38	78	7	2	6	5	1
6AN6	6	41	52	7	1	12	3	1	6B10	6	36	34	1	12	12	3	1	6BK4B▲	6	38	78	7	2	6	5	1
			52	7	1	12	3	1				34	1	12	12	5	1	6BK5	6	10	53					1
			52	7	1	12	4	1				65	7	2	12	4	1	6BK6	6	6	86					1
			52	7	1	12	5	1	6B31	6	41	33	3	4	12	2	1				70					2
6AN8	6	13	62					1				34	1	12	12	3	1	6BK7	6	8	55					1
			61					2				34	1	12	12	8	1				55					2
6AQ4	6	41	*29	4	3	6	1	1	6B32	6	41	33	3	4	12	2	1	6BK11	6	36	35	1	12	12	7	1
*Normally shows short position 2-5.			77					1				33	3	4	12	7	1				35	1	12	12	9	1
6AQ5	6	3	77					1	6BA3	6	44	33	4	5	7	2	1				35	1	12	12	11	1
6AQ6	6	6	89					1	6BA6	6	1	78					1	6BL4	6	34	10					1
			80					2				33	3	4	12	2	1	6BL7	6	25	57					1
6AQ7	6	38	45	8	7	12	4	1	6BA7	6	39	33	5	4	12	2	1				57					2
			58	8	7	12	1	1	6BA8	6	12	53					1	6BL8	6	11	66					1
			58	8	7	12	3	1				59				2				55						2
6AQ8	6	8	70					1	6BA11	6	36	29	1	12	12	4	1	6BM8	6	39	33	5	4	12	3	1
			70					2				37	1	12	12	9	1				39	5	4	12	1	1
6AR5	6	3	91					1	6B-B14◆	6	44	*33	4		1	2	1	6BN4	6	41	*33	4	3	2	7	1
6AR6	6	38	33	8	6	12	7	1	*Normally shows short position 3-6-7-8.			60	5	4	3	7	1				*33	4	3	2	7	1
6AR8	6	39	30	5	4	12	6	1	6BC4	6	40	30	5	4	3	7	1	6BN5	6	39	*39	5	4	1	2	1
6AR11	6	36	28	1	12	12	5	1	6BC5	6	1	74					1				*Normally shows short position 6-8.					1
			28	1	12	12	10	1	6BC7	6	39	32	5	4	12	2	1	6BN6	6	7	75					1
6AS5	6	4	55					1				32	5	4	12	6	1	6BN8	6	39	35	5	4	12	8	1
6AS6	6	1	77					1	6BC8	6	8	53				8	1				35	5	4	12	1	1
6AS7	6	38	35	8	7	12	1	1				32	5	4	12	8	1	6BN11	6	36	35	5	4	12	6	1
			35	8	7	12	4	1	6BC32	6	6	91					1				29	1	12	12	3	1
6AS8	6	39	31	5	4	12	2	1				32	5	4	12	8	1	6BQ5	6	23	68					1
			32	5	4	12	6	1	6BD5	6	38	29	7	2	12	1	1	6BQ6	6	27	69					1
6AS11	6	36	28	1	12	12	11	1	6BD6	6	1	85					1	6BQ7	6	8	54					1
			32	1	12	12	6	1	6BD11	6	36	26	1	12	12	11	1				54					2
			32	1	12	12	3	1				31	1	12	12	3	1	6BR3	6	15	10					1
6AT6	6	6	85					1				31	1	12	12	6	1	6BR8	6	14	72					1
			78					2	6BE3	6	36	26	1	12	4	10	1				55					2
6AT8	6	14	77					1	6BE6	6	1	91					1									1
			55					2	6BE7	6	39	33	5	4	3	7	1									2
6AU4	6	34	10				</																			

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE						TUBE TYPE						TUBE TYPE					
Heater	Socket	Pin-ality	A	B	D	Heater	Socket	Pin-ality	A	B	D	Heater	Socket	Pin-ality	A	B	D
6EB8	6 12	35				6FD7	6 39	25	4	5	2	6GM5	6 39	*26	4	5	2
		99						32	4	5	2			*May show short position 3-8.			
6EC4	6 38	32	7	8	2	6FE5	6 29	37				6GM6	6 1	64			
6ED4	6 44	*52	4	5	12	6FG5	6 41	31	4	3	2	6GM8	6 39	33	5	4	12
	*Normally shows short position 2-3-6-7-9.					6FG7	6 14	68						33	5	4	12
6EF4*	6 36	76	1	12	6			56				6GN7	6 9	21			
	*Insert a 2.7K 1W 5% resistor from pin hole No. 4 to No. 6 of socket No. 37, remove resistor after test is completed.					6FH5	6 41	33	4	3	1	6GN8	6 12	36			
	*Normally shows short position 2-9.					6FH8	6 39	32	5	4	12			98			
6EH4*	6 36	80	1	12	6	6FJ7	6 36	36	1	12	2	6GQ7	6 39	24	4	5	3
	*Insert a 2.7K, 1w., 5% resistor from pin hole #4 to #6 of socket #37. Remove resistor after test is completed.							44	1	12	10			24	4	5	3
	*Normally shows short position 2-5-9-11.					6FM7	6 36	25	1	12	3	6GS7	6 14	80			
6EH5	6 4	57				6FM8	6 39	47	5	4	12	6GS8	6 21	95			
6EH7	6 9	40						34	5	4	12			95			
6EH8	6 12	71				6FQ5	6 41	33	4	3	1	6GT5	6 35	63			
		54				6FQ5A	6 41	31	4	3	1	6GT5A	6 35	63			
6EJ4*	Use 6EF4 settings.					6FQ7	6 8	68				6GU5	6 41	27	3	4	2
	May show short position 2-9-11.					6FR7	6 39	24	4	5	2	6GU7	6 8	56			
6EJ7	6 9	58						32	4	5	2			56			
6EL4	6 38	78	7	2	6	6FS5	6 1	99				6GV5	6 36	*26	1	12	5
6EM5	6 16	53				6FV6	6 1	54						*Normally shows short position 3-4-7-10-11.			
6EM7	6 38	32	8	7	12	6FV8	6 14	65				6GV7	6 39	30	4	5	8
6EN4	6 38	*40	7	2	6			54						33	4	5	8
	*Normally shows short position 1-3-4-8.					6FW5	6 28	57				6GV8	6 39	25	4	5	12
	*Tube good if it reads 40 or more.					6FW8	6 8	30						25	4	5	12
6EQ7	6 39	34	5	4	12	6FY5	6 41	33	4	3	1	6GW5	6 41	29	3	4	6
		71	5	4	12	6FY7	6 36	25	1	12	12	6GW6	6 27	62			
6ER5	6 41	33	4	3	1	6G6	6 29	94				6GW8	6 39	25	4	5	2
6ES5	6 41	33	4	3	1	6G11	6 36	33	1	12	12			35	4	5	7
6ES8	6 8	30						31	1	12	12	6GX6	6 1	85			
		30				6G-B3A	6 27	65				6GX7	6 22	76			
6ET6	6 41	30	4	3	12	6GB5	6 44	*25	4	5	2			73			
6ET7	6 39	30	5	4	12		*Normally shows short position 3-6-7-8.					6GY5	6 36	*25	1	12	5
		70	5	4	12	6G-B6	6 27	64						82			
		70	5	4	12	6G-B7	6 27	58				6GY6	6 1	82			
6EU7	6 39	35	2	1	12	6GC5	6 16	26				6GY8	6 39	*32	5	4	12
		35	2	1	12	6GC6	6 26	52						*32	5	4	12
6EU8	6 39	32	5	4	12	6GD7	6 14	74						*94	5	4	12
		32	5	4	12			63							6		
6EV5	6 1	57				6GE5	6 36	*24	1	12	11	6HZ5	6 1	91			
6EV7	6 8	78					*Normally shows short position 4-10.					6HA5	6 5	56			
		78				6GE8	6 39	33	5	4	12	6HA6	6 9	23			
6EW6	6 1	77						33	5	4	12	6HB5	6 36	*25	1	12	11
6EW7	6 20	87				6GF5	6 36	*24	1	12	11		*Normally shows short position 4-10.				
		92					*Normally shows short position 4-10.					6HB6	6 9	20			
6EX6	6 26	42				6GF7	6 44	27	4	5	12	6HB7	6 22	75			
6EY6	6 29	65						38	4	5	12			75			
6EZ5	6 29	65				6GF7A	6 44	27	4	5	12	6HC8	6 39	36	5	4	12
6EZ8	6 39	33	5	4	12			38	4	5	12			38	5	4	12
		33	5	4	12	6GH8	6 11	68				6HD5	6 36	*27	1	12	3
6F5	6 38	40	7	2	1			56					*Normally shows short position 4-5-9-10.				
6F6	6 29	91				6GH8A	6 11	68				6HD7	6 39	30	4	5	1
6F8	6 38	45	7	2	12			56						30	4	5	1
		45	7	2	12	6GJ5	6 35	65				6HE5	6 36	*32	1	12	9
6F10	6 30	60				6GJ5A	6 35	65					*Normally shows short position 3-4-10-11.				
6F31	6 1	78				6GJ7	6 22	62				6HE7	6 36	27	1	12	10
6F33	6 1	77						78						27	1	12	10
6F36	6 1	58				6GJ8	6 11	70				6HF5	6 36	*25	1	12	9
6F40	6 39	39	5	4	2			53					*Normally shows short position 3-4-6-8-10-11.				
6FA7	6 39	33	5	4	12	6GK5	6 41	25	4	3	1	6HF8	6 12	27			
		65	5	4	12			40						80			
6FC7	6 39	29	4	5	7	6GK6	6 9	40				6HG5	6 3	85			
		29	4	5	7	6GL7	6 25	54				6HG8	6 39	25	4	5	3
6FD6	6 41	26	3	4	2			98						25	4	5	1
												6HJ5	6 36	*27	1	12	3

*Normal Shorts refer to position of "D" Switch.

6EB8-6HJ5

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.									
6HJ7	6	39	*78 30	4	5	1	7	1	6JL8	6	12	40 70					1	6KS8	6	12	33 84					1									
*For grid emission turn D switch to position 2.									6JM6	6	36	26	1	12	4	5	1	6KT6	6	9	52					1									
6HJ8	6	39	29 31	5	4	12	2	1	6JN6	6	36	27	1	12	4	11	1	6KT8	6	12	67 91					1									
6HK5	6	5	56					1	6JN8	6	14	67					1	6KU8	6	39	22 60 60	4	5	12	7	1									
6HL5	6	39	30	4	5	1	2	1	6JQ6	6	39	*34 *57	4	5	8	7	1	6KV6	6	44	30	4	5	1	2	1									
6HL8	6	11	60					1	*May show short position 2-3.									6KV8	6	12	22					1									
6HM5	6	5	57					2	6JR6	6	35	50					1	6KW6◆	6	44	82 30	4	5	1	8	1									
6HM6	6	9	68					1	6JS6	6	36	*29	1	12	9	5	1	6KY6	6	9	20					1									
6HQ5	6	5	55					1	*Normally shows short position 3-4-10-11.									6KY8	6	44	27 39	4	5	12	2	1									
6HR5	6	3	77					1	6JT6	6	35	65					1	6KY8A	6	44	27 39	4	5	12	2	1									
6HR6	6	1	71					1	6JT6A	6	35	65					1	6KZ8	6	39	26 26	4	5	12	9	1									
6HS5	6	36	*30	1	12	11	2	1	6JT8	6	12	20					1	6L5	6	38	53	7	2	6	5	1									
*Normally shows short position 3-10.									*99									6L6	6	29	63					1									
6HS6	6	1	66					1	*Tube good if reads 60 or more.									6L7	6	38	44	7	2	1	10	1									
6HS8	6	21	99 99					2	6JU6	6	35	55					1	6L10	6	30	38					1									
6HT5	6	36	*52	1	12	2	6	1	6JU8	6	39	*32 **32	4	5	2	1	1	6L12	6	8	70 70					1									
*May show short position 4-7-9-11.									*Normally shows short position 8.									6L41	6	39	33	5	4	8	9	1									
6HT6	6	9	60					1	**Normally shows short position 2.									6L43	6	39	*32	5	4	2	9	1									
6HU6	6	39	52	4	5	2	1	1	6JU8A	6	39	*32 **32	4	5	2	1	1	*Normally shows short position 3-8.									6LB6	6	36	*30	1	12	9	5	1
6HU8	6	39	29 29	4	5	12	2	1	*Normally shows short position 8.									*Normally shows short position 3-4-10-11.																	
6HV5	6	36	*33	1	12	2	11	1	6JV8	6	12	55 85					1	6LB8	6	12	21 71					1									
*Normally shows short position 3-10.									6JW8	6	11	80 85					2	6LC6▲	6	38	78	7	2	12	5	1									
6HW8	6	39	32	4	5	12	6	1	6JX8	6	22	88 93					2	6LC8	6	39	24 24	4	5	3	6	1									
6HZ6	6	1	83					1	6JY8	6	12	40 55					2	6LD6	6	9	51					1									
6HZ8	6	12	28					1	6JZ6	6	36	*31	1	12	4	5	1	6LD12	6	16	90 63					1									
6J4	6	41	*85	4	3	1	7	1	*Some tubes may show short position 9-11.									6LE8	6	39	29	4	5	12	9	1									
*Normally shows short position 5-6.									6K6	6	29	92					1	6LF6	6	36	*31	1	12	5	9	1									
6J5	6	29	93					1	6K7	6	38	52	7	2	1	10	1	*May show short position 3-4-7-10-11.																	
6J6	6	2	60					1	6K8	6	38	35	7	2	1	5	1	6LF8	6	12	55 95					1									
6J7	6	38	50	7	2	1	10	1	6K11	6	36	38	1	12	12	7	1	6LG6	6	36	*32	1	12	9	5	1									
6J9	6	39	26 26 26	4	5	12	9	1	6KA8	6	39	26	4	5	12	6	1	*May show short position 2-3-4-7-10-11.																	
6J10	6	36	96	1	12	12	6	1	6KD6	6	36	*26	1	12	9	5	1	6LH6▲	6	38	78	7	2	12	5	1									
6J11	6	36	22 22	1	12	12	5	1	*Normally shows short position 3-4-10-11.									6LJ6▲	6	38	78 95	2	7	12	5	1									
6JA8	6	39	25	4	5	12	7	1	6KD8	6	11	68 52					2	6LJ8	6	14	85 60					1									
6JB5	6	36	*35	1	12	9	2	1	6KE8	6	11	88 53					1	6LM8	6	11	68 58					1									
*Normally shows short position 3-4-10-11.									6KF8	6	21	92 92					2	6LN8	6	11	66 55					1									
6JB6	6	35	62					1	6KG6◆	6	44	*26	4	5	1	8	1	6LQ6	6	35	52					1									
6JB6A	6	35	62					1	*Normally shows short position 2-3-6-7.									6LQ8	6	12	31 50					1									
6JC6	6	9	65					1	6KL8	6	39	31 70	4	5	12	2	1	6LR6	6	36	*32	1	12	9	5	1									
6JC6A	6	9	59					1	6KM6	6	35	53					1	*May show short position 3-4-7-10-11.																	
6JC8	6	39	24 24	4	5	1	2	1	6KM8	6	39	31	4	5	12	7	1	6LR8	6	44	31	4	5	12	2	1									
6JD6	6	9	61					1	6KNG	6	36	*30	1	12	9	5	1	6L78	6	39	27 32	4	5	7	9	1									
6JE6A	6	35	59					1	*Normally shows short position 3-4-10-11.									6L88	6	36	27	1	12	6	7	1									
6JE6B	6	35	59					1	6KN8	6	39	86 90	4	5	12	1	1	6LX8	6	11	27 80 85	1	12	6	10	1									
6JE6C	6	35	52					1	6KR8	6	12	22 59					2	6LX8	6	11	80 85					1									
6JE8	6	12	56 78					2	6KR8A	6	12	22 59					2	6LX8	6	11	80 85					2									
6JF6	6	44	*26	4	5	2	6	1	6KS6	6	7	83					1																		
*Normally shows short position 1-7.																																			
6JG6	6	35	56					1																											
6JG6A	6	35	56					1																											
6JH6	6	1	64					1																											
6JH8	6	39	26	4	5	12	6	1																											
6JK6	6	1	61					1																											
6JK8	6	8	54 55					1																											
6JL6	6	1	23					1																											

*Normal Shorts refer to position of "D" Switch.

◆Use TC-80 Adapter.
▲Use TC-75 Adapter.

6HJ7-6LX8

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	
6LY8	6	12	21					1	6S7	6	38	47	7	2	1	10	1	6W7	6	38	50	7	2	12	10	1	
			*99					2	6S8	6	38	45	8	7	5	10	1	6X4	6	41	44	4	3	12	1	1	
			*Tube good if it reads 28 or more.									62	8	7	5	1	1	6X5	6	33	15	4	3	12	6	1	
6M11	6	36	25	1	12	12	2	1			62	8	7	5	4	1	1				15					1	
			25	1	12	12	5	1			63	8	7	2	3	1	1	6X6	6	38	48	7	2	12	3	1	
			25	1	12	12	8	1										6X8	6	12	73	7	2	12	5	1	
6MB8	6	14	84					1	6SA7	6	38	37	7	2	1	5	1									1	
			61					2	6SB7Y	6	38	34	7	2	1	5	1									1	
			61					2	6SC7	6	38	48	8	7	1	3	1									1	
6MD8	6	44	35	4	5	12	6	1			48	8	7	1	4	1									2		
			35	4	5	12	8	1	6SD7	6	30	69						6X9	6	42	30	5	6	12	3	1	
			35	4	5	12	9	1	6SF5	6	38	41	8	7	1	3	1									1	
6ME8	6	39	30	4	5	12	6	1	6SF7	6	38	46	8	7	1	2	1	6Y6	6	29	40	5	6	12	10	1	
6MF8	6	36	35	1	12	6	7	1			69	8	7	1	5	1		6Y9	6	42	27	5	6	12	1	1	
			34	1	12	6	10	1	6SG7	6	30	77														1	
6MG8	6	11	80					1	6SH7	6	30	77						6Y10	6	36	29	1	12	4	3	1	
			59					2	6SJ7	6	30	83														1	
6M-HH3	6	2	56					1	6SK7	6	30	84						6Z10	6	36	30	1	12	12	11	1	
			56					2	6SL7	6	25	*85														1	
6MJ8	6	36	35	1	12	7	8	1			*85							6Z31	6	41	44	4	3	12	1	1	
			35	1	12	7	10	1																		1	
			35	1	12	7	11	1	*Tube good if it reads 22 or more.									6ZY5	6	33	17						1
6MK8	6	21	98					1	6SN7	6	25	78						7A4	6	37	41	8	1	12	6	1	
			98					2			78							7A5	6	37	34	8	1	12	6	1	
6M-L4	6	41	*24	4	3	2	6	1	6SQ7	6	38	42	8	7	1	2	1	7A6	6	37	48	8	1	12	3	1	
			*Normally shows short position 1-7.									71	8	7	1	4	1										1
			33	1	12	7	8	1			71	8	7	1	5	1		7A7	6	37	45	8	1	12	6	1	
6MN8	6	36	33	1	12	7	10	1	6SR7	6	38	46	8	7	1	2	1	7A8	6	37	40	8	1	12	4	1	
			33	1	12	7	11	1			68	8	7	1	4	1		7AD7	6	37	35	8	1	12	6	1	
			33	1	12	7	11	1	6SS7	6	38	46	7	2	1	4	1	7AF7	6	37	41	8	1	12	4	1	
6M-P17	6	3	90					1	6ST7	6	38	52	8	7	1	2	1				41	8	1	12	5	1	
6M-P18	6	41	34	3	4	7	1	1			72	8	7	1	4	1		7AG7	6	37	32	8	1	12	6	1	
6MP20	6	1	43					1			72	8	7	1	5	1		7AH7	6	37	32	8	1	12	6	1	
6MQ8	6	11	65					2	6SU7	6	38	43	8	7	12	1	1	7AK7	6	37	33	8	1	12	6	1	
			66					1			43	8	7	12	4	1		7AN7	7	39	33	5	4	7	2	1	
6MU8	6	11	42					2	6SZ7	6	38	44	8	7	1	2	1				33	5	4	7	6	1	
			60					2			72	8	7	1	4	1		7AU7	7	8	75					1	
6N3	6	39	29	4	5	6	9	1			72	8	7	1	4	1					75				2		
6N7	6	38	47	7	2	1	4	1			72	8	7	1	5	1		7B4	6	37	40	8	1	12	6	1	
			47	7	2	1	5	1	6T4	6	41	*33	4	3	2	6	1		7B5	6	37	52	8	1	12	6	1
6N8	6	39	37	5	4	12	2	1			90							7B6	6	37	40	8	1	4	3	1	
			64	5	4	12	7	1	6T8	6	17	90														1	
			64	5	4	12	8	1			63															1	
6NK7GT	6	30	84					1	6T8A	6	17	90														1	
6P5	6	29	93					1			63							7B7	6	37	45	8	1	12	6	1	
6P15	6	23	68					1	6T9	6	36	27	1	12	12	8	1	7B8	6	37	42	8	1	12	4	1	
6Q7	6	38	40	7	2	1	10	1			27	1	12	12	4	1		7C4	6	37	53	8	1	12	4	1	
			63	7	2	1	4	1	6T10	6	36	28	1	12	12	3	1	7C5	6	37	38	8	1	12	6	1	
			63	7	2	1	5	1			25	1	12	12	8	1		7C6	6	37	50	8	1	4	3	1	
6Q11	6	36	38	1	12	12	7	1	6U4	6	34	11														1	
			38	1	12	12	9	1	6U6	6	29	54														1	
			38	1	12	12	11	1	6U7	6	38	35	7	2	12	10	1				68	8	1	4	5	1	
			38	1	12	12	11	1	6U8	6	11	79						7C7	6	37	37	8	1	12	6	1	
6R3	6	39	33	5	4	2	9	1			55							7DJ8	7	39	31	5	4	12	2	1	
6R4	6	39	30	4	5	12	1	1	6U9	6	42	28	5	6	12	3	1				31	5	4	12	7	1	
6R7	6	38	52	7	2	1	10	1			32	5	6	12	10	1		7E5	6	37	*33	8	2	1	5	1	
			63	7	2	1	4	1	6U10	6	36	32	1	12	12	7	1				40	8	1	4	3	1	
			63	7	2	1	5	1			32	1	12	12	9	1		*Normally shows short position 3-4-6-7.									
6R8	6	17	86					1			32	1	12	12	11	1		7E6	6	37	40	8	1	4	3	1	
			62					2			32	1	12	12	11	1					69	8	1	4	5	1	
6RA6	6	40	34	4	5	9	7	1	6V3	6	15	10						7E7	6	37	47	8	1	12	6	1	
6R-A9	6	39	30	4	5	7	2	1	6V4	6	39	40	5	4	12	1	1				68	8	1	12	3	1	
6R-B11	6	39	32	4	5	6	3	1			40	5	4	12	7	1					68	8	1	12	4	1	
			53					1	6V6	6	29	79						7ES8	7	8	30					1	
6R-HH2	6	8	53					2	6V8	6	39	40	5	4	12	6	1</										

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE						TUBE TYPE						TUBE TYPE											
Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.
7GS7	7 14	80					1 2	8BN11	8 36	29	1 12	12 3	1 1			8JV8	8 12	55					1 2
7GV7	7 39	30	4 5	8 7			1 1	8BQ5	8 23	29	1 12	12 7	1 1			8K11	8 36	38	1 12	12 7		1 1	
7H7	6 37	35	8 1	12 6			1 1	8BQ7	8 8	68							38	1 12	12 9		1 1		
7HG8	7 39	25	4 5	3 2			1 1	8BQ11	8 36	54							38	1 12	12 11		1 1		
7J7	6 37	35	8 1	12 6			1 1	8BU11	8 36	28	1 12	12 10	1 1			8KA8	8 39	26	4 5	12 6		1 1	
7K7	6 37	45	8 1	12 4			1 1	8BU11	8 36	28	1 12	12 8	1 1			8KR8	8 12	22	4 5	12 2		1 1	
		65	8 1	12 5			1 1	8CB11	8 36	28	1 12	12 5	1 1			8KS8	8 12	33				1 1	
		65	8 1	12 6			1 1	8CG7	8 8	76						8KT8	8 12	84				2 1	
7KY6	7 9	20					1 1	8CG7	8 8	76						8LC8	6 39	24	4 5	3 6		1 1	
7KZ6	7 9	17					1 1	8CH8	8 39	33	5 4	12 7	1 1			8LE8	8 39	29	4 5	12 9		1 1	
7L7	6 37	36	8 1	12 6			1 1	8CH8	8 39	33	5 4	12 8	1 1			8LT8	8 39	27	4 5	7 9		1 1	
7M-P18	7 41	34	3 4	7 1			1 1	8CL8	8 14	69						8M-P12	8 1	60				1 1	
7N7	6 37	42	8 1	12 4			1 1	8CL8	8 14	51						8MU8	8 11	42				1 1	
		42	8 1	12 5			1 1	8CM7	8 19	80							60					2 1	
7Q7	6 37	35	8 1	12 4			1 1	8CM7	8 19	94						8R-HP1	8 39	33	4 5	12 3		1 1	
7R7	6 37	35	8 1	12 6			1 1	8CN7	8 18	94						8R-LP1	8 39	35	4 5	12 1		1 1	
		72	8 1	12 3			1 1	8CN7	8 18	60						8SN7	8 25	78				1 1	
		72	8 1	12 4			1 1	8CS7	8 20	96							35	4 5	12 8		1 1		
7S7	6 37	38	8 1	12 6			1 1	8CS7	8 20	95						8M-P12	8 1	60				1 1	
7V7	6 37	32	8 1	12 6			1 1	8CU8	8 39	32	5 4	1 7	1 1			8MU8	8 11	42				2 1	
7W7	6 37	31	8 1	4 6			1 1	8CU8	8 39	33	5 4	6 8	1 1				60					2 1	
7X6	6 37	35	8 1	12 3			1 1	8CW5	8 23	58						8R-HP1	8 39	39	4 5	12 1		1 1	
		35	8 1	12 6			1 1	8CX8	8 12	45						8R-LP1	8 39	35	4 5	12 1		1 1	
7X7	6 37	43	8 1	12 3			1 1	8CX8	8 12	67						8SN7	8 25	32	4 5	12 3		1 1	
		36	8 1	12 5			1 1	8CY5	8 1	54							78					2 1	
		35	8 1	12 6			1 1	8CY7	8 39	31	5 4	2 3	1 1			8U9	8 42	28	5 6	12 3		1 1	
7Y4	6 37	45	8 1	12 3			1 1	8CY7	8 39	45	5 4	2 7	1 1			8X9	8 42	32	5 6	12 10		1 1	
		45	8 1	12 6			1 1	8DE7	8 20	81							30	5 6	12 3		1 1		
7Z4	6 37	50	8 1	12 3			1 1	8DE7	8 20	90							30	5 6	12 10		1 1		
		50	8 1	12 6			1 1	8DX8	8 39	26	4 5	12 8	1 1				30	5 6	12 10		1 1		
8A8	8 11	66					1 1	8EB8	8 12	26	4 5	12 1	1 1			9A8	9 11	66				1 1	
8AC9	8 36	28	1 12	3 9			1 1	8EB8	8 12	35							55					2 1	
		45	1 12	3 2			1 1	8EM5	8 16	99						9AH9	9 36	37	1 12	5 2		1 1	
		35	1 12	2 3			1 1	8ET7	8 39	53							30	1 12	5 6		1 1		
8AC10	8 36	32	1 12	12 7			1 1	8ET7	8 39	30	5 4	12 7	1 1			9AK8	9 16	90				1 1	
		32	1 12	12 9			1 1			70	5 4	12 2	1 1				63					2 1	
		32	1 12	12 11			1 1	8FQ7	8 8	70	5 4	12 3	1 1			9AK10	9 36	32	1 12	12 7		1 1	
8AL9	8 36	28	1 12	12 5			1 1	8FQ7	8 8	68							32	1 12	12 9		1 1		
		28	1 12	12 11			1 1	8GJ7	8 22	68							32	1 12	12 11		1 1		
8AR11	8 36	28	1 12	12 5			1 1	8GJ7	8 22	62						9AQ8	9 8	70				1 1	
		28	1 12	12 10			1 1			78							70					2 1	
8AU8	8 12	56					1 1	8GM6	8 1	64						9AU7	9 8	75				1 1	
		72					2 1	8GN8	8 12	36							75					2 1	
8AV11	8 36	30	1 12	12 7			1 1	8GU7	8 8	98						9BJ11	9 36	28	1 12	12 6		1 1	
		30	1 12	12 9			1 1	8GU7	8 8	56							28	1 12	12 11		1 1		
		30	1 12	12 11			1 1			56						9BR7	9 39	32	5 4	9 2		1 1	
8AW8	8 12	44					1 1	8GX7	8 22	76							37	5 4	9 6		1 1		
		78					2 1	8GX7	8 22	73							37	5 4	9 7		1 1		
8B8	8 39	33	4 5	12 3			1 1	8HA6	8 9	23						9BR8	9 14	72				1 1	
		39	4 5	12 1			1 1	8HG8	8 39	25	4 5	3 2	1 1				55					2 1	
8B10	8 36	34	1 12	12 3			1 1			25	4 5	1 6	2 1			9CG8A	9 14	73				1 1	
		34	1 12	12 5			1 1	8JE8	8 12	56							57					2 1	
		34	1 12	12 8			1 1	8JE8	8 12	78							69					1 1	
		34	1 12	12 10			1 1	8JK8	8 8	54							51					2 1	
8BA8	8 12	53					1 1	8JK8	8 8	55							9DZ8	9 39	27	4 5	8 3		1 1
		59					2 1			40								30	4 5	2 1		1 1	
8BA11	8 36	29	1 12	12 4			1 1	8JL8	8 12	70							9EA8	9 11	71				1 1
		37	1 12	12 9			1 1	8JT8	8 12	20								56					2 1
8BH8	8 12	59					1 1			*99							9ED4	9 44	*52	4 5	12 8		1 1
		54					2 1																2 1
8BM11	8 36	30	1 12	12 6			1 1																1 1
		30	1 12	12 11			1 1	8JU8A	8 39	*32	4 5	2 1	1 1				9GH8A	9 11	68				2 1
8BN8	8 39	35	5 4	12 8			1 1			**32	4 5	8 7	1 1				56						2 1
		35	5 4	12 1			1 1											25	4 5	12 9		1 1	
																		25	4 5	12 2		1 1	

*Tube good if reads 60 or more.

*Normally shows short position 8.

**Normally shows short position 2.

*Normally shows short position 2-3-6-7-9.

*Normal Shorts refer to position of "D" Switch.

◆Use TC-80 Adapter.

7GS7-9HS6

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
9J6	9	2	60					1	10GM8	10	39	33	5	4	12	2	1	11LT8	12	39	27	4	5	7	9	1
			60					2				33	5	4	12	7	1				32	4	5	1	6	1
9MN8	9	36	33	1	12	7	8	1	10GN8	10	12	36									32	4	5	1	8	1
			33	1	12	7	10	1				98						11MS8	10	39	25	4	5	12	9	1
			33	1	12	7	11	1	10GV8	10	39	25	4	5	12	9	1				25	4	5	12	2	1
9JW8	9	11	80					1				25	4	5	12	2	1	11R3	10	39	33	5	4	2	9	1
			85					2	10HA6	10	9	23						11Y9	12	42	27	5	6	12	1	1
9KC6	9	39	25	4	5	12	2	1	10HF8	10	12	27									27	5	6	12	8	1
			83	4	5	12	9	1				80						12A4	12	40	32	5	4	3	7	1
9KGG♦	9	44	*26	4	5	1	8	1	10JA8	10	39	25	4	5	12	7	1	12A6	12	29	92					
												95	4	5	12	3	1	12A8	12	38	45	7	2	12	5	1
*Normally shows short position 2-3-6-7.									10JT8	10	12	20						12AB5	12	16	67					
9KV8	9	12	22					1				*99						12AC6	12	41	42	4	3	12	1	1
			82					2	*Tube good if it reads 60 or more.									12AD6	12	41	35	4	3	12	1	1
9KX6	9	9	16					1	10JY8	10	12	36						12AD7	12	8	85					
9KZ8	9	39	26	4	5	12	2	1				61								85						2
			26	4	5	12	9	1	10KR8	10	12	22						12AE6	12	41	52	4	3	12	1	1
9LA6	9	9	21					1				59								66	4	3	12	5	1	
9M-HH3	9	2	56					1	10KU8	10	39	22	4	5	12	7	1			66	4	3	12	6	1	
			56					2				60	4	5	12	2	1	12AE7	12	39	32	5	4	9	2	1
9M-P12	9	41	38	3	4	2	1	1				60	4	5	12	3	1				32	5	4	9	7	1
9R-A6	9	40	34	4	5	9	7	1	10LB8	10	12	21						12AE10	12	36	30	1	12	12	8	1
9R-AL1	9	39	33	4	5	2	3	1				71								31	1	12	12	3	1	
9R-HR2	9	11	68					1	10LD6	10	9	51						12AF3	12	15	12					
			56					2	10LD12	10	17	90						12AF6	12	41	37	4	3	12	1	1
9U8	9	11	79					1				63						12AF11	12	36	31	1	12	12	11	1
			55					2	10LE8	10	39	29	4	5	12	9	1				31	1	12	12	6	1
9V9	9	42	31	5	6	12	3	1	10LW8	10	12	25						12AG6	12	41	35	4	3	12	1	1
			30	5	6	12	8	1				92						12AH7	12	38	48	8	7	12	1	1
9X8	9	12	73					1	10LY8	10	12	21								48	8	7	12	5	1	
			61					2				*99						12AJ6	12	41	40	4	3	12	1	1
10AF11	10	36	31	1	12	12	11	1				*Tube good if it reads 28 or more.								66	4	3	12	5	1	
			31	1	12	12	6	1	10LZ8	10	12	54								66	4	3	12	6	1	
			35	1	12	12	3	1				*99								35	5	4	12	9	1	
10AL11	10	36	31	1	12	12	3	1	*Tube good if it reads 40 or more.									12AJ7	12	39	32	5	4	12	2	1
			27	1	12	12	8	1	10T10	10	36	28	1	12	12	3	1				33	3	4	12	2	1
10BQ5	10	23	68					1				25	1	12	12	8	1	12AL5	12	41	33	3	4	12	2	1
10C8	10	13	59					1	10Z10	10	36	30	1	12	12	11	1				33	3	4	12	7	1
			73					2				95	1	12	12	6	1	12AL8	12	39	34	5	4	12	3	1
10CW5	10	23	58					1	11AF9	10	42	27	5	6	7	1	1				52	5	4	12	8	1
10D2	19	41	33	3	4	12	2	1				27	5	6	2	8	1	12AL11	12	36	31	1	12	12	3	1
			33	3	4	12	7	1	11AR11	12	36	28	1	12	12	5	1				27	1	12	12	8	1
10DE7	10	20	81					1				28	1	12	12	10	1	12AQ5	12	3	77					
			90					2	11BM8	12	39	33	5	4	12	3	1	12AS5	12	4	55					1
10DR7	10	39	32	5	4	2	3	1				39	5	4	12	1	1	12AT6	12	6	85					
			41	5	4	2	7	1	11BN11	10	36	29	1	12	12	3	1				78					2
10DX8	10	39	26	4	5	12	8	1				29	1	12	12	7	1	12AT7	12	8	74					
			26	4	5	12	1	1	11BQ11	10	36	28	1	12	12	5	1				74					2
10/E/312	25	29	47					1				28	1	12	12	10	1	12AU5	12	28	71					
10/E/349	6	29	79					1	11BT11	10	36	27	1	12	6	11	1	12AU6	12	1	82					1
10/E/558	6	38	52	7	2	12	10	1				30	1	12	8	5	1	12AU7	12	8	75					1
			93					1				26	1	12	8	3	1				75					2
10/E/11448	6	29	63					1	11C5	12	4	54						12AU8	12	12	56					1
10/E/11533	6	29	63					1	11CA11	10	36	35	1	12	8	3	1				72					2
10/E/11581	6	38	40	7	2	12	10	1				33	1	12	8	6	1	12AV5	12	28	62					1
10EB8	10	12	35					1				33	1	12	8	6	1	12AV6	12	6	91					1
			99					2	11CY7	12	39	33	1	12	7	8	1				78					2
10EG7	10	38	32	8	7	12	1	1				31	5	4	2	3	1	12AV7	12	8	55					1
			45	8	7	12	4	1	11DS5	10	3	76									55					2
10EM7	10	38	32	8	7	12	1	1	11FY7	12	36	25	1	12	12	3	1	12AW6	12	1	78					1
			45	8	7	12	4	1				42	1	12	12	10	1	12AW8	12	12	44					1
10EW7	10	20	87					1				42	1	12	12	10	1				78					2
			92					2	11HM7	10	39	*29	4	5	6	2	1	12AX3	12	36	30	1	12	10	4	1
10FD7	10	39	25	4	5	2	3	1	*Normally shows short position 3-9.									12AX4	12	34	13					

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
12AZ7	12	8	73					1	12D4	12	34	11					1	12EM6	12	39	34	5	4	12	1	1
			73					2	12DA6	12	9	80					1	12EN6	12	29	90	5	4	12	9	1
12B4	12	40	35	5	4	3	7	1	12DB5	12	16	30					1	12EQ7	12	39	36	5	4	12	2	1
12B7	12	37	45	8	1	12	6	1	12DE8	12	39	36	5	4	12	1	1	12EZ6	12	41	34	5	4	12	8	1
12BA6	12	1	78					1				34	5	4	12	3	1	12F5	12	38	71	5	4	12	8	1
12BA7	12	39	33	5	4	12	2	1	12DF5	12	39	52	5	4	9	1	1	12F8	12	39	32	4	3	12	1	1
12BA11	12	36	28	1	12	12	4	1				52	5	4	9	6	1	62	5	4	12	1	1	1	1	
◆12B-B14	12	44	*33	4	5	1	2	1	12DF7	12	8	*85					2	62	5	4	12	1	1	1	1	
												*85						62	5	4	12	6	1	1	1	
									*Normally shows short position 3-6-7-8.																	
12BC32	12	6	91					1	12DJ8	12	39	31	5	4	12	2	1	12F31	12	1	78					1
			78					2				31	5	4	12	7	1	12FK6	12	41	40	4	3	12	1	1
12BD6	12	1	85					1	12DK6	12	1	61					1	65	4	3	12	5	1	1	1	
12BE3	12	36	26	1	12	4	10	1	12DK7	12	39	33	5	4	8	1	1	65	4	3	12	6	1	1	1	
12BE6	12	1	91					1				80	5	4	8	6	1	12FM6	12	41	35	4	3	12	1	1
12BF6	12	6	85					1	12DL8	12	39	80	5	4	8	9	1	68	4	3	12	5	1	1	1	
			80					2				35	5	4	12	3	1	68	4	3	12	6	1	1	1	
12BF11	12	36	25	1	12	12	3	1				65	5	4	12	9	1	12FQ7	12	8	68				1	
			25	1	12	12	8	1	12DM4	12	34	65	5	4	12	1	1	68							2	
12BH7	12	8	56					1				65	5	4	12	1	1	12FQ8	12	39	39	5	4	12	2	1
			56					2	12DN6	12	26	47					1	39	5	4	12	7	1	1	1	
12BK5	12	10	53					1	12DQ4	12	34	11					1	12FR8	12	39	*25	4	5	12	3	1
12BK6	12	6	86					1	12DQ6	12	27	65					1	*37	4	5	12	1	1	1	1	
			70					2	12DQ6B	12	27	62					1	*62	4	5	12	8	1	1	1	
12BL6	12	41	35	4	3	12	1	1	12DQ7	12	9	36					1	*Normally shows short position 5.								
12BN6	12	7	75					1	12DS7	12	39	34	5	4	12	3	1	12FS5	12	1	99				1	
12BQ6	12	27	69					1				*85	5	4	12	1	1	12FT6	12	41	52	4	3	12	1	1
12BR3	12	15	10					1				*85	5	4	12	9	1	66	4	3	12	5	1	1	1	
12BR7	12	39	32	5	4	9	2	1				*85	5	4	12	9	1	66	4	3	12	6	1	1	1	
			36	5	4	9	6	1	12DT5	12	16	45					1	12FV7	12	8	42				1	
			36	5	4	9	7	1				91					1	42						2		
12BS3	12	44	27	4	5	2	7	1	12DT6	12	1	91					1	12FX5	12	4	68				1	
12BT3	12	36	27	1	12	4	10	1	12DT7	12	8	*85					2	12FX8	12	39	32	5	4	12	2	1
12BT6	12	6	85					1				*85					1	28	5	4	12	6	1	1	1	
			78					2	12DT8	12	8	71					1	12G4	12	41	41	4	3	1	6	1
			85					1				71					2	12G11	12	36	33	1	12	12	3	1
12BU6	12	6	80					2	12DU7	12	39	31	5	4	12	1	1	31	1	12	12	8	1	1	1	
12BV7	12	9	39					1				77	5	4	12	7	1	12GA6	12	41	36	4	3	12	1	1
12BV11	12	36	30	1	12	12	6	1	12DV7	12	39	77	5	4	12	9	1	12G-B3A	12	27	65				1	
			30	1	12	12	7	1				49	5	4	9	7	1	12G-B7	12	27	61				1	
12BW4	12	39	50	5	4	12	1	1				78	5	4	9	2	1	12GC5	12	16	26				1	
			50	5	4	12	7	1	12DV8	12	39	78	5	4	9	3	1	12GC6	12	26	52				1	
12BX6	12	9	76					1				35	5	4	12	3	1	12GE5	12	36	*24	1	12	11	3	1
12BX7	12	25	55					1				58	5	4	12	9	1	*Normally shows short position 4-10.								
			55					2				58	5	4	12	1	1	12GJ5	12	35	65				1	
12BY7	12	9	42					1	12DW4A	12	44	27	4	5	2	7	1	12G-K17	12	34	12				1	
12BZ6	12	1	61					1	12DW5	12	16	30					1	12GN7	12	9	21				1	
12BZ7	12	8	95					1	12DW7	12	8	75					1	12GT5	12	35	63				1	
			95					2				*90					2	12GT5A	12	35	63				1	
12C5	12	4	44					1	*Tube good if it reads 22 or more.																	
12C8	12	38	55	7	2	12	10	1	12DW8	12	39	32	5	4	12	2	1	*Normally shows short position 3-4-7-10-11.								
			65	7	2	12	4	1				44	5	4	12	7	1	12GW6	12	27	62				1	
			65	7	2	12	5	1	12DY8	12	39	30	5	4	12	1	1	12H4	12	40	44	4	3	2	6	1
12C8Y	12	38	55	7	2	12	10	1				35	5	4	12	9	1	12H6	12	38	48	7	2	12	3	1
			65	7	2	12	4	1				35	5	4	12	9	1	48	7	2	12	5	1	1	1	
12CA5	12	4	55					1	12DZ6	12	41	33	4	3	12	1	1	12H31	12	1	91				1	
12CK3	12	44	25	4	5	7	2	1	12DZ8	12	39	27	4	5	8	3	1	12HB25◆	12	44	*33	4	5	1	2	1
12CL3	12	44	27	4	5	2	7	1				30	4	5	2	1	1	*Normally shows short position 3-6-7-8.								
12CM6	12	16	64					1	12E5	12	25	93					1	12HE7	12	36	27	1	12	10	2	1
12CN5	12	41	33	4	3	2	5	1	12EA6	12	41	32	4	3	12	1	1	27	1	12	10	9	1	1	1	
12CR6	12	41	39	4	3	12	7	1	12EC8	12	39	30	5	4	12	9	1	12HG7	12	9	28				1	
			61	4	3	12	2	1				32	5	4	12	1	1	12HL5	12	39	30	4	5	1	2	1
12CS6	12	1	94					1	12ED5	12	4	57					1	12HL7	12	39	*33	4	5	6	2	1
12CT3	12	39	32	4	5	6	2	1	12EG6	12	41	36	4	3	12	1	1	*Normally shows short position 3-9.								
12CT8	12	13	57					1	12EH5	12	4	57					1	12HU8	12							

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
12J8	12	39	30	5	4	12	1	1	12T10	12	36	28	1	12	12	3	1	14E6	12	37	40	8	1	4	3	1
			35	5	4	12	8	1				25	1	12	12	8	1				69	8	1	4	5	1
			35	5	4	12	9	1	12U7	12	39	40	5	4	9	2	1				69	8	1	4	6	1
12JB6	12	35	62					1	12V6	12	29	79	5	4	9	7	1	14E7	12	37	47	8	1	12	6	1
12JB6A	12	35	62					1													68	8	1	12	3	1
12JM6	12	36	26	1	12	4	5	1	12W6	12	29	51									68	8	1	12	4	1
12JN6	12	36	27	1	12	4	11	1	12X4	12	41	44	4	3	12	1	1	14F7	12	37	45	8	1	12	4	1
12JN8	12	14	67					2				44	4	3	12	6	1				45	8	1	12	5	1
			53					2	13CM5	12	27	57						14F8	12	37	30	7	2	12	1	1
12JQ6	12	39	*34	4	5	8	7	1	13CW4	14	43	*87	10	12	12	2	1				30	7	2	12	8	1
			*57	4	5	8	6	1													52	5	4	12	8	1
			*May show short position 2-3.					1	*For grid emission turn D switch to position 4.												35	5	4	12	2	1
12JS6	12	36	*29	1	12	9	5	1	13D1	25	25	78									35	5	4	12	6	1
			*Normally shows short position 3-4-10-11.					1	13DE7	12	20	81									35	5	4	12	6	1
12JT6	12	35	65					1				90						14GW8	14	39	25	4	5	2	8	1
12JT6A	12	35	65					1	13DF7	12	8	*85									35	4	5	7	1	1
12JZ8	12	36	29	1	12	6	7	1				*85						14H7	12	37	35	8	1	12	6	1
			40	1	12	6	10	1										14J7	12	37	35	8	1	12	6	1
12K5	12	41	35	4	3	5	6	1	13DR7	12	39	32	5	4	2	3	1				50	8	1	12	4	1
12K7	12	38	52	7	2	12	10	1				41	5	4	2	7	1	14JG8	14	39	32	4	5	12	8	1
12K8	12	38	35	7	2	12	5	1	13EM7	12	38	32	8	7	12	1	1				27	4	5	12	6	1
12KA8	12	39	26	4	5	12	6	1				45	8	7	12	4	1	14N7	12	37	42	8	1	12	4	1
			33	4	5	12	2	1	13FD7	12	39	25	4	5	2	3	1				42	8	1	12	5	1
12KL8	12	39	31	4	5	12	2	1				32	4	5	2	7	1	14Q7	12	37	35	8	1	12	4	1
			70	4	5	12	8	1	13FG7	12	14	68						14R7	12	37	35	8	1	12	6	1
12L6	12	29	47					1				56									72	8	1	12	3	1
12MD8	12	44	35	4	5	12	6	1	13FM7	14	36	25	1	12	3	8	1				72	8	1	12	4	1
			35	4	5	12	8	1				36	1	12	3	10	1	14S7	12	37	38	8	1	12	6	1
			35	4	5	12	9	1	13FR7	12	39	24	4	5	2	3	1				52	8	1	12	4	1
12Q7	12	38	40	7	2	12	10	1				32	4	5	2	7	1	14V7	12	37	32	8	1	12	6	1
			63	7	2	12	4	1	13GB5	12	44	*25	4	5	2	1	1	14W7	12	37	31	8	1	4	6	1
			63	7	2	12	5	1				27	4	5	12	2	1	14X7	12	37	43	8	1	12	3	1
12R5	12	41	39	4	3	2	5	1	13GF7	12	44	27	4	5	12	2	1				36	8	1	12	5	1
12R-K19	12	15	10					1				38	4	5	12	9	1				35	8	1	12	6	1
12R-LL5	12	8	68					1	13GF7A	12	44	27	4	5	12	2	1	14Y4	12	37	45	8	1	12	3	1
			68					2				38	4	5	12	9	1				45	8	1	12	6	1
12S8	12	38	45	8	7	5	10	1	13J10	12	36	96	1	12	12	6	1	15A6	15	39	30	5	4	12	2	1
			62	8	7	5	1	1				28	1	12	12	11	1	15A8	15	38	36	7	2	12	4	1
			62	8	7	5	4	1	13JT8	12	12	20									40	7	2	12	3	1
			63	8	7	2	3	1				*99									31	1	12	12	11	1
								2																		
12SA7	12	38	37	7	2	12	5	1													31	1	12	12	6	1
12SC7	12	38	48	8	7	12	3	1	13JZ8	12	36	29	1	12	6	7	1				35	1	12	12	3	1
			48	8	7	12	4	1				40	1	12	6	10	1	15BD11	15	36	26	1	12	12	11	1
12SF5	12	38	41	8	7	12	3	1	13SJ7	12	30	83									31	1	12	12	3	1
12SF7	12	38	46	8	7	12	2	1	13V10	12	36	33	1	12	12	3	1				31	1	12	12	6	1
			69	8	7	12	5	1				33	1	12	12	8	1	15BD11A	15	36	26	1	12	12	11	1
12SG7	12	30	77					1	13Z10	12	36	30	1	12	12	11	1				31	1	12	12	3	1
12SH7	12	30	77					1				95	1	12	12	6	1	15CW5	15	23	58					
12SJ7	21	30	83					1	14A4	12	37	41	8	1	12	6	1	15DQ8	15	39	26	4	5	12	8	1
12SK7	12	30	84					1	14A5	12	37	34	8	1	12	6	1				26	4	5	12	8	1
12SL7	12	25	*85					1	14A7	12	37	45	8	1	12	6	1	15EA7	15	38	26	4	5	12	1	1
			*85					2	14AF7	12	37	41	8	1	12	4	1				35	8	7	12	1	1
			*Tube good if it reads 22 or more.					1				41	8	1	12	5	1	15EW6	15	1	77					
12SN7	12	25	78					1	14B6	12	37	40	8	1	4	3	1									
			78					2				68	8	1	4	5	1									
12SQ7	12	38	42	8	7	12	2	1																		
			71	8	7	12	4	1	14B8	12	37	42	8	1	12	4	1	15EW7	15	20	87					
			71	8	7	12	5	1	14BF11	14	36	25	1	12	12	3	1				92					
12SR7	12	38	46	8	7	12	2	1				25	1	12	12	3	1	15FM7	15	36	25	1	12	3	8	1
			68	8	7	12	4	1	14BL11	14	36	29	1	12	12	3	1				36	1	12	3	10	1
								1				31	1	12	12	5	1	15FY7	15	36	25	1	12	12	3	1
12SS7	12	30	97					1				29	1	12	12	11										

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
15MF8	15	36	35	1	12	6	7	1	17CA5	17	4	55					1	18A5	18	28	69					1
			34	1	12	6	10	1	17CK3	17	44	25	4	5	7	2	1	18AJ10	18	36	32	1	12	4	3	1
16A5	16	23	68					1	17CL3	17	44	27	4	5	2	7	1				33	1	12	4	8	1
16A8	16	39	33	5	4	12	3	1	17CQ4	17	34	11					1	18AK5	18	1	63					1
			39	5	4	12	1	1	17CT3	17	39	32	4	5	6	2	1	18AQ5	18	3	77					1
16AK9	7	36	33	6	12	6	10	1	17CU5	17	4	47					1	18C51	18	39	29	9	1	12	3	1
			35	6	12	6	3	1	17D4	17	34	11					1				29	9	1	12	7	1
			31	6	12	6	8	1	17DE4	17	34	13					1	18DZ8	18	39	27	4	5	8	3	1
16AQ3*	16	40	30	5	4	7	3	1	17DM4	17	34	11					1				30	4	5	2	1	1
								1	17DQ4	17	34	11					1	18FW6	18	1	79					1
								1	17DQ6	17	27	65					1	18FX6	18	1	92					1
16AQ3	16	40	30	5	4	3	7	1	17DQ6B	17	27	62					1	18FY6	18	6	84					1
16BQ11	16	36	28	1	12	12	5	1	17DW4A	17	44	27	4	5	2	7	1				81					2
			28	1	12	12	10	1	17EW8	17	8	65					1	18GB5♦	18	44	*25	4	5	2	1	1
16BX11	16	36	32	1	12	12	2	1				65					2									1
			31	1	12	12	5	1	17FY7	17	36	25	1	12	12	3	1	18GD6	18	1	80					1
			31	1	12	12	8	1				42	1	12	12	10	1	18GE6	18	6	78					1
16C-B28	16	36	*28	1	12	5	9	1	17GE5	17	36	*24	1	12	11	3	1				85					2
								1									1	18GV5	18	36	*26	1	12	5	9	1
16CL8	16	14	69					2	17GJ5	17	35	65					1									1
			51					2	17GJ5A	17	35	65					1	18GV8	18	39	25	4	5	12	9	1
16GK6	16	9	40					1	17GT5	17	35	63					1				25	4	5	12	2	1
16GY5	16	36	*25	1	12	5	9	1	17GT5A	17	35	63					1	18HB8	18	39	36	5	4	12	9	1
								1	17GV5	17	36	*26	1	12	9	5	1				33	5	4	12	1	1
16HBS	16	36	*25	1	12	11	3	1									1	18J6	18	6	60					1
								1	17GW6	17	27	62					1				60					2
16K11	16	36	38	1	12	12	7	1	17GY5	17	36	*25	1	12	5	9	1	18R-AL1	18	39	33	4	5	2	3	1
			38	1	12	12	9	1									1	19AJ8	6	39	85	5	4	12	1	1
			38	1	12	12	11	1	17H3	17	15	13					1				38	5	4	12	9	1
16KA6	16	36	30	1	12	4	5	1	♦17H-B25	17	44	*33	4	5	1	2	1	19AQ5	19	3	77					1
								1									1	19AU4	19	34	10					1
16LD6	16	9	51					1									1	19B6	19	26	66					1
16LU8	16	36	27	1	12	6	7	1	17HC8	17	39	36	5	4	12	3	1	19B6G	19	26	66					1
			27	1	12	6	10	1				38	5	4	12	1	1	19BX6	19	9	76					1
16Y9	16	42	27	5	6	12	1	1	17HG8	17	39	25	4	5	3	2	1	19BY7	19	9	62					1
			27	5	6	12	8	1				25	4	5	1	6	1	19C8	19	17	94					1
17A8	17	11	66					1	17JB6	17	35	62					1				62					2
			55					2	17JB6A	17	35	62					1	19CG3	19	36	30	1	12	4	10	1
17AB10	17	36	29	1	12	12	11	1	17JF6	17	44	*26	4	5	2	6	1	19CL8-A	19	14	74					1
			95	1	12	12	6	1									1				53					2
17AF3	17	15	12					1	17JG6	17	35	56					1	19D8	19	39	32	5	4	12	2	1
17AV5	17	28	62					1	17JG6A	17	35	56					1				35	5	4	12	9	1
17AX3	17	36	30	1	12	10	4	1	17JK8	17	8	54					1	19DE7	19	20	81					1
17AX4	17	34	13					1				55					2				90					2
17AY3	17	44	27	5	4	7	2	1	17JM6	17	36	26	1	12	4	5	1	19DN6	19	26	47					1
17AY3B	17	44	27	5	4	7	2	1	17JN6	17	36	27	1	12	4	11	1	19EA8	19	11	71					1
♦17B-B14	17	44	*33	4	5	1	2	1	17JQ6	17	39	*34	4	5	8	7	1				56					2
								1				*57	4	5	8	6	1	19EW7	19	20	87					1
17BD11	17	36	26	1	12	12	11	1									1				92					2
			31	1	12	12	3	1	17JR6	17	35	50					1	19EZ8	19	39	33	5	4	12	2	1
			31	1	12	12	6	1	17JS6	17	36	*29	1	12	9	5	1				33	5	4	12	7	1
17BE3	17	36	26	1	12	4	10	1									1				33	5	4	12	9	1
17BF11	17	36	25	1	12	12	3	1	17JT6	17	35	65					1	19FX5	19	4	68					1
			25	1	12	12	8	1	17JT6A	17	35	65					1	19GQ7	19	39	24	4	5	3	2	1
17BF11A	17	36	25	1	12	12	3	1	17JZ8	17	36	29	1	12	6	7	1				24	4	5	3	6	1
			25	1	12	12	8	1				40	1	12	6	10	1				24	4	5	3	8	1
17BH3	17	44	27	5	4	7	2	1	17KV6	17	44	30	4	5	1	2	1	19GY5	19	36	*25	1	12	5	9	1
17BH3A	17	44	27	5	4	7	2	1	17KW6♦	17	44	30	4	5	1	8	1									1
17BJ6	17	1	81					1	17L6	17	29	47					1	19HR6	19	1	71					1
17BQ6	17	27	69					1	17LD8	17	44	25	4	5	12	2	1	19HS6	19	1	66					1
17BR3	17	15	10					1				33	4	5	12	9	1	19HV8	19	14	64					1
17BS3	17	44	27	4	5	2	7	1	17R5	17	4	50					1				*99					2
17BW3	17	36	28	1	12	4	10	1	17W6	17	29	52					1									1
17BZ3	17	36	30	1	12	4	10	1	17X10	17	36	98	1	12	12	6	1	19J6	19	2	60					1
17C5	17	4	44					1				28	1	12	12	11	1				60					2
17C8	17	39	33	5	4	12	2	1	17Y9	17	42	27	5	6	12	1	1	19JC6	19	9	65					1
			65	5	4	12	7	1									1				67					1
			65	5	4	12	8	1	17Z3*	17	39	33	4	5	2	9	1	19JN8	19	14	53					2
17C9	17	39	28	5	4	6	1	1									1	♦19KF6	19	44	33	4	5	7	1	1
			28	5	4	10	7	1									1	19KG8	19	39	21	4	5	12	9	1
								1									1				21	4	5	12	2	1

*Normal Shorts refer to position of "D" Switch.

♦Use TC-80 Adapter.

15MF8-19KG8

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi-tivity	A	B	C	D	Test Pos.																		
19MR9	19	1	73					1	23JS6A	22	36	*29	1	12	9	5	1	26Z5	25	39	36	5	4	9	1	1																		
19Q9	19	39	25	4	5	12	1	1	*Normally shows short position 3-4-10-11.									27GB5	25	44	*25	4	5	2	1	1																		
19T8	19	17	90	4	5	12	8	1	23Z9	22	36	30	1	12	6	10	1	*Normally shows short position 3-6-7-8.									27KG6	25	44	*26	4	5	1	8	1									
			63					2				39	1	12	6	3	1	*Normally shows short position 2-3-6-7.									28D7	30	37	40	8	1	12	2	1									
19V8	19	39	40	5	4	12	6	1	24BF11	25	36	25	1	12	12	3	1	28EC4	30	38	40	8	1	12	7	1	28GB5	30	44	*25	4	5	2	1	1									
			32	5	4	12	2	1				25	1	12	12	8	1	*Normally shows short position 3-6-7-8.									28HA6	30	9	23					1									
			32	5	4	12	7	1	24JE6A	25	35	59					1	28HD5	30	36	*27	1	12	3	11	1	*Normally shows short position 4-5-9-10.									29GK6	30	9	40					1
			61	5	4	12	9	1	24JZ8	25	36	29	1	12	6	7	1	29GK6	30	9	40					1	29KQ6	30	44	*29	4	5	1	8	1									
19X3	19	39	29	5	4	12	9	1				40	1	12	6	10	1	*Normally shows short position 2-3-6-7.									29LE6	30	44	*30	4	5	8	1	1									
19X8	19	12	73					1	24LQ6	25	35	52					1	30A5	30	41	27	3	4	5	2	1	*If no test, use alternate settings.									30AE3	30	40	30	5	4	7	3	1
			61					2	25A6	25	29	74					1	30AE3	30	40	30	5	4	3	7	1	*If no test, use alternate settings.									30AG11	30	36	28	1	12	12	8	1
19Y3	19	39	29	4	5	12	9	1	25AU4	25	34	10					1	30AG11	30	36	28	1	12	12	5	1				33	1	12	12	10	1				33	1	12	12	3	1
20AQ3*	19	40	30	5	4	7	3	1	25AV5	25	28	62					1	30C1	9	11	66					1	30CW5	30	23	58					1				30	1	12	3	11	1
*If no test, use alternate settings.									25AX4	25	34	13					1	30HD5	30	36	*27	1	12	3	11	1	*Normally shows short position 4-5-9-10.									30HJ5	30	36	*27	1	12	3	11	1
20AQ3	19	40	30	5	4	3	7	1	25B6	25	29	48					1	*Normally shows short position 4-5-9-10.									30JZ6	30	36	*31	1	12	4	5	1									
20D1	9	41	33	3	4	12	2	1	25BK5	25	10	53					1	*Some tubes may show short position 9-11.									30KD6	30	36	*26	1	12	9	5	1									
			33	3	4	12	7	1	25BQ6	25	27	69					1	30KJ5	30	36	*27	1	12	3	11	1	*Normally shows short position 3-4-10-11.									30KG6	30	44	*26	4	5	1	8	1
20EQ7	19	39	34	5	4	12	2	1	25BR3	25	15	10					1	30L1	7	39	33	5	4	7	2	1	*Normally shows short position 2-3-6-7.									30M-P23	30	41	30	3	4	5	2	1
			71	5	4	12	8	1	25C5	25	4	44					1	30M-P27	30	41	30	3	4	5	2	1	*Normally shows short position 2-3-6-7.									30P16	16	23	68					1
20EW7	19	20	87					1	25C6	25	29	45					1	31AL10	30	36	51	1	12	6	3	1	*Normally shows short position 3-4-10-11.									31J6	30	36	51	1	12	6	3	1
			92					2	25CA5	25	4	55					1				33	1	12	6	8	1	*Normally shows short position 3-4-10-11.									31LQ6	30	35	52					1
20EZ7	19	39	35	2	1	3	5	1	25CD6	25	26	53					1	32A8	30	39	33	5	4	12	3	1	*Normally shows short position 3-4-10-11.									32ET5	30	4	60					1
			35	2	1	3	8	1	25CG3	25	36	30	1	12	4	10	1	32H7	35	36	34	1	12	7	2	1	*Normally shows short position 9-11.									32HQ7	35	36	34	1	12	7	2	1
20LF6	20	36	*31	1	12	5	9	1	25CK3	25	44	30	4	5	7	2	1	*Normally shows short position 9-11.									33GT7	30	36	*55	1	12	7	10	1									
*May show short position 3-4-7-10-11.									25CM3	25	44	30	4	5	2	7	1	33GY7	30	36	*56	1	12	7	11	1	*Normally shows short position 9-10.									33GY7A	30	36	*56	1	12	7	11	1
21A6	22	39	*32	5	4	7	2	1	25CT3	25	39	32	4	5	6	2	1	*Normally shows short position 9-10.												*26	1	12	7	2	1									
*Normally shows short position 1-6-9.									25CU6	25	27	69					1	33HE7	30	36	27	1	12	10	2	1	*Normally shows short position 9-10.									33JR6	30	35	55					1
21AK6	22	1	82					1	25D4	25	34	11					1	33JV6	30	36	28	1	12	4	11	1	*Some tubes may show short position 5-6-8-9.									34CD3	35	36	*27	1	12	4	10	1
21EX6	22	26	42					1	25DK4	25	41	26	3	4	6	5	1	*Normally shows short position 9-11.																										
21GY5	22	36	*25	1	12	5	9	1	25DN6	25	26	47					1				27	1	12	3	11	1				27	1	12	10	9	1				27	1	12	10	9	1
*Normally shows short position 3-4-7-10-11.									25DQ6	25	27	65					1	30KJ5	30	36	*27	1	12	3	11	1				28	1	12	4	11	1				28	1	12	4	11	1
21HB5	22	36	*25	1	12	11	3	1	25DT5	25	16	45					1	*Normally shows short position 4-5-9-10.												28	1	12	4	11	1									
*Normally shows short position 4-10.									25E5	25	27	58					1	30JZ6	30	36	*31	1	12	4	5	1				28	1	12	4	11	1									
21HD5	22	36	*27	1	12	3	11	1	25EC6	25	26	53					1	*Some tubes may show short position 9-11.												28	1	12	4	11	1									
*Normally shows short position 4-5-9-10.									25EH5	25	4	57					1	30KD6	30	36	*26	1	12	9	5	1				28	1	12	4	11	1									
21HJ5	22	36	*27	1	12	3	11	1	25F5	25	4	54					1	*Normally shows short position 3-4-10-11.												28	1	12	4	11	1									
*Normally shows short position 4-5-9-10.									25F5A	25	4	54					1	30KG6	30	44	*26	4	5	1	8	1				28	1	12	4	11	1									
21JS6	22	36	*29	1	12	9	5	1	25G-B6	25	27	64					1	*Normally shows short position 2-3-6-7.												28	1	12	4	11	1									
*Normally shows short position 3-4-10-11.									25GE5	25	36	*24	1	12	11	3	1	30L1	7	39	33	5	4	7	2	1				28	1	12	4	11	1									
21JV6	22	36	28	1	12	4	11	1	*Normally shows short position 4-10.									30M-P23	30	41	30	3	4	5	2	1				28	1	12	4	11	1									
21JZ6	22	36	*29	1	12	4	5	1	25HX5	25	44	*30	4	5	7	1	1	30M-P27	30	41	30	3	4	5	2	1				28	1	12	4	11	1									
*Some tubes may show short position 9-11.									*Normally shows short position 2-3.									30P16	16	23	68					1				28	1	12	4	11	1									
21KA6	22	36	*30	1	12	9	5	1	25JQ6	25	39	*34	4	5	8	7	1	31AL10	30	36	51	1	12	6	3	1				28	1	12	4	11	1									
*May show short position 3-4-7-11.												*57	4	5	8	6	1				33	5	4	7	6	1				28	1	12	4	11	1									
21KQ6	22	44	*29	4	5	1	8	1	25L6	25	29	47					1	30M-P23	30	41	30	3	4	5	2	1				33	5	4	7	6	1									
*Normally shows short position 2-3-6-7.									25R-K19	25	15	10					1	30M-P27	30	41	30	3	4	5	2	1				33	5	4	7	6	1									
21LG6	22	36	*32	1	12	9	5	1	25SN7	25	25	78					1	30P16	16	23	68					1				33	5	4	7	6	1									
*May show short position 2-3-4-7-10-11.												78					2	31AL10	30	36	51	1	12	6	3	1				33	5	4	7	6	1									
21LR8	22	44	31	4	5	12	2	1	25U4	25	34	11					1	31J6	30	36	*29	1	12	9	5	1				33	5	4	7	6	1									
			31	4	5	12	9	1	25W4	25	34	11					1	*Normally shows short position 3-4-10-11.									31LQ6	30	35	52					1									
21LU8	22	36	27	1	12	6	7	1	25W6	25	29	51					1	32A8	30	39	33	5	4	12	3	1				33	5	4	7	6	1									
			27	1	12	6	10	1	25Z6	25	38	34	7	2	12	3	1	32ET5	30	4	60					1				33	5	4	7	6	1									
22AL3*	22	40	30	5	4	7	3	1	26A6	25	1	77					1	32HQ7	35	36	34	1	12	7	2	1				33	5	4	7	6	1									
*If no test,																																												

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.						
6087	5	33	23					1	6677	6	39	*32	5	4	2	9	1	7308	6	8	23					1						
			23					2													24					2						
6096	6	1	63					1	6678	6	11	79					1	7320	6	23	68					1						
6097	6	41	33	3	4	12	2	1				55				2	7355	6	38	37	7	2	12	6	1							
			33	3	4	12	7	1	6679	12	8	79				1	7360	6	39	29	4	5	12	3	1							
6100	6	41	41	4	3	1	6	1				79				2	7370	40	39	24	4	5	8	2	1							
6101	6	2	60					1	6680	12	8	75				2					24	4	5	8	7	1						
			60					2				75				2	7408	6	29	80					1							
6113	6	25	*85					1	6681	12	8	*85				2	7543	6	1	85					1							
			*85					2				*85				1	7551	15	39	*33	4	5	9	2	1							
	*Tube good if it reads 22 or more.												*Tube good if it reads 22 or more.												*Normally shows short position 3-8.							
6134	6	30	60					1	6686	6	9	60				1	7558	6	39	*26	4	5	3	2	1							
6135	6	41	41	4	3	1	6	1	6687	6	1	89				1					*Normally shows short position 1-9.											
6136	6	1	82					1	6688	6	23	82				1	7581	6	29	64					1							
6137	6	30	84					1	6689	6	39	25	4	5	12	2	1	7586	6	43	*65	10	12	12	2	1						
6146	6	38	*38	7	2	1	5	1	6829	12	8	54				1					*For grid emission turn D switch to position 4.											
	*Normally shows short position 4-6.											54				2	7587	6	43	*67	10	12	12	2	1							
6147	6	29	63					1	6883	12	38	*38	7	2	1	5	1				*For grid emission turn D switch to position 4.											
6159	25	38	*38	7	2	1	5	1				*38	4	3	12	2	1	7591	6	38	34	7	2	4	6	1						
	*Normally shows short position 4-6.									6887	6	41	33	4	3	12	2	1	7607	6	38	*32	7	2	1	5	1					
6180	6	25	78					1				33	4	3	12	7	1				*Normally shows short position 4-6.											
			78					2	6888	6	30	62				1	7643	6	11	72					1							
6186	6	1	80					1	6919	6	41	33	3	4	12	2	1				55				2							
6187	6	1	87					1				33	3	4	12	7	1	7687	6	11	77				1							
6188	6	25	*81					1	6922	6	8	24				1					67				2							
			*81					2				24				2	7693	6	1	93					1							
	*Tube good if it reads 22 or more.									6968	6	1	63			1	7694	6	1	84					1							
6189	12	8	75					1	6973	6	16	62				1	7695	50	39	34	5	4	12	6	1							
			75					2	7000	6	38	50	7	2	12	10	1	7701	12	39	*38	5	4	1	2	1						
6197	6	39	*32	5	4	2	9	1	7025	12	8	*85				1					*Normally shows short position 3-7-8-9.											
	*Normally shows short position 3-8.												*85			2	7716	12	12	53					1							
6198	12	8	75					1					*Tube good if it reads 22 or more.														2					
			75					2	7027	6	38	*36	7	2	5	6	1				*Tube good if it reads 20 or more.											
6201	12	8	74					1				92				1	7719	12	40	29	4	5	1	7	1							
			74					2	7036	6	1	92				1	7722	6	23	80					1							
6202	6	41	44	4	3	12	1	1	7044	12	39	30	4	5	8	2	1	7724	14	39	52	5	4	12	8	1						
			44	4	3	12	6	1				30	4	5	8	7	1				35	5	4	12	2	1						
6203	6	39	41	4	5	12	1	1	7054	12	9	42				1					35	5	4	12	6	1						
			41	4	5	12	9	1	7055	12	41	33	3	4	12	2	1	7728	12	8	74				1							
6211	12	8	54					1				33	3	4	12	7	1				74				2							
			54					2	7056	12	1	64				1	7729	12	8	*85					1							
6216	6	39	*29	4	5	3	2	1	7057	12	8	53				1					*85				2							
	*Normally shows short position 1-6.											53				2						*Tube good if it reads 22 or more.										
6218	6	39	72	4	5	12	2	1	7058	12	8	*85				2	7730	12	8	75					1							
6227	6	9	53					1				*85				2					75				2							
6265	6	1	89					1					*Tube good if it reads 22 or more.															1				
6267	6	39	40	5	4	2	9	1	7059	12	11	79				1	7731	6	11	79					1							
6336	6	38	29	8	7	12	1	1				55				2	7732	6	1	55					2							
			29	8	7	12	4	1	7060	12	13	55				1	7733	12	9	64					1							
6350	12	39	31	4	5	9	3	1				75				2	7738	6	41	*33	4	3	2	6	1							
			31	4	5	9	8	1	7061	12	16	67				1					*Normally shows short position 1-7.											
6360	12	39	30	4	5	9	1	1	7062	12	8	54				1	7751	6	38	30	2	7	4	5	1							
			30	4	5	9	3	1				54				2	7754	6	39	34	5	4	12	6	1							
6384	6	38	33	8	6	12	7	1	7105	12	38	35	8	7	12	1	1	7788	6	39	*29	4	5	3	2	1						
6417	12	39	33	5	4	8	9	1				35	8	7	12	4	1				*Normally shows short position 6-9.											
6463	12	39	28	4	5	9	3	1	7119	12	39	30	4	5	8	2	1	7867	6	26	53					1						
			28	4	5	9	8	1				30	4	5	8	7	1	7868	6	44	*27	4	5	2	6	1						
6485	6	1	58					1	7167	12	1	54				1					*Normally shows short position 1-7.											
6516	6	41	34	4	3	12	1	1	7189	6	39	*33	5	4	1	2	1	7895	6	43	*85	10	12	12	2	1						
6520	6	38	35	8	7	12	1	1				*33	5	4	1	2	1				*For grid emission turn D switch to position 4.											
			35	8	7	12	4	1	7199	6	39	30	5	4	12	7	1	7898	14	8	73					1						
6550	6	29	52					1				32	5	4	12	9	1				73				2							
6660	6	1	78					1	7233	6	39	33	5	4	2	7	1	7984	12	36	*59	1	12	7	11	1						
6661	6	1	89					1				*33	5	4	2	7	1				*Normally shows short position 2-3-4-5-6-8-9.											
6662	6	1	81					1	7247	12	8	75				1	8016	1	32	55					1							
6663	6	41	33	3	4	12	2	1				*90				2	8056	6	43	*63	10	12	12	2	1							
			33	3	4	12	7	1					*Tube good if it reads 22 or more.															1				
6664	6	2	83					1	7258	12	13	62				1					*For grid emission turn D switch to position 4.											
6669	6	3	77					1				61																				

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	O	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	O	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	O	D	Test Pos.									
8106	12	39	*24	4	5	3	7	1	CV450	6	29	*62					1	CV665	6	1	*73					1									
*Normally shows short position 2-6-9.									*For plate cap use jack next to socket 26.									*Tube good if it reads 23 or more.																	
8113	6	1	58					1	CV452	6	6	85					2	CV686	50	38	*85	2	11	3	5	1									
8136	6	1	65					1										*Normally shows short position 11.																	
8156	12	36	*32	1	12	9	10	1	CV453	6	1	91					1	*Normally shows grid emission.																	
*Normally shows short position 2-3-4-5-6-7-8-11.									CV454	6	1	78					1	CV692	6	31	8					1									
8233	6	44	*25	4	5	7	8	1	CV455	12	8	74					2	CV694	12	30	77				1										
*Normally shows short position 2-6.																		CV697	12	30	83				1										
8278	6	44	*31	4	5	3	7	1	CV491	12	8	75					2	CV698	12	30	83				1										
*Normally shows short position 1-2-6-8.																		*Normally shows short position 11.																	
8327	6	23	65					1	CV492	12	8	*85					1	CV700	12	38	46	8	7	12	2	1									
8417	6	29	54					1	*Tube good if it reads 22 or more.									CV703	6	38	35	7	2	12	5	1									
8458	12	44	32	4	5	9	1	1	CV493	6	41	44	4	3	12	1	1	CV706	6	38	48	7	2	12	10	1									
																		CV717	5	33	22					1									
9001	6	1	93					1	CV511	6	29	79					1	CV723	3	38	39	7	2	12	5	1									
9002	6	41	*46	4	3	1	6	1	CV538	12	38	37	7	2	12	5	1	CV726	35	37	31	8	1	12	2	1									
*Normally shows short position 2-7.									CV544	12	30	84					1	CV728	2	38	53	7	2	12	10	1									
9003	6	1	*73					1	CV547	12	38	42	8	7	12	2	1	CV729	5	33	12					1									
*Tube good if it reads 23 or more.																		CV731	6	29	91					1									
9006	6	41	*55	4	3	1	5	1	CV551	25	29	45					1	CV732	6	34	11					1									
*Normally shows short position 2-7.									CV552	25	29	47					1	CV747	6	30	60					1									
A863	6	38	50	7	2	12	10	1	CV553	25	29	47					1	CV753	2	41	*70	7	1	2	6	1									
A1834	6	38	35	8	7	12	1	1	CV554	6	38	48	7	2	12	3	1	*Normally shows short position 5-11.																	
																		CV755	1	38	55	7	2	12	5	1									
AR18	6	38	40	7	2	12	10	1	CV559	25	38	34	7	2	12	3	1	CV756	1	38	55	7	2	12	5	1									
																		CV760	1	38	55	7	2	12	5	1									
ARDD3	6	38	63	7	2	12	4	1	CV561	35	29	54					1	CV764	2	38	54	7	2	12	10	1									
																		CV768	2	38	48	7	2	12	5	1									
ARH1	6	38	48	7	2	12	5	1	CV562	35	29	54					1	CV770	2	38	54	7	2	12	10	1									
ARP15	6	38	52	7	2	12	10	1	CV565	35	37	31	8	1	12	2	1																		
ARP16	6	38	50	7	2	12	10	1	CV567	35	38	33	7	2	3	5	1	CV772	1	38	55	7	2	12	4	1									
ARP17	6	29	91					1	CV568	35	38	33	7	2	3	5	1	CV773	1	38	55	7	2	12	4	1									
ARP32	6	29	79					1	CV571	50	29	47					1	CV775	1	37	62	8	1	12	4	1									
ARP33	6	29	79					1	CV572	6	33	15					1	CV776	1	37	55	8	1	12	6	1									
ARTH-1	6	38	35	7	2	12	5	1	CV573	6	33	15					2	CV777	1	37	54	8	1	5	6	1									
AU13	5	33	32					1	CV574	6	33	15					1	CV778	1	37	68	8	1	12	4	1									
																		CV779	2	37	53	8	1	12	6	1									
AZ32	4	33	32					2	CV575	5	33	16					2	CV780	2	37	52	8	1	12	6	1									
																		CV781	1	37	53	8	1	5	6	1									
B36	12	25	78					1	CV578	6	38	45	7	2	12	5	1	CV782	1	41	57	7	1	5	4	1									
																		CV580	6	38	45	7	2	12	5	1									
B65	6	25	78					1	CV581	6	29	99					1	CV783	1	41	*55	7	1	5	3	1									
B152	12	8	74					1	CV582	6	29	99					1	*Normally shows short position 2-6.																	
																		CV583	6	29	99					1									
B309	12	8	74					2	CV586	6	29	63					1	CV784	1	41	56	7	1	12	6	1									
																		CV587	6	38	40	7	2	12	10	1									
B329	12	9	75					1										CV588	6	38	40	7	2	12	10	1									
																											CV589	6	38	40	7	2	12	10	1
B339	12	8	*85					1	CV590	6	30	83					1	CV785	1	41	55	7	1	5	6	1									
*Tube good if it reads 22 or more.																		CV591	6	30	83					1									
B719	6	8	70					1	CV592	6	30	83					1	CV786	1	38	54	7	2	12	5	1									
																		CV593	5	33	12					1									
BPM04	6	3	77					1	CV594	6	30	77					1	CV797	6	41	32	4	3	5	1	1									
CV131	6	41	35	4	3	12	1	1	CV595	6	30	77					1	CV805	50	38	35	7	2	12	3	1									
CV133	6	41	41	4	3	1	6	1										CV807	3	41	*36	7	1	5	4	1									
CV136	6	41	34	4	3	12	1	1										*Normally shows short position 2-6.																	
CV138	6	41	30	4	3	12	1	1	CV808	3	41	45	7	1	4	3	1	CV819	3	38	45	7	2	8	5	1									
CV140	6	41	33	3	4	12	2	1	CV815	2	37	43	8	1	7	6	1	CV820	3	41	*48	7	1	5	3	1									
																		CV818	3	41	*42	7	1	5	3	1									
CV216	50	38	*99	2	1	3	5	1										*Normally shows short position 2-6.																	
*Normally shows short position 11.																		*Normally shows short position 2-6.																	
*Normally shows grid emission.																																			
CV283	6	41	33	3	4	12	2	1	CV657	6	38	50	7	2	12	10	1	CV841	5	33	16					1									
																		CV660	6	30	60					1									
																		CV661	6	30	74					1									
																		CV664	6	41	*46	4	3	1	6	1									
																		*Normally shows short position 2-7.																	

*Normal Shorts refer to position of "D" Switch.

◆Use TC-80 Adapter.

8106-CV841

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
CV842	5	33	32					1	CV921	12	38	46	8	7	12	2	1	CV1852	5	38	47	8	7	12	3	1
			32					2				69	8	7	12	5	1				47	8	7	12	5	1
CV844	6	38	40	7	2	12	5	1	CV922	12	30	77					1	CV1854	5	33	32					1
CV845	6	38	40	7	2	12	5	1	CV924	12	25	*85					1				32					2
CV846	6	30	60					1				*85					2	CV1856	5	33	32					1
CV848	6	1	80					1	*Tube good if it reads 22 or more.												32					2
CV849	6	30	60					1	CV925	12	25	78					1	CV1857	5	38	52	8	7	12	3	1
CV850	6	1	63					1				78					2				52	8	7	12	5	1
CV851	6	38	35	7	2	12	5	1	CV930	12	37	45	8	1	12	4	1	CV1862	6	3	77					1
CV852	6	41	14	4	3	1	6	1				45	8	1	12	5	1	CV1863	5	33	12					1
CV858	6	2	60					1	CV939	25	38	40	7	2	12	5	1				12					2
			60					2	CV945	30	37	40	8	1	12	2	1	CV1864	5	33	12					1
CV862	6	38	53	7	2	12	5	1	CV946	30	37	40	8	1	12	2	1				12					2
CV865	6	30	69					1				40	8	1	12	7	1	CV1873	6	30	74					1
CV866	6	30	83					1	CV995	6	41	36	4	3	2	1	1	CV1876	6	30	60					1
CV867	6	38	46	8	7	12	2	1	CV1067	6	29	93					1	CV1878	6	38	54	7	2	12	5	1
			68	8	7	12	4	1	CV1071	5	33	16					1				62	7	2	12	1	1
			68	8	7	12	5	1	CV1074	6	38	50	7	2	12	10	1	CV1882	6	30	38					1
CV873	6	33	17					1	CV1268	5	33	32					2	CV1893	6	38	55	7	2	12	10	1
			17					2				32					1				65	7	2	12	4	1
CV876	6	37	48	8	1	12	3	1	CV1280	6	38	44	7	2	12	10	1	CV1894	6	38	55	7	2	12	10	1
			48	8	1	12	6	1	CV1285	6	38	47	7	2	12	4	1				65	7	2	12	4	1
CV877	6	37	45	8	1	12	6	1	CV1301	6	38	48	7	2	12	3	1	CV1895	50	38	*70	2	11	3	5	1
CV878	6	37	40	8	1	12	4	1				48	7	2	12	5	1	*Normally shows short position 11.								
CV879	6	37	40	8	1	12	6	1	CV1375	6	9	62					1	*Normally shows grid emission.								
CV880	6	37	52	8	1	12	6	1	CV1377	5	33	10					1	CV1902	6	38	45	7	2	12	5	1
CV881	6	37	52	8	1	12	6	1				10					2	CV1908	6	38	40	7	2	12	10	1
CV882	6	37	40	8	1	4	3	1	CV1633	12	8	74					1	CV1909	6	38	40	7	2	12	10	1
			68	8	1	4	5	1				74					2	CV1910	6	38	40	7	2	12	10	1
			68	8	1	4	6	1	CV1649	6	29	99					1	CV1911	6	29	91					1
CV883	6	37	42	8	1	12	4	1	CV1741	6	29	53					1	CV1912	6	29	91					1
CV885	6	37	38	8	1	12	6	1	CV1753	35	37	34	8	1	12	6	1	CV1926	6	26	52					1
CV886	6	37	38	8	1	12	6	1	CV1757	6	1	93					1	CV1928	12	1	78					1
CV887	6	37	50	8	1	4	3	1	CV1758	1	41	55	7	1	5	6	1	CV1929	6	38	48	7	2	12	3	1
			68	8	1	4	5	1	CV1762	6	1	82					1				48	7	2	12	5	1
			68	8	1	4	6	1	CV1763	6	41	*85	4	3	1	7	1	CV1930	6	38	48	7	2	12	3	1
CV890	6	37	*33	8	2	1	5	1	*Normally shows short position 5-6.									CV1931	6	38	48	7	2	12	3	1
*Normally shows short position 3-4-6-7.			40	8	1	4	3	1	CV1777	6	37	37	8	1	12	6	1				48	7	2	12	5	1
CV891	6	37	69	8	1	4	5	1	CV1784	6	30	38					1	CV1932	6	29	93					1
			69	8	1	4	6	1	CV1790	6	37	50	8	1	12	3	1	CV1933	6	29	93					1
CV892	6	37	47	8	1	12	6	1	CV1800	1	38	57	7	2	12	5	1	CV1934	6	29	93					1
			68	8	1	12	3	1	CV1802	1	38	57	7	2	12	5	1	CV1935	6	38	50	7	2	12	10	1
			68	8	1	12	4	1	CV1803	1	38	54	7	2	12	5	1	CV1936	6	38	50	7	2	12	10	1
CV893	6	37	45	8	1	12	4	1	CV1805	1	38	54	7	2	12	5	1	CV1937	6	38	50	7	2	12	10	1
			45	8	1	12	5	1	CV1811	1	38	58	7	2	12	5	1	CV1938	6	29	92					1
CV894	6	37	36	8	1	12	6	1				86	7	2	12	10	1	CV1940	6	29	92					1
CV895	6	37	35	8	1	12	6	1	*99 7 2 12 8 1									CV1941	6	38	52	7	2	12	10	1
CV896	6	37	45	8	1	12	4	1	CV1818	1	38	55	7	2	12	10	1	CV1942	6	38	52	7	2	12	10	1
			65	8	1	12	5	1	*Tube good if it reads 30 or more.									CV1943	6	38	52	7	2	12	10	1
CV897	6	37	35	8	1	12	6	1	CV1819	6	29	93					1	CV1944	6	38	35	7	2	12	5	1
			35	8	1	12	6	1	CV1820	1	38	55	7	2	12	10	1	CV1945	6	38	35	7	2	12	5	1
CV898	6	37	42	8	1	12	4	1	CV1821	2	38	53	7	2	12	10	1	CV1946	6	38	35	7	2	12	5	1
			42	8	1	12	4	1	CV1823	2	38	53	7	2	12	10	1	CV1947	6	29	63					1
			42	8	1	12	5	1	CV1824	1	38	48	7	2	12	5	1	CV1948	6	29	63					1
CV899	6	37	35	8	1	12	4	1	CV1826	1	38	48	7	2	12	5	1	CV1949	6	41	43	4	3	12	1	1
CV900	6	37	35	8	1	12	6	1	CV1829	1	38	54	7	2	12	5	1	CV1950	6	38	44	7	2	12	10	1
			72	8	1	12	3	1	CV1846	5	33	22					2	CV1951	6	38	44	7	2	12	10	1
			72	8	1	12	4	1				22					1	CV1956	6	38	47	7	2	12	4	1
CV901	6	37	45	8	1	12	3	1	CV1849	5	33	32					1				47	7	2	12	5	1
			45	8	1	12	6	1	CV1851	5	38	47	8	7	12	3	1	CV1957	6	38	47	7	2	12	4	1
CV910	12	38	45	7	2	12	5	1				47	8	7	12	5	1				47	7	2	12	5	1
CV916	12	38	48	7	2	12	3	1				47	8	7	12	5	1	CV1958	6	38	47	7	2	12	4	1
			48	7	2	12	5	1				32					2				47	7	2	12	5	1
CV917	12	38	50	7	2	12	10	1	CV1851	5	38	47	8	7	12	3	1	CV1959	50	4	44					1
			48	7	2	12	5	1				47	8	7	12	5	1	CV1961	12	1	82					1
CV918	12	38	52	7	2	12	10	1				32					2	CV1962	6	38	52	7	2	12	10	1
CV919	12	38	41	8	7	12	3	1				47	8	7	12	5	1				63	7	2	12	4	1
CV920	12	38	41	8	7	12	3	1				47	8	7	12	5	1									1

*Normal Shorts refer to position of "D" Switch.

CV842-CV1962

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
CV1963	6	38	63	7	2	12	5	1	CV2984	6	38	35	8	7	12	1	1	DK92	1	41	48	7	1	12	4	1
			52	7	2	12	10	1				35	8	7	12	4	1	DK96	1	41	54	7	1	12	4	1
			63	7	2	12	4	1	CV3512	6	41	34	4	3	5	6	1	DL33	3	38	45	7	2	8	5	1
			63	7	2	12	5	1	CV3523	6	38	*38	7	2	1	5	1	DL35	1	38	54	7	2	12	5	1
CV1964	6	38	52	7	2	12	10	1	*Normally shows short position 4-6.									DL36	1	38	48	7	2	12	5	1
			63	7	2	12	4	1	*Normally shows grid emission.									DL91	1	41	*55	7	1	5	3	1
			63	7	2	12	5	1	CV3798	50	38	*70	2	11	3	5	1	*Normally shows short position 2-6.								
CV1966	6	38	37	7	2	12	5	1	*Normally shows short position 11.									DL92	3	41	*48	7	1	5	3	1
CV1967	6	38	37	7	2	12	5	1	*Normally shows grid emission.									*Normally shows short position 2-6.								
CV1969	6	38	48	8	7	12	3	1	CV3799	50	38	*69	2	11	3	5	1	DL93	3	41	*36	7	1	5	4	1
			48	8	7	12	4	1	*Normally shows short position 11.									*Normally shows short position 2-6.								
			48	8	7	12	4	1	*Normally shows grid emission.									DL94	3	41	45	7	1	5	6	1
CV1970	6	38	48	8	7	12	3	1	CV4007	6	41	33	3	4	12	2	1	DL95	3	41	*42	7	1	5	3	1
			48	8	7	12	4	1				33	3	4	12	7	1	*Normally shows short position 2-6.								
CV1972	6	38	41	8	7	12	3	1	CV4010	6	1	63					1	DL96	3	41	45	7	1	5	6	1
CV1973	6	38	41	8	7	12	3	1	CV4018	6	41	32	4	3	5	1	1	DP61	6	1	63					1
CV1974	6	38	47	7	2	12	10	1	CV4024	12	8	74					2	DY30	1	32	55					1
CV1975	6	38	47	7	2	12	10	1				74					1	DY80	1	24	85					1
CV1976	6	38	37	7	2	12	5	1	D2M9	6	41	33	3	4	12	2	1	DY86	1	24	35					1
CV1978	6	30	77					1				33	3	4	12	7	1	DY87	1	24	35					1
CV1981	6	30	84					1	D63	6	38	48	7	2	12	3	1	DY802	1	24	56					1
CV1982	6	30	84					1				48	7	2	12	5	1	E55L	6	44	*25	4	5	7	8	1
CV1985	6	25	*85					1	D77	6	41	33	3	4	12	2	1	*Normally shows short position 2-6.								
			*85					2				33	3	4	12	7	1	E80CC	12	8	74					1
*Tube good if it reads 22 or more.									D152	6	41	33	3	4	12	2	1				74					2
CV1988	6	25	78					1				33	3	4	12	7	1	E80CF	6	11	72					1
			78					2	D193	3	41	*36	7	1	5	4	1				55					2
CV1990	6	38	42	8	7	12	2	1	*Normally shows short position 2-6.									E80F	6	39	34	4	5	7	9	1
			71	8	7	12	4	1	DA90	2	41	*70	7	1	2	6	1	E80L	6	39	25	4	5	1	2	1
			71	8	7	12	5	1	*Normally shows short position 5-11.									E80T	6	39	72	4	5	12	2	1
CV1991	6	38	42	8	7	12	2	1	DAC32	1	38	55	7	2	12	10	1	E81L	6	9	60					1
			71	8	7	12	4	1				96	7	2	12	5	1	E83F	6	39	25	4	5	12	2	1
			71	8	7	12	5	1	DAF91	1	41	56	7	1	12	6	1	E88CC	6	8	24					1
CV1993	6	30	92					1				95	7	1	12	3	1				24					2
CV1995	6	38	52	8	7	12	2	1	DAF92	2	41	55	7	1	12	6	1	E90CC	6	2	49					1
			72	8	7	12	4	1				70	7	1	12	4	1				49					2
CV1996	6	38	52	8	7	12	2	1	DAF96	1	41	58	7	1	12	6	1	E90F	6	1	82					1
			72	8	7	12	4	1				70	7	1	12	3	1	E91AA	6	41	33	3	4	12	2	1
			72	8	7	12	5	1	DC90	1	41	*70	7	1	5	6	1				33	3	4	12	7	1
CV2128	6	39	85	5	4	12	1	1	*Normally shows short position 2-3.									E91H	6	1	89					1
			38	5	4	12	9	1	DCC90	3	41	45	7	1	4	3	1	E91N	6	41	32	4	3	5	1	1
CV2129	6	39	33	5	4	8	9	1				45	7	1	4	5	1	E92CC	6	2	61					1
CV2370	3	41	*48	7	1	5	3	1	DD6	6	41	33	3	4	12	2	1				61					2
*Normally shows short position 2-6.									DF33	2	38	53	7	2	12	10	1	E99F	6	1	84					1
CV2390	3	41	*36	7	1	5	4	1				33	3	4	12	7	1	E180F	6	23	82					1
*Normally shows short position 2-6.									DF91	1	41	55	7	1	5	6	1	E182CC	6	39	30	4	5	8	2	1
CV2500	35	38	33	7	2	12	5	1	DF92	1	41	55	7	1	5	6	1				30	4	5	8	7	1
CV2507	1	41	52	7	1	5	6	1	DF96	1	41	58	7	1	5	6	1	E188CC	6	8	23					1
CV2522	6	1	77					1	DF97	1	41	40	7	1	5	6	1				24					2
CV2524	6	1	82					1	DF904	1	41	52	7	1	5	6	1	E235L	6	38	30	2	7	4	5	1
CV2526	6	6	91					1	DH63	6	38	40	7	2	12	10	1	E280F	6	23	80					1
			78					2				63	7	2	12	4	1	EEA91	6	41	33	3	4	12	2	1
CV2534	50	29	47					1				63	7	2	12	5	1				33	3	4	12	7	1
CV2704	6	37	*33	8	2	1	5	1	DH74	12	38	40	7	2	12	10	1	EABC80	6	17	90					1
*Normally shows short position 3-4-6-7.												63	7	2	12	4	1				63					2
CV2706	6	37	53	8	1	12	4	1				63	7	2	12	5	1	EB34	6	38	48	7	2	1	3	1
CV2714	6	29	67					1	DH76	12	38	40	7	2	12	10	1				48	7	2	1	5	1
CV2716	6	38	48	8	7	12	3	1				63	7	2	12	4	1	EB91	6	41	33	3	4	12	2	1
			48	8	7	12	4	1				63	7	2	12	5	1				33	3	4	12	7	1
CV2721	6	39	*32	5	4	7	2	1	DH107	19	6	85						EBC90	6	6	85					1
*Normally shows short position 1-6-9.												78									78					2
CV2748	5	33	12					1	DH149	6	37	50	8	1	4	3	1	EBC91	6	6	91					1
			12					2				68	8	1	4	5	1				78					2
CV2769	6	41	*55	4	3	1	5	1				68	8	1	4	6	1	EBF80	6	39	37	5	4	12	2	1
*Normally shows short position 2-7.									DH710	6	17	90									64	5	4	12	7	1
CV2901	6	39	40	4	5	2	9	1				63									64	5	4	12	8	1
CV2938	6	29	53					1	DH719	6	17	90														

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.		
EBF89	6	39	33	5	4	12	2	1	ECH84	6	22	88					1	EL821	6	9	55					1		
			60	5	4	12	7	1				93				2	ELL80	6	39	29	4	5	12	2	1			
			60	5	4	12	8	1	ECH200	6	42	31	5	6	12	3	1				29	4	5	12	6	1		
EC81	6	39	30	4	5	12	1	1				30	5	6	12	8	1	EM-87	6	39	52	4	5	2	1	1		
EC86	6	40	29	4	5	3	6	1	ECL80	6	39	37	5	4	12	9	1	EN93	6	41	43	4	3	12	1	1		
EC88	6	39	*85	4	5	7	8	1				44	5	4	12	2	1	EQ80	6	39	33	5	4	3	7	1		
			*Normally shows short position 1-3-6-9.							ECL82	6	39	33	5	4	12	3	1	EY81	6	39	33	5	4	2	9	1	
EC90	6	41	41	4	3	1	6	1				39	5	4	12	1	1	EY82	6	39	29	4	5	6	9	1		
EC91	6	41	*29	4	3	6	1	1	ECL84	6	39	26	4	5	12	8	1	EY86	6	40	*95	5	4	1	10	1		
			*Normally shows short position 2-5.										26	4	5	12	1	1	*Normally shows short position 6-11.									
EC92	6	2	83					1	ECL85	6	39	25	4	5	12	9	1	EY87	6	40	*95	5	4	1	10	1		
EC95	6	41	32	4	3	1	2	1				25	4	5	12	2	1	*Normally shows short position 6-11.										
EC97	6	41	33	4	3	1	2	1	ECL86	6	39	25	4	5	2	8	1	EY88*	6	40	30	5	4	7	3	1		
EC900	6	5	56					1				35	4	5	7	1	1	*If no test, use alternate settings.										
ECC35	6	25	*85					1	ECLL800	6	39	*99	4	5	12	1	1	EY88	6	40	30	5	4	3	7	1		
			*Tube good if it reads 22 or more.										36	4	5	12	2	1	EY500	6	38	32	7	8	2	5	1	
ECC81	12	8	74					1				36	4	5	12	6	1	EZ35	6	33	15					1		
			74					2	*Tube good if it reads 25 or more.											15							2	
ECC82	12	8	75					1	ED2	6	41	33	3	4	12	2	1	EZ80	6	39	40	5	4	12	1	1		
			75					2				33	3	4	12	7	1				40	5	4	12	7	1		
ECC83	12	8	*85					1	ED500	6	44	*52	4	5	12	8	1	EZ81	6	39	34	5	4	12	1	1		
			*85					2	*Normally shows short position 2-3-6-7-9.											34	5	4	12	7	1			
			*Tube good if it reads 22 or more.							EF22	6	37	36	8	1	12	6	1	EZ90	6	41	44	4	3	12	1	1	
ECC84	6	39	33	5	4	7	2	1	EF80	6	9	76				1	1				44	4	3	12	6	1		
			33	5	4	7	6	1	EF85	6	9	62				1	1	G180/ZM	50	38	*99	2	11	3	5	1		
ECC85	6	8	70					1	EF86	6	39	40	5	4	2	9	1	*Tube good if it reads 60 or more.										
			70					2	EF89	6	9	80				1	1	*Normally shows short position 11.										
			70					1	EF91	6	41	30	4	3	12	1	1	*Normally shows grid emission.										
ECC86	6	39	33	5	4	12	2	1	EF92	6	41	35	4	3	12	1	1	GZ-30	5	33	12					1		
			33	5	4	12	7	1	EF93	6	1	78				1	1				12					2		
ECC88	6	39	31	5	4	12	2	1	EF94	6	1	82				1	1	GZ-32	5	33	12					1		
			31	5	4	12	7	1	EF95	6	1	63				1	1				12					2		
ECC89	6	39	29	4	5	7	2	1	EF96	6	1	80				1	1	GZ-34	5	33	10					1		
			29	4	5	7	6	1	EF98	6	41	30	4	3	12	1	1				10					2		
ECC91	6	2	60					1	EF183	6	9	40				1	1	H63	6	38	40	7	2	12	10	1		
			60					2	EF184	6	9	58				1	1	HABC80	19	17	90					1		
ECC189	6	8	30					1	EF804	6	39	39	5	4	2	9	1				63					2		
			30					2	EF-806S	6	39	40	4	5	2	9	1	HBC90	12	6	85					1		
ECC801S	12	8	74					1	EFL200	6	42	27	5	6	12	1	1				78					2		
			74					2				27	5	6	12	8	1	HBC91	12	6	91					1		
ECC802S	12	8	75					1	EH90	6	1	94				1	1				78					2		
			75					2	EH-900S	6	1	91				1	1	HCC85	17	8	65					1		
ECC808	6	39	36	4	5	12	1	1	EK90	6	1	91				1	1				65					2		
			36	4	5	12	9	1	EL34	6	29	53				1	1	HCH81	12	39	32	5	4	12	2	1		
ECC960	6	2	49					1	EL36	6	27	58				1	1				35	5	4	12	9	1		
			49					2	EL37	6	29	63				1	1	HD14	1	38	55	7	2	12	10	1		
ECF80	6	11	66					1	EL38	6	29	*62				1	1				96	7	2	12	5	1		
			55					2	*For plate cap use jack next to socket 26.										HF93	12	1	78					1	
ECF82	6	11	79					1	EL81	6	39	*32	5	4	7	2	1	HF94	12	1	82					1		
			56					2	*Normally shows short position 1-6-9.										HK90	12	1	91					1	
ECF86	6	39	25	4	5	3	2	1	EL82	6	23	68				1	1	HL90	19	3	77					1		
			25	4	5	1	6	1	EL83	6	39	30	5	4	12	2	1	HL92	50	4	44					1		
ECF200	6	42	30	5	6	12	3	1	FL84	6	23	68				1	1	HL94	30	41	27	3	4	5	2	1		
			30	5	6	12	10	1	FL85	6	39	*39	5	4	1	2	1	HM04	6	1	91					1		
			*Normally shows short position 6-8.							*Normally shows short position 6-8.										HY90	35	41	33	4	3	6	5	1
ECF201	6	42	28	5	6	12	3	1	FL86	6	23	58				1	1	KT32	25	29	47					1		
			32	5	6	12	10	1	EL90	6	3	77				1	1	KT63	6	29	91					1		
ECF202	6	42	29	5	6	12	3	1	EL91	6	41	34	4	3	12	1	1	KT66	6	29	63					1		
			33	5	6	12	10	1	EL95	6	3	88				1	1	KT88	6	29	43					1		
ECF801	6	22	62					1	EL500	6	44	*25	4	5	2	1	1	KTZ63	6	38	50	7	2	12	10	1		
			78					2	*Normally shows short position 3-6-7-8.										L63	6	29	93					1	
ECF802	6	11	80					1	EL503	6	44	*31	4	5	3	7	1	1	L77	6	41	41	4	3	1	6	1	
			85					2	*Normally shows short position 1-2-6-8.										LC900	3	5	56					1	
ECF-805	6	39	30	4	5	8	7	1	EL505	6	44	*26	4	5	1	8	1	LCF80	6	11	66					1		
			33	4	5	8	9	1	*Normally shows short position 2-3-6-7.											55							2	
ECH81	6	39	85	5	4	12	1	1	EL508	6	44	30	4	5	1	8	1	LCF200	5	42	30	5						

B & K DYNA-JET MODEL 707 TUBE CHART

TUBE TYPE	Heater	Socket	Gen.-ality	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Gen.-ality	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Gen.-ality	A	B	C	D	Test Pos.
U192	19	39	29	4	5	6	9	1	VT86	6	38	52	7	2	12	10	1	XC900	2	5	56					1
U709	6	39	34	5	4	12	1	1	VT87	6	38	44	7	2	12	10	1	XCC189	4	8	30					1
UAA91	19	41	33	3	4	12	2	1	VT88	6	38	52	7	2	12	10	1				30					2
			33	3	4	12	7	1				63	7	2	12	4	1	XCF80	4	11	66					1
			33	3	4	12	7	1				63	7	2	12	5	1				65					2
UABC80	25	17	90					2	VT90	6	38	48	7	2	12	3	1	XCF86	5	39	24	4	5	3	2	1
			63					1				48	7	2	12	5	1				25	4	5	1	6	1
UBF80	17	39	33	5	4	12	2	1	VT91	6	38	50	7	2	12	10	1	XCF801	4	22	62					1
			65	5	4	12	7	1	VT93	6	38	55	7	2	12	10	1	XCH81	3	39	85	5	4	12	1	1
			65	5	4	12	8	1				65	7	2	12	4	1				38	5	4	12	9	1
UCC84	22	39	33	5	4	7	2	1	VT94	6	29	93					1	XCL82	8	39	33	5	4	12	3	1
			33	5	4	7	6	1	VT96	6	38	47	7	2	12	4	1				39	5	4	12	1	1
UCC85	25	8	70					2				47	7	2	12	5	1	XCL84	8	39	26	4	5	12	8	1
			70					1	VT97	5	33	32					1				26	4	5	12	1	1
UCF80	25	11	66					1				32					2	XCL85	18	39	25	4	5	12	9	1
			55					2	VT99	6	38	45	7	2	12	5	1				25	4	5	12	2	1
UCH81	19	39	32	5	4	12	2	1				45	7	2	12	10	1	XF80	3	9	76					1
			35	5	4	12	9	1	VT102	6	29	92					1	XF85	3	9	62					1
UCL82	50	39	33	5	4	12	3	1	VT103	6	38	42	8	7	12	2	1	XF183	3	9	40					1
			39	5	4	12	1	1				71	8	7	12	4	1	XF184	3	9	58					1
UF86	12	39	40	5	4	2	9	1	VT104	12	38	42	8	7	12	2	1	XL36	12	27	57					1
UF89	12	9	80					1				71	8	7	12	4	1	XL84	8	23	68					1
UL84	50	23	58					1				71	8	7	12	4	1	XL86	8	23	58					1
UU12	6	39	34	5	4	12	1	1	VT105	6	38	48	8	7	12	3	1	XL500*	12	44	*25	4	5	2	1	1
			34	5	4	12	7	1				48	8	7	12	4	1	*Normally shows short position 3-6-7-8.								
UY82	50	39	29	4	5	6	9	1	VT107	6	29	79					1	XY88*	16	40	30	5	4	7	3	1
UY85	35	40	30	4	5	1	6	1	VT112	6	30	60					1	*If no test, use alternate settings.								
V2M70	6	41	44	4	3	12	1	1	VT114	5	33	16					1	XY88	16	40	30	5	4	3	7	1
			44	4	3	12	6	1				16					2	XXD	12	37	41	8	1	12	4	1
V884	6	41	35	4	3	12	1	1	VT115	6	29	63					1				41	8	1	12	5	1
VP6	6	41	35	4	3	12	1	1	VT116	6	30	83					1	XXFM	6	37	43	8	1	12	3	1
VP1321	12	41	*55	4	3	1	5	1	VT117	6	30	84					1				36	8	1	12	5	1
			*Normally shows short position 2-7.						VT124	1	38	55	7	2	12	5	1				35	8	1	12	6	1
VR75	50	38	*70	2	11	3	5	1	VT125	1	38	54	7	2	12	5	1	XXL	6	37	41	8	1	12	6	1
			*Normally shows short position 11.						VT126	6	33	15					1	YF183	4	9	40					1
			*Normally shows grid emission.									15					2	YF184	4	9	58					1
VR90	50	38	*69	2	11	3	5	1	W17	1	41	55	7	1	5	6	1	Z14	2	38	53	7	2	12	10	1
			*Normally shows short position 11.						W77	6	41	35	4	3	12	1	1	Z63	6	38	50	7	2	12	10	1
			*Normally shows grid emission.						W149	6	37	45	8	1	12	6	1	Z719	6	9	76					1
VR105	50	38	*85	2	11	3	5	1	W719	6	9	62					1	Z729	6	39	40	5	4	2	9	1
			*Normally shows short position 11.						W727	6	1	78					1	ZD17	1	41	*55	7	1	5	3	1
			*Normally shows grid emission.						X63(M)	6	38	45	7	2	12	5	1	*Normally shows short position 2-6.								
VR150/30	50	38	*99	2	11	3	5	1	X73(M)	6	38	45	7	2	12	5	1	ZD25	1	41	58	7	1	12	6	1
			*Tube good if it reads 60 or more.						X107	19	1	91					1				/0	7	1	12	3	1
			*Normally shows short position 11.						X155	6	8	55					1	ZD151	6	39	37	5	4	12	2	1
			*Normally shows grid emission.									55					2				64	5	4	12	7	1
VT52	6	29	92					1	X727	6	1	91					1				64	5	4	12	8	1
VT65	7	29	99					1	XB767A	6	38	34	7	2	12	5	1	ZD152	6	39	37	5	4	12	2	1
VT66	6	29	91					1	XC95	2	41	33	4	3	1	2	1				64	5	4	12	7	1
VT74	5	33	12					1	XC97	2	41	33	4	3	1	2	1				64	5	4	12	8	1
			12					2																		

*Normal Shorts refer to position of "D" Switch

■ Use TC-62B Adapter.

◆ Use TC-80 Adapter.

U192-ZD152